

Oct. 15, 1974

43-37

•

EPA Reg. No. 43-37. EPA Est 43-MA-1

Cabot's Creosote Stains

For use on wood shingles, siding and clapboards Wood Preserving

0249 CHARCOAL

4 LITERS - 1.057 U. S. GALLONS

WARNING — KEEP OUT OF THE REACH OF CHILDREN SEE SIDE PANEL FOR FURTHER WARNING STATEMENTS.

ACTIVE INGREDIENT
Water-Gas Creosote Oil
Not under
INERT INGREDIENTS
Not over

65%

35 % 100 %

•

WARNING

Keep away from heat and open f get on skin. Do not breathe va-Do not get in eyes or on c' tainer after each use. Harr lowed. Do not induce vom immediately. Before smokir using, clean hands thoroug product indoors, or any or where the vapors may conce injury to plant or animal life. \ injury if adequate ventilation is no.

This product is toxic to fish and wildlife. Keep out of lakes, streams or ponds. Do not contaminate water by cleaning of equipment or disposal of waste and container. Do not reuse container. Destroy when empty. Apply this product only as specified on this label.

Je

ad.

MANUFACTURING CHEMISTS SINCE 1877 BOSTON, MASSACHUSETTS 02108

CABOT'S CREOSOTE STAINS dye the wood, penetrating deep into the surface, producing rich lively colors that enhance the beau. • of the grain. Meanwhile, their high Creosote content (over 60% of a carefully refined Creosote oil) prevents wood rot and decay causing fungi.

For use on wooden roof and wall shingles, clapboards, siding, trim and all other exterior woodwork. Will not crack, peel or blister — surface needs no priming, sanding or scraping. Available in 24 distinctive shades. These Creosote Stains should not be used on any previously painted, treated or sealed surfaces.

DIRECTIONS

- 1. Surface must be clean and dry. Stir stains thoroughly before applying, and stir them occasionally while applying, to maintain a uniform solution. Do not thin stains. If the job requires more than one can of Stain, mix all together in one container and stir till color is uniform. Apply with a broad flat brush, spray machine or dip shingles before laying. Two coats are recommended for best appearance and durability. When staining vertical siding begin at the top with several boards and go all the way to the bottom. On horizontal siding begin at one edge and follow thru to a break at a door, window or corner.
- 3. DIPPING dip the shingles in and out rapidly; allow two-thirds of the shingles to be immersed; then throw them in a loose pile and allow them to dry. When dry, brush off excess stain. Wear protective clothing and rubber gloves when handling the freshly treated lumber.

NOTE: Do not stain when the temperature is below 40°. Since these are stain finishes, the colors may be affected by the color and porosity of the surface to which they are applied.

PAINT OVER STAINS: Any of Cabot's Creosote Stains can be painted over after two years exposure except #0280 and #0281.

DRYING TIME: For shingles and rough wood surfaces, allow 24 hours between coats. For clapboards and smooth siding, allow 3-5 days between coats if possible.

COVERING CAPACITY: On shingles or rough wood, about 100 square feet per gallon, two coats. On clapboards and smooth wood, 200 to 250 square feet per gallon, two coats. Hand dipping and one brush coat; 2½ to 3½ gallons of stain per square of 16" or 18" shingles.