




Allied Corporation  
Chemical Sector  
P.O. Box 100  
Morgantown, WV 26507



Use Directions for Pressure Treatment  
Of Wood With Creosote

Individuals should wear gloves impervious to the wood treatment formulation in all situations where dermal contact with creosote is expected (e.g., handling freshly treated wood and manually opening cylinder doors).

Individuals who manually open cylinder doors should wear gloves and a respirator.

Individuals who enter pressure treatment cylinders and other related equipment that is contaminated with the wood treatment formulation (e.g., cylinders that are in operation or are not free of the treatment formulation) should wear protective clothing (including overalls, jacket, gloves and boots) impervious to the wood treatment formulation and a respirator.

Applicators should not eat, drink, or use tobacco products during those parts of the application process that may expose them to the wood treatment formulation (e.g., manually opening/closing cylinder doors, moving trams out of cylinders, mixing chemicals, and handling freshly treated wood).

Wash thoroughly after skin contact, and before eating, drinking, use of tobacco products, or using restrooms.

Pesticide wastes are toxic. Improper disposal of excess pesticide, spray mixture, or sinate is a violation of Federal Law. If these wastes cannot be disposed of by use according to label instructions, contact your State Pesticide or Environmental Control Agency, or the Hazardous Waste representative at the nearest EPA Regional Office for guidance.

Protective clothing should be changed when it shows signs of contamination. Applicators should leave protective clothing and work shoes or boots and equipment at the plant. Worn-out protective clothing and work shoes or boots should be left at the plant and disposed of in any general landfill, in the trash, or in any other manner approved for pesticide disposal.



