

# K-BAN<sup>®</sup>

Net Wt. \_\_\_\_\_ Lbs.

## Ground Line Treatment

ACC  
 May 11, 1971  
 UNDER THE FEDERAL INSECTICIDE ACT  
 PUBLIC LAW 85-623, REGISTERED  
 UNDER NO. 1020-240 SUBJECT  
 TO ATTACHED CONDITIONS

## BANDAGE U. S. PATENT<sup>®</sup> 2955331

**K-BANS add years of life to standing poles -  
 -- by controlling wood rotting organisms.**

1022-240

<b>ACTIVE INGREDIENTS:</b>	
Pentachlorophenol .....	9.14%
Other chlorophenols and related compounds .....	1.07%
Aromatic petroleum derivative solvents .....	81.17%
<b>INERT INGREDIENTS</b>	<u>8.62%</u>
	100.00%

\*Equivalent to 10.66% pentachlorophenol, technical as defined by Federal Specification TT-W-570a.

This product is toxic to fish and wildlife. Do not contaminate water by cleaning of equipment, or disposal of wastes. Apply this product only as specified on this label.

### CAUTION

**KEEP OUT OF REACH OF CHILDREN**  
 Harmful or fatal if swallowed or absorbed through the skin. If swallowed, induce vomiting by administration of emetic. Call a physician. Do not get in eyes or on clothing. To remove from skin wash with plenty of soap and warm water. Keep away from foodst. fts, pets and livestock. Avoid inhalation of vapors. Inflammable —keep away from fire and flame.

## DIRECTIONS

### TO OPEN K-BAN

1. Lay flat with label side up.
2. Insert knife or razor at either upper corner and slit open the 3 sealed edges just inside of seal.  
**CUT UPPER PAPER LAYER ONLY**  
 Canting the blade at a sharp angle will insure that only the upper paper layer is cut.
3. Open like a book.

### TO APPLY K-BAN

1. Dig around pole to a depth of 18 inches.
2. Clean surface of pole with steel brush removing all dirt and loose decayed wood.
3. Inspect pole for rejection or treatment.
4. Open K-BAN packet. Wrap K-BAN bandage around pole base with preservative grease next to pole leaving three inches above the ground line. Use hand staple gun to assist in holding in place tightly while wrapping. Overlap ends of K-BAN to insure complete coverage of pole with preservative grease. Staple securely — Staples should be applied every 4 to 5 inches on top edge and overlap.
5. Back-fill and tamp dirt solidly.
6. Do not pile back-fill above K-BAN treated area.

### NON-WARRANTY

Neither the manufacturer nor the seller makes any representation or warranty, expressed or implied concerning this product, except that it is of the manufacturer's standard quality. Neither shall be held responsible in any manner for any personal injury, property damage or other type of loss resulting from the improper handling, storage and use of this product. The buyer accepts and uses this product on these conditions.

USDA REG. NO. 1022-240

MANUFACTURED BY

**CHAPMAN CHEMICAL COMPANY**  
 MEMPHIS, TENNESSEE