

DOLFINITE

ACCEPTED

JAN 3 1975
UNDER THE FEDERAL INSECTICIDE
FUNGICIDE AND RODENTICIDE ACT
FOR ECONOMIC POISON REGISTER-
ED UNDER NO. 365-73 SUBJECT
TO ATTACHED COMMENTS.

DANGER!
KEEP OUT OF REACH
OF CHILDREN
FLAMMABLE VAPOR
HARMFUL
HARMFUL OR FATAL
IF SWALLOWED
See Other Cautions on
Back Panel.

9131 Blue Vinyl Antifouling Bottom Paint

NET CONT. 32 FL. OZ. (1 QT.)

9131 VINYL ANTIFOULING	
	BY WEIGHT
ACTIVE INGREDIENT:	52.2%
Cuprous Oxide	
INERT INGREDIENTS:	47.8%
	100.0%
Copper as metallic: 47.30%	

MANUFACTURED BY THE DOLPHIN PAINT & CHEMICAL COMPANY TOLEDO, OHIO 43603 U.S.A.

DIRECTI
ing toxic
insure ev
not reco
only a s
complete
between
NEW WO
required.
OLD WO
paint, sca
FIBERGL
cloth dan
ALUMINU
one coat
apply two
9131 Blu
STEEL: F
then app
instructio
coats of
coats of
brush. C
CAUTION:
from heat
Close cont
crushing.
ment or d
immediate

★ QUALITY PRODUCTS SINCE 1885 ★

9131 BLUE VINYL ANTIFOULING BOTTOM PAINT

DIRECTIONS FOR APPLICATION: A vinyl-based, antifouling bottom paint containing toxic properties. Shake thoroughly before and stir frequently while using to insure even and complete distribution of the antifouling ingredients. Thinning is not recommended or required. Should a partially used can require thinning, add only a small amount of Dolfinite No. 1006 Vinyl Thinner. Too much thinner may completely destroy the effectiveness of the antifoulant. Allow overnight drying between coats. Finish coat should dry overnight before launching.

NEW WOOD: The surface should be clean, dry and well sanded. No undercoat is required. Apply two coats to insure complete protection.

OLD WOOD: Remove existing paint unless vinyl, surface must be free of loose paint, scale, wax, dirt, or other contaminants. Sand thoroughly and apply two coats.

FIBERGLASS: Remove existing paint unless vinyl, sand thoroughly, wipe with cloth dampened in xylol, and apply two coats.

ALUMINUM: Remove existing paint unless vinyl, etch with Alumiprep, then apply one coat of Dolfinite No. 9660-61 Wash Coat Primer according to instructions, apply two coats of No. 9662 Red Lead Barrier and follow with two coats of No. 9131 Blue Vinyl Antifouling Bottom Paint.

STEEL: Remove existing paint by sanding or sand blasting, etch with Metalprep, then apply one coat of Dolfinite No. 9660-61 Wash Coat Primer, according to instructions on the can. As soon as priming operation is complete, apply two coats of Dolfinite No. 9662 Vinyl Red Lead Barrier Primer and follow with two coats of No. 9131 Blue Vinyl Antifouling Bottom Paint with enamel type roller or brush. Clean brushes and roller with 1006 Vinyl Thinner only.

CAUTION: CONTAINS XYLOL, KETONES AND COPPER. WARNING - FLAMMABLE. Keep away from heat and open flame. Avoid contact with skin and breathing of vapor and spray mist. Close container after each use. Do not reuse empty container. Destroy by perforating or crushing. Bury or discard in a safe place. Do not contaminate water by cleaning of equipment or disposal of waste. Antidote: If swallowed do not induce vomiting. Call Physician immediately. Use with adequate ventilation.

E.P.A. Reg. No. 3658-43

E.P.A. Est. 3658 OH-1

" DO IT RIGHT - WITH *Dolfinite* "