

von ting ical a

DIRECTIONS 2. Apply on clean dry so 3 Apply generously with part thomer to two parts. Say Cote 770 5. Then apply two roats fol strength BOX to dean tools 0

NEW JERSEY

LAKEWOOD

CAUTION

THE SAV-COTE DO NOTS and eyes and prolonged breathing of eapors 3 Aftermount is sent on the San Community most by months a performance in the sent of the ing quirely bearith in har fate with a dry and tomay take up to one week. Thereafter outs a say to to eath an inapplied with note a trying spood



DIRECTIONS

- 1 Stir colors well
- 2. Apply on clean day surfaces.
- 3. Apply generously with ininimum of brushing. flow on.
- 4. Thin down first coat, one part thinner to two parts sav-Cote.
- 5. Then apply two coats full strength.
- 6. Use Sav-Cote thinner, to clean tools.

O. BOX 770, LAKEWOOD, NEW

CAUTION

important

Lously

as the pe

1 Keep away from open flame and sparks.

Cauttan: Flammable, the with Ventilation

- 2. If applying indoors use plenty of ventilation
- 3: Avoid contact with skin and eyes, and prolonged breathing of vapors.
- 4 Keep out of reach of children
- 5 If swallowed, induce vomiting, call a physician

THE SAV-COTE DO NOTS

1 Do not apply Sav-Cote on surfaces FRESHLY painted with an oil rubber. alkyd or synthetic enamel varnish or lacquer Apply Sav-Cote ONLY over other finishes which are at least 3 months old 100 00-

50 0% 50 0%

TOTAL

- 2 Do not mix Sav-Cote with other finishes Do not thin Sav-Cote with anything ex-cept Sav-Cote Special Thinner & Cleaner
- 3. If remover is used under Sav-Cote it must be neutralized. If remover is still active it will retard Sav-Cote from drying quickly. Nevertheless, Sav-Cote will dry and it may take up to one week. Thereafter other Sav-Cote coats can be applied with normal drying speed
 4 Do not apply on very wet oily greasy
 badly cracked or penling surface