

42750-120

07/06/2007

1/11

IMIDACLOPRID 75WSP TC
Insecticide in Water Soluble Packets

* For use by individuals/firms licensed or registered by the state to apply termiticide products. States may have more restrictive requirements regarding qualifications of persons using this product. Consult the structural pest control regulatory agency of your state prior to use of this product.

* For prevention or control of subterranean termites, drywood termites, dampwood termites, carpenter ants, and other wood-infesting insects.

ACTIVE INGREDIENT:

Imidacloprid, 1-[(6-Chloro-3-pyridinyl)methyl]-N-nitro-2-imidazolidinimine 75.0%

INERT INGREDIENTS: 25.0%

TOTALS: 100.0%

Do Not Remove Packets From Container Except For Immediate Use.

Keep water soluble packets in this container and store in a cool dry place but not below freezing (32°F).

Stop - Read the label before use.

KEEP OUT OF REACH OF CHILDREN.

CAUTION

PRECAUCION AL USUARIO: Si usted no puede leer o entender ingles, no use este producto hasta que la etiqueta le haya sido explicada ampliamente.

(TO THE USER: If you cannot read or understand English, do not use this product until the label has been fully explained to you.)


FIRST AID	
IF SWALLOWED:	<ul style="list-style-type: none"> • Call a poison control center or doctor immediately for treatment advice. • Have person sip a glass of water if able to swallow. • Do not induce vomiting unless told to do so by the poison control center or doctor. • Do not give anything by mouth to an unconscious person.
IF ON SKIN OR CLOTHING:	<ul style="list-style-type: none"> • Take off contaminated clothing. • Rinse skin immediately with plenty of soap and water for 15-20 minutes. • Call a poison control center or doctor for treatment advice.
IF IN EYES:	<ul style="list-style-type: none"> • Hold eyelids open and rinse slowly and gently with water for 15-20 minutes. • Remove contact lenses, if present, after the first 5 minutes, then continue rinsing eye. • Call a poison control center or doctor for treatment advice.
Contact CHEMTREC toll free at 1-800-424-9300 for transportation or medical emergencies. Have the product container or label with you when calling a poison control center or doctor, or going for treatment.	
NOTE TO PHYSICIAN: No specific antidote is available. Treat the patient symptomatically.	

EPA Reg. No. 42750-120
AD 080806

EPA Est. No. xxxxxx-xx-xxx

NET CONTENTS: 12 2.25 OZ. WATER SOLUBLE PACKETS PER CASE

Manufactured For:
ALBAUGH, INC.
ANKENY, IA 50021



2/11

PRECAUTIONARY STATEMENTS
HAZARDS TO HUMANS AND DOMESTIC ANIMALS

CAUTION: Harmful if swallowed, inhaled, or absorbed through skin. Causes eye irritation. Avoid contact with skin, eyes, or clothing. Avoid breathing dust or vapor. Wash thoroughly with soap and water after handling.

Remove contaminated clothing and wash before reuse. Keep children or pets away from treated area until dry.

When treating adjacent to an existing structure, the applicator must check the area to be treated, and immediately adjacent areas of the structure, for visible and accessible cracks and holes to prevent any leaks or significant exposures to persons occupying the structure. People present or residing in the structure during application must be advised to remove their pets and themselves from the structure if they see any signs of leakage. After application, the applicator is required to check for leaks. All leaks resulting in the deposition of termiticide in locations other than those prescribed on this label must be cleaned up prior to leaving the application site. Do not allow people or pets to contact contaminated areas or to reoccupy contaminated areas of the structure until the clean up is completed.

PERSONAL PROTECTIVE EQUIPMENT

Pesticide handlers (mixers, loaders, and applicators) must wear long-sleeved shirt and long pants, socks, shoes, and water-proof gloves. After the product is diluted in accordance with label directions for use, shirt, pants, socks, shoes and water-proof gloves are sufficient. In addition: all pesticide handlers must wear protective eyewear when working in a non-ventilated space or when applying termiticide by rodding or sub-slab injection.

ENVIRONMENTAL HAZARDS

This product is highly toxic to aquatic invertebrates. Do not apply directly to water, to areas where surface water is present or to intertidal areas below the mean high water mark. Do not contaminate water when disposing of equipment washwaters. Apply this product only as specified on this label. Extreme care must be taken to avoid runoff. Apply only to soil or other fill substrate that will accept the solution at the specified rate. Do not treat soil that is water-saturated or frozen. or in any conditions where run-off or movement from the treatment area (site) is likely to occur.

STORAGE AND DISPOSAL

Do not contaminate water, food, or feed by storage or disposal.

PESTICIDE STORAGE: Store in a cool, dry place and in such a manner as to prevent cross contamination with other pesticides, fertilizers, food, and feed. Do not store below freezing (32°F). Exposure to moisture or excessive handling of water soluble packets may cause breakage. Store water soluble packets in original container and out of reach of children, preferably in a locked storage area. Handle and open container carefully. Do not cut water soluble packets when opening. If container is leaking or material spilled for any reason or cause, carefully sweep material into a pile. Refer to PRECAUTIONARY STATEMENTS on label for hazards associated with the handling of this material. Do not walk through spilled material. Dispose of pesticide as directed below. In spill or leak incidents, keep unauthorized people away.

PESTICIDE DISPOSAL: Wastes resulting from the use of this product may be disposed of on site (in the treatment area) or at an approved waste disposal facility.

CONTAINER DISPOSAL: Do not use carton in connection with food, feed or drinking water. The empty foil wrappers may be disposed of in the trash. After removing all PVA packets, the carton may be disposed of in the trash.

DIRECTIONS FOR USE

It is a violation of Federal law to use this product in a manner inconsistent with its labeling.

Structures that contain wells or cisterns within the foundation of the structure can only be treated using the treated backfill method described in the treatment around wells and cisterns section of this label. Consult state and local specifications for recommended distances of wells from treated area, or if such regulations do not exist, refer to Federal Housing Administration Specifications (H.U.D.) for guidance.

Do not formulate this product into other end-use products.

MIXING TABLE FOR IMIDACLOPRID 75WSP TC		
GALLONS OF FINISHED SOLUTION DESIRED	NUMBER OF IMIDACLOPRID 75WSP TC PACKETS NEEDED	
	0.05% Concentrate	0.1% Concentrate
25	1	2
50	2	4
100	4	8

MIXING: Refer to Mixing Table for proper amount of IMIDACLOPRID 75WSP TC to be used.

Within each foil envelope are clear inner packets containing IMIDACLOPRID 75WSP TC. The clear inner packet is water soluble. Do not allow packets to become wet prior to adding to the spray tank. Do not handle the clear inner packets with wet hands or wet gloves. Rough handling may cause breakage. Reseal foil envelope to protect remaining packets. To prepare the spray mixture, open the foil envelope and drop the required number of unopened clear water soluble packets into the spray tank while filling with water to the desired level. Operate the agitator while mixing. Depending on the water temperature and the degree of agitation, the packets should be completely dissolved within a few minutes from the time they are added to the water. Cooler water temperatures increase the time needed for the inner packet to dissolve completely.

Note: IMIDACLOPRID 75WSP TC packets should not be used with products or in a tank that may contain boron or release free chlorine. The resultant reaction of PVA and boron or free chlorine is a plastic which is not soluble in water or solvents such as diesel oils, kerosene, gasoline or alcohol. Use of chlorinated water is acceptable.

APPLICATION VOLUME

It is recommended that application volumes described in the IMIDACLOPRID 75WSP TC "DIRECTIONS FOR USE" be used whenever possible. However, where soil conditions will not accept application of 4 gallons of IMIDACLOPRID 75WSP TC per 10 linear feet, twice the IMIDACLOPRID 75WSP TC concentration may be applied in 2 gallons of solution per 10 linear feet. For example, if 0.05% is the correct use rate to be applied in 4 gallons of water, then 2 gallons of 0.1% dilution may be used per 10 linear feet to deliver an equivalent amount of IMIDACLOPRID 75WSP TC per unit of soil.

CONTROL - GENERAL

Treatment standards for subterranean termite control may vary due to regulations, treatment procedures, soil types, construction practices and other factors. The purpose of chemical soil treatment for termite control is to establish a continuous chemical treated zone (horizontal and/or vertical as needed) between the wood and other cellulose material in the structure and the termite colonies in the soil. Follow all federal,

4/11

state, and local regulations and treatment standards for protection of a structure from termites. In some instances where an aerial or above ground colony is established, supplemental treatments to control the termites, landscape modifications, and/or structural repairs may be needed to deprive termites of a moisture source. Use a 0.05% to 0.1% dilution based on local recommendations. Generally a 0.05% dilution is used for typical control situations. Where severe or persistent infestations occur, a 0.1% dilution may be used.

PRE-CONSTRUCTION TREATMENT

Do not apply at a lower dosage and/or concentration than specified on this label for application prior to installation of the finished grade. Prior to each application, applicators must notify the general contractor, construction superintendent, or similar responsible party, of the intended termiticide application and intended sites of application and instruct the responsible person to notify construction workers and other individuals to leave the area to be treated during application and until the termiticide is absorbed into the soil.

CONCRETE SLAB-ON-GROUND OR BASEMENTS: Apply an overall treatment to the entire surface of soil or other substrate to be covered by the slab including areas to be under carports, porches, basement floor and entrance platforms. Apply at the rate of 1 gallon of solution to accurately and uniformly cover 10 square feet. If fill under slab is gravel or other coarse aggregate, apply at the rate of 1.5 gallons or sufficient volume of solution, to accurately and uniformly cover 10 square feet. In addition, apply 4 gallons of solution (see APPLICATION VOLUME) per 10 linear feet to provide a uniform treated zone in soil at critical areas such as along the inside of foundation walls, and around plumbing, bath traps, utility services, and other features that will penetrate the slab.

After completion of grading, make an application by trenching or trenching and rodding around the slab or foundation perimeter. Rodding may be done from the bottom of a shallow trench. When rod-ding, rod holes must be spaced in a manner that will allow for a continuous chemical treated zone, not to exceed 12 inches, to be deposited along the treated area. Rod holes should not extend below the footing. Apply 4 gallons of solution (see APPLICATION VOLUME) per 10 linear feet, per foot of depth to provide a uniform treated zone. When trenching, the trench along the outside foundation should be about 6 inches in width and 6 inches in depth. Use a low pressure spray (not to exceed 25 PSI at the treatment tool when the valve is open) to treat soil which will be placed in the trench after rodding. Mix the spray solution with soil as it is being placed in the trench. When treating voids in hollow masonry units, use 2 gallons of solution per 10 linear feet of wall. Apply solution so it will reach the footing by injecting into the lower areas of the wall, just above the floor or footing.

When treating foundations deeper than 4 feet, apply the termiticide as the backfill is being replaced, or if the construction contractor fails to notify the applicator to permit this, treat the foundation to a minimum depth of 4 feet after the backfill has been installed. The applicator must trench and rod into the trench or trench along the foundation walls and around pillars and other foundation elements, at the rate prescribed from grade to a minimum depth of 4 feet. When the top of the footing is exposed, the applicator must treat the soil adjacent to the footing to a depth not to exceed the bottom of the footing. However, in no case should a structure be treated below the footing.

Rodding in trench followed by flooding of trench and treatment of back-fill may provide a better opportunity to achieve a continuous chemical treated zone than using soil rodding alone to establish a vertical termiticide treated zone.

CRAWL SPACES: Application must be made by trenching or trenching and rodding downward along the inside and outside of foundation walls, around piers, interior supports in contact with the soil, plumbing, and utility services. Apply 4 gallons of solution (see APPLICATION VOLUME) per 10 linear feet, per foot of depth to provide a uniform treated zone. Rodding may be done from the bottom of a shallow trench to top of the footing or a minimum of 4 feet. When rodding, rod holes must be spaced in a manner that will allow for a

5/11

continuous chemical treated zone to be deposited along the treated area. Rod holes should not extend below the footing. When trenching, the trench should be about 6 inches wide and 6 inches deep. Use a low pressure spray to treat soil which will be placed in the trench, mixing the spray solution with soil as it is being placed in the trench.

HOLLOW BLOCK FOUNDATIONS OR VOIDS: Hollow block foundations or voids in masonry resting on the footing may be treated to provide a continuous chemical treated zone in the voids at the footing. Apply 2 gallons of solution per 10 linear feet to the lower part of the void so that it reaches the top of the footing or soil.

Treatment of voids in block or rubble foundation walls must be closely examined. Applicators must inspect areas of possible runoff as a pre-caution against application leakage in the treated areas. Some areas may not be treatable or may require mechanical alteration prior to treatment.

All leaks resulting in the deposition of termiticide in locations other than those prescribed on this label must be cleaned up prior to leaving the application site (refer to Precautionary Statements). Do not allow people or pets to contact or to reoccupy the contaminated areas of the structure until the clean up is completed.

POST-CONSTRUCTION TREATMENT

CONCRETE SLAB-ON-GROUND: To apply a treatment under the slab, including attached porches, carports, entrance platforms, garages and similar slab structures, it may be necessary to drill through the slab or exterior foundation. Drill holes should be spaced in a manner that will allow for application of a continuous chemical treated zone. Treat all existing cracks and cold, construction or expansion joints. Also, treat around bath traps, plumbing and utility services which penetrate the slab. Apply 4 gallons of solution (see APPLICATION VOLUME) per 10 linear feet per foot of depth to provide a uniform treated zone. **DO NOT MAKE TREATMENT UNTIL LOCATION OF HEAT OR AIR CONDITIONING DUCTS AND VENTS ARE KNOWN AND IDENTIFIED. USE EXTREME CAUTION TO AVOID CONTAMINATION OF DUCTS AND VENTS.** Plug and fill all drilled holes in commonly occupied areas with a suitable sealant. Plugs must be of non-cellulose material or covered by an impervious, non-cellulose material.

An application should be made by trenching or trenching and rodding around the outside of the foundation wall. Apply 4 gallons of solution (see APPLICATION VOLUME) per 10 linear feet per foot of depth to provide a uniform treated zone. When trenching, the trench along the out-side foundation should be about 6 inches wide and 6 inches deep. Use a low pressure spray to treat soil as it is being placed in the trench.

Rodding can be done from the bottom of a shallow trench. When rodding, rod holes should be spaced in a manner that will allow for a continuous chemical treated zone, not to exceed 12 inches, to be deposited along the treated area. Rod hole depth should not extend below the footing.

BATH TRAPS: Exposed soil or soil covered with tar or a similar type sealant beneath and around plumbing and/or drain pipe entry areas should be treated with 3 gallons of solution per square foot. An access door or inspection vent should be cut and installed, if not already pre-sent. After inspection and removal of any wood or cellulose debris, the soil can be treated by rodding or drenching the soil.

CRAWL SPACES: When there is insufficient clearance between floor joists and ground surfaces to allow applicator access, excavate, if possible, and treat according to crawl spaces (refer to Pre-Construction Treatment). If unable to excavate, crawl space soil and wood treatment may be used to prevent surface access by termites. Apply 1 gallon of solution (see APPLICATION VOLUME) per 10 square feet to provide a uniform chemical treated zone. Use a very coarse spray at a pressure not exceeding 25 PSI at the treatment tool when the valve is open.

Where a crawl space cannot be reached with the application wand, use extension wands or other suitable

6/11

equipment to apply a coarse spray on the soil, wood and structural members contacting the soil at the above rates. Do not apply to inaccessible crawl space areas using pressures greater than 25 PSI at the treatment tool when the valve is open. Treatment may also be made by drilling through the foundation wall or through the floor above and treating the soil perimeter at a rate of 1 gallon of solution per 10 square feet. Drill spacing must be at intervals not to exceed 16 inches. Many states have smaller intervals so check state regulations which may apply.

To prevent subterranean termites from constructing mudtubes between soil and crawl space wood members above, an overall soil treatment of this product may be applied. Remove all cellulose debris before application. Apply 1 gallon of solution (see APPLICATION VOLUME) per 10 square feet to provide a uniform chemical treated zone.

SHALLOW FOUNDATIONS: For shallow foundations, one foot or less in depth, dig a narrow trench approximately 6 inches wide and deep along the outside and inside of the foundation walls, being careful not to dig below the bottom of the footings. For foundations with exposed footings, dig a trench alongside the footing taking care not to undermine the footing. Apply 4 gallons of solution (see APPLICATION VOLUME) per 10 linear feet to the top of footer to provide a uniform treated zone. The dilution should be applied to the trench and mixed with the soil as it is placed in the trench.

BASEMENTS - OUTSIDE PERIMETER: Along the outside of the exterior walls, an application must be made by trenching or rodding within the trench. Rodding depth should be to the top of the footer, or to a minimum of 4 feet or according to state or local regulations. When rodding through a trench, dig a narrow trench about 6 inches wide and 6 inches deep. Apply 4 gallons of solution (see APPLICATION VOLUME) per 10 linear feet, per foot of depth to provide a uniform treated zone by rodding through the trench. Use a low pressure spray to treat soil which will be placed into the trench after rodding. Mix spray solution with the soil as it is being placed in the trench.

BASEMENTS - INSIDE PERIMETER: If necessary, treat by drilling along the perimeter of the interior walls. Applications also may be necessary around sewer pipes, floor drains, conduits, expansion joints or any cracks or holes in the basement floor. Apply 4 gallons of solution (see APPLICATION VOLUME) per 10 linear feet to provide a uniform treated zone.

Drill holes should be spaced in a manner that will allow for application of a continuous chemical treated zone. Plug and fill all drill holes in commonly occupied areas of the building with a suitable sealant. Plugs must be of non-cellulose material or covered by an impervious, non-cellulose material.

HOLLOW BLOCK FOUNDATION OR VOIDS: Hollow block foundations or voids in masonry resting on the footing may be treated to provide a continuous chemical treated zone in the voids at the footing. Apply 2 gallons of solution per 10 linear feet to the lower part of the void so that it reaches the top of the footing or soil. Drill spacing must be at intervals not to exceed 16 inches. Many states have smaller intervals so check state regulations which may apply.

Treatment of voids in block or rubble foundation walls must be closely examined. Applicators must inspect areas of possible runoff as a pre-caution against application leakage in the treated areas. Some areas may not be treatable or may require mechanical alteration prior to treatment.

All leaks resulting in the deposition of termiticide in locations other than those prescribed on this label must be cleaned up prior to leaving the application site (refer to Precautionary Statements). Do not allow people or pets to contact or to reoccupy the contaminated areas of the structure until the clean up is completed.

PLENUMS: For plenum-type structures which use a sealed underfloor space to circulate heated and/or cooled air throughout the structure, apply the dilution at the rate of 4 gallons of solution (see APPLICATION VOLUME) per 10 linear feet, per foot of depth of soil to provide a uniform treated zone adjacent to both

sides of foundation walls, supporting piers, plumbing and conduits. The soil should be treated by trenching to a depth of 6 inches or trenching and rodding (where conditions permit) or to the top of the footing. When conditions will not permit trenching or rodding, a surface application adjacent to interior foundation walls may be made, but the treated strip shall not exceed a width of 18 inches, horizontally, from the foundation walls, piers or pipes. The surface application will be made at a rate of 1.5 gallons of solution per 10 square feet as a very coarse spray under low pressure (not to exceed 25 PSI when measured at the treating tool when valve is on).

When treating plenums, turn off the air circulation system of the structure until application has been completed and all termiticide has been absorbed by the soil.

TREATMENT AROUND WELLS OR CISTERNS: Do not contaminate wells or cisterns.

Structures With Wells/Cisterns Inside Foundations: Structures that contain wells or cisterns within the foundation of a structure can only be treated using the following techniques:

1. Do not apply within 5 feet of any well or cistern by rodding and/or trenching or by the backfill method. Treat soil between 5 and 10 feet from the well or cistern by the backfill method only. Treatment of soil adjacent to water pipes within 3 feet of grade should only be done by the backfill method.

- a) Trench and remove soil to be treated onto heavy plastic sheeting or similar material or into a wheelbarrow.
- b) Treat the soil at the rate of 4 gallons of solution per 10 linear feet per foot of depth of the trench, or 1 gallon per 1.0 cubic feet of soil. Mix thoroughly into the soil taking care to contain the liquid and prevent runoff or spillage.
- c) After the treated soil has absorbed the solution, replace the soil into the trench.

2. Treat infested and/or damaged wood in place using an injection technique such as described in the (Control of Wood Infesting Pests-section of this label.

Structures With Adjacent Wells / Cisterns and/or Other Water Bodies: Applicators must inspect all structures with nearby water sources such as wells, cisterns, surface ponds, streams, and other bodies of water and evaluate, at a minimum, the treatment recommendations listed below prior to making an application.

1. Prior to treatment, if feasible, expose the water pipe(s) coming from the well to the structure, if the pipe(s) enter the structure within 3 feet of grade.
2. Prior to treatment applicators are advised to take precautions to limit the risk of applying the termiticide into subsurface drains that could empty into any bodies of water. These precautions include evaluating whether application of the termiticide to the top of the footer may result in contamination of the subsurface drain. Factors such as depth to the drain system and soil type and degree of compaction should be taken into account in determining the depth of treatment.
3. When appropriate (i.e., on the water side of the structure), the treated backfill technique (described above) can also be used to minimize off-site movement of termiticide.

FOAM APPLICATIONS

Construction practices, soil subsidence and other factors may create situations in which a continuous chemical treated zone cannot be achieved using conventional treatment alone. In situations where necessary, conventional application methods can be supplemented through use of foam generating equipment, or similar devices, to provide a continuous treated zone.

Foam application may be made alone or in combination with conventional application methods, provided that the labeled amount of active ingredient per unit area is used.

Foam Application Use Directions: Mix solution of IMIDACLOPRID 75WSP TC with manufacturer's recommended volume of foaming agent (see table for foaming recommendations). Apply a sufficient volume of IMIDACLOPRID 75WSP TC foam alone or in combination with liquid solution to provide a continuous treated zone at the recommended rate for specific application sites. Use appropriate dispersion tips and application method for site.

MIXING TABLE FOR IMIDACLOPRID 75WSP TC FOAM				
IMIDACLOPRID 75WSP1	GALLONS OF WATER	FOAM EXPANSION RATIO	FINISHED FOAM	
			(gallons)	(ai%)
ONE	1	25:1		
	2.5	10:1	25	
	5	5:1		0.05
Two	1	50:1		
	2.5	20:1	50	
	5	10:1		

1 Add the manufacturer's recommended quantity of foam agent to the IMIDACLOPRID 75WSP TC solution.

Depending on the circumstances, foam applications may be used alone or in combination with liquid solution applications. Applications may be made behind veneers, piers, chimney bases, into rubble foundations, into block voids or structural voids, wall voids, under slabs, stoops, porches, or to the soil in crawlspaces, and other similar voids.

Foam and liquid applications must be consistent with volume and active ingredient instructions in order to ensure proper application has been made. The volume and amount of active ingredient are essential to an effective treatment. At least 75% of the gallons of Imidacloprid 75WSP TC must be applied as a typical liquid treatment. The remaining 25% or less gallons are delivered to appropriate locations using a foam application.

NOTE: When foam is used solely to kill subterranean termites in above ground locations (such as feeding galleries in wooden framing, or in voids with framed walls), and whenever the target pest is other than subterranean termites (drywood termites, beetles, ants, etc.). Dilute solutions of PREMISE may be expanded by foaming without concentrating the PREMISE solution as previously described for soil applications. Add the manufacturers' recommended volume of foaming agent to produce foam of the desired expansion ratio. Use application tips and methods suitable to the site and pest.

CONTROL OF WOOD INFESTING PESTS

For control of above ground termites and carpenter ants in localized areas, apply a 0.05 to 0.1% solution or sufficient volume of IMIDACLOPRID 75WSP TC foam to voids and galleries in damaged wood, and in spaces between wooden structural members and between the sill plate and foundation where wood is vulnerable. Applications may be made to inaccessible areas by drilling, and then injecting the suspension or foam with a suitable directional injector into the damaged wood or wall voids. Termite carton nests in building voids may be injected with a 0.05 to 0.1% suspension or foam. Multiple injection points to varying depths may be necessary. It is desirable to physically remove carton nest material from building voids when such nests are found. Application to attics, crawl spaces, unfinished basements, or man-made voids may be made with a coarse fan spray of 0.05 to 0.1 % solution or foam to control exposed worker and winged reproductive forms of termites or carpenter ants. This type of application is intended to be a supplemental treatment for control of above ground subterranean termites and carpenter ants.

9/11

It is recommended to remove or prune away any shrubbery, bushes, and tree branches touching the structure. Vegetation touching the structure may offer a route of entry for ants into the structure. This may allow ants to inhabit the structure without coming in contact with the treatment. If nests are found, direct treatment of Premise 75 can be made to these nests.

Use a 0.05% to 0.1% solution to control existing infestations of or to prevent infestation by termites or carpenter ants in trees, utility poles, fencing and decking materials, landscape timbers and similar non-structural wood-to-soil contacts. If possible, locate the interior infested cavity and inject a 0.05 to 0.1% solution or sufficient volume of IMIDACLOPRID 75WSP TC foam using an appropriate treatment tool with a splashback guard. These non-structural wood-to-soil contacts may also be treated by applying a solution* to the soil as a spot application or continuous treated zone applied as a drench or by rodding around the base of the point(s) of soil contact(s). Rod holes should be placed approximately 3 inches away from the soil contact point(s) and spaced no more than 12 inches along the perimeter of the soil contact(s). For small poles or posts (< 6 inches in diameter), apply 1 gallon per foot of depth. For larger constructions, apply 4 gallons per 10 linear feet per foot of depth. Retreat as needed to maintain protection.

Termite carton nests in trees may be injected with a 0.05 to 0.1% solution or sufficient volume of foam using a pointed injection tool. Multiple injection points to varying depths may be necessary. Removal of carton material from trees is desirable but may not be necessary when foam application is used. In some instances, a perimeter application of a 0.05% to 0.1% solution applied to soil around the root flare of the tree may be necessary to prevent reinfestation by termites in the soil. For small trees (< 6 inches in diameter), apply 1 gallon of solution. For larger trees, apply 4 gallons per 10 linear feet (measured as the circumference at the root flare).

For protection of firewood or other wood products stored in contact with soil from carpenter ants and termites, treat soil prior to stacking with a 0.05 to 0.1% solution at 1 gallon per 10 square feet to prevent infestation. Curative application to the soil around firewood or other wood products stored in contact with soil may be made as described for non-structural wood-to-soil contacts (above).

Drywood termites and wood-infesting beetles or borers (such as, but not limited to, powder post beetles, anobiid or deathwatch beetles, false powder post beetles, old house borers, wharf borers, or ambrosia or bark beetles). Galleries and structure voids can be treated with sprays, mists, or foams of a 0.05% to 0.1% IMIDACLOPRID 75WSP TC solution. Locate galleries by using visual signs (frass or pellets, blistered wood, emergence or clean out holes), the presence of live insects, mechanical sounding techniques, or listening devices (e.g., stethoscopes, acoustic emission detectors). Penetrate the gallery system by drilling holes to receive the injector tip or treatment tool. Distribute drill holes to adequately cover the gallery system. [NOTE: Avoid drilling where electrical wiring, plumbing lines, etc. are located.] Apply IMIDACLOPRID 75WSP TC solutions as a low pressure (about 20 psi) spray or by misting or, where appropriate, by foaming. It is not necessary to treat to the point where runoff is detected from adjacent holes. [NOTE: Do not apply where electrical shock hazards exist.] Drill holes should be sealed after treatment. Also, wood surfaces can be sprayed or misted with a 0.05% to 0.1% solution or, where appropriate, use a sufficient volume of foam. For inaccessible surfaces, drill and treat the interior of structural voids. Surfaces treated may include exposed wooden surfaces in crawl-spaces, basements, or attics, wooden exterior surfaces such as decks, fencing, or siding, structural voids, channels in damaged wood, in spaces between wooden members of a structure, and junctions between wood and foundations. Apply by brushing or as a coarse, low pressure (about 20 psi) spray to the wood surface; apply sufficient volume to cover the surface to the point of wetness, but avoid applying to the point of runoff. When spraying overhead in living areas, cover surfaces below the treated area with plastic sheeting or similar material. Avoid contact with treated surfaces until spray deposits have dried. Retreat as needed to maintain protection.

10/11

Localized treatment for carpenter bees: Apply a 0.05% to 0.1% solution as a spray or mist, or sufficient volume of foam, directly into gallery entrance holes. Following treatment, entrance holes may be plugged with small pieces of steel wool or similar material.

RETREATMENT

Retreatment for subterranean termites can only be performed if there is clear evidence of reinfestation or disruption of the treated zone due to construction, excavation, or landscaping and/or evidence of the breakdown of the termiticide treated zone in the soil. These vulnerable or reinfested areas may be retreated in accordance with application techniques described in this product's labeling. The timing and type of these retreatments will vary, depending on factors such as termite pressure, soil types, soil conditions and other factors which may reduce the effectiveness of the treated zone. Retreatment may be made as either a spot or complete treatment.

When a structure is not known to be reinfested and the treated zone is not disturbed, but where the structure was last treated five or more years ago, retreatment may be performed if, in the judgment of the applicator, it is necessary to ensure adequate protection of the structure. In determining the timing of any retreatment, the applicator should consider efficacy and/or degradation data and/or site-specific conditions and previous experience that indicate a vulnerability of the structure to termite attack.

Annual retreatment of the structure is prohibited unless there is clear evidence that reinfestation or treated zone disruption has occurred.

APPLICATION IN CONJUNCTION WITH BORATES OR BAITING SYSTEMS: When another registered termite control product/system is used as the primary treatment for prevention or control of subterranean termites and is applied to all label-specified areas, PREMISE may be applied as a spot application in a secondary treatment to critical areas of the structure including plumbing and utility entry sites, bath traps, expansion joints, foundation cracks, the outside foundation wall, and areas of known or suspected activity at either a pre-construction or post-construction timing. These secondary treatments must be made applied in amounts and concentration in accordance with label directions relevant to the treatment area(s) to receive the secondary treatment.


PERIMETER PEST CONTROL

ANTS: For control of ants in houses and other structures, apply a 0.05 to 0.1% solution as a general surface, spot, crack and crevice or wall void application. Apply to surfaces on buildings, porches, patios and other structures, around doors and windows, eaves and attic vents, utility entry points, soffit areas and other exterior openings (including foundation cracks or drilled holes) where these pests enter the structure or where they crawl or hide. Spray into cracks and crevices. Spray, mist or foam into voids where these ants or their nests are present. Apply the volume of spray mist or foam sufficient to cover the area, but do not allow excessive dripping or run-off to occur from vertical or overhead surfaces.

Treat soil, turf or ground cover adjacent to the structure where ants are trailing or may find food or harborage. Apply to flower, shrub or ornamental plant beds adjacent to the structure where ants may find food or forage. To control ants tunneling in soil apply a 0.05% to 0.1% solution as a drench or soil injection at intervals to establish a continuous treated zone. Treat along the edge of walls, driveways or other hard surfaces where ants are tunneling beneath the surface.

Aerial Nests: If ant nests are located in tree hollows or non-structural wooden construction (e.g.; posts, fences, decks) treat the interior cavity and/or the nest site by injecting a 0.05%-0.01% solution as a spray mist, or sufficient volume of foam.

Apply in sufficient water to cover the foliage and soil area being treated. Maximum application is once per



month to maintain control.

Do not allow residents or pets into the immediate area during the application or contact with treated areas until spray has dried.

Do not use this product against native or imported fire ants, pharaoh or harvester ants.

NOTE: Where severe pest pressures may exist and when rapid knockdown or exclusion at pest entry points is desired, supplement treatments using PREMISE with targeted applications of a pyrethroid such as TEMPO SC ULTRA or SUSPEND SC to doors and windows, utility entry points, and other places where these pests enter the structure. Read and follow all label directions for use of this companion product

GENERAL PRECAUTIONS FOR APPLICATIONS

After treatment, plug and fill all holes drilled in concrete slab areas of the building with a suitable sealant. Do not apply solution until location of heat pipes, ducts, water and sewer lines and electrical conduits are known and identified. Caution must be taken to avoid puncturing and injection into these structural elements.

Do not plant for the purpose of consumption, edible plants into the treated areas of soil.

Avoid contamination of public and private water supplies.

Use anti-backflow equipment or an air gap on filling hoses.

Consult State, Federal, or local authorities for information regarding the approved treatment practices for areas in close proximity to potable water supplies.

IMPORTANT: READ BEFORE USE

Read the entire Directions for Use, Conditions, Disclaimer of Warranties and Limitations of liability before using this product. If terms are not acceptable, return the unopened product container at once. By using this product, user or buyer accepts the following conditions, disclaimer of warranties and limitations of liability.

CONDITIONS: The directions for use of this product are believed to be adequate and must be followed carefully. However, because of manner of use and other factors beyond ALBAUGH, INC.'s control it is impossible for ALBAUGH, INC. to eliminate all risks associated with the use of this product. As a result, crop injury or ineffectiveness is always possible. All such risks shall be assumed by the user or buyer.

DISCLAIMER OF WARRANTIES: TO THE EXTENT CONSISTENT WITH APPLICABLE LAW, ALBAUGH, INC. MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, OF MERCHANTABILITY OR OF FITNESS FOR A PARTICULAR PURPOSE OR OTHERWISE, THAT EXTEND BEYOND THE STATEMENTS MADE ON THIS LABEL. No agent of Albaugh, Inc. is authorized to make any warranties beyond those contained herein or to modify the warranties contained herein. Albaugh, Inc. disclaims any liability whatsoever for special, incidental or consequential damages, resulting from the use or handling of this product.

LIMITATIONS OF LIABILITY: TO THE EXTENT CONSISTENT WITH APPLICABLE LAW, THE EXCLUSIVE REMEDY OF THE USER OR BUYER FOR ANY AND ALL LOSSES, INJURIES OR DAMAGES RESULTING FROM THE USE OR HANDLING OF THIS PRODUCT, WHETHER IN CONTRACT, WARRANTY, TORT, NEGLIGENCE, STRICT

LIABILITY OR OTHERWISE, SHALL NOT EXCEED THE PURCHASE PRICE PAID, OR AT ALBAUGH, INC.'s ELECTION, THE REPLACEMENT OF PRODUCT.