

# Estimated Catch basin Sampling Schedule for Phase 1

The purpose of this document is to create a schedule for the "Condition 6 Catch Basin Sampling Plan for Phase 1 IPWP". Dates can be based on our informal starting work date- May 19<sup>th</sup>, 2014 or a week after anticipated EPA approval to Phase 1 Work Plan.

The schedule will be as followed:

CB #	Sample # 1	Sample # 2	Sample # 3
CB1	A week before blasting work starts	3 weeks from starting staging or one week after blasting work starts.	One week follow blasting work completion and containment break down.
CB3	A week before blasting work starts	3 weeks from starting staging or one week after blasting work starts.	One week follow blasting work completion and containment break down.
MH6/CB16	A week before blasting work starts	3 weeks from starting staging or one week after blasting work starts.	One week follow blasting work completion and containment break down.

\*Attached figure 1 for the three sampling locations, see the red-clouded areas with red boxed labels.  
 \*\*see IPWP attachment No. 8 item #1, "If NVL is unable to obtain an adequate sediment sample from the designated sampling locations, then, in that event, NVL will review adjacent locations to either collect a sample or complete a sample to obtain minimum sample amounts."

