




EPA EST. NO. 3780-NC-01
EPA REG. NO. 539

Teas • Rest

exterior

WEATHERBEATER

beautifies, penetrates and protects wood siding, shingles and shakes

WARRANTED
3 WAYS:

- No Cracking
- No Peeling
- No Blistering

ACRYLIC LATEX SEMI-TRANSPARENT STAIN AND PRESERVATIVE

**KEEP OUT OF REACH OF CHILDREN
WARNING**

[illegible]

ONE GALLON

ACTIVE INGREDIENT
FENITROTHION

WEATHERBEATER SEMI-TRANSPARENT STAIN AND PRESERVATIVE

colors and accents the grain and texture of new or weathered shingles, shakes, rough-hewn exterior woods and unfinished paneling. Lightly pigmented to let the natural grain show through.

PRESERVES—Special ingredient protects against wood rot and mildew

PROTECTS—Tough, durable acrylic resins resist rain, sunlight and wind

PENETRATES—Weatherbeater Semi-Transparent Stain deeply penetrates wood fibers for adhesion and superior protection

NO MESS—Easy latex application features minimal drip, run and splatter

BEFORE STAINING: Prepare the surface properly for best results

Can be used for staining over either oil or latex stained surfaces. Either surface must be clean to achieve proper adhesion. Scrape and wire brush weathered surfaces to remove all loose flakes. Brush away loose dust and dirt. Scrub with Sears HEAVY DUTY CLEANER to remove embedded dirt. Rinse completely. Fill the cracks, open construction joints, knots, and holes with Sears STAINABLE WOOD TEXTURE CAULK.

MILDEW: It is important to remove mildew from the surface before staining by scrubbing with a long-handled scrub brush with a mixture of 1 cup Sears HEAVY DUTY CLEANER, 1 qt. household bleach and 3 qts. of warm water. CAUTION: DO NOT USE DETERGENTS CONTAINING AMMONIA. WEAR RUBBER GLOVES AND SAFETY GLASSES TO AVOID SKIN AND EYE CONTACT. DO NOT BREATHE FUMES.

NOW APPLY STAIN with Sears EXTERIOR LATEX PAINT PAD, ROUGH SURFACE BRUSH or WEATHERBEATER BRUSH. Roller application is not recommended except with Sears ROUGH SURFACE ROLLER over textured surfaces.

APPLICATION: Mix thoroughly before using, and stir periodically while using. For very porous or badly weathered wood, apply a second coat after four hours for increased protection and richer color. The surface to be stained may be damp, but excessive moisture should be removed before staining.

Work with wood grain, rather than against, to avoid unsightly overlap patterns. Not recommended for sprayer application. Avoid application of stain in direct sunlight. Follow the shade around the house. Although this stain dries to touch in one hour or less, allow four hours between coats. Apply at temperatures above 60°F (16°C). Do not apply if temperatures below 45°F (7°C) are expected within 24 hours. Directly after application stain will appear milky. True color will be evident when allowed to dry thoroughly.

CLEAN-UP: Clean tools immediately after use with soap and water. If brush bristles are sticky, rinse lightly in Sears TIRPOLENE™ and re-wash with soap and water.

STORAGE AND DISPOSAL:

Do not contaminate water, food or feed by storage or disposal. Keep from freezing.



THIS PAINT
IS NOT TO BE
USED IN
WATER

COVERAGE: Porous woods—up to 200 square feet (18 sq. meters) per gallon. For best protection and color uniformity, apply liberally. More coats give additional protection, but reveal less texture. Color may vary depending on number of coats and type of wood. Although this stain may be used on exterior decks, railings, docks, swimming pool walks and outdoor furniture, when used on such horizontal surfaces, this stain must be recoated when signs of wearing or weathering appear. To assure color uniformity over entire surface, always buy enough stain to complete the whole job. During application, intermix gallons of the same color.

LIMITED WARRANTY—This Sears WEATHERBEATER Latex Stain, when applied according to label instructions at a spreading rate not to exceed 200 square feet per gallon over a properly prepared surface, excluding horizontal surfaces such as decks or walks, will have the following qualities provided that the substrate and previously applied coatings remain intact.

FOR 3 YEARS FROM DATE OF APPLICATION:

- (1) No cracking
- (2) No peeling
- (3) No blistering

If stain fails to perform as specified above, contact your nearest Sears store and Sears will furnish without charge enough additional stain to correct the condition or, if you prefer, refund the purchase price. This warranty does not include labor or cost of labor for the application of stain, and this warranty does not apply to stain applied to horizontal surfaces, such as decks and walks.

This warranty gives you specific legal rights and you may also have other rights which may vary from state to state.

SEARS, ROEBUCK AND CO. Sears Tower, BSC 41-3 Chicago, IL 60684

Keep from freezing. LABORATORY TESTED FOR QUALITY
Sold by SEARS, ROEBUCK AND CO., Chicago, IL 60684

3. Submit five (5) copies of your final printed labeling before you release the product for shipment. Refer to the A-79 Enclosure for a full description of final printed labeling.

If these conditions are not complied with, the registration will be subject to cancellation in accordance with FIFRA sec. 5(e). Your release and shipment of the product constitutes acceptance of these conditions.

A stamped copy of the label is enclosed for your records.


Henry H. Jacoby
Product Manager (21)
Fungicide-Herbicide Branch
Registration Division (TS-757)


Enclosure



SEARS PAINT
FOR GREAT AMERICAN
HOMES LIKE YOURS

ACCEPTED

SEP 20 1962



exterior

WEATHERBEATER

beautifies, penetrates and protects wood
siding, shingles and shakes



SOLID COLOR ACRYLIC LATEX STAIN AND PRESERVATIVE

KEEP OUT OF REACH OF CHILDREN
WARNING

See Side Panel for Additional Instructions

ONE GALLON
(3.785L)

EPA EST. NO. 8788-NC-01
EPA REG. NO. 539

ACTIVE INGREDIENT
Inert Ingredients

WEATHERBEATER SOLID COLOR STAIN AND PRESERVATIVE

colors and accents the texture of new, weathered or previously coated shingles, shakes, rough-hewn exterior woods.

PRESERVES—Special ingredient protects against wood rot and mildew

PROTECTS—Tough, durable acrylic resins resist rain, sunlight and wind

PENETRATES—Weatherbeater Solid Color Stain penetrates wood fibers for adhesion and superior protection

NO MESS—Easy latex application with minimal drip, run and splatter

BEFORE STAINING: Prepare the surface properly for best results

Can be used for staining over old or new latex stained surfaces. Either surface must be clean to achieve proper adhesion. Scrape and wire brush weathered surfaces to remove loose flakes. Brush away loose dust and dirt. Scrub with Sears HEAVY DUTY CLEANER to remove embedded dirt. Rinse completely. Fill the cracks, open contraction joints, knots, and holes with Sears STAINABLE WOOD TEXTURE CAULK.

MILDEW: It is important to remove mildew from the surface before staining by scrubbing with a medium and scrub brush with a mixture of 1 cup Sears HEAVY DUTY CLEANER, 1 qt. household bleach and 1 1/2 pints of warm water. CAUTION: DO NOT USE DETERGENTS CONTAINING AMMONIA. WEAR RUBBER GLOVES AND SAFETY GLASSES TO AVOID SKIN AND EYE CONTACT. DO NOT BREATHE FUMES.

NOW APPLY STAIN—For best results, use Sears EXTERIOR LATEX PAINT PAD, ROUGH SURFACE BRUSH or WEATHERBEATER BRUSH. Roller application is not recommended except with Sears ROUGH SURFACE ROLLER over textured surfaces.

APPLICATION: Stir gently for best results. For very porous or badly weathered wood, apply a second coat after four hours for increased protection and richer color. The surface may be damp, but remove excessive moisture before staining.

Apply stain to entire length, work with wood grain, rather than against, to avoid overlap patterns. May be applied by the spray method if followed immediately with a brush to insure a uniform application. Avoid application of stain in direct sunlight. Follow the shade around the house. Although this stain dries to touch in one hour or less, allow four hours between coats. Apply at temperatures above 60 F (16 C). Do not apply at temperatures below 45 F (7 C), are expected within 24 hours. True stain color will be evident after application when allowed to dry thoroughly.

CLEAN-UP: Clean tools immediately after use with soap and water. If brush bristles are sticky, rinse lightly in Sears TIRPOLENE™ and re-wash with soap and water.

STORAGE AND DISPOSAL:

Do not contaminate water, food or feed by storage or disposal. Keep from freezing.



THIS PAINT
CONTAINS MILDERS

COVERAGE: Porous woods—up to 200 square feet (18 sq. meters) per gallon. For best protection and color uniformity, apply liberally. More coats give additional protection, but reveal less texture. Color may vary depending on number of coats and type of wood. Although this stain may be used on exterior decks, railings, docks, swimming pool walks and outdoor furniture, when used on such horizontal surfaces, this stain must be recoated when signs of wearing or weathering appear. To assure color uniformity over entire surface, always buy enough stain to complete the whole job. During application, intermix gallons of the same color.

LIMITED WARRANTY—The Sears WEATHERBEATER Latex Stain, when applied according to label instructions at a spreading rate not to exceed 200 square feet per gallon over a properly prepared surface, excluding horizontal surfaces such as decks or walks, will have the following qualities, provided that the substrate and previously applied coatings remain intact.

FOR 3 YEARS FROM DATE OF APPLICATION

1. No cracking
2. No peeling
3. No blistering

If stain fails to perform as specified above, contact your nearest Sears store and Sears will furnish without charge enough additional stain to correct the condition or, if you prefer, refund the purchase price. This warranty does not include labor or cost of labor for the application of any stain, and this warranty does not apply to stain applied to horizontal surfaces, such as decks and walks.

This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state.

SEARS, ROEBUCK AND CO.® Sears Tower, 450 41 3, Chicago, IL 60684

Keep from freezing. LABORATORY TESTED FOR QUALITY
Sold by SEARS, ROEBUCK AND CO., Chicago, IL 60684