

STERA-SHEEN

NEW SCIENTIFIC WONDER CHEMICAL FOR ALL CLEANING AND SANITIZING

Stera-Sheen is a potent sanitizer combined with a fast acting milkstone remover containing special sequestering and catalytic agents to neutralize hard water minerals.

DIRECTIONS

FOR CLEANING SOFT SERVE MACHINES

Empty freezer and mix hopper. Fill mix hopper with warm water and rinse through freezer. Add 3 heaping tablespoons of Stera-Sheen to 3 gallons of hot water, and stir 30 seconds or until all crystals are dissolved. Pour into mix hopper, operate beater a maximum of 5 minutes, and drain through draw-off.

After cleaning as directed above, then sanitize with fresh solution providing 100 p.p.m. of available chlorine. Do not rinse until just before re-use, then re-sanitize with 100 p.p.m. available chlorine.

NOTE: Stera-Sheen may also be used for cleaning mix cans and utensils. For removal of hardened milkstone, calcium, or rust, apply Stera-Sheen directly to surface just like scouring powder. Never use steel wool with Stera-Sheen. Use a flat sponge.

Stera-Sheen Sanitizer required to test strength in parts per million:

3 oz. to 3 gal. of water - 100 P.P.M.

Follow Health Dept. Regulations

**pH BETWEEN
9 and 10**

Using 1 oz. to 1 gal. gives 100 p.p.m. available chlorine and will effectively kill Escherichia Coli and Staphylococcus Aureus within 30 seconds in 500 p.p.m. hardness of water.

**AVAILABLE
CHLORINE
1.7 to 1.8%**

STERA-SHEEN[®]

DAIRY

SANITIZER AND CLEANER

ACTIVE INGREDIENTS	2
POTASSIUM DICHORO-S-TRIAZINETRIONE	3%
TRISODIUM PHOSPHATE	20%
TETRASODIUM ETHYLENEDIAMINE TETRAACETATE	2%
INACTIVE INGREDIENTS	7
Total	10

CAUTION: KEEP OUT OF REACH OF CHILDREN
See panel at right for additional cautions.

STERA-SHEEN SANITIZER

N. B. PURDY PRODUCTS

WAUCONDA, ILLINOIS

STERA-SHEEN[®]

DAIRY

SANITIZER AND CLEANER

ACTIVE INGREDIENTS		25%
POTASSIUM DICHLORO-S-TRIAZINETRIONE	3%	
SODIUM PHOSPHATE	20%	
POTASSIUM ETHYLENEDIAMINE TETRAACETATE	2%	
INERT INGREDIENTS	75%	
Total		100%

CAUTION: KEEP OUT OF REACH OF CHILDREN
See panel at right for additional cautions.

Contents 4 1/2 lbs.
Net Weight

CAUTION

HARMFUL IF TAKEN INTERNALLY

AVOID CONTAMINATION OF FOOD STUFFS.

AVOID CONTACT WITH SKIN AND EYES AND LUNGS. IN CASE OF CONTACT, FLUSH FREELY WITH WATER. IF IRRITATION PERSISTS CALL PHYSICIAN.

USDA Reg. No. 178-1

THE GREATEST ADVANCE IN DAIRY SANITATION STERA-SHEEN

With STERA-SHEEN, science brings new ease, effectiveness, and economy to your daily sanitation control.

DIRECTIONS--FOR GLASSES AND DISHES

1. Scrape and pre-wash glasses, dishes and utensils whenever possible.
2. Wash with Stera-Sheen Sanitizer and Cleaner, Green Label.
3. Rinse with clean water.
4. Sanitize in a solution of 3 ounces to 3 gallons of water (100 p.p.m.). NOTE: Health Departments require a 2 minute exposure time to all glasses, dishes, and dairy utensils to be sanitized.
5. Place sanitized glasses, dishes, and utensils on a rack to air dry.

STERA-SHEEN is the only powdered chemical with all these advantages. Use it for all your cleaning and sanitizing.

Follow Health Dept. Regulations

Manufactured by

N. B. PURDY PRODUCTS COMPANY
Wauconda, Illinois 60084

PURDY PRODUCTS CO.

WAUCONDA, ILLINOIS

STERA-SHEEN SANITIZER