

# Characterization and Development of Measurement Methods for Ambient Nitrogen Dioxide (NO<sub>2</sub>)

*Melinda Beaver and Russell Long -  
ORD/NERL/HEASD/PMRB*

*Keith Kronmiller - Alion Science and Technology*

# Research Questions and Motivation:

---

- How do direct, optical measurements of NO<sub>2</sub> compare with the Federal Reference Method and photolytic conversion techniques?
- What is the optimum method for calibration and span/zero checks for each type of monitor (Gas Phase Titration of NO vs bottled NO<sub>2</sub>)?
- EPA's ORD interest in accurate NO<sub>2</sub> measurements supports:
  - Reference and equivalent method determinations and evaluations
  - EPA's monitoring networks
  - Ground-based satellite validation work with NASA

- I. NO<sub>2</sub> sources, trends, and regulations
- II. Gas-phase chemiluminescence measurement methods:
  - a. Federal Reference Method
  - b. Photolytic conversion
- III. Direct, optical techniques:
  - a. Cavity ringdown spectroscopy (CRDS)
  - b. Cavity attenuated phase shift (CAPS)
- IV. Results from DISCOVER-AQ Campaign
- V. Preliminary Results from RTP, NC

# Atmospheric nitrogen families



“nitrogen oxides”



“total reactive nitrogen”



“reacted oxides of nitrogen”

- **NO<sub>2</sub>** serves as the **indicator species** for the family of the oxides of nitrogen.

# Current NO<sub>2</sub> Regulations

- Clean Air Act requires EPA to set National Ambient Air Quality Standards (NAAQS) for criteria pollutants:

NO <sub>2</sub> Primary Standards		
<i>level</i>	<i>averaging time</i>	<i>year implemented</i>
53 ppb	Annual	1971
100 ppb*	1 hr	2010


\* The new monitoring locations for the Jan 2010 primary standard will be sited in near roadway locations to capture areas of maximum concentration.

(<http://epa.gov/ttn/amtic/nearroad.html>)


\* Continuous monitors capable of hourly data are now necessary.

# What are the sources of NO<sub>x</sub>?

## Global (natural and anthropogenic):




## anthropogenic (US):



- Primarily emitted as NO
- Emissions reductions aimed at mobile and point sources


# Emissions of NO<sub>2</sub> are declining



- 48% decrease in the national average.
- Achieved by reducing NO<sub>x</sub> for O<sub>3</sub> purposes (mobile and point source regulations).

# How is NO<sub>2</sub> (currently) measured?

- Federal (Automated) Reference Method (40 CFR, Part 50, Appendix F):
  - **Gas-phase chemiluminescence**
  - Indirectly measure NO<sub>2</sub> by conversion to NO, then NO is detected by chemiluminescence ( $\text{NO} + \text{O}_3 \rightarrow \text{NO}_2^*$ ,  $\text{NO}_2^*$  = excited state);




-Advantage → in use since the 1970s (long term record)

-Disadvantages → non-specific; indirect




# Method has possible interferences

- Non-specific to  $\text{NO}_2$   $\rightarrow$  heated metal catalysts known to convert other  $\text{NO}_y$  species to  $\text{NO}$ .




- Considered an upper limit measurement of  $\text{NO}_2$ .




# Method has possible interferences

- NO spikes → The indirect determination requires a slowly changing NO<sub>x</sub> distribution. Otherwise, negative spikes of NO<sub>2</sub> are possible:




# Alternative Technique: Photolytic-chemiluminescence

- Replace the metal bed reducer with a photolysis cell to photolyze  $\text{NO}_2$  to  $\text{NO}$  ( $\text{NO}_2 + h\nu \rightarrow \text{NO} + \text{O}$ ).
  - Use high-power light sources to maximize conversion to  $\text{NO}$ .




- Advantage → more specific to  $\text{NO}_2$
- Disadvantages → non-unity conversion efficiency; still indirect

# UV/Vis Spectroscopy of NO<sub>2</sub>




# Direct Optical Techniques

- Cavity ringdown spectroscopy
  - instrument manufactured by Los Gatos Research, Inc.




$$N(\text{cm}^{-3}) = \frac{1}{c\sigma} \left( \frac{1}{\tau} - \frac{1}{\tau_0} \right)$$



- 10 s time resolution
- Advantage → DIRECT measurement
- Disadvantages → not-necessarily specific to NO<sub>2</sub>, but to any molecule that absorbs light at 405 nm

# Direct Optical Techniques


- Cavity ringdown spectroscopy
  - instrument manufactured by Los Gatos Research, Inc.



- 10 s time resolution
- Advantage → DIRECT measurement
- Disadvantages → not-necessarily specific to  $\text{NO}_2$ , but to any molecule that absorbs light at 405 nm

# Direct Optical Techniques


- Cavity attenuated phase shift spectroscopy (CAPS)
  - instrument manufactured by Aerodyne Research, Inc.



- Advantage → DIRECT measurement
- Disadvantage → not-necessarily specific to  $\text{NO}_2$ , but to any molecule that absorbs light at  $\sim 450 \text{ nm}$
- 2 versions: fast response (1 s) and ambient (10 s)

# Direct Optical Techniques

- Cavity attenuated phase shift spectroscopy (CAPS)
  - instrument manufactured by Aerodyne Research, Inc.



- Advantage → DIRECT measurement
- Disadvantage → not-necessarily specific to NO<sub>2</sub>, but to any molecule that absorbs light at ~450 nm
- 2 versions: fast response (1 s) and ambient (10 s)




# NASA DISCOVER-AQ and EPA collaboration


- Supplement the existing local monitoring sites with NO<sub>2</sub> measurement technologies → satellite validation.
- First deployment was July 2011 in/around the greater Baltimore/DC metro area.
- Deployed two NO<sub>x</sub> monitors: one FRM and one photolytic-chemiluminescence



# Results from Padonia, MD Ground Site





# Preliminary Results from Padonia, MD Ground Site



$$\Delta NO_2 = NO_2\_FRM - NO_2\_photo$$

- The interference in the FRM monitor over predicts by ~50% during the hours surrounding noon.

# Preliminary Results from Padonia, MD Ground Site



$$\Delta NO_2 = NO_2\_FRM - NO_2\_photo$$

- The interference in the FRM monitor over predicts by ~50% during the hours surrounding noon.

# EPA's AIRS site, RTP, NC



- Currently conducting an intercomparison of direct optical, photolytic conversion, and FRM monitors throughout the summer months.



- Site operational with all monitors starting in mid – February 2012.

- Glass inlet, 5 m AGL, all instruments sample from common sampling manifold.



# Monitors Tested

<b><i>Manufacturer and Model</i></b>	<b><i>Operation Principle</i></b>	<b><i>FRM/FEM status</i></b>
Teledyne T200U	Moly-chemiluminescence	FRM
Teledyne 200EUP	Photolytic-chemiluminescence	FEM (application approved, designation imminent)
Aerodyne CAPS (both versions: fast response and ambient)	Cavity attenuated phase shift	--
Los Gatos Research CRDS	Cavity ringdown spectroscopy	--


# Instrument Specifics

<b><i>Manufacturer and Model</i></b>	<b><i>Size (h x w x l)</i></b>	<b><i>weight (lbs.)</i></b>	<b><i>Power (W)</i></b>	<b><i>Sample flow, vol (Lpm)</i></b>	<b><i>Cost (\$USD)</i></b>
Teledyne T200U	7"x 17"x 24"	55	500	1.0	~16K
Teledyne 200EUP	7"x 17"x 24"	61	600	1.1	~25K
Aerodyne CAPS (both versions: fast response and ambient)	9"x 17"x 26"	27	<100	0.9 (ambient) 4.5 (fast)	~25K
Los Gatos Research CRDS	7"x 19"x 24" (plus external drier)	60	100	0.9	~30K

# Nightly span/zero cycle

Gas-phase titration of  
NO (excess) with  $O_3$


Bottled  $NO_2$  gas






# March 2012 Span/Zero checks

**GPT (zero)**




**gas (zero)**

**GPT (low)**






**gas (low)**

**GPT (high)**





**gas (high)**



# Initial Performance Characterization

- EPA's AIRS site – RTP, NC; March 2012



# Operational Experiences

<b><i>Manufacturer and Model</i></b>	<b><i>Data Interface/Accessibility</i></b>	<b><i>Calibration Procedures</i></b>
Teledyne T200U	- easily interfaced to our Envidas Ultimate data logger	- zero, high NO span to set slope and offset
Teledyne 200EUP		- zero, high NO span to set slope and offset; then determine conversion efficiency using NO <sub>2</sub>
Aerodyne CAPS (both versions: fast response and ambient)	- Currently not interfaced with our data logger; operates using Aerodyne software which generates .txt files (comma delimited)	- Multipoint calibration periodically suggested to compare with factory calibration. Manual baseline check required weekly.
Los Gatos Research CRDS	- Can be interfaced with data logger via the provided 0-5V analog out signal; however no 'status' flag provided (yet); using .txt files generated by the instrument (tab delimited)	- Automatically checks the baseline signal at user defined interval; no further calibration required.

## ORD's Current Initiatives for NO<sub>2</sub> (FY12- FY15) include:

- Method inter-comparison through the summer
  - Including detailed NO<sub>y</sub> and reduced nitrogen speciation to look at potential interferences
- Develop calibration procedures for direct measurement techniques
  - NO<sub>2</sub> cylinder vs GPT
- Detailed laboratory based assessments
  - Interference testing
  - 40 CFR part 53 subpart B performance testing
- Develop and document performance criteria including calibration and challenge procedures
- Evaluate optical monitors in a near-roadway environment

# Acknowledgements

---

## EPA

- Jim Szykman
- David Williams
- Richard Baldauf
- Surender Kaushik

## Arcadis

- Parik Deshmukh

**Aerodyne Research, Inc.**

**Teledyne API**

**Los Gatos Research, Inc.**

## Disclaimer:

Although this work was reviewed by EPA and approved for presentation, it may not necessarily reflect official Agency policy.