

**THE
FULD
LINE**

SCALE-GO


LIQUID BOWL CLEANER

Scale Solvent & Disinfectant

ACTIVE INGREDIENTS16.00%
Hydrogen Chloride; n-Alkyl [C12 (47%),
C14 (18%), C16 (10%), C18 (10%), re-
lated C8 to C15 (15%)] Dimethyl Benzyl
Ammonium Chloride.

INERT INGREDIENTS84.00%
Water, Nonylphenoxypolyethoxyethanol,
Methyl Ethyl Ketone, Dyes.

Net Contents: 1 Liquid Quart

DANGER  **POISON**
May be Fatal If Swallowed
SEE ANTIDOTE & PRECAUTIONS
ON BACK PANEL
KEEP OUT OF REACH OF CHILDREN

MANUFACTURED BY

FULD BROTHERS, INC.

BALTIMORE, MARYLAND 21231
LOS ANGELES, CALIFORNIA 90013

SOLD THROUGH DISTRIBUTORS ONLY

NOTICE: This is a strong acid type liquid cleaner and must be used only according to directions. Read direction labels carefully before using. Precautions required. Removes Rust and Lime Scale, Scum, Scale, Filth and Discoloration from Toilet Bowls, Urinals and all Vitreous Ware. Cleans lights and De-scales Sterilizers.

DIRECTIONS

CLEANING CLOSET BOWLS: Pour about two ounces around edge of bowl. Let remain few minutes. Then swab with a bowl mop up under flush ring and around inside surface. If all incrustations and discolorations have not been removed, repeat operation. After cleaning, rinse bowl thoroughly by flushing.

MAINTAINING CLEAN BOWLS: To keep bowl clean and disinfected, pour 2 ozs. into bowl daily. Flush solution under flush ring and on inside surface.

TO CLEAN FLOORS AROUND BOWL: For hard surfaced floors only. Never use on resilient floors. Sprinkle a few drops on floor. Brush well. Flush with water on mop or brush.

CLEANING URINALS: Remove protecting screen. Pour about 8 ounces around pipe edges. Let remain short time. This cleaner is heavier than water. Let it stay in trap short time to remove scale. Then flush.

CLEANING URINAL FLUSH RING: Use same method as closet bowls.

MAINTAINING CLEAN URINALS: Pour small amount in drain pipe and apply to flush ring regularly. Always rinse.

NOTICE: This is a strong acid type liquid cleaner, and must be used only according to directions. Read direction labels carefully before using. Note cautions required. Removes Rust and Lime Stains, Scum, Scale, Filth and Discoloration from Toilet Bowls, Urinals and all Vitreous Ware. Cleans Skylights and De-scales Sterilizers.

DIRECTIONS

CLEANING CLOSET BOWLS: Pour about two ounces around edge of bowl. Let remain few minutes. Then swab with a bowl mop up under flush ring and around inside surface. If all incrustations and discolorations have not been removed, repeat the operation. After cleaning, rinse bowl thoroughly by flushing.

MAINTAINING CLEAN BOWLS: To keep bowl clean and disinfected, pour 2 ozs. into bowl daily. Swab solution under flush ring and on inside surfaces.

TO CLEAN FLOORS AROUND BOWL: For hard surfaced floors only. Never use on resilient floors. Sprinkle a few drops on floor. Brush well. Flush with water on mop or brush.

CLEANING URINALS: Remove protecting screen. Pour about 8 ounces around pipe edges. Let remain short time. This cleaner is heavier than water. Let it stay in trap short time to remove scale. Then flush.

CLEANING URINAL FLUSH RING: Use same method as closet bowls.

MAINTAINING CLEAN URINALS: Pour small amount in drain pipe and apply to flush ring regularly. Always rinse.

FOR CLEANING SKYLIGHTS: Dilute this product with equal parts of water. Then rinse with clear cold water. Then wash surface with scrubbing soap and water.

FOR DESCALING STERILIZERS: Dilute this product with 8 parts of water. Cover scale with this solution and apply heat. Allow solution to remain in contact with surface not in excess of 30 minutes. Then flush surface several times with clear cold water.

CAUTION:

CONTAINS HYDROCHLORIC ACID

Use on other than vitreous ware is done at users risk. Never let material contact skin, fabrics, soft flooring, painted or varnished surfaces as it attacks organic matter. **DO NOT GET IN EYES. Caustic:** Produces chemical burns. Do not breathe vapor or fumes. Do not get on skin or on clothing.

ANTIDOTES: Internal — Drink a teaspoonful or more of Magnesia, Chalk, Whiting or Wall Plaster, or small pieces of soap, softened with water, in milk, mucilage or raw egg whites. **CALL PHYSICIAN.**

External — Wipe off acid gently. Immediately flood surface with water, using soap freely, then cover with moist Baking Soda or Magnesia. **No. 817**

Made for Industrial and Institutional Use Only
Container, Contents & Printing: Product of USA
U.S.D.A. Reg. No. 257-196 — 1608 6/66

ACCEPTED WITH COMMENTS