

ACCEPTED

APR 15 1965

UNDER THE FEDERAL INSECTICIDE
FUNGICIDE AND RODENTICIDE ACT
FOR ECONOMIC POISON REGISTERED
ED UNDER NO. 292-48

DAIRY AND FOOD PROCESSING EQUIPMENT

1. Rinse equipment with clean lukewarm water immediately after use. Flush thoroughly to remove all loose material.
2. Brush-wash all surfaces with proper Klenzade detergent.
3. Rinse thoroughly with hot (145°F) water.
4. Sanitize just before using equipment with K-San at 1 oz. to 1 gallon of water. All surfaces should be exposed to the germicide for a period of not less than 2 minutes.

TABLE OF PROPORTIONS

Dilutions	Sanitizer
1 oz. K-SAN to 1 gal. of water	200 ppm
3 oz. K-SAN to 2 gals. of water	300 ppm
2 oz. K-SAN to 1 gal. of water	400 ppm

Manufactured Exclusively by
KLENZADE PRODUCTS
Division of Economics Laboratory, Inc.
BELLEVILLE, WISCONSIN • U.S.A.

SYSTEMATIZED SANITATION all over the nation!

KLENZADE. ACID SANITIZER



formula S-15
USDA Reg. No. 292-48

ACTIVE INGREDIENTS:	
Orthophosphoric Acid	21.00%
Dodecyl benzene sulfonic acid, sodium salt	2.75%
INERT INGREDIENTS:	76.25%
(Contains a non-ionic detergent)	
TOTAL	100.00%

CAUTION

KEEP OUT OF REACH OF CHILDREN.

See side panel for additional precautionary labeling.

NET CONTENTS: 1 U.S. GALLON

INSTITUTIONAL APPLICATIONS

DISHES, GLASSES, UTENSILS AND EQUIPMENT

1. Scrape and prewash dishes, glasses, utensils and equipment whenever possible.
2. Wash with appropriate Klenzade detergent.
3. Rinse with clean water.
4. Sanitize in a solution of 1 oz. K-San to 1 gallon of water. (200 ppm). Immerse all utensils for at least two minutes or for contact time specified by governing sanitary code.
5. Place sanitized utensils on rack or drain board to air dry.

CAUTION

Harmful if swallowed. Causes skin irritation. Avoid contact with skin or eyes. In case of accidental contact with eyes, wash with water for 10 to 15 minutes. Get medical attention. Avoid contamination of foods. Do not mix with chlorine sanitizers. Use in recommended dilutions.

292-48

04/15/1965

1/1