

72

292-61

04/19/1965

1/1

DIRECTIONS FOR DETERGENT SANITIZER
FOR HALF WASHING EQUIPMENT,
TANKS, VATS, PAILS, ETC.

1. Flush equipment with lukewarm water immediately after use.
2. Wash by brushing with a solution of 1 ounce KLENZADE MIKROKLENE DF to each 5 gallons of water.
3. Rinse with clean water.
4. Sanitize utensils with 1 ounce KLENZADE MIKROKLENE DF to each 10 gallons of water. The sanitizing rinse must always be used whether the equipment is washed with a detergent sanitizer or an ordinary detergent.

For removal of light milkstone or light film apply a solution of 1 ounce KLENZADE MIKROKLENE DF to 3 gallons of water. For removal of heavy milkstone apply undiluted KLENZADE MIKROKLENE DF. After 3 to 5 minutes brush surfaces with lukewarm water using proper KLENZADE brushes. Repeat if necessary. KLENZADE MIKROKLENE DF is effective in reducing the spread of mastitis when used for washing udders.

~~NET CONTENTS: 1 U.S. GALLON~~



Mikroklene DF[®]

USDA Reg. No. 292-61

IODINE BASED DETERGENT SANITIZER

Approved For Use In The Automatic Mikro Master

ACTIVE INGREDIENTS:

Butoxy polypropoxy polyethoxy ethanol-iodine complex, providing 1.75% available iodine	15.5%
Phosphoric acid	9.0%

INACTIVE INGREDIENTS

Total	100.0%
-------	--------

CAUTION

KEEP OUT OF REACH OF CHILDREN!

See side panel for additional precautionary labeling

NET CONTENTS: 1 U.S. GALLON

DIRECTIONS FOR SANITIZING

FOR PIPELINES AND CLOSED SYSTEMS
After washing, followed by a clean water rinse, circulate KLENZADE MIKROKLENE DF solution at 12½ ppm available iodine at an exposure time of not less than 2 minutes.

FOR EQUIPMENT, TANKS, VATS, PAILS, ETC.
After the equipment has been washed and rinsed properly, sanitize with KLENZADE MIKROKLENE DF at a concentration of 12½ ppm available iodine for a period of not less than 2 minutes. Discard solution when the available iodine drops below 8 ppm. Always use freshly prepared solutions. Effective in cold or warm water. Follow procedures recommended by local health authorities.

TABLE OF DILUTIONS:

1 oz. KLENZADE MIKROKLENE DF to 5 gallons of water — 25 ppm available iodine
1 oz. KLENZADE MIKROKLENE DF to 10 gallons of water — 12½ ppm available iodine
Note — 1 ounce is equal to 2 tablespoonfuls.

CAUTION — Avoid contamination of food. Harmful if swallowed. Use in recommended dilutions, not to exceed temperatures of 115°F. Avoid contact with skin and eyes. In case of contact flush skin or eyes with plenty of water; for eyes get medical attention. Keep from freezing.

MANUFACTURED BY
KLENZADE PRODUCTS
DIVISION OF ECONOMICS LABORATORY, INC.
BELLEVILLE, WISCONSIN, U.S.A.

A KLENZADE Product

MANUFACTURED BY
KLENZADE PRODUCTS
DIVISION OF ECONOMICS LABORATORY, INC.
BELLEVILLE, WISCONSIN, U.S.A.

ACCEPTED

APR 19 1965

UNDER THE FEDERAL INSECTICIDE
FUNGICIDE AND RODENTICIDE ACT
FOR ECONOMIC POISON REGISTERED
UNDER NO. 292-61