



Mikroklene[®] DF

USDA Reg. No. 292-61

IODINE BASED DETERGENT SANITIZER

ACTIVE INGREDIENTS:

Butoxypolypropoxy polyethoxy ethanol-iodine complex, providing 1.75% titratable iodine	15.5%
Phosphoric acid	6.5%
INERT INGREDIENTS	78.0%
Total	100.0%

CAUTION

KEEP OUT OF REACH OF CHILDREN

See side panel for additional precautionary labeling

NET CONTENTS 1 U.S. GALLON

KLENZADE KLENZADE PRODUCTS

ST. PAUL, MINNESOTA 55102

KLENZADE MIKROKLENE DF

Directions For Sanitizing Dairy and Food Equipment:

FOR PIPELINES AND CLOSED SYSTEMS —

After washing, just before use, sanitize with KLENZADE MIKROKLENE DF solution at 12.5 ppm titratable iodine, allowing at least a 2-minute exposure time.

FOR EQUIPMENT, TANKS, VATS, PAILS, ETC. —

After the equipment has been cleaned and rinsed, sanitize just prior to use with KLENZADE MIKROKLENE DF at a concentration of 12.5 ppm titratable iodine for at least a 2-minute exposure time.

Directions For Sanitizing Poultry And Meat Processing Equipment:

FOR EQUIPMENT —

After washing equipment, just before use, sanitize with a concentration of 25 ppm titratable iodine for at least a 2-minute exposure time.

FOR CONTINUOUS TREATMENT OF MEAT AND POULTRY CONVEYORS —

Wash, rinse, and sanitize conveyance equipment. During processing, apply MIKROKLENE DF at a 25 ppm titratable iodine level to conveyors with MIKROMASTER feeding equipment. Controlled volumes of sanitizer are applied through nozzles so located as to permit maximum drainage of sanitizer from equipment.

During interruptions in operation, spray equipment with a MIKROMASTER dispensed MIKROKLENE DF solution at 25 ppm titratable iodine. This includes peelers, collators, slicers, saws, et cetera. Conveyor equipment should be free of product when applying this spray.

TABLE OF DILUTIONS:

1 oz. KLENZADE MIKROKLENE DF to 5 gallons water - 25 ppm titratable iodine
1 oz. KLENZADE MIKROKLENE DF to 10 gallons water - 12.5 ppm titratable iodine
Always use freshly prepared solutions. Effective in cold or warm water. Follow procedures recommended by local health authorities.

CAUTION: Avoid contamination of food. Harmful if swallowed. Use at recommended dilutions and at a temperature not exceeding 115°F. Avoid contact with skin and eyes. Causes skin irritation. In case of contact, thoroughly flush skin and eyes with water; for eyes get medical attention. Keep from freezing.

KLENZADE PRODUCTS

Division of KLENZADE LABORATORIES, INC.

ST. PAUL, MINNESOTA 55102

4065/0302/0369

© 1969 ECONOMICS LABORATORY, INC.

Printed in USA

ACCEPTED

JUN 12 1969

292-61

best copy available

292-61

06/12/1969

11