

Huntington.

PHENOCIDE 256

germicidal detergent

- Cleans, Disinfects & Deodorizes
- Pleasant Fragrance
- Economical-to-use

ACTIVE INGREDIENTS:

o-benzyl-p-chlorophenol
o-phenylphenol

9.5%

4.5%

INERT INGREDIENTS

81.0%

Total

100.0%

KEEP OUT OF REACH OF CHILDREN

DANGER

(See side panel for additional precautionary and practical treatment statements.)

CONTENTS ONE GALLON (3.785 Liters)

ACCEPTED

MAR 26 1990

Under the Pesticide Act
Phenocide, 256 is
as amended, for the purpose
registered under
EPA Reg. No. 303-221

DILUTION: 1 to 256

DIRECTIONS FOR USE

It is a violation of Federal Law to use this product in a manner inconsistent with its labeling.

GENERAL USE DIRECTIONS

USE: Floors, walls, metal surfaces, painted surfaces, exterior bowl surfaces, empty bathtubs, showers, conductive flooring, and lavatory fixtures. For institutional use only such as in hospitals and nursing homes, schools and colleges, medical and dental offices, and veterinary clinics.

APPLICATION: Use 1/2 ounce of Phenocide 256 per gallon of water for a minimum contact of 10 minutes in a single application. For disinfecting, remove gross filth and heavy soil deposits, then thoroughly wet surfaces. Phenocide 256 is extremely versatile and can be applied with a mop, sponge, or cloth as well as soaking. The recommended use solution is used once and discarded. Rinsing is not necessary on floor surfaces unless floors are to be waxed or polished. Tuberculocidal effectiveness is in 10 minutes at 20°C.

*Kills HIV-1 (AIDS virus) on pre-cleaned environmental surfaces/objects previously soiled with blood/body fluids in healthcare settings or other settings in which there is an expected likelihood of soiling surfaces/objects with blood or body fluids, and in which the surfaces/objects likely to be soiled with blood or body fluids can be associated with the potential for transmission of human immunodeficiency virus Type 1 (HIV-1) (associated with AIDS).

SPECIAL INSTRUCTIONS FOR CLEANING AND DECONTAMINATION AGAINST HIV-1 (AIDS Virus) OF SURFACES/OBJECTS SOILED WITH BLOOD/BODY FLUIDS.

PERSONAL PROTECTION: Intact latex or intact vinyl gloves must be worn during all cleaning of body fluids and decontamination procedures.

CLEANING PROCEDURE: Blood and other body fluids must be thoroughly cleaned from surfaces and objects before application of Phenocide 256. This cleaning may be accomplished with any cleaning solution including this product.

CONTACT TIME: HIV-1 (AIDS Virus) is inactivated after 1 minute of contact at room temperature to 25°C. Use a 10 minute contact time at 20°C for other common types of viruses and bacteria claimed.

DISPOSAL OF INFECTIOUS MATERIALS: Blood and other body fluids should be autoclaved and disposed of according to local regulations for infectious waste disposal.

EPA Reg. No. 303- EPA Est. No. 303-IN-1

PSEUDOMONACIDAL STAPHYLOCIDAL *VIRUCIDAL FUNGICIDAL

Phenocide 256 is a concentrated multi-purpose germicidal detergent proven effective by the ADAC Use-Dilution Method in 400 ppm hard water (Calculated as CaCO₃) in the presence of 5% organic bio-load (Fetal Bovine Serum).

Phenocide 256's superior powerful formula disinfects, cleans, and deodorizes in one labor saving step. It is effective against the following pathogenic organisms:

<i>Pseudomonas aeruginosa</i>	<i>Salmonella typhimurium</i>	<i>Streptococcus faecalis</i>
<i>Enterobacter aerogenes</i>	<i>Salmonella typhi</i>	<i>Staphylococcus aureus</i>
<i>Escherichia coli</i>	<i>Pseudomonas citrea</i>	<i>Rubella</i>
<i>Proteus mirabilis</i>	<i>Enterococcus sp.</i>	<i>HIV-1 (AIDS Virus)</i>
<i>Shigella flexneri</i>	<i>Providencia rettgeri</i>	<i>Adenovirus Type 2</i>
<i>Serratia marcescens</i>	<i>Mycobacterium bovis</i>	<i>Herpes Simplex Type 2</i>
<i>Salmonella choleraesuis</i>	<i>Trichosporon</i>	<i>Influenza Type A/Mich</i>
<i>Enterobacter cloacae</i>	<i>Moraxella</i>	<i>Vaccinia</i>
<i>Klebsiella pneumoniae</i>	<i>Candida albicans</i>	<i>Newcastle Disease Virus</i>
<i>Proteus vulgaris</i>	<i>Staphylococcus aureus</i>	<i>Canine parvovirus</i>
	<i>Streptococcus pyogenes</i>	<i>Human coronavirus Type 229E</i>

*Infectious Bovine Rhinotracheitis

*Feline picornavirus

*Feline leukemia

*Tested against antibiotic resistant strain only

*Tested against standard ATCC strains and antibiotic resistant strains.

*Classified by Underwriters Laboratories Inc. ®, as to electrical conductivity when used on conductive floors and spontaneous heating. For use with listed electrically conductive flooring of the vinyl type. 378Y. Phenocide 256

For product information or to place orders call toll free:

1-800/537-8724, in Indiana 1-800/449-8522, in Canada call collect 416/791-2338.
Huntington Laboratories, Inc., Huntington, Indiana 46769 • London, PA 19046 • Dallas, TX 75227
Beverly, CO 80025 • Oakland, CA 94621 • Brampton, Ontario, Canada L6Y 1E2

STATEMENT OF PRACTICAL TREATMENT

In case of skin contact, wash thoroughly with soap and water. In case of eye contact, immediately flush eyes with water for 15 minutes and get prompt medical attention. If swallowed, drink promptly a large quantity of water. Avoid alcohol.

Call a physician immediately.

NOTE TO PHYSICIAN: Probable mucosal damage may contraindicate the use of gastric lavage. Measures against circulatory shock, respiratory depression and convulsion may be needed.

PRECAUTIONARY STATEMENTS

HAZARDS TO HUMANS AND DOMESTIC ANIMALS

DANGER

Corrosive.

Causes eye and skin damage.

Do not get in eyes, on skin or clothing. Wear goggles or face shield and rubber gloves when handling. Wash thoroughly with soap and water after handling. Remove and wash contaminated clothing before reuse. Harmful if swallowed. Avoid contamination of food, water or feed.

STORAGE AND DISPOSAL

PROHIBITIONS

Do not contaminate water, food, or feed by storage or disposal. Open dumping is prohibited. Do not reuse empty container.

PESTICIDE DISPOSAL

Pesticide wastes are acutely hazardous. Improper disposal of excess pesticide, spray mixture, or residue is a violation of Federal Law. If these wastes cannot be disposed of by use according to label instructions, contact your State Pesticide or Environmental Control Agency, or the Hazardous Waste representative at the nearest EPA Regional Office for guidance.

CONTAINER DISPOSAL

PLASTIC CONTAINERS

Triple rinse (or equivalent), then allow for recycling or reconditioning, or puncture and dispose of in a sanitary landfill, or incineration, or, if allowed by state and local authorities, by burning. If burned, stay out of smoke.

GENERAL

Consult federal, state, or local disposal authorities for approved alternative procedures such as limited open burning.

BEST AVAILABLE COPY