

E.P.A. REGISTRATION NO. 323 - 52

FOR USE IN HOSPITALS AND CLINICS

EFFECTIVE AGAINST STAPHYLOCOCCUS AUREUS, SALMONELLA CHOLERAESUIS, PSEUDOMONAS AERUGINOSA, PATHOGENIC FUNGI AND TRICHOPHYTON INTERDIGITALE, *INFLUENZA A₂ HERPES SIMPLEX, VACCINIA AND ADENOVIRUS TYPE 5 VIRUSES WHEN USED ACCORDING TO DIRECTIONS.

USE DIRECTIONS

FOR GENERAL CLEANING AND DISINFECTING USE A 1.25% SOLUTION (1/2 oz. per gallon of water).

PREPARATION OF SOLUTION:

For controlled dispensing accuracy and ease of measurement, use dispenser pump available with each case of bottles. One full stroke (pull up, then press down) delivers 1/2 ounce of Clinic Disinfectant concentrate. This is the correct amount for each gallon of use solution prepared.

FOR REGULAR CLEANING AND DISINFECTING:

Apply properly prepared Clinic Disinfectant solution liberally with sponge, cloth, mop or wet spray to wall, floors or other hard surfaces.

FOR REMOVING HEAVY SOIL AND DISINFECTING:

Use as in regular cleaning and disinfecting, pick up dirty solution and re-clean surface.

FOR USE IN SANITIZING FOOD EQUIPMENT OR FOOD CONTACT SURFACES:

Limit level of active quaternary ingredients to 200 PPM. (1 oz. per 5 gallons of water.) Treated food contact surfaces and equipment must be rinsed with potable water prior to rinse.

After use rinse empty container thoroughly with water and discard.

SOLE BY J. I. HOLCOMB MANUFACTURING CO.

CLEVELAND, OHIO 44103

Plants in Principal Cities

79969 (REV. 10/74)

1459 PA.

CLINIC DISINFECTANT

... WITH CONTROLLED DISPENSING

CONCENTRATED DETERGENT DISINFECTANT, FUNGICIDE, VIRUCIDE*, AND DEODORIZER

ACTIVE INGREDIENTS: n-alkyl (60%C14, 30%C16, 5%C12, 5%C18) dimethyl benzyl ammonium chlorides - 6.25%; n-alkyl (68%C12, 32%C14) dimethyl ethylbenzyl ammonium chlorides 6.25%; Tetrasodium ethylenediamine tetraacetate - 3.60%; Ethyl Alcohol - 3.12%;

INERT INGREDIENTS:

80.78%

DANGER: KEEP OUT OF REACH OF CHILDREN: See back panel for first aid and other precautions.

**NET CONTENTS: 1/2 GALLON
64 FL.OZ. (1.89 liters)**

FOR INSTITUTIONAL, COMMERCIAL AND INDUSTRIAL USE ONLY

CLINIC DISINFECTANT is a non-phosphate detergent, disinfectant, fungicide, *VIRUCIDAL deodorant. Especially formulated for institutional, commercial and industrial use where housekeeping is of the utmost importance in preventing cross infection from environmental surfaces.

CLINIC DISINFECTANT IS RECOMMENDED FOR USE ON:

FLOORS	FIXTURES
WALLS	REST ROOMS
LOCKERS	NURSERIES
FURNITURE	OPERATING ROOMS
REFRIGERATORS	FOOD SERVICE AREAS
STEAM TABLES	SERVING CARTS
FOOD CARTS	FIRST AID ROOMS
OTHER HARD SURFACES	

DANGER: KEEP OUT OF REACH OF CHILDREN. Corrosive, causes skin irritation and severe eye damage. Do not get in eyes, or on skin or clothing. Harmful if swallowed. Avoid contamination of food.

FIRST AID: In case of contact, immediately flush eyes or skin with plenty of water for at least 15 minutes. For eyes, call a physician. Remove and wash all contaminated clothing before reuse. If swallowed, do not induce vomiting. Drink large quantities of fluid and call a physician.

NOTE TO PHYSICIAN: Probable mucosal damage may contraindicate the use of gastric lavage. Measures against circulatory shock, respiratory depression and convulsion may be needed.