

FRONT PANEL

DIVERSEY

UDDER-BAC

IODOPHOR UDDER WASH, BACTERICIDE,
SANITIZER AND DEODORIZER

Active Ingredients:

Polyethylene glycol ether of linear secondary alcohol - Iodine complex (providing 1.75% available iodine)	13.45%
Phosphoric acid	6.75%
Citric acid	4.00%

Inert Ingredients:

75.80%

CAUTION - Keep out of reach of children.

See side panel for additional cautions.

This product contains only biodegradable surfactants.
This product will not create foam problems in sewage systems, rivers
or streams.

Net Contents 1 Gallon

MAR 24 1967
875-46

THE DIVERSEY CORPORATION

CHICAGO, ILLINOIS

SIDE PANEL

SANITIZING UTENSILS AND EQUIPMENT

1. Immediately after use, clean equipment in the usual manner using Diversy FUK-ET (chlorinated alkaline detergent) for manual cleaning of farm tanks, utensils and bucket milking machines or Diversy DICKEM for spray cleaning of farm tanks.
2. Prepare a sanitizing solution using 1 oz. of UDDER-BAC to each 5 gallons of tap water. This solution gives 25 ppm of available iodine. It also serves as a water conditioning acidified rinse to prevent milkstone formation and water spotting. Expose equipment to the sanitizing solution at least 2 minutes or as specified by local regulations. After rinsing in UDDER-BAC solution, rack equipment to drain and dry.

NOTE: The Diversy D-SPRAY chemical injector for proportioning the proper amount of Diversy UDDER-BAC into the spray hose for both udder washing and sanitizing will save time, labor, and conserve sanitizer.

CONCENTRATION CHART
(25 ppm available iodine)

WATER	UDDER-BAC
2½ gallons	½ ounce
5 gallons	1 ounce
10 gallons	2 ounces

Nutrition Research
Member
National
Dairy
Council
Education - Public Relations

USDA Reg. No. 875-46

W. H. L. 11/15/46
U.S. DEPARTMENT OF AGRICULTURE
IN U.S. MAIL
NO ATTACHED LABELS

SIDE PANEL

UDDER WASHING

1. Use a plastic pail. Prepare solution of 1 oz. Diversey UDDER-BAC to each 5 gallons of 115°F. water.
2. About one minute before applying test cups, dip single service paper towel into the UDDER-BAC solution. Wash and massage udder thoroughly for sanitizing and udder stimulation. Discard towel.
3. Use a strip cup to examine each quarter before applying machine.
4. Right after milking machine is removed, dip each test into a cup containing the UDDER-BAC solution.
5. Prepare fresh solution when the brown iodine color disappears.

CAUTION

This is an acidic material. Concentrate may cause skin irritation. Harmful if swallowed. If swallowed give 1 or 2 glasses of water or milk. Call doctor. Avoid contact with skin or eyes. If it gets in eyes, flush freely with water. Consult doctor. Avoid continuation of feeds.

WARRANTY

The Diversey Corporation warrants to the original purchaser of this product that it will perform satisfactorily when used according to directions and will refund the cost of this product to the purchaser if it fails to perform as stated. The company assumes no other express or implied obligation in connection with said product.

Made in U.S.A.

Printed in U.S.A.