



NEW

for use by:

**DAIRIES • DAIRY FARMS
BREWERIES • CANNING PLANTS
MEAT and POULTRY PROCESSORS**

• Meets the requirements of Appendix F of the Grade A Pasteurized Milk Ordinance 1965 recommendations and 1953 recommendations of the U.S. Public Health Service when tested by the Chambers method.

Active Ingredients	
Sodium Phosphate expressed as $\text{Na}_2\text{PO}_4 \cdot 12\text{H}_2\text{O}$	91.76%
Sodium Hypochlorite	3.25%
Inert Ingredients	4.99%

USDA Registration No. 1214 - 32

DIRECTIONS FOR USE

For General Cleaning of Lines, Tanks and other Equipment by Hand Brushing or Circulation Method:

1. Rinse all lines and equipment with clear water.
2. Make a cleaning solution using ¾ - 1 oz. ECHO-CLOR per gallon of water and brush clean all equipment and circulate through all lines.
3. Rinse thoroughly with clean water and drain.
4. Allow to dry.

For Sanitizing Lines, Tanks and other Food and Beverage Processing and Handling Equipment:

1. Rinse all lines, tanks and equipment with clean water immediately after use.

2. Clean with recommended Echo Product.
3. Rinse thoroughly with clean water and drain.
4. Sanitize Lines, Tanks and equipment immediately before re-use with a solution of 1½ oz. ECHO-CLOR in 3 gallons of water (100 ppm available chlorine).
5. For Pre-Cleaned Utensils — immerse utensils in a solution of 1½ oz. ECHO-CLOR in 3 gallons of water (100 ppm available chlorine).

Allow sanitizing solution to remain in contact with surfaces for at least 2 minutes and drain.

For Spray Sanitizing—Use a solution of 1 oz. ECHO-CLOR in 1 gallon of water

ECHO-CLOR
CHLORINATED CLEANER
SANITIZER • DEODORIZER

10/26/67

1214-32

1214-32

(250 ppm available chlorine) making certain that all surfaces are contacted. Drain and allow to dry.

For Deodorizing—Wash walls, floors and other surfaces with a solution of 1 oz. ECHO-CLOR in 1 gallon water, rinse and let dry.

—CAUTION—

KEEP OUT OF REACH OF CHILDREN

Avoid contamination of feed and foodstuffs. This is an alkaline material. Do not take internally. If swallowed, give 1 or 2 glasses of water or milk. Call Doctor. If material gets in eyes, flush freely with water. Consult Doctor.

• DO NOT USE ON ALUMINUM •

NET CONTENTS



manufactured exclusively by

ECHO PRODUCTS

• P. O. BOX 1082 • ATLANTA, GA. 30301 •

● Meets the requirements of Appendix F of the Grade A Pasteurized Milk Ordinance 1965 recommendations and 1953 recommendations of the U.S. Public Health Service when tested by the Chambers method.

Active Ingredients	
Sodium Phosphate expressed as	
Na ₂ PO ₄ ·12H ₂ O	91.76%
Sodium Hypochlorite	3.25%
Inert Ingredients	4.99%

USDA Registration No. 1214-32

DIRECTIONS FOR USE

For General Cleaning of Lines, Tanks and other Equipment by Hand Brushing or Circulation Method:

1. Rinse all lines and equipment with clear water.
2. Make a cleaning solution using ¾ - 1 oz. ECHO-CLOR per gallon of water and brush clean all equipment and circulate through all lines.
3. Rinse thoroughly with clean water.

ECHO-

CHLORINATED SANITIZER ● I

2. Clean with recommended Echo Product.
3. Rinse thoroughly with clean water and drain.
4. Sanitize Lines, Tanks and equipment immediately before re-use with a solution of 1½ oz. ECHO-CLOR in 3 gallons of water (10 ppm available chlorine).
5. For Pre-Cleaned Utensils — in

10