

BIO-LENE

CRESYLIC DISINFECTANT

SAPONIFIED CRESOL SOLUTION

ACTIVE INGREDIENTS:

Cresylic Acid	50.0%
Potassium soap of tall oil.....	18.5%
Sulfonated castor oil	13.5%
Total active	82.0%
INERT INGREDIENTS:	18.0%
Phenol Coefficient (A.O.A.C. Method).....	4

BIO-LENE conforms to Commercial Standard CS71-41, Group 1, entitled "Phenolic Disinfectant (Soluble Type)". It also meets the specifications of the United States Department of Agriculture, Agricultural Research Service, Animal Health Division, for permitted cresylic disinfectants for use in official disinfection as published in the Code of Federal Regulations, Title 9, Sub-Chapter C.

DIRECTIONS: For use as a general disinfectant use 2 to 4 ounces BIO-LENE to one gallon of water. This is equivalent to from 4 to 8 tablespoonsful per gallon of water, or 1 to 2 tablespoonsful per quart of water. On a solution basis it is equivalent to 1 part BIO-LENE in 30 to 60 parts water. Stir well—particularly when using very cold water—to insure complete dispersion. In applying BIO-LENE solutions wet thoroughly all surfaces treated.

To meet U.S.D.A. requirements for official disinfection, use not less than 4 ounces of BIO-LENE to one gallon of water. Mix well to insure complete solution.

WARNING — KEEP OUT OF REACH OF CHILDREN



WARNING: May be fatal if swallowed or absorbed through skin! May produce severe burns! Do not get in eyes or on skin or clothing. Avoid breathing spray mist. Wash thoroughly after handling. Keep away from feed or food products. Never use BIO-LENE full strength—always dilute it with water as directed and see that solution is complete.

ANTIDOTE: Internal—give milk or white of egg beaten with water. Give a tablespoonful of salt in a glass of warm water and repeat until vomit is clear. Follow with milk or white of eggs beaten with water. Have patient lie down and keep warm. CALL A PHYSICIAN.

EXTERNAL: Wash immediately with soap and water, working up good rich suds, then rinse well. If in eye flush with copious quantities of water and consult physician.



U.S. PATENT NO. 2,811,117