

## DIRECTIONS

**COLD DISINFECTION** — For disinfection of previously cleaned surgical instruments, barber tools and dental equipment, simply submerge instruments into solution containing 1½ ounce Ster-O-Kem 26 Disinfectant per gallon of water for 10 minutes.

**RESTAURANT AND BAR RINSE** — Dishes, glassware, silverware, cooking utensils, wash with soap or synthetic detergent; rinse thoroughly and immerse in a sanitizing solution containing 1 ounce Ster-O-Kem 26 Disinfectant to 4 gallons of water. No Terminal Potable Water Rinse Required at this level.

## DANGER: KEEP OUT OF REACH OF CHILDREN

Corrosive. Causes severe eye and skin damage. Do not get in eyes, on skin or on clothing. Wear goggles or face shield, and rubber gloves when handling. Harmful or fatal if swallowed. Avoid contamination of food.

**FIRST AID** — In case of contact, immediately flush eyes or skin with plenty of water for at least 15 minutes. For eyes, call a physician. Remove and wash all contaminated clothing before reuse. If swallowed, drink milk, egg whites, gelatin solution, or if these are not available, drink large quantities of water. Call a physician.

Rinse empty container thoroughly with water and discard.



ACCEPTED



## DISINFECTANT - BACTERICIDE SANITIZER

### Active Ingredients:

Alkyl (60% C14, 30% C16, 5% C12, 5% C18) dimethyl benzyl ammonium chlorides 5.0%  
Alkyl (68% C12, 32% C14) dimethyl ethylbenzyl ammonium chlorides 5.0%

### Inert Ingredients:

90.0%

Ster-O-Kem 26 is a concentrate and should be diluted before using.

E.P.A. Registration No 6186-45

**CONTENTS: 1 GALLON - 3.784 LITERS**

## DANGER: KEEP OUT OF REACH OF CHILDREN

See other precautions on left panel.

MANUFACTURED AND  
GUARANTEED BY **DAMON CHEMICAL CO., INC., Alliance, Ohio**  
44601

HO  
and  
Ro  
Offi  
San  
of w  
to 5  
ella  
prec

HOS  
Nur  
Pails  
fecta  
O-K  
PRD

FOO  
vious  
dilut  
water  
No I

DAI  
sink  
thor  
Ster  
At tl  
omm

QUALITY

STER-O-KEM  
NO. 26  
DISINFECTANT

PRODUCTS

DISINFECTANT - BACTERICIDE  
SANITIZER

Active Ingredients:

AIKYL 60% C14, 30% C16, 5% C12, 5% C18 dimethyl benzyl ammonium chlorides 5.0%  
AIKYL 68% C12, 32% C14 dimethyl ethylbenzyl ammonium chlorides 5.0%

90.0%

Inert Ingredients:

Ster-O-Kem 26 is a concentrate and should be diluted before using.

E.P.A. Registration No. 6186-45

CONTENTS: 1 GALLON - 3.784 LITERS

DANGER: KEEP OUT OF REACH OF CHILDREN

See other precautions on left panel.

MANUFACTURED AND  
GUARANTEED BY

DAMON CHEMICAL CO., INC., Alliance, Ohio  
44601

DIRECTIONS

**HOUSEHOLD** — For sanitizing and disinfecting floors, walls and inanimate hard surfaces. For Schools, Homes, Locker Rooms, Garbage Pails, Sink Tops, Corridors, Classrooms, Offices and shower stalls. Apply solution with mop or cloth. Sanitize with 1 ounce Ster-O-Kem 26 Disinfectant to 4 gallons of water. Disinfect with 3 ounces Ster-O-Kem 26 Disinfectant to 5 gallons of water. Kills Staphylococcus aureus and Salmonella choleraesuis. For heavily soiled or contaminated areas, a precleaning step is recommended.

**HOSPITALS** — For floors, walls and other hard surfaces. In Nursing Homes, Institutions as well as Sink Tops, Garbage Pails, Telephones and Restrooms, use Ster-O-Kem 26 Disinfectant at 3½ ounces per 5 gallons of water. At this level Ster-O-Kem will be effective against Pseudomonas aeruginosa PRD-10.

**FOOD PROCESSING EQUIPMENT** — For sanitation of previously cleaned food processing equipment and food utensils dilute 1 ounce Ster-O-Kem 26 Disinfectant per 4 gallons of water to provide 200 ppm of active quaternary. At this level, No Potable Water Rinse is required.

**DAIRIES** — To sanitize dairy equipment, such as tanks, lines, sinks, and milk cans, first clean and rinse the equipment thoroughly. Then apply sanitizing solution containing 1 ounce Ster-O-Kem 26 Disinfectant to 4 gallons of water (200 ppm). At this level, No Potable Water Rinse is required. Follow recommendations of local Health Board.

QUALITY  
DAMON  
PRODUCTS

