

COMPLETE LABEL WILL BE ENLARGED

O-D-406
6840-530-7109
TYPE L

PINEAROMA
(FDA-REG. 7960-6)
DISINFECTANT, GERMICIDAL &
FUNGICIDAL CONCENTRATE

CONTINENTAL CHEMICAL CORP.
TERRE HAUTE, INDIANA

Mfg. 5-66
Batch No. 010566-2
DSA-4-074017-PC409
ONE GALLON

PINEAROMA
Disinfectant, Germicidal and
Fungicidal Concentrate

ACTIVE INGREDIENTS:.....21.0%

- Steam Distilled Pine Oil
- Vegetable Oil Soap
- 2-Benzyl-4-chlorophenol
- Isopropyl alcohol

INERT INGREDIENTS:.....79.0%

- Water
- Sodium Nitrite

100.0%

PHENOL COEFFICIENT
5 A.O.A.C. Method

CAUTION: Avoid contact with food. Keep away from children. Dilute as directed Do not mix with other cleaners. Avoid getting the concentrate in the eyes. In case of contact, wash thoroughly with water. If irritation persists, get medical attention.

DIRECTIONS FOR USE
DO NOT ADD TO SOAP
OR DETERGENT SOLUTION

1. FOR ROUTINE USE. Swab, wipe or rinse surfaces (such as floors, walls, urinals, washstands, garbage pails) thoroughly, using 1% solution (see DILUTION TABLE). Disinfect smaller objects by immersion in 1% solution for at least 10 minutes. Permit all surfaces to dry before use.
2. FOR SPECIAL USE.
 - A. If known heavy contamination exists, use 2% solution on surfaces. Swab, wipe or rinse surfaces with disinfectant solution at least twice, allowing solution to act for at least 10 minutes between applications. Disinfect smaller objects by immersion for at least 10 minutes. Permit all surfaces to dry before use.
 - B. Cold disinfection of surgical instruments.—Sterilization by autoclave shall be performed wherever possible. Cold sterilization of surgical instruments with this material may be used as an emergency alternate. In the absence of heat, immerse in 2% solution for at least 10 minutes after removing excess soil by cleaning.
3. Precaution—To disinfect RUBBER and Plastic objects, swab surfaces if possible. Immerse only if required. LIMIT EXPOSURE TO 10 MINUTES. PROLONGED IMMERSION IN

ACCEPTED
Feb. 23, 1967
UNDER THE FEDERAL PESTICIDE ACT
AND THE ECONOMIC INSECTICIDE ACT
REGISTERED UNDER NO. 7960-6

Comment

18 Point

100.0%

ACCEPTED WITH COMMENTS

ACCEPTED

Feb. 23, 1967

UNDER THE FEDERAL PESTICIDE
REGISTRATION ACT
OR ECONOMIC INSECTICIDE ACT
AND UNDER NO. 7960-6

Comment

DISINFECTANT, GERMICIDAL &
FUNGICIDAL CONCENTRATE

PINEAROMA
Disinfectant, Germicidal and
Fungicidal Concentrate

ACTIVE INGREDIENTS:21.0%
Sesam Distilled Pine Oil
Vegetable Oil Soap
2-Benzyl-4-chlorophenol
Isopropyl alcohol

INERT INGREDIENTS:79.0%
Water
Sodium Nitrite

100.0%

PHENOL COEFFICIENT
5 A.O.A.C. Method

CAUTION: Avoid contact with food. Keep
away from children. Dilute as directed Do not
mix with other cleaners. Avoid getting the
concentrate in the eyes. In case of contact, wash
thoroughly with water. If irritation persists,
get medical attention.

CONTINENTAL CHEMICAL CORP.
Terre Haute, Indiana

DSA-4-074017-PC409
ONE GALLON

DIRECTIONS FOR USE
DO NOT ADD TO SOAP
OR DETERGENT SOLUTION

1. FOR ROUTINE USE. Swab, wipe or
rinse surfaces (such as floors, walls, urinals,
washstands, garbage pails) thoroughly, us-
ing 1% solution (see DILUTION TABLE).
Disinfect smaller objects by immersion in
1% solution for at least 10 minutes. Permit
all surfaces to dry before use.

2. FOR SPECIAL USE.

A. If known heavy contamination exists,
use 2% solution on surfaces. Swab, wipe
or rinse surfaces with disinfectant solution
at least twice, allowing solution to act for
at least 10 minutes between applications.
Disinfect smaller objects by immersion for
at least 10 minutes. Permit all surfaces to
dry before use.

B. Cold disinfection of surgical instru-
ments.—Sterilization by autoclave shall be
performed wherever possible. Cold sterili-
zation of surgical instruments with this
material may be used as an emergency
alternate. In the absence of heat, immerse
in 2% solution for at least 10 minutes
after removing excess soil by cleaning.

3. Precaution—To disinfect RUBBER and Plas-
tic objects, swab surfaces if possible. Im-
merse only if required. LIMIT EXPOSURE TO
10 MINUTES. PROLONGED IMMERSION IN
DISINFECTANT MAY AFFECT PLASTICS AND
RUBBER SERIOUSLY.

18 point

10 point

DILUTION TABLE

DILUTION	OUNCE CONCEN- TRATE PER GALLON WATER	ML. CONCEN- TRATE PER LITER WATER	TEASPOONS CONCENTRATE PER GALLON WATER
1% SOLUTION (Routine Use)	1 1/4	10	10
2% SOLUTION (Special Use)	2 1/2	20	20

ACCEPTED WITH COMMENTS