

WASH THOROUGHLY WITH WATER. IF IRRITATION PERSISTS, GET MEDICAL ATTENTION.

**DIRECTIONS FOR USE
DO NOT ADD TO SOAP
OR DETERGENT SOLUTION**

1. FOR ROUTINE USE. Swab, wipe or rinse surfaces (such as floors, walls, urinals, washstands, garbage pails) thoroughly, using 1% solution (see DILUTION TABLE). Disinfect smaller objects by immersion in 1% solution for at least 10 minutes. Permit all surfaces to dry before use.

2. FOR SPECIAL USE.

A. If known heavy contamination exists, use 2% solution on surfaces. Swab, wipe or rinse surfaces with disinfectant solution at least twice, allowing solution to act for at least 10 minutes between applications. Disinfect smaller objects by immersion for at least 10 minutes. Permit all surfaces to dry before use.

B. Cold disinfection of surgical instruments.—Sterilization by autoclave shall be performed wherever possible. Cold sterilization of surgical instruments with this material may be used as an emergency alternate. In the absence of heat, immerse in 2% solution for at least 10 minutes after removing excess soil by cleaning.

3. Precaution—To disinfect RUBBER and Plastic objects, swab surfaces if possible. Immerse only if required. LIMIT EXPOSURE TO 10 MINUTES. PROLONGED IMMERSION IN DISINFECTANT MAY AFFECT PLASTICS AND RUBBER SERIOUSLY.

DILUTION TABLE

DILUTION	OUNCE CONCENTRATE PER GALLON WATER	ML. CONCENTRATE PER LITER WATER	TEASPOONS CONCENTRATE PER GALLON WATER
1% SOLUTION (Routine Use)	1 1/4	18	18
2% SOLUTION (Special Use)	2 1/2	28	28

