



### Cold Disinfection

For disinfection of previously cleaned surgical instruments, barber tools and dental equipment, simply submerge instruments into solution containing 1½ ounce CHEMCO DSD-X per gallon of water for 10 minutes.

### Directions: FOR ROOM FOGGING

To minimize the danger of cross-contamination from environmental surfaces apply solution CHEMCO DSD-X as a fog as described below, before applying standard routine terminal cleaning and disinfecting practices. 1. Remove all human, animal, and plant life from room. 2. Open closet doors and drawers. 3. Set up 34" revolving platform in center of room. 4. Mount Jet FOGMASTER TRI-JET MODEL 6208 or other fogging device delivering equivalent spray at 3 RPM. 5. Fill sprayer reservoir with 1.5 oz. of CHEMCO DSD-X to 1 gallon of water to produce 1150 ppm active ingredients. 6. Set sprayer mechanism to deliver 1 gallon of solution. 7. Fog for 15 minutes for an average 2100 cu. ft. room. For different room sizes, vary spray time proportionately to ensure complete wetting of exposed surfaces. 8. Wait 2 hours before entering room after treatment. 9. Rinse fogging equipment thoroughly with clear water following use.

### DANGER

Keep Out of Reach of Children. Corrosive. Causes severe eye and skin damage. Do not get in eyes, on skin or on clothing. Protect eyes and skin when handling concentrate. Harmful if swallowed. Avoid contamination of food.

### FIRST AID

In case of contact, immediately flush eyes or skin with plenty of water for at least 15 minutes. For eyes, call a physician. Remove and wash all contaminated clothing before reuse. If swallowed, drink milk, egg whites, gelatin solution, or if these are not available, drink large quantities of water. Call a physician.

### NOTE TO PHYSICIAN:

Probable mucosal damage may contraindicate the use of gastric lavage. Measures against circulatory shock, respiratory depression and convulsion may be needed. Rinse empty container thoroughly with water and discard.

<b>CHEMCO DSD-X</b> DISINFECTANT      SANITIZER DEODORIZER	
<b>Active Ingredients:</b>	
n-Alkyl (60% C <sub>14</sub> , 30% C <sub>16</sub> , 5% C <sub>12</sub> , 5% C <sub>18</sub> ) dimethyl benzyl ammonium chlorides .....	5%
n-Alkyl (68% C <sub>12</sub> , 32% C <sub>14</sub> ) dimethyl ethylbenzyl ammonium chlorides .....	5%
<b>Inert Ingredients:</b> .....	90%
	100%
CHEMCO DSD-X is a concentrate and should be diluted before using.	
<b>NET CONTENTS: 1 GALLON</b>	
EPA Reg. No. 8957-9	EPA Est. No. 8957-OK-1

### DANGER

KEEP OUT OF REACH OF CHILDREN.

(See other precautionary and first aid statements on left side panel.)

**CHEMCO PRODUCTS, INC.**  
P. O. BOX 9248  
TULSA, OKLAHOMA 74107

### WARRANTY

Our recommendations for use of this product are based upon tests believed to be reliable. The use of this product being beyond the control of the manufacturer, no guarantee, expressed or implied, is made. The buyer must assume all responsibility, including injury or damage, resulting from its mis-use as such, or in combination with other products, to be construed as recommending the infringement of any patent, and no liability for infringement arising out of any such use is assumed.