

USE DIRECTIONS:

For instruments use STERILE DISINFECTANT 4 ounces per gallon. If contaminated with blood or heavy organic matter, preclean and immerse in the 4 ounce per gallon dilution for one hour.

For inanimate environmental hard surfaces in the preparation room, such as prep tables, floors, walls, doors, counter tops and cabinets: a 2 ounce per gallon dilution of STERILE DISINFECTANT applied with cloth or mop with a total contact time of fifteen minutes before rinsing and drying is recommended.

STERILE DISINFECTANT demonstrates Bactericidal activity at 2 ounces per gallon against Staphylococcus aureus ATCC #6538, Salmonella choleraesuis ATCC #10708, and Pseudomonas aeruginosa ATCC #15422.

Confirmed by the A.O.A.C. Use Dilution method.

STERILE DISINFECTANT demonstrates Fungicidal activity at 2 ounces per gallon against Trichophyton interdigitale Strain #640.

Confirmed by the A.O.A.C. Fungicidal Test.

When container is empty rinse thoroughly with water and cut plastic bottle with scissors and discard.

STERILE DISINFECTANT is a cleaner, disinfectant and sanitizer designed for Mortuary preparation rooms where good housekeeping is of prime importance in controlling the hazard of cross infection from environmental surfaces. STERILE DISINFECTANT, can provide the assurance you need in this area when used as directed.

*STERILE DISINFECTANT, when used on environmental inanimate hard surfaces at 2 ounces per gallon is effective against *Influenza A₂, *Herpes Simplex, *Adenovirus type 2, and *Vaccinia.

WARNING

KEEP OUT OF REACH OF CHILDREN. CAUSES EYE AND SKIN IRRITATION. DO NOT GET ON EYES, ON SKIN OR ON CLOTHING. HARMFUL IF SWALLOWED.

FIRST AID

IN CASE OF CONTACT FLUSH EYES OR SKIN WITH PLENTY OF WATER FOR 15 MINUTES. FOR EYES CALL A PHYSICIAN. REMOVE AND WASH ALL CONTAMINATED CLOTHING BEFORE REUSE. IF SWALLOWED DRINK MILK, EGG WHITES, OR IF THESE ARE NOT AVAILABLE, LARGE QUANTITIES OF WATER. CALL A PHYSICIAN.

UNDER THE CONTROL OF
FUNCTIONAL UNIT 919551019

ACCEPTED
8-2-73

STERILE DISINFECTANT

CLEANER DEODORIZER
VIRUCIDE* FUNGICIDE

Designed for Mortuary Use Only

ACTIVE INGREDIENTS

n-Alkyl (60% C ₁₄ , 30% C ₁₆ , 5% C ₁₂ , 5% C ₁₈) dimethyl benzyl ammonium chlorides	2.25
n-Alkyl (68% C ₁₂ , 32% C ₁₄) dimethyl ethylbenzyl ammonium chlorides	2.25%
Sodium carbonate	3.00%
Tetrasodium ethylenediamine tetraacetate	1.00%
INERT INGREDIENTS	91.50%

NET VOLUME: ONE PINT
EPA Reg. No. 9195-2

WARNING

KEEP OUT OF REACH OF CHILDREN. SEE RIGHT SIDE PANEL FOR ADDITIONAL PRECAUTIONARY STATEMENTS.

Royal Bond, Inc.

1919 N. Broadway
St. Louis, Missouri 63102

ACCEPTED

DEC 17 1973

REGISTERED TRADE MARK
E. I. du Pont de Nemours & Co.
TO ATTACHED DOCUMENTS



MASURY-COLUMBIA

MYCO Q-99-NR

CONCENTRATED DETERGENT, SANITIZER
FUNGICIDE, DISINFECTANT, DEODORIZER

ACTIVE INGREDIENTS:	
n-Alkyl (60% C14, 30% C16, 5% C12, 5% C18) dimethyl benzyl ammonium chlorides	4.5%
n-Alkyl (68% C12, 32% C14) dimethyl ethylbenzyl ammonium chlorides	4.5%
Tetrasodium ethylenediamine tetraacetate	2.0%
Sodium Carbonate	4.0%
INERT INGREDIENTS:	85.0%
	100.0%

USE DIRECTIONS

APPROXIMATELY

NET CONTENTS

DANGER - Keep Out of Reach of Children

DANGER

FOR FURTHER

Products for Environmental Cleanliness

MASURY-COLUMBIA CO.

ELMHURST ILLINOIS 60126 - GLENDALE CALIFORNIA 91204