

8/21/72
 10885-7
 USE DIRECTIONS:

ADCO
DS - 27

Cold Disinfection

For disinfection of previously cleaned surgical instruments, barber tools and dental equipment, simply submerge instruments into solution containing 1½ ounce DS-27 per gallon of water. A submersion time of at least ten minutes.

Restaurant and Bar Rinse

Dishes, glassware, silverware, cooking utensils, wash with soap or synthetic detergent; rinse thoroughly and immerse in a sanitizing solution containing 1 ounce DS-27 to 4 gallons of water. **No Terminal Potable Water Rinse Required.**

DANGER

Keep Out of Reach of Children. Causes severe eye and skin damage. Do not get in eyes, on skin or on clothing. Wear goggles or face shield, and rubber gloves when handling. Harmful or fatal if swallowed. Avoid contamination of food.

FIRST AID

In case of contact, immediately flush eyes or skin with plenty of water for at least 15 minutes. For eyes, call a physician. Remove and wash all contaminated clothing before reuse. If swallowed, drink milk, egg whites, gelatin solution, or if these are not available, drink large quantities of water. Call a physician.

Rinse empty container thoroughly with water and discard.

DISINFECTANT DEODORIZER **SANITIZER**

ACTIVE INGREDIENTS:

n-Alkyl (60% C₁₄, 30% C₁₆, 5% C₁₂, 5% C₁₈) dimethyl benzyl ammonium chlorides..... 5%
 n-Alkyl (68% C₁₂, 32% C₁₄) dimethyl ethylbenzyl ammonium chlorides 5%

INERT INGREDIENTS:..... 90%
100%

DS-27 is a concentrate and should be diluted before using.

Net Contents _____ U. S. Gallons

DANGER

Keep Out of Reach of Children. See other precautionary statements on left side panel.

CORROSIVE

ADCO CHEMICALS, INC.
1307 KIRKLAND DRIVE
RALEIGH, N. C. 27603

EPA Reg. No. 10885-7

Household

For sanitizing and disinfecting floors, walls and inanimate hard surfaces. For Schools, Homes, Locker Rooms, Garbage Pails, Sink Tops, Corridors, Classrooms, Offices and shower Stalls. Apply solution with mop or cloth. Sanitize with 1 ounce DS-27 to 4 gallons of water. Disinfect with 3 ounces DS-27 to 5 gallons of water. Kills Staphylococcus aureus and Salmonella choleraesuis.

Hospitals

For floors, walls and other hard surfaces. In Nursing Homes, Institutions, as well as Sink Tops, Garbage Pails, Telephones and Restrooms, use DS-27 at 3½ ounces per 5 gallons of water. At this level DS-27 will be effective against Pseudomonas aeruginosa PRD-10.

Food Processing Equipment

For sanitization of food processing equipment and food utensils dilute 1 ounce DS-27 per 4 gallons of water to provide 200 ppm of active quaternary. At this level, No Potable Water Rinse is required.

Dairies

To sanitize dairy equipment, first clean and rinse the equipment thoroughly. Then apply sanitizing solution containing 1 ounce DS-27 to 4 gallons of water (200 ppm). At this level, No Potable Water Rinse is required. Follow recommendations of local Health Board.