70627-6 5-1-2002

(Note to Agency: Text appearing in parenthesis or brackets is done to show optional text.)

# Johnson Wax Professional

## Phenolic Disinfectant HG

### ONE-STEP GERMICIDAL DETERGENT • PHENOLIC DISINFECTANT CLEANER

Bactericidal • Tuberculocidal • Fungicidal • \*Virucidal • Mildewstatic • Deodorizer (Odor Counteractant)

Cleans, Disinfects & Deodorizes • (Pleasant Fragrance) • (Lemon Scent)
Meets OSHA Bloodborne Pathogen Standard for HBV & HIV

For (Hosptial,) (Foodservice,) (Commercial,) (Industrial) (&) (Institutional) Use (Only) Kills HBV, HIV, Tb

ACTIVE INGREDIENTS:	
o-Benzyl-p-chlorophenol	10.5%
o-Phenylphenol	10.5%
INERT (OTHER) INGREDIENTS:	
TOTAL:	

# KEEP OUT OF REACH OF CHILDREN DANGER

See additional precautionary statements on (back; (side) (left) (right) (of) (panel) (label) (below).

See reference sheet (enclosed in each case) for (complete list of pathogenic organisms) (additional features, claims, creations for use) (claimed for this product).

Net Contents:	(Product of USA)
	(11000000000000000000000000000000000000

MAY - 1 2002

2/10

(MARKETING CLAIMS): (Note to EPA - This text will only appear on the appropriate container.)

ACCUMIX™ CONTAINERS (32 oz. container) - ACCUMIX™. (Remove [Loosen] cap). Squeeze. (Squeeze bottle.) Measure. (Measure amount). Pour. (Pour contents). (Designed) For use with 5 gallon Buddy Jugs™ (BIG BUDDY™ [ACCUTAINER™] Containers). Phenolic Disinfectant HG can also be diluted into pre-cleaned and properly labeled 5-gallon BUDDY JUG™ (ACCUTAINERS™) (Dispensing Containers) for dispensing as needed.

SOLUTIONS CENTER™ (64 oz. containers) - For use with (JOHNSON™) (PRISM™) (DRACKETT™) (SOLUTIONS CENTER™) Brand Dispensing Equipment. Eliminates Mixing. The Accurate Solution To Cleaner Dilution. Disinfectant Cleaning With The Convenience Of (SOLUTIONS CENTER™). (SOLUTIONS CENTER™) (This) packaging offers) Reduced Exposure To Concentrate Due To Closed Transfer System. Solutions To Go!

J-FILL™ DISPENSING SYSTEMS (84.5 oz. containers) - For use with (JOHNSON™) (PRISM™) (DRACKETT™) (J-FILL™) Brand Dispensing Equipment. Eliminates Mixing. The Accurate Solution To Cleaner Dilution. Disinfectant Cleaning With The Convenience Of J-FILL™. J-FILL™ (This) packaging offers) Reduced Exposure To Concentrate Due To Closed Transfer System. Solutions To Go!

ACCUPACK™ CONTAINERS (Pre-measured packets) - Pre-Measured [Tear-Open] Packets.

#### eneral Uses)

For use on hard, non-porous surfaces such as floors, walls, metal surfaces, painted surfaces, exterior bowl surfaces, empty basins, showers, conductive flooring and lavatory fixtures. For use in hospitals, nursing homes, schools, colleges, medical and dental offices, farms, hog farms, equine farms, poultry and turkey farms, meat and poultry plants, kennels, pet shops, veterinary clinics, and animal life science laboratories. This includes barns, calf pens, laying operations, breeder operations, hatcheries, agricultural buildings and premises, live haul equipment, trucks, foot baths, and meat and poultry processing plants.

Phenolic Disinfectant HG cleans quickly by removing dirt, grime, body oils and other common soils. This product is for use in hospitals, medical clinics, nursing homes, schools and colleges, (day care centers), (medical) offices, funeral homes, veterinary clinics, pet shops, (equine farms), animal life science laboratories, hotels, motels, restrooms, food service establishments (restaurants).

It is designed for use on (Use daily on) the following hard, non-porous environmental surfaces: vinyl, painted surfaces, plastic (surfaces), glazed ceramic, glazed porcelain, chrome, stainless steel, aluminum, laminated surfaces and baked enamel surfaces associated with floors, walls, ceilings, tables, chairs, countertops, telephones, fixtures, glazed tile, 'ets, urinals, sinks, shower rooms and locker rooms areas - (food and non-food contact) surface where disinfection is required. A potable water rinse is required for food contact surfaces. Do not use on glasses, dishes, and utensils.

#### (Hospitals/Health Care Facilities)

Phenolic Disinfectant HG is a one-step (hospital-use) germicidal (disinfectant) cleaner and deodorant (odor-counteractant) (odor neutralizer) designed for general cleaning, (and) disinfecting, (deodorizing) (of) hard, non-porous environmental surfaces. Phenolic Disinfectant HG cleans quickly by removing dirt, grime, food residue, body oils, dead skin, blood and other organic matter commonly found in hospitals (in health care facilities) (on medical surfaces). It (also) eliminates odors leaving (restroom) surfaces smelling clean and fresh. Use where odors are a problem.

Phenolic Disinfectant HG cleans, disinfects and deodorizes (hard, non-porous environmental hospital (medical) surfaces) in one step (with no rinsing required). Its non-abrasive formula is designed for use on (Use daily on) the following hard, non-porous environmental surfaces): vinyl, painted surfaces, plastic (surfaces), glazed ceramic, glazed porcelain, chrome, stainless steel, laminated surfaces and baked enamel surfaces typically associated with floors, walls, ceilings, tables, chairs, countertops, telephones, fixtures, glazed tile, toilets, urinals, sinks found in (health care facilities [hospitals],) patient rooms, resident rooms, operating rooms, ICU areas, shower rooms, and locker rooms. (It can also be used to pre-clean and disinfect hospital items: wheelchairs, [hospital] [patient] bed rails and linings, wash basins, bedpans, [and] [hospital] medical equipment [& devices,]) - any washable (food and non-food contact) surface (where disinfection is required). A potable water rinse is required when disinfecting food contact surfaces. Do not use on glasses, dishes, and utensils.

#### (Food Service:)

Phenolic Disinfectant HG removes dirt, grime and food soils in food preparation and processing areas. Its non-abrasive formula will not harm (scratch) surfaces. It cleans, disinfects and eliminates odors leaving surfaces smelling clean and fresh. Use where odors are a problem.

Its non-abrasive formula is designed for use on (Use daily on) the following hard, non-porous environmental surfaces: vinyl, painted surfaces, plastic (surfaces), glazed ceramic, glazed porcelain, chrome, aluminum, stainless steel, brass, copper, laminated surfaces and baked enamel surfaces (associated with floors, walls, ceilings, tables, chairs, countertops, fixtures, glazed tile, toilets, (toilet bowls), urinals, sinks found in food establishments, (restaurants), (commercial kitchens) & restrooms. A potable water rinse is required for food contact surfaces.

#### (Animal Housing Facilities:)

Phenotic Disinfectant HG cleans by removing dirt, grime, blood, urine, fecal matter and other common soils found in animal housing facilities, livestock, swine or poultry facilities, grooming facilities, farms, kennels, pet stores, veterinary clinics, laboratories or other small animal facilities. It (also) eliminates odors leaving surfaces smelling clean and fresh.

Phenolic Disinfectant HG cleans, disinfects and deodorizes (hard, non-porous environmental surfaces) in one step. Its non-abrasive formula is designed for use on (Use daily on) (Use daily to clean and disinfect) hard, non-porous surfaces: plated or stainless steel, aluminum, chrome, glazed porcelain, glazed tile, laminated surfaces (typically associated with ors, walls, countertops, cages, kennels, animal equipment) found in (barns, pens and stalls) animal housing facilities.

#### (Public Restrooms:)

Phenolic Disinfectant HG is a one-step disinfectant cleaner and deodorant (odor-counteractant) (odor-neutralizer) designed for general cleaning, (and) (disinfecting) (deodorizing) on (of) a variety of hard, non-porous environmental surfaces.

Phenolic Disinfectant HG cleans, disinfects and deodorizes surfaces by killing odor-causing germs. Its non-abrasive formula is designed for use on (restroom surfaces): glazed ceramic (restroom) tile, glazed porcelain, chrome, stainless steel and plastic surfaces typically associated with floors, walls, fixtures, toilets, urinals, sinks, shower rooms and locker rooms.

#### (Non-Acid Bowl [& Bathroom] Disinfectant Cleaner:)

Phenotic Disinfectard HG is a (concentrated) non-acid (bowl and) bathroom cleaner which cleans, disinfects and deodorizes in one easy step. It cleans, disinfects and deodorizes toilet bowls, urinals, rims, sinks, sink basins, faucets, tubs, glazed tiles, glazed ceramic, glazed porcelain, chrome, stainless steel, and all hard non-porous, washable surfaces found in the bathroom (restroom) (in the presence of organic soil).

enolic Disinfectant HG eliminates odors leaving bathrooms (restrooms) smelling clean and fresh. Use where odors are a problem. It cleans, disinfects and deodorizes surfaces by killing odor-causing microorganisms. Its non-abrasive formula is designed for use (Use it daily) on ([hard, non-porous environmental] restroom surfaces): glazed ceramic (restroom) tile, glazed porcelain, chrome, stainless steel and plastic surfaces typically associated with floors, walls, fixtures, toilets, urinals, sinks, shower rooms and locker rooms.

#### (For Refilling Concentrate From Large Containers Into Smaller Containers:)

Phenolic Disinfectant HG may be used to fill and refill clean, properly labeled containers for dilution elsewhere within your facility. Make sure the small container has been cleaned, dried and properly labeled. Also make sure other items (such as funnels or hand pumps) are properly cleaned and dried. To refill, simply pour (or pump) product from the larger container directly into the smaller one being careful not to spill any product. Keep both containers sealed when not in use. When ready for use, mix product according to the Directions for Use.



#### (CLAIMS:)

Phenolic Disinfectant HG is (a multi-purpose germicidal detergent) proven effective by the AOAC Use-Dilution method in 400 ppm hard water (calculated as CaCO<sub>3</sub>) in the presence of 5% organic bioload (Fetal Bovine Serum). Phenolic Disinfectant HG's formula disinfects, cleans, and deodorizes in one labor-saving step. Phenolic Disinfectant HG is effective against the following pathogenic organisms:

### Bacteria (Bactericidal Activity) - kills on hard non-porous inanimate surfaces:

Pseudomonas aeruginosa, (ATCC 15442) Salmonella choleraesuis. (ATCC 10708) Staphylococcus aureus, (ATCC 6538) Brevundimonas diminuta, (ATCC 4335) formerly known as Pseudomonas diminuta Bordetella bronchiseptica, (ATCC 10580) Corynebacterium ammoniagenes, (ATCC 6872) formerly known as Brevibacterium ammoniagenes Campylobacter fetus, (ATCC 27374) Citrobacter freundii, (ATCC 8090) Chlamydia psittaci, (VR-125) Enterobacter aerogenes, (ATCC 13048) robacter cloacae, (ATCC 23355) ∌rococcus faeca≨s, (ATCC 19433) formerly known as Streptococcus faecalis Enterococcus hirae, (ATCC 10541) Escherichia coli, (ATCC 11229)

Escherichia coli 0157:H7, (ATCC 43888) Haemophilus influenza, (ATCC 10211) Klebsiella oxytoca, (ATCC 43863) Klebsiella pneumoniae, (ATCC 13883) Leclarcia adecarboxylata, (ATCC 29916) formerly known as Enterobacter agglomerans Listeria monocytogenes, (ATCC 15313) Micrococcus luteus, (ATCC 4698) Morganella morganii, (ATCC 25830) Neisseria gonorrhoeae, (ATCC 40369) Pasteurella multocida, (ATCC 43137) Proteus mirabilis, (ATCC 25933) Proteus vulgaris, (ATCC 13315) Pseudomonas cepacia, (ATCC 25609) Pseudomonas fluorescens, (ATCC 13525) Salmonella choleraesuis, (ATCC 10719) formerly known as Salmonella schottmuelleri

Salmonella choleraesuis, (ATCC 13076) formerly known as Salmonella enteritidis Salmonella cholerasuis pullorum, (ATCC 19945) Salmonella typhi, (ATCC 6539) Salmonella typhimurium, (ATCC 14028) Serratia marcescens, (ATCC 8100) Shigella dysenteriae, (ATCC 13313) Shigelle flexneri, (ATCC 12022) Staphylococcus aureus (Toxic Shock), (ATCC 33586) Staphylococcus epidermidis, (ATCC 14990) Staphylococcus haemolyticus, (ATCC 29970) Staphylococcus saprophyticus, (ATCC 15305) Streptococcus agaiactiae, (ATCC 13813) Streptococcus pyogenes, (ATCC 19615) Streptococcus pyogenes, (Clinical isolate) (Strep A - Flesh Eating Strain) Vibro cholera, (ATCC 11623) Yersinia enterocolitica, (ATCC 23715)

## Antibiotic-Resistant (Strains of) Bacteria (Antibiotic-Resistant Bactericidal Activity) - kills on hard non-porous inanimate surfaces:

Enterococcus faecalis (VRE), (ATCC 51299) Resistant to Vancomycin

Enterococcus faecium (VRE), (ATCC 51559)
Resistant to Vancomycin, Ampicillin,

Ciprofloxacin, Gentarricin, Rifampin, Teicoplanin

Micrococcus sedentarius, (ATCC 27573) Resistant to Methicillin, Penicillin

'9robacter cloacae, (Clinical isolate HL 129) 9rcoccus species, (Clinical isolate HL 128) Proteus mirabilis, (Clinical isolate HL 126) Staphylococcus aureus, (ATCC 14154)
Resistant to Erythromycin, Penicillin, Streptornyocin,
Tetracycline

Staphylococcus aureus (MRSA/GRSA), (ATCC 33592), Resistant to Methicillin, Gentamicin

Staphylococcus aureus (VISA), (HIP 5836) întermediate Resistance to Vancomycin

Providencia rettgeri, (Clinical isolateHL 92)
Pseudomonas maltophila, (Clinical isolate HL 131)
Staphylococcus aureus, (Clinical isolate HL 121)

Staphylococcus epidermidis (MRSE), (ATCC 51625), Resistant to Methicillin

Streptococcus pneumoniae (PRSP), (ATCC 51915), Resistant to Penicillin

Staphylococcus aureus, (Clinical isolate HL 122) Staphylococcus aureus, (Clinical isolate HL 130)

**Tuberculocidal Activity** - This product exhibits disinfectant efficacy against *Mycobacterium bovis* (ATCC 19015) in 10 minutes at 20° C when used as directed on previously cleaned hard non-porous environmental surfaces.

HBV & HIV Activity - This product kills HBV & HIV (AIDS virus) (HTLV-III<sub>B</sub>) when used as directed on hard, non-porous inanimate surfaces with a 1 minute contact time and 10% serum.

#### Viruses (\*Virucidal Activity) - kills on hard non-porous inanimate surfaces:

Adenovirus Type 2, (VR-2) Herpes Simplex Type 1, (VR-733) Herpes Simplex Type 2, (CCL 26) Human Coronavirus, (VR-740) Human Rhinovirus Type 38, (VR-511) Influenza Type A/Michigan Poliovirus Type 1, (VR-192) Reovirus Type 3, (VR-232) Respiratory Syncytial virus, (VR-26) Rotavirus, (Strain WA) Rubella virus, (CCL 7) Vaccinia virus, (VR-117)

Veterinary viruses: Avian Influenza, (Type A/Michigan) Canine parvovirus, (VR-2006)

Feline leukemia, (VR-717) Feline picomavirus, (VR-649) Feline Rhinotracheitis virus, (VR-636)

Infectious Bovine Rhinotracheitis, (VR-93)
Newcastle Disease Virus, (VR-109)
Transmissible Gastroenteritis virus (TGE), (Univ.of Minn.)

5/10

Fungi/Yeast (Fungicidal and Yeast Activity) - kills on hard non-porous inanimate surfaces:

Candida albicans, (ATCC 10231)

Trichophyton mentagrophytes, (ATCC 9533)

Mold/Mildew (Mildewstatic Activity) - controls (inhibits) the growth of mold and mildew: Aspergillus niger (ATCC 16404) (and the odors caused by them when applied to hard, non-porous environmental surfaces).

**Malodor(s)** (Activity) (Counteractancy) – eliminates (destroys) odors and odor-causing bacteria in restroom areas, behind and under sinks and counters, and storage areas (and other places where bacterial growth can cause malodors).

#### **DIRECTIONS FOR USE:**

It is a violation of Federal Law to use this product in a manner inconsistent with its labeling.

(This product is not to be used as a terminal sterilant/high level disinfectant on any surface or instrument that (1) is introduced directly into the human body, either into or in contact with the bloodstream or normally sterile areas of the body, or (2) contacts intact mucous membranes but which does not ordinarily penetrate the blood barrier or otherwise enter normally sterile areas of the body. This product may be used to pre-clean or decontaminate critical or semi-critical medical devices prior to sterilization or high level disinfection.)

anolic Disinfectant HG can be applied by mop, sponge, cloth, paper towel, (hand pump) (coarse) trigger sprayer or by saking. Change cloth, sponges or towels frequently to avoid redeposition of soil. For disinfection, all surfaces must remain wet for 10 minutes. Rinsing is not necessary on floor surfaces unless floors are to be waxed or polished.

#### To Prepare Use Solution:

Add the product at ½ oz. per gallon of water (4 mL/L) (1:256).

(Note to EPA: The directions that appear for specific container sizes will be substitued for the sentence above only on that container size.)

Accumix™ Containers (32 oz. container) - Add the product at 1/2 oz. per gallon of water (4mL/L) (1:256).

SOLUTIONS CENTER™ (64 oz. containers) - Remove cap and insert cartridge into dispenser. Note: See dispenser instructions for proper cartridge placement. Once cartridge is in place, squeeze the handle or press the button to dispense a 1:256 solution into a bucket, bottle, scrubber or other container.

J-FILL™ DISPENSING SYSTEMS (84.5 oz. containers) - Remove cap and insert cartridge into dispenser. Note: See dispenser instructions for proper cartridge placement. Once cartridge is in place, squeeze the handle or press the button to dispense a 1:256 solution into a bucket, bottle, scrubber or other container.

ACCUPACK™ CONTAINERS (Pre-measured packets) - (Simply) open and pour contents into xx gallons of water (for a 1:256 dilution). Keep packets in box until ready to use. (Pour contents of packet into xx gallons of water for a 1:256 dilution.)

#### For use as a (General) Cleaner and/or Deodorizer:

- 1. Apply use-solution evenly over surface to be cleaned.
- 2. Wipe with clean cloth, sponge or paper towel. For heavily soiled areas or stubborn spots, let solution stay on the surface longer before wiping.

6/10

#### For use as a One-Step Cleaner/Disinfectant:

- 1. Apply use-solution evenly over surface. Be sure to wet all surfaces thoroughly.
- 2. Let use-solution remain on surface for ten (10) minutes.
- 3. Wipe with clean cloth, sponge or paper towel.
- 4. For heavily soiled areas, thoroughly clean surface prior to disinfecting.
- 5. When disinfecting food contact surfaces such as kitchen counters, tables used for food preparation, cutting boards, appliances and sinks, rinse surfaces thoroughly with potable water. This product must not be used to clean the following surfaces: utensils, glassware, and dishes.

#### For use as a Cleaner/Disinfectant in Food Processing Plants:

- 1. Before using this product in food processing areas, food products and packaging materials must be removed from the room or carefully protected.
- 2. Apply use-solution evenly over surface. Be sure to wet all surfaces thoroughly.
- 3. Let use-solution remain on surface for ten (10) minutes.
- 4. Wipe with clean cloth, sponge or paper towel.
- 5. For heavily soiled areas, thoroughly clean surface prior to disinfecting.
- 6. When disinfecting food contact surfaces used for food preparation, rinse surfaces thoroughly with potable water. This product must not be used to clean the following surfaces: utensils, glassware, and dishes.

### `r Use To Clean and Disinfect Barber and Beauty/Manicure Instruments and Tools:

- .. Pre-clean heavily soiled items.
- 2. Completely immerse pre-cleaned combs, brushes, scissors, clipper blades, razors, manicure implements and other non-porous instruments in the use-solution so that surfaces remain wet for ten (10) minutes.
- 3. Rinse surfaces thoroughly and let air dry before reuse.
- 4. Change solution daily or when visibly dirty.

NOTE: Plastics may remain immersed until ready to use. Stainless steel shears and other metal instruments must be removed after 10 minutes, rinsed, dried and kept in a clean, non-contaminated receptacle. Prolonged soaking may cause damage to metal instruments.

#### To Control Mold and Mildew:

- 1. Apply use-solution to hard, non-porous inanimate surfaces.
- 2. Allow to air dry.
- 3. Repeat application weekly or when growth reappears.

#### To Kill Fungi:

- Pre-clean heavily soiled areas.
  Apply use-solution to hard, non-porous inanimate surfaces.
- 3. Allow surface to remain wet for ten (10) minutes.
- 4. Wipe surfaces (and let air dry).

HATCHERY: Can be used for cleaning, disinfecting and deodorizing floors, walls and equipment throughout the hatchery. This includes incubators, setters, and racks. Add 1/2 ounce per gallon of water. Hot or cold water may be used. Remove loose waste, gross filth, and heavy soil deposits prior to disinfecting. Repeat with fresh solution to disinfect.

MEAT AND POULTRY PLANTS: For use as a floor and wall cleaner. Before use of this compound, food products and packaging materials must be removed from the room and carefully protected. After use of this compound, all surfaces must be thoroughly rinsed with potable water. Use 1/2 ounce per gallon of water. For use on all surfaces in inedible product processing areas, nonprocessing areas, and/or exterior areas. For use as an antimicrobial agent in all departments. Use product in accordance with its label. All surfaces must be thoroughly rinsed with potable water. Avoid contamination of food contact surfaces in the application of this product.

#### For Use For Treatment of Animal Housing Facilities:

- 1. Remove all animals and feed from areas being treated.
- 2. Remove all litter and manure from floors, walls and surfaces of barns, pens, stalls, chutes, and other facilities occupied or traversed by animals.
- 3. Empty or cover all troughs, racks and other feeding and watering appliances.
- 4. Thoroughly clean all surfaces with soap and rinse with water.
- 5. Apply use-solution to floors, walls, cages and other washable hard, non-porous inanimate surfaces. For smaller surfaces, use a trigger spray bottle to spray all surfaces with solution until wet. To disinfect, all surfaces must remain wet for ten (10) minutes.
- 6. Do not house animals or employ equipment until product has dried.
- 7. For disinfection of feed racks, troughs, automatic feeders, fountains and watering appliances scrub with use-solution, let stand ten (10) minutes. Then thoroughly scrub all treated surfaces with soap or detergent and rinse with potable water before reuse.

\*Kills HBV and HIV-1 (AIDS Virus) on pre-cleaned environmental surfaces/objects previously soiled with blood/body fluids in health care settings (Hospitals, Nursing Homes) and other settings in which there is an expected likelihood of soiling of inanimate surfaces/objects with blood or body fluids and in which the surfaces/objects likely to be soiled with blood or body fluids can be associated with the potential for transmission of Hepatitis B virus and Human Immunodeficiency virus Type 1 (HIV-1) (associated with AIDS).

# SPECIAL INSTRUCTIONS FOR CLEANING AND DECONTAMINATION AGAINST HBV and HIV-1 (AIDS VIRUS) OF SURFACES/OBJECTS SOILED WITH BLOOD/BODY FLUIDS.

**Personal Protection:** Disposable latex or vinyl gloves, gowns, face masks or eye coverings as appropriate, must be worn during all cleaning of body fluids, blood, and decontamination procedures.

**Cleaning Procedures:** Blood and body fluids must be thoroughly cleaned from surfaces and objects before application of this product.

Contact Time: Allow surface to remain wet for 1 minute to kill HBV and HIV-1 and 10 minutes to kill all other organisms.

**Disposal of Infectious Material:** Blood and other body fluids should be autoclaved and disposed of according to Federal, State, and local regulations for infectious waste disposal.

#### STORAGE AND DISPOSAL

Do not contaminate water, food, or feed by storage or disposal. Do not store near heat or open flame.

#### TISTICIDE STORAGE:

In not reuse empty container (unless refilling from a larger container of the same product according to the refilling directions outlined previously). (Keep from freezing.)

#### **PESTICIDE DISPOSAL:**

Pesticide wastes are acutely hazardous. Improper disposal of excess pesticide, spray mixture, or rinsate is a violation of Federal Law. If these wastes cannot be disposed of by use according to label instructions, contact your State Pesticide or Environmental Control Agency, or the Hazardous Waste representative at the nearest EPA Regional Office for guidance.

#### **CONTAINER DISPOSAL:**

(Plastic Containers:)

If not being refilled with Phenolic Disinfectant HG, triple rinse (or equivalent). Then offer for recycling or reconditioning, or puncture and dispose of in a sanitary landfill, or by incineration or if allowed, by state and local authorities, by burning. If burned, stay out of smoke.

(Sealed Dispenser Cartridges/Portion-Dose (ACCUMIX™) bottles/Tear-open pouches:)

Do not reuse. Wrap empty container and put in trash. [Note to Agency: Please note that neither dispenser cartridges nor portion-dose (ACCUMIX) bottles can be triple rinsed because they are closed sealed systems designed to reduce worker exposure to the concentrate.]

8/10

#### ENVIRONMENTAL HAZARDS (for containers 5 gallons and larger)

Do not discharge effluent containing this product into lakes, streams, estuaries, oceans or other waters unless in accordance with the requirements of a National Pollutant Discharge Elimination System (NPDES) permit and the permitting authority has been notified in writing prior to discharge. Do not discharge effluent containing this product to sewer systems without previously notifying the local sewage treatment plant authority. For guidance contact your State Water Board or Regional Office of the EPA.

# PRECAUTIONARY STATEMENTS HAZARD TO HUMANS AND DOMESTIC ANIMALS

**DANGER: Corrosive.** Concentrate causes irreversible eye damage and skin burns. Do not get in eyes, on skin, or on clothing. Wear chemical splash-proof goggles and chemical resistant gloves when handling concentrate. Concentrate is harmful if swallowed, absorbed through skin or inhaled. Avoid breathing concentrate spray mist. Wash thoroughly with soap and water after handling. Remove contaminated clothing and wash clothing before reuse.

#### **FIRST AID**

**IF IN EYES:** Hold eye open and rinse slowly and gently with water for 15-20 minutes. Remove contact lenses, if present, after the first 5 minutes, then continue rinsing eye.

IF ON SKIN: Take off contaminated clothing. Rinse skin immediately with plenty ow water for 15-20 minutes.

**SWALLOWED:** Call a poison control center or doctor immediately for treatment advice. Have a person sip a glass of sucher if able to swallow. Do not induce vomiting unless told to do so by a poison control center or doctor. Do not give anything by mouth to an unconscious person.

**IF INHALED:** Move person to fresh air. If person is not breathing, call 911 or an ambulance, then give artificial respiration, preferably mouth-to-mouth if possible.

#### IN CASE OF EMERGENCY, CALL A POISON CONTROL CENTER OR DOCTOR FOR TREATMENT ADVICE. 1-800-851-7145

Have the product container or label with you when calling a Poison Control Center or doctor or going in for treatment.

Note to Physician: Probable mucesal damage may contraindicate the use of gastric lavage.

EPA Reg. No. 70627-6 EPA Est. No.

∠\_J01 S.C. Johnson Commercial Markets, Inc, Sturtevant, WI 53177-0902
U.S.A. All Rights Reserved



# Johnson wax Professional

## Phenolic Disinfectant HG REFERENCE SHEET

Phenolic Disinfectant HG is (a multi-purpose germicidal detergent) proven effective by the AOAC Use-Dilution method in 400 ppm hard water (calculated as CaCO<sub>3</sub>) in the presence of 5% organic bioload (Fetal Bovine Serum). Phenolic Disinfectant HG's formula disinfects, cleans, and deodorizes in one labor-saving step. Phenolic Disinfectant HG is effective against the following pathogenic organisms:

#### Bacteria (Bactericidal Activity) - kills on hard non-porous inanimate surfaces:

Pseudomonas aeruginosa, (ATCC 15442) Salmonella choleraesuis. (ATCC 10708) ohylococcus aureus, (ATCC 6538) vundimonas diminuta, (ATCC 4335) formerly known as Pseudomonas diminuta Bordetella bronchiseptica, (ATCC 10580) Corynebacterium ammoniagenes, (ATCC 6872) formerly known as Brevibacterium ammoniagenes Campylobacter fetus, (ATCC 27374) Citrobacter freundii, (ATCC 8090) Chlamydia psittaci (VR-125) Enterobacter aerogenes, (ATCC 13048) Enterobacter cloacae, (ATCC 23355) Enterococcus faecalis, (ATCC 19433) formerly known as Strephococcus faecalis Enterococcus hirae, (ATCC 10541) Escherichia coli, (ATCC 11229)

Escherichia coli 0157:H7, (ATCC 43888) Haemophilus influenza, (ATCC 10211) Klebsiella oxytoca, (ATCC 43863) Klebsiella pneumoniae, (ATCC 13883) Leclercia adecarboxylata, (ATCC 29916) formerly known as Enterobacter agglomerans Listeria monocytogenes, (ATCC 15313) Micrococcus luteus, (ATCC 4698) Morganette morganii, (ATCC 25830) Neisserie gonorrhoeae, (ATCC 40369) Pasteurella multocida, (ATCC 43137) Proteus mirabilis, (ATCC 25933) Proteus vulgaris, (ATCC 13315) Pseudomonas cepacia, (ATCC 25609) Pseudomonas fluorescens, (ATCC 13525) Salmonella choleraesuis, (ATCC 10719) formerly known as Salmonella schottmuelleri

Salmonella choleraesuis, (ATCC 13076) formerly known as Salmonella enteritidis Salmonella cholerasuis pullorum, (ATCC 19945) Salmonella typhi, (ATCC 6539) Salmonella typhimurium, (ATCC 14028) Serratia marcescens, (ATCC 8100) Shigella dysenteriae, (ATCC 13313) Shioella flexneri, (ATCC 12022) Staphylococcus aureus (Toxic Shock), (ATCC 33586) Staphylococcus epidermidis, (ATCC 14990) Staphylococcus haemolyticus, (ATCC 29970) Staphylococcus saprophyticus, (ATCC 15305) Streptococcus agalactiae, (ATCC 13813) Streptococcus pyogenes, (ATCC 19615) Streptococcus pyogenes, (Clinical isolate) (Strep A - Flesh Eating Strain) Vibro cholera, (ATCC 11623) Yersinia enterocolitica, (ATCC 23715)

## Antibiotic-Resistant (Strains of) Bacteria (Antibiotic-Resistant Bactericidal Activity) - kills on hard non-porous inanimate surfaces:

\*\*rococcus faecalis (VRE), (ATCC 51299) sistant to Vancomycir.

Enterococcus faecium (VRE), (ATCC 51559)
Resistant to Vancomycin, Ampicillin,
Ciprofloxacin, Gentamicin, Rifampin, Telcoplanin
Micrococcus sedentarius, (ATCC 27573)
Resistant to Methicillin, Penicillin

Enterobacter cloacae, (Clinical isolate HL 129) Entercoccus species, (Clinical isolate HL 128) Proteus mirabilis, (Clinical isolate HL 126) Staphylococcus aureus, (ATCC 14154)
Resistant to Erythromycin, Penicillin, Streptomyccin,
Tetracycline
Staphylococcus aureus (MRSA/GRSA),

(ATCC 33592), Resistant to Methicillin, Gentamicin

Staphylococcus aureus (VISA), (HIP 5836) Intermediate Resistance to Vancomycin

Providencia rettgeri, (Clinical isolateHL 92) Pseudomonas maltophila, (Clinical isolate HL 131) Staphylococcus aureus, (Clinical isolate HL 121) Staphylococcus epidermidis (MRSE), (ATCC 51625), Resistant to Methicillin

Streptococcus pneumoniae (PRSP), (ATCC 51915), Resistant to Penicillin

Staphylococcus aureus, (Clinical isolate HL 122) Staphylococcus aureus, (Clinical isolate HL 130)

**Tuberculocidal Activity** - This product exhibits disinfectant efficacy against *Mycobacterium bovis* (ATCC 19015) in 10 minutes at 20° C when used as directed on previously cleaned hard non-porous environmental surfaces.

HBV & HIV Activity - This product kills HBV & HIV (AIDS virus) (HTLV-III<sub>B</sub>) when used as directed on hard, non-porous inanimate surfaces with a 1 minute contact time and 10% serum.

10/10

## Viruses (\*Virucidal Activity) - kills on hard non-porous inanimate surfaces:

Adenovirus Type 2, (VR-2) Herpes Simplex Type 1, (VR-733) Herpes Simplex Type 2, (CCL 26) Human Coronavirus, (VR-740) Human Rhinovirus Type 38, (VR-511) Influenza Type A/Michigan Poliovirus Type 1, (VR-192) Reovirus Type 3, (VR-232) Respiratory Syncytial virus, (VR-26) Rotavirus, (Strain WA) Rubella virus, (CCL 7) Vaccinia virus, (VR-117)

Veterinary viruses: Avian Influenza, (Type A/Michigan) Canine parvovirus, (VR-2006)

Feline leukemia, (VR-717) Feline picornavirus, (VR-649) Feline Rhinotracheitis virus, (VR-636) Infectious Bovine Rhinotracheitis, (VR-93)
Newcastle Disease Virus, (VR-109)
Transmissible Gastroenteritis virus (TGE), (Univ.of Minn.)

## Fungi/Yeast (Fungicidal and Yeast Activity) - kills on hard non-porous inanimate surfaces:

Candida albicans, (ATCC 10231)

Trichophyton mentagrophytes, (ATCC 9533)

Mold/Mildew (Mildewstatic Activity) - controls (inhibits) the growth of mold and mildew: Aspergillus niger (ATCC 16404) (and the odors caused by them when applied to hard, non-porous environmental surfaces).

\*" lodor(s) (Activity) (Counteractancy) – eliminates (destroys) odors and odor-causing bacteria in restroom areas, lind and under sinks and counters, and storage areas (and other places where bacterial growth can cause malodors).

EPA Reg. No. 70627-6

©2001 S.C. Johnson Commercial Markets, Inc, Sturtevant, WI 53177-0902 U.S.A. All Rights Reserved