



UNITED STATES ENVIRONMENTAL PROTECTION AGENCY
WASHINGTON, DC 20460

OFFICE OF CHEMICAL SAFETY
AND POLLUTION PREVENTION

October 7, 2021

Coleen Gerber
Scientist, Keller & Heckman. LLC
PeroxyChem, LLC
2005 Market Street, Suite 3200
Philadelphia, PA 19103

Subject: Label Amendment – Add the statement “Not For The Use In California” and to
Add Alternate Brand names
Product Name: B-Cap 35 Antimicrobial Agent
EPA Registration Number: 72372-1
Received Date: November 7, 2019
Action Case Number: 00221113

Dear Coleen Gerber:

The amended label referred to above, submitted in connection with registration under the Federal Insecticide, Fungicide and Rodenticide Act (FIFRA), as amended, is acceptable. This approval does not affect any conditions that were previously imposed on this registration. You continue to be subject to existing conditions on your registration and any deadlines connected with them.

A stamped copy of your labeling is enclosed for your records. This labeling supersedes all previously accepted labeling. Pursuant to 40 CFR 156.10(a)(6) you must submit one copy of the final printed labeling before you release the product for shipment with the new labeling. In accordance with 40 CFR 152.130(c), you may distribute or sell this product under the previously approved labeling for 18 months from the date of this letter. After 18 months, you may only distribute or sell this product if it bears this new revised labeling or subsequently approved labeling. “To distribute or sell” is defined under FIFRA section 2(gg) and its implementing regulation at 40 CFR 152.3.


Should you wish to add/retain a reference to the company’s website on your label, then please be aware that the website becomes labeling under FIFRA and is subject to review by the Agency. See FIFRA section 2(p)(2). If the website is false or misleading, the product would be misbranded and unlawful to sell or distribute under FIFRA section 12(a)(1)(E). 40 CFR 156.10(a)(5) lists examples of statements EPA may consider false or misleading. In addition, regardless of whether a website is referenced on your product’s label, claims made on the website may not substantially differ from those claims approved through the registration process, FIFRA section 12(a)(1)(B). Therefore, should the Agency find or if it is brought to our attention that a website contains false or misleading statements or claims substantially differing from the EPA approved registration, the website will be referred to the EPA’s Office of Enforcement and Assurance.

The following alternate brand names have been added to the product record:

- OXTERIL
- OXTERIL LRA
- OXTERIL LRD
- OXTERIL LRA-S

Your release for shipment of the product constitutes acceptance of these conditions. If these conditions are not complied with, the registration will be subject to cancellation in accordance with FIFRA section 6. If you have any questions, please contact Zebora Johnson by phone at (703) 308-7080 or via email at johnson.zebora@epa.gov.

Sincerely,

A handwritten signature in black ink that reads "Steven Snyderman". The signature is written in a cursive style with a horizontal line underneath the name.

Steven Snyderman, Product Manager 33
Regulatory Management Branch II
Antimicrobials Division (7510P)
Office of Pesticide Programs

Enclosure: Stamped Label

B-Cap[®] 35 Antimicrobial Agent

(ABNs: Durox, Durox LRA, Durox LRD, Durox LRA Type-S, OXTERIL, OXTERIL LRA, OXTERIL LRD, OXTERIL LRA-S)

EPA Registration No. 72372-1

EPA Est. No. _____

For Industrial Use Only

Not for human consumption or household use

ACTIVE INGREDIENT:

Hydrogen Peroxide.....35%

OTHER INGREDIENTS:65%

TOTAL:100%

ACCEPTED

10/07/2021

Under the Federal Insecticide, Fungicide
and Rodenticide Act as amended, for the
pesticide registered under
EPA Reg. No. 72372-1

KEEP OUT OF REACH OF CHILDREN DANGER

[Note to Reviewer: In accordance with 40 CFD 156. 68(d), all first aid statements, as prescribed, will appear on the front panel of the product label.]

B-Cap[®] 35 Antimicrobial Agent is for use as a sterilant in conjunction with Bioquell Hydrogen Peroxide Vapor (HPV) generating equipment.

B-Cap[®] 35 Antimicrobial Agent is for biofouling and slime control in:

- Pulp and paper mill systems
- Recirculating and once through cooling water systems
- Pasteurizer cooling water systems
- Process Waters
- Biocidal control in packaging and storage vessels

B-Cap[®] 35 Antimicrobial Agent is for use in aseptic food processing operations to achieve commercial sterility of food packaging and equipment.

B-Cap[®] 35 Antimicrobial Agent is for use to control bacteria and fungi in dispersed pigments and synthetic and natural polymers in aqueous solutions

B-Cap[®] 35 Antimicrobial Agent is for antimicrobial use with aqueous treatment fluids in subterranean oilfield and gas-field well operations such as well drilling, formation fracturing, productivity enhancement and secondary recovery.

First Aid

Have the product container or label with you when calling a poison control center or doctor, or going for treatment.

If in eyes: Hold eye open and rinse slowly and gently with water for 15-20 minutes. Remove contact lenses, if present, after the first 5 minutes, then continue rinsing eye. Call a poison control center or doctor for treatment advice.

If on skin or clothing: Take off contaminated clothing. Rinse skin immediately with plenty of water for 15-20 minutes. Call a poison control center or doctor for treatment advice.

If inhaled: Move person to fresh air. If person is not breathing, call 911 or an ambulance, then give artificial respiration, preferably by mouth-to-mouth if possible. Call a poison control center or doctor for further treatment advice.

If swallowed: Call poison control center or doctor immediately for treatment advice. Have person sip a glass of water if able to swallow. Do not induce vomiting unless told to do so by a poison control center or doctor. Do not give anything by mouth to an unconscious person.

Note to Physician: Probable mucosal damage may contraindicate the use of gastric lavage.

Precautionary Statements

Hazards to Humans and Domestic Animals

DANGER: Corrosive, causes eye and skin damage. Harmful if swallowed. Do not get in eyes, on skin or on clothing. Wear goggles or face shield and rubber gloves when handling. Wash thoroughly with soap and water after handling. Do not breathe vapor or spray mist. Do not enter an enclosed area without proper respiratory protection. If concentrations in excess of the OSHA PEL TWA for hydrogen peroxide are expected, NIOSH approved (TC-19C) full face supplied air respirators must be worn. If the concentrations are unknown or could exceed the NIOSH IDLH of 75 PPM, then either NIOSH approved (TC-13F) Self-Contained Breathing Apparatus (SCBA) or supplied air respirators with escape bottles must be worn.

Environmental Hazards

This pesticide is toxic to birds, mammals, fish and aquatic invertebrates. Do not discharge effluent containing this product into lakes, streams, ponds, estuaries, oceans, or other waters unless in accordance with requirements of a National Pollutant Discharge Elimination System (NPDES) permit and the permitting authority has been notified in writing prior to discharge. Do not discharge effluent containing this product to sewer systems without previously notifying the local sewage treatment plant authority. For guidance contact your State Water Board or Regional Office of the EPA.

Any solution released from the system should be diluted with water and tested for residuals to ensure that there is less than 3 ppm peroxygen remaining.

Physical or Chemical Hazards

Strong oxidizing agent. Mix only with water. B-Cap[®] 35 Antimicrobial Agent is not combustible; however, at temperatures exceeding 156°F, decomposition occurs releasing oxygen. The oxygen released could initiate or promote combustion of other materials.



PeroxyChem, LLC

2005 Market St Ste 3200

Philadelphia PA 19103-7014

Net Contents: _____



and B-Cap[®] are trademarks of PeroxyChem, LLC

DIRECTIONS FOR USE

It is a violation of Federal law to use this product in a manner inconsistent with its labeling.

STORAGE AND DISPOSAL

STORAGE: NEVER RETURN B-CAP® 35 ANTIMICROBIAL AGENT TO THE ORIGINAL CONTAINER AFTER IT HAS BEEN REMOVED. Avoid all contaminants, especially dirt, caustic, reducing agents, and metals. Contamination and impurities will reduce shelf life and can induce decomposition. In case of a decomposition, isolate container, douse container with cool water and dilute B-Cap® 35 Antimicrobial Agent with large volumes of water.

Avoid damage to containers. Keep container closed at all times when not in use. Keep container out of direct sunlight. To maintain product quality, store this product in a cool and dry area. Do not store on wooden pallets.

Procedure for Leak or Spill

Stop leak if this can be done without risk. Shut off ignition sources; no flames, smoking, flares, or spark producing tools. Keep combustible and organic materials away. Flush spilled material with large quantities of water. Undiluted material should not enter confined spaces.

Disposal

Pesticide Disposal: If material has been spilled, an acceptable method of disposal is to dilute with at least 20 volumes of water followed by discharge into suitable treatment system in accordance with all local, state, and Federal environmental laws, rules, regulations, standards, and other requirements. Because acceptable methods of disposal may vary by location, regulatory agencies should be contacted prior to disposal.

B-Cap® 35 Antimicrobial Agent, which is to be discarded, should be disposed of as hazardous waste after contacting the appropriate local, state, or Federal agency to determine proper procedures.

Container Disposal

Nonrefillable containers less than 5 gallons. Nonrefillable container. Do not reuse or refill this container. Offer for recycling, if available. Triple rinse container (or equivalent) promptly after emptying. Triple rinse as follows: Empty the remaining contents into application equipment or a mix tank and drain for 10 seconds after the flow begins to drip. Fill the container ¼ full with water and recap. Shake for 10 seconds. Pour rinsate into [application equipment or] a mix tank or store rinsate for later use or disposal. Drain for 10 seconds after the flow begins to drip. Repeat this procedure two more times.

Nonrefillable containers greater than or equal to 5 gallons. Nonrefillable container. Do not reuse or refill this container. Offer for recycling, if available. Triple rinse container (or equivalent) promptly after emptying. Triple rinse as follows: Empty the remaining contents into application equipment or a mix tank. Fill the container ¼ full with water. Replace and tighten closures. Tip container on its side and roll it back and forth, ensuring at least one complete revolution, for 30 seconds. Stand the container on its end and tip it back and forth several times. Turn the container over into its other end and tip it back and forth several times. Empty the rinsate into application equipment or a mix tank or store rinsate for later use or disposal. Repeat this procedure two more times. Empty drums are not returnable to PeroxyChem unless special arrangements have been made. Dispose of drums in accordance with local, state, and Federal regulations.

All Refillable containers. Refillable container. Refill this container with pesticide only. Do not reuse this container for any other purpose. Cleaning the container before final disposal is the responsibility of the person disposing of the container. Cleaning before refilling is the responsibility of the refiller. To clean the container before final disposal, empty the remaining contents from this container into application equipment or mix tank. Fill the container about 10 percent full with water. Agitate vigorously or recirculate water with the pump for 2 minutes. Pour or pump rinsate into application equipment or rinsate collection system. Repeat this rinsing procedure two more times. Return to PeroxyChem for reuse.

Note to reviewer – bracketed text is not applicable to automatic dispenser systems such as Bioquell Hydrogen Peroxide Vapor (HPV) generating equipment.

B-Cap® 35 Antimicrobial Agent

A microbiocide for use in controlling slime and sulfate forming bacteria in process waters, air washing systems, recirculating and once through water cooling towers and systems, including pasteurizer cooling water systems and industrial closed recirculating process water systems, and packaging and storage vessels. (Not for Use in CA)

Air Washers and Recirculating and Once Through Cooling Water Systems, (cooling towers, evaporative condensers). (Not for Use in CA)

1. Severely fouled systems should be cleaned prior to treatment.
2. This product may be used in all types of cooling water systems that have mist-eliminating components. B-Cap® 35 Antimicrobial Agent should be added at a point where uniform mixing can be achieved, for example the basin area. Addition may be intermittent or continuous. Hydrogen peroxide should not be mixed with other chemicals or additives without first checking for compatibility. Contamination with other chemicals could cause product decomposition.
 - Intermittent (Slug Dose) – For severely fouled systems add 3 to 163 fl oz of B-Cap® 35 Antimicrobial Agent per 1000 gallons of water in the system, (10 to 500 ppm). Repeat until control is achieved. When control is evident add 1 to 31 fl oz of B-Cap® 35 Antimicrobial Agent per 1000 gallons of water in system (3 to 100 ppm H₂O₂) as needed to maintain control.
 - Continuous Feed – Initial Dose: If the system is noticeably fouled, use slug dose procedure for the initial treatment. Once control is achieved, use a continuous feed of 0.3 to 16 fl oz B-Cap® 35 Antimicrobial Agent per 1000 gallons of water per day in the system (1 to 50 ppm H₂O₂). Dosage rates should be increased or decreased depending on the extent of biofouling and control achieved.

Pasteurizer Cooling Water Systems (Not for Use in CA)

The product can be used at the same application rates and in the same manner as described above. The solution should be added to the closed recirculating system at a point where uniform mixing can be achieved, e.g., basin, sump, or collection areas.

Biofouling Control in Pulp and Paper Mill Systems (Not for Use in CA)

For use in the manufacture of paper and paperboard intended for non-food contact only. Not for use in the manufacture of paper and paperboard intended for food contact.

The product can be used to control bacterial, fungal and yeast growth in pulp, paper and paperboard mills.

1. Severely fouled systems should be cleaned prior to treatment with B-Cap® 35 Antimicrobial Agent. Add B-Cap® 35 Antimicrobial Agent directly to the system, don't mix with other chemicals or additives without first testing for compatibility. Contamination with other chemicals could result in product decomposition.
2. Add B-Cap® 35 Antimicrobial Agent at a point in the system where it can be mixed uniformly with the pulp, e.g., the beater, hydropulper, fan pump, broke pump, etc.
3. Apply 1 to 40 fl oz of B-Cap® 35 Antimicrobial Agent per ton of (dry basis) pulp or paper produced, (10 to 500 ppm H₂O₂). Addition may be continuous or intermittent depending on the type of system and severity of the biofouling.

Process Water (Not for Use in CA)

B-Cap® 35 Antimicrobial Agent may be used to aid in minimizing slime formation in process waters intended for use in precleaning hard non-porous surfaces, e.g., metals, glass or plastics prior to being painted, plated, or coated; cleaning pipes, equipment or other process equipment.

1. Add B-Cap® 35 Antimicrobial Agent at a point in the system where it can be mixed uniformly. The quantity of product required will depend upon the severity of the fouling.
2. Apply 0.3 to 163 fl oz per 1000 gallons of water in the system (1 to 500 ppm). Once control is achieved, reduce application rate accordingly.

Control of Slime, Bacteria, Fungi, and Other Microorganisms in packaging and storage vessels such as railcars, trucks, ships, totes, IBCs tanks, etc. used to contain clays, calcium carbonate, titanium dioxide, barium sulfate, and other filler materials. (Not for Use in CA)

1. If treating the container or vessel in the field, place the vessel or container on an area with an impervious surface with controlled runoff. Ensure that the antimicrobial treatment solution will not be released to the environment.
2. Remove gross contamination with a cleaner or other suitable detergent and rinse with water.
3. Prepare a dilute solution of the product by adding 1 to 4 volumes of B-Cap® 35 Antimicrobial Agent to 11 volumes of potable water. This will provide solutions containing 3% to 10% hydrogen peroxide. Apply the diluted solution, at ambient or elevated temperatures, to the surface as a coarse spray, wipe/mop or flood to reduce bacterial and fungal contamination.
4. Allow antimicrobial agent to contact the surface for a period of time sufficient to ensure adequate cleaning. Depending on the microbial load, contact times can range from 5 to 30 minutes or longer.
5. Drain dry. Do not rinse.

B-Cap® 35 Antimicrobial Agent is a sterilant for use in conjunction with Bioquell Hydrogen Peroxide Vapor (HPV) generating equipment.
[for container sizes 500 mL or larger]

The following directions are to be followed when using the Bioquell HPV equipment: The hydrogen peroxide vapor is intended for use as a sterilant in treating enclosures up to 3500 cubic feet (validated) or greater (non-validated). Use this product for sterilization as instructed in the Bioquell Use Manual. This product may not be used on food-contact surfaces unless followed by a potable water rinse.

For Enclosures up to 35 cubic feet

1. Ensure that all porous and non-porous surfaces are visibly clean and free from gross organic contamination.
2. Connect the Bioquell HPV generator and add B-Cap® 35 Antimicrobial Agent according to the Use Manual instructions. Seal the enclosure to be sterilized.
3. Apply B-Cap® 35 Antimicrobial Agent at an injection rate of 3.1 g/minute for 55 minutes.
4. Allow vapor to remain for a minimum of 3 hours.
5. Aerate the chamber using the Bioquell HPV generator until hydrogen peroxide vapor is at or below 1.0 ppm. See the Bioquell Use Manual for complete instructions for aeration and recommended methods of measuring hydrogen peroxide vapor.

For Enclosures Greater than 35 Cubic Feet to a Maximum of 3500 Cubic Feet

(Multiple 500 mL containers required for volumes greater than 35 cubic feet – refer to the table in item 3 below.)

1. Ensure that all porous and non-porous surfaces are visibly clean and free from gross organic contamination.
2. Connect the Bioquell HPV generator and add B-Cap® 35 Antimicrobial Agent according to the Use Manual instructions. Seal the enclosure to be sterilized.
3. Apply B-Cap® 35 Antimicrobial Agent at an injection rate of 10 g/minute for 2.5 hours.

Volume to be treated	B-Cap® 35 Antimicrobial Agent required	Number of 500 mL Packages Required	Number of 1000 mL Packages Required
Up to 35 cubic feet	170.5 g	1	1
36-3500 cubic feet	1500 g	3	2

4. Allow vapor to remain for a minimum of 15 minutes.
5. Aerate the chamber using the Bioquell HPV generator until hydrogen peroxide vapor is at or below 1.0 ppm. See the Bioquell Use Manual for complete instructions for aeration and recommended methods of measuring hydrogen peroxide vapor.

[for 150 mL containers only]

The following directions are to be followed when using the rapid gassing HPV generator, the Bioquell QUBE. The hydrogen peroxide vapor is intended for use as a sterilant in treating enclosures up to 37 cubic feet. Use this product for sterilization as instructed in the Bioquell Use Manual. This product may not be used on food-contact surfaces unless followed by a potable water rinse.

For Enclosures Up to 16 Cubic Feet

1. Ensure that all porous and non-porous surfaces are visibly clean and free from gross organic contamination.
2. Add B-Cap® 35 Antimicrobial Agent according to the Use Manual instructions.
3. Apply B-Cap® 35 Antimicrobial Agent at an injection rate of 6 g/minute until 26g has been injected.
4. Allow vapor to remain for a minimum of 10 minutes.
5. Aerate the chamber using hydrogen peroxide vapor is at or below 1.0 ppm. See the Bioquell Use Manual for complete instructions for aeration and recommended methods of measuring hydrogen peroxide vapor.

For Enclosures Greater than 16 Cubic Feet to a Maximum of 37 Cubic Feet

1. Ensure that all porous and non-porous surfaces are visibly clean and free from gross organic contamination.
2. Add B-Cap® 35 Antimicrobial Agent according to the Use Manual instructions.
3. Apply B-Cap® 35 Antimicrobial Agent at an injection rate of 4 g/minute until 120g has been injected.
4. Allow vapor to remain for a minimum of 70 minutes.
5. Aerate the chamber using hydrogen peroxide vapor is at or below 1.0 ppm. See the Bioquell Use Manual for complete instructions for aeration and recommended methods of measuring hydrogen peroxide vapor.

Aseptic Food Processing Operations

B-Cap® 35 Antimicrobial Agent is a ready to use solution. It may be used to achieve commercial sterility of food packaging materials and food processing equipment.

Apply B-Cap® 35 Antimicrobial Agent on the exterior and interior of food containers and closure systems (caps, seals, etc.), or appropriate food processing equipment surfaces. Use techniques such as, but not limited to, immersion, coarse spray, or circulations to sterilize the equipment. Apply B-Cap® 35 Antimicrobial Agent at a minimum temperature of 75°C. The product must remain in contact with the packaging surface for a minimum of 20 seconds.

Such use must comply with all applicable FDA regulations, including but not limited to 21 CFR parts 108, 110, 113, and 114. Use in an aseptic food processing operation includes testing required for the process validation. Food subject to these FDA regulations may not be sold in a treated package until after the scheduled process for the food processing operation has been accepted by the FDA.

Control of Bacteria and Fungi in Dispersed Pigments and Synthetic and Natural Polymers in Aqueous Solutions (Not for Use in CA)

B-Cap® 35 Antimicrobial Agent can be used to control bacteria and fungi in the manufacture and storage of dispersed pigments and aqueous polymers used in paint and paper production such as kaolin clay, titanium dioxide, calcium carbonate, calcium sulfate, barium sulfate, magnesium silicate, and kieselguhr and applications containing natural and synthetic polymer lattices based on acrylates, butadiene, PVA, styrene, and other monomers (e.g. water based emulsions, latexes, and dispersions).

Apply 1.3 to 8.9 gallons of B-Cap® 35 Antimicrobial Agent solution to each 1,000 gallons of fluid. This will provide 500 ppm to 3,500 ppm of hydrogen peroxide. The hydrogen peroxide content for finished products is 0.05% (500 ppm) to 0.35% (3,500 ppm).

For open pouring systems, avoid breathing vapors, mist or gas. Be sure to use personal protective equipment including impervious gloves, impervious clothing and eye protection. Protective engineering solutions should be implemented and in use before PPE equipment is considered. This includes proper ventilation to maintain hydrogen peroxide levels below the OSHA PEL TWA of 1 ppm.

If concentrations in excess of the OSHA PEL TWA for hydrogen peroxide are expected, NIOSH approved (TC-19C) full face supplied air respirators must be worn. If the concentrations are unknown or could exceed the NIOSH IDLH of 75 PPM, then either NIOSH approved (TC-13F) Self-Contained Breathing Apparatus (SCBA) or supplied air respirators with escape bottles must be worn.

For antimicrobial use with aqueous treatment fluids in subterranean oilfield and gas-field well operations such as well drilling, formation fracturing, productivity enhancement and secondary recovery. (Not for Use in CA)

B-Cap® 35 Antimicrobial Agent can be for control of slime forming and spoilage bacteria, yeast and fungi and anaerobic sulfate reducing bacteria, *Desulfovibrio vulgaris*, that lead to reservoir souring and metal corrosion.

This product must be introduced through a closed mixed/loading and delivery transfer system equipped with a metering device that is appropriate for its intended uses.

Drilling Muds, Fracturing Fluids, Well Squeezed Fluids (Not for Use in CA)

For the preservation of drilling muds, workover and completion fluids and other product susceptible to contamination, pre-mix with the fluid or add directly at the point of use at 16.2 fluid ounces per 1000 gallons of water (50 ppm of Hydrogen Peroxide) to 161.7 fluid ounces per 1000 gallons of water (500 ppm of Hydrogen Peroxide). Depending on the severity of the contamination, initial application may be added up to 4 gallons per 1000 gallons of water (1,578 ppm of Hydrogen Peroxide).

Flooding, Injection and Produced Water (Not for Use in CA)

For Water Flooding operations, add initially at 16.2 fluid ounces per 1000 gallons of water (50 ppm of Hydrogen Peroxide) to 161.7 fluid ounces per 1000 gallons of water (500 ppm of Hydrogen Peroxide) and repeat until control is achieved. Subsequent treatment may be continued on a weekly basis or as required.

Injection wells associated with gas storage systems may be treated up to 150 ppm of Hydrogen Peroxide when diluted in the formation water. Any additional top-up water should be treated as required.

For hydrostatic systems, apply 16.2 fluid ounces per 1000 gallons of water (50 ppm of Hydrogen Peroxide) to 161.7 fluid ounces per 1000 gallons of water (500 ppm of Hydrogen Peroxide) on the water quality and the duration of the shut-in.

Pipeline and Tank Maintenance (Not for Use in CA)

For microbial control in water-bottoms in crude and refined hydrocarbon storage tanks, piping and transportation systems: Apply 16.2 fluid ounces per 1000 gallons of water (50 ppm of Hydrogen Peroxide) to 161.7 fluid ounces per 1000 gallons of water (500 ppm of Hydrogen Peroxide) in the aqueous phase, directly injected into the water-bottom, pipeline or may be added to the hydrocarbon phase. Treatment may be applied daily or monthly for both storage and transportation systems as needed.

[Emerging Viral Pathogens Claim – Hard, porous and non-porous surfaces]

This product qualifies for emerging viral pathogen claims per the EPA's 'Guidance to Registrants: Process for Making Claims Against Emerging Viral Pathogens not on EPA-Registered Disinfectant Labels' when used in accordance with the appropriate use directions indicated below.

(Note to the reviewer: The statements shall be made only through the following communications outlets: technical literature distributed exclusively to health care facilities, physicians, nurses and public health officials, "1-800" consumer information services, social media sites and company websites (non-label related). These statements shall not appear on marketed (final print) product labels.)

This product meets the criteria to make claims against certain emerging viral pathogens from the following viral category[ies]:

- Enveloped Viruses
- Large Non-Enveloped Viruses
- Small Non-Enveloped Viruses

For an emerging viral pathogen that is a/an...	...following the sterilant directions for use in conjunction with Bioquell Hydrogen Peroxide Vapor (HPV) generating equipment. Use this product for sterilization as instructed in the Bioquell Use Manual according to the size of the space to be treated.
Enveloped virus	
Large, non-enveloped virus	
Small, non-enveloped virus	

B-Cap® 35 Antimicrobial Agent has demonstrated effectiveness as a **sterilant** which is defined in 40 CFR 158.2203 as "a substance, or mixture of substances, that destroys or eliminates all forms of microbial life in the inanimate environment, including all forms of vegetative bacteria, bacterial spores, fungi, fungal spores, and viruses". Thus, it is expected to be effective against viruses similar to **[name of emerging virus]** on hard, **[porous and/or non-porous surfaces]**. Therefore, **B-Cap® 35 Antimicrobial Agent** can be used against **[name of emerging virus]** when used in accordance with the directions for use as a sterilant on **[hard, porous/non-porous surfaces]**. Refer to the **[CDC or OIE]** website at **[pathogen-specific website address]** for additional information.

[Name of illness/outbreak] is caused by **[name of emerging virus]**. As a sterilant, **B-Cap® 35 Antimicrobial Agent** is expected to kill similar viruses and therefore can be used against **[name of emerging virus]** when used in accordance with the directions for use as a sterilant on **[hard, porous/non-porous surfaces]**. Refer to the **[CDC or OIE]** website at **[website address]** for additional information.

Note: This product may not be used to sterilize medical devices.

In all applications, always prepare a new solution daily to ensure effectiveness. Do not reuse solutions. Dispose of any unused solution.

EMERGENCY TELEPHONE NUMBERS (24 HOURS)

MEDICAL: COLLECT 303-389-1409

CHEMTREC: 800-424-9300

OTHER: 281-474-8750

For more information see Safety Data Sheet

Proper Shipping Name:

Hydrogen peroxide, aqueous solution with not less than 20 percent but not more than 40 percent hydrogen peroxide.

UN 2014