



SDMS DocID 000218341

Final Report:

Laboratory Testing Results: KPEG Treatment of New Bedford Soil

Work done for REM III Contract #68-01-7250

December 20, 1988

**Galson Research
Corporation**



6601 Kirkville Road
East Syracuse, NY 13057

(315) 463-5160 (within NYS)
(800) PCBS-123 (outside NYS)

TABLE OF CONTENTS

Volume 1

| | |
|---|----|
| Executive Summary | 1 |
| 1. General Description of KPEG Treatment Technology | 2 |
| 2. Description of Bench Testing | 5 |
| 3. Pre-Treatment and Post-Treatment | 7 |
| 4. Results of Advance Testing | 8 |
| 5. Procedures for Documentation | 12 |
| 6. Results of Bench Testing | 13 |
| 6.1. PCB Results | 13 |
| 6.2. Results of Reagent Recovery Study | 15 |
| 6.3. Results of Soil Washing Test | 16 |
| 6.4. Results of CLP Analysis | 17 |
| 7. Effects of Varying Operating Parameters | 19 |
| 8. Estimate of Full Scale Processing Cost | 20 |
| 9. Process Optimization | 23 |
| 10. Information Specific to KPEG Processing | 24 |
| 10.1. Destruction and Removal Efficiencies | 24 |
| 10.2. Toxicity of Reaction Products | 25 |
| 10.3. Reagent Residuals in Processed Soil | 25 |
| 10.4. Separation of Fine Grained Sediment from Reagent and Wash Water | 26 |
| 10.5. Effect of Water on KPEG Processing | 26 |

Appendix

- A. Data Sheets for Gallon Reactions
- B. Results of CLP Analysis
- C. Sample Log
- D. Analytical Spreadsheets
- E. Copies of Notebook Pages

Executive Summary

Two samples of sediment from New Bedford Harbor were used to test KPEG treatment for removal of PCB. The two samples were "low PCB" sediment containing 400 - 500 ppm PCB and "high PCB" sediment containing 6000 - 7500 ppm PCB. KPEG reduced the PCB concentration in the "low PCB" sediment to less than 1 ppm in 9 hours. It reduced the PCB concentration in the "high PCB" sediment to 4 ppm in 12 hours. Both reactions were carried out at 165°C.

Reagent recovery for reactions of New Bedford sediment was slightly greater than usual for a laboratory study, probably because the reaction size was greater than usual. In gallon size reactions with New Bedford Sediment, at least 75% of each reagent component was accounted for analytically. Most of the reagent components were recovered in the recovered reagent and the first wash. Recoveries of potassium hydroxide were unusually high for laboratory tests, indicating favorable results for full scale processing. Residual concentrations of reagents in treated soil are consistent with 98+% reagent recoveries.

In general, laboratory recovery of reagent is less than pilot test recoveries. In studies preceding treatment of the Bengart & Memel site, 98+% reagent recoveries were achieved in pilot tests. Since reagent recovery analysis was not done during lab testing for that site, data to compare with the pilot study results do not exist. In recent lab and pilot studies for another site with fine grained soil, reagent recoveries from pilot tests were 10 - 18% higher than they had been for lab tests. For example, the average recovery for DMSO was 64% in the lab and 89% in the pilot. Based on the improvement in recovery seen at the other site, reagent recoveries for New Bedford sediment are expected to improve as the process is scaled up.


The cost for processing PCB contaminated soils at the New Bedford site is estimated at \$80 to \$104/ton of soil processed, depending on the volumes to be handled, cleanup levels desired and other factors. This cost compares favorably with other forms of permanent disposal, along with the natural safety advantages associated with closed system batch processing

This work was done under REM III Contract #68-01-7250

1. General Description of KPEG Treatment Technology

In KPEG soils processing, soil and reagent are mixed to form a slurry. The soil/reagent mixture is then heated to 30-180 °C with mixing until the PCBs in the soil decompose to lower toxicity, water soluble materials. At the end of the reaction, reagent is recovered and the soil is washed with at least two volumes of water. The decontaminated soil is then discharged, and the reagent and wash waters are recycled, as shown in the simplified process diagram below.


PROCESS DIAGRAM FOR APEG SOIL DECONTAMINATION



*SEPARATION BY PRESSURE FILTRATION, CENTRIFUGATION, OR SETTLING/DECANTATION

The following page is a more detailed process diagram and mass balance form for a single large reactor. A multiple reactor system would be used for the New Bedford Harbor site.

FULL SCALE PROCESS DIAGRAM



- ① Contaminated soil into reactor
- ② Reagent into reactor
- ③ Makeup reagent into reagent tank
- ④ Volatiles from reactor heatup
- ⑤ Water return
- ⑥ Hydrocarbons from separator
- ⑦ Soil/reagent slurry from reaction
- ⑧ Reagent decant from first centrifugation
- ⑨ Soil decant from first centrifugation
- ⑩ Water/reagent from decant to still
- ⑪ Water/reagent from decant to reagent tank
- ⑫ First wash water input
- ⑬ Soil/water slurry from first wash
- ⑭ Reagent/water decant from second centrifugation
- ⑮ Soil decant from second centrifugation
- ⑯ Second wash water input
- ⑰ Soil/water slurry from second wash
- ⑱ Reagent/water decant from third centrifugation
- ⑲ Soil decant from third centrifugation
- ⑳ Wash water input for third wash
- ㉑ Soil/water slurry from third wash
- ㉒ Water/reagent from 4th centrifugation
- ㉓ Decontaminated soil
- ㉔ Water/reagent feed to distillation system
- ㉕ Reagent from distillation system
- ㉖ Water from distillation system
- ㉗ Water/acid makeup to system
- ㉘ Salt blowdown from reagent tank

- ⑮ Soil decant from second centrifugation
- ⑯ Second wash water input
- ⑰ Soil/water slurry from second wash
- ⑱ Reagent/water decant from third centrifugation
- ⑲ Soil decant from third centrifugation
- ⑳ Wash water input for third wash
- ㉑ Soil/water slurry from third wash
- ㉒ Water/reagent from 4th centrifugation
- ㉓ Decontaminated soil
- ㉔ Water/reagent feed to distillation system
- ㉕ Reagent from distillation system
- ㉖ Water from distillation system
- ㉗ Water/acid makeup to system
- ㉘ Salt blowdown from reagent tank

- ① Numbered process stream
- H/R Heatup/reaction step
- COND/SEP Vapor condensation/hydrocarbon separation
- CF1, CF2, CF3 1st, 2nd, 3rd centrifuge steps
- RGT SEP Reagent separation
- RGTK Reagent tank
- RS1, RS2, RS3 1st, 2nd, 3rd reslurry steps
- W1, W2, W3 Wash water tanks 1,2,3
- STK Distillation feed tank
- STILL Distillation system
- CF4/DS 4th centrifuge step/solids discharge

PRO-FORMA MASS BALANCE

| Stream # | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | | | |
|----------------------|-------|------|------|------|------|-----|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|-----|------|-----|-----|-----|--|--|
| Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Mass, thousand lbs | 56.0 | 33.0 | 0.24 | 19.0 | 19.0 | 0.0 | 89.8 | 31.4 | 58.2 | 16.4 | 14.9 | 33.6 | 91.8 | 33.1 | 58.7 | 33.6 | 58.2 | 33.6 | 92.5 | 33.6 | 58.8 | 63.0 | 18.4 | 64.6 | 2.6 | 0.0 | 0.0 | | | | |
| Kilos soil | 44.8 | 0.0 | 0.00 | 0.0 | 0.0 | 0.0 | 44.8 | 0.0 | 44.8 | 0.0 | 0.0 | 0.0 | 44.8 | 0.0 | 44.8 | 0.0 | 44.8 | 0.0 | 44.8 | 0.0 | 44.8 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | | | | |
| Kilos water | 11.2 | 5.6 | 0.00 | 18.8 | 18.8 | 0.0 | 16.8 | 11.8 | 5.0 | 6.2 | 5.6 | 33.3 | 38.4 | 26.9 | 11.5 | 33.6 | 46.1 | 31.8 | 13.5 | 33.6 | 47.1 | 33.0 | 14.1 | 64.6 | 0.0 | 64.6 | 2.6 | 0.0 | | | |
| Kilos KOH | 0.0 | 5.6 | 0.05 | 0.0 | 0.0 | 0.0 | 0.0 | 5.6 | 3.0 | 1.7 | 2.1 | 1.9 | 0.0 | 1.7 | 1.2 | 0.5 | 0.0 | 0.5 | 0.4 | 0.2 | 0.0 | 0.2 | 0.1 | 0.0 | 3.6 | 3.6 | 0.0 | 0.0 | 0.0 | | |
| Kilos PEG | 0.0 | 5.6 | 0.05 | 0.0 | 0.0 | 0.0 | 0.0 | 5.6 | 3.9 | 1.7 | 2.1 | 1.9 | 0.1 | 1.8 | 1.3 | 0.5 | 0.0 | 0.5 | 0.4 | 0.2 | 0.0 | 0.2 | 0.1 | 0.0 | 3.7 | 3.7 | 0.0 | 0.0 | 0.0 | | |
| Kilos TMH | 0.0 | 5.6 | 0.05 | 0.0 | 0.0 | 0.0 | 0.0 | 5.6 | 3.9 | 1.7 | 2.1 | 1.9 | 0.1 | 1.8 | 1.3 | 0.5 | 0.0 | 0.5 | 0.4 | 0.2 | 0.0 | 0.2 | 0.1 | 0.0 | 3.7 | 3.7 | 0.0 | 0.0 | 0.0 | | |
| Kilos DMSO | 0.0 | 11.2 | 0.10 | 2.2 | 2.2 | 0.0 | 11.2 | 7.8 | 3.4 | 4.1 | 3.7 | 0.2 | 3.6 | 2.5 | 1.1 | 0.0 | 1.1 | 0.8 | 0.3 | 0.0 | 0.3 | 0.2 | 0.1 | 7.4 | 7.4 | 0.0 | 0.0 | 0.0 | | | |
| Kilos PCB products | 0.0 | 0.0 | 0.00 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | | | |
| Kilos PCB | 0.0 | 0.0 | 0.00 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | | | |
| Kilos HC misc | 0.0 | 0.0 | 0.00 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | | |
| Kilos sulfuric acid | 0.0 | 0.0 | 0.00 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | | |
| reagent/wash loading | 60% | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| % Stage efficiency | 70% | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| % soil carryover | 0% | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| % Reagent loss | 0.71% | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Reagent formula | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| % KOH | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| % water | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| % PEG | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| % TMH | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| % DMSO | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

The reagent components for APEG processing include: a sulfoxide, e.g. sulfolane (SFLN) or dimethyl sulfoxide (DMSO); a glycol and/or capped glycol, e.g. polyethylene glycol 400 (PEG) and/or triethylene glycol methyl ether and higher homologs (TMH); solid or aqueous potassium hydroxide (KOH); and water. The glycol is reacted with KOH in the presence of DMSO to form an alkoxide. The alkoxide reacts with one of the chlorine atoms on the biphenyl ring to produce a glycol-biphenyl ether and potassium chloride. The sulfoxide acts as a extraction solvent and catalyst, increasing the overall rate of reaction. The reactions involved are shown in Figure 2.




Figure 2. Reactions

Regardless of the processing scale, the reaction system is closed during the reaction to prevent release of materials to the environment. Water is distilled out of the reactor and collected in a condensate receiver. A trap is in line between the condensate receiver and the environment to collect any volatile compounds that are not condensed.

At the end of the reaction, reagent is recovered by decantation, filtration, or centrifugation and the soil is washed with water to remove the residual reagent. The number of water washes required may vary from one soil to another and must be determined through lab and pilot studies. The decontaminated soil is discharged, and the reagent can be recycled.

2. Description of Bench Testing

Bench testing consisted of demonstrating the effectiveness of KPEG treatment on two types of New Bedford soil, "low PCB" (<500 ppm) and "high PCB" (> 1000 ppm), and developing a cost estimate for full scale soil processing. The testing program was divided into two sections, advance testing in which the reaction parameters were investigated and set and bench testing in which the final parameters were demonstrated. In advance testing, GRC ran seven "small" reactions and one "gallon" reaction. The purpose of the small reactions was to develop the necessary analytical cleanup method for New Bedford soil and to establish the optimum reagent formulation, temperature, reaction time, and procedures for the gallon reactions. The small reactions were followed by a single 1 gallon reaction to test the use of large lab equipment in this process. (Normal laboratory reactions do not use such large amounts of material.) During Bench testing, two reactions (one for each soil) simulated processing under the finalized conditions and generated samples needed for further analysis. Table 1 lists all of the reactions done for this project.

Table 1. Reactions Done for New Bedford Project

| <u>Advance Testing</u> | | | | |
|------------------------|--------|------|---|--------------------|
| # | size | soil | description | comment |
| 1 | small | low | reagent formulation with DMSO, 150°C | initial test |
| 2 | small | low | reagent formulation with Sulfolane, 150°C | DMSO was better |
| 3 | small | low | add vermiculite at 120°C, react at 150°C | faster reaction |
| 4 | small | low | add vermiculite at 150°C | no effect |
| 5 | small | high | like #3 plus replace KOH during reaction | inadequate |
| 6 | small | high | like #1 plus replace KOH during reaction | inadequate |
| 7 | small | high | triple initial KOH, increase temperature | successful |
| 8 | gallon | low | final conditions (3x KOH, 165°C) | equipment test |
| <u>Bench Testing</u> | | | | |
| # | size | soil | description | comment |
| 9 | gallon | high | final conditions | process simulation |
| 10 | gallon | low | final conditions | process simulation |

The laboratory scale reaction apparatus is shown in Figure 3. All components that come into contact with soil, reagent or condensate are glass except for the thermocouple probe. The bottom of the reactor is positioned in a thermostatically controlled oil bath. The oil bath with circulating heater and associated ring stands are set up in a fume hood. The condensate receiver and glass jars for reagent, soil, and washes are tared before starting the reaction. Soil, and reagents are weighed into the reactor bottom. The reactor is then clamped together and set up with all the accessories.




Figure 3. Lab Scale Soil Reactor

Reactions are timed from the start of heating. During heating, slight vacuum (<1" Hg) is maintained to encourage water distillation and prevent steam from escaping except through the vent trap. Water distills between 110 and 130°C. When the distillation is complete, the vacuum is turned off. Samples are taken throughout the reaction, about one per hour, and analyzed according to GRC's method for PCBs in soil.

After the PCB concentration in the soil has reached the desired "clean" level the reactor is cooled to about 100°C and water is added to prevent solidification of the KOH and restore the reagent to its original water content. The reactor is cooled to room temperature and the as much reagent as possible is recovered from the soil. Possible separation methods include settling/decantation, pressure filtration, and centrifugation. The recovered reagent is collected in its tared jar.

The soil is washed with water to remove residual reagent. The number of washes may be varied as desired. Each wash will have a volume similar to the volume of the reagent. Each wash is thoroughly mixed with the soil and then recovered from the soil by the same separation method that was used to recover the reagent. Each wash is collected in its tared jar. When all the liquids are in their tared jars, the jars (and the condensate receiver) are re-weighed and mass recoveries are calculated.

In a laboratory study, recycling of the reagent is impractical because of the mass losses associated with the high surface to volume ratio of laboratory equipment. The reagents and washes are simply analyzed for reagent components so that the efficiency of reagent removal and the potential for reagent recycling on a larger scale can be evaluated.

3. Pre-Treatment and Post-Treatment

One of the great advantages of KPEG processing is that very little pre-treatment of soil is required. The main considerations for lab work were to prevent small rocks from breaking the reaction glassware and to verify that the soil contained enough PCB for demonstration purposes.

3.1. Soil Preparation and Analysis

Two batches of soil were received in gallon jars with teflon lined screw caps. Each batch was passed through a screen with 0.25 inch openings to remove any large rocks and homogenized as much as possible by hand mixing in a plastic pan. Both batches of soil had a distinct sulfurous odor and were completely saturated with water. No water was removed during the sieving and homogenizing procedures. Portions of each soil were collected for PCB analysis and percent moisture analysis and the soil was returned to its original containers. The results of the preliminary analyses are presented in Table 2.

Table 2. Results of Preliminary Analyses

| <u>Soil Batch</u> | <u>ppm PCBa</u> | <u>% moisture^b</u> |
|-------------------|-----------------|-------------------------------|
| "High PCB" | 6100 | 68 |
| "Low PCB" | 460 | 61 |

^a mg total PCB per kg dry soil

^b % moisture = $100 \times (\text{wet soil weight} - \text{dry soil weight}) / \text{wet soil weight}$

The soil samples were analyzed according to GRC's usual method except that decachlorobiphenyl (the usual recovery surrogate) was not added. Since DCB could have been present in the soil, use of DCB as a recovery surrogate was not appropriate for the initial analysis of the samples. These analyses showed that there was no detectable concentration of decachlorobiphenyl in the soil. Percent moisture was calculated by weighing wet soil in a tared beaker, drying the soil on a steam tray for a week, and re-weighing.

3.2. Post Treatment

The soil received no post treatment other than the soil washing steps described as a part of processing. In full scale processing, neutralization of the residual KOH will be necessary. The cost for neutralization has been included in the cost estimate.

4. Results of Advance Testing

Advance testing involved running a series of small reactions with the sediment. The purpose of the initial reaction series was to establish the reagent formulation and other handling parameters for the larger reactions requested by the client and to test GRC's analytical methods for this soil.


Four reactions were carried out using the "low PCB" soil. For these reactions 300 g of wet soil were mixed with 300 g of reagent. A 300 g portion of the wet sediment is roughly equivalent to 100 g of soil on a dry weight basis.

The first two reactions were done to compare dimethyl sulfoxide (DMSO) with sulfolane (SFLN) as the sulfoxide in the reagent formulation. The reagent formulation for both reactions was 1:1:2:2 PEG: TMH: sulfoxide: KOH(45%aqueous), and the reaction temperature was 150°C. The initial analysis of samples from these two reactions was not successful due to a large interfering peak in the middle of the PCB chromatogram. GC/MS analysis showed that the interfering compound was sulfur. An additional cleanup step - shaking the hexane extract with copper powder just before acid washing - was added to the analytical method. This procedure removed the sulfur from the hexane extracts without reducing recovery of PCBs. Enough samples were re-analyzed that an accurate reaction curve could be constructed for the first two reactions. All subsequent PCB analyses for this project included the copper cleanup step.

DMSO proved to be the better sulfoxide. Reagent containing DMSO reduced the PCB concentration to less than 10 ppm in 5.5 hours. Reagent containing sulfolane failed to reduce the PCB concentration to 10 ppm in 10 hours.

The second pair of reactions were done to test the effect of adding 1% vermiculite (1 g vermiculite/100 g soil) to the reaction slurry. Past experience has shown that for some soils, particularly those high in clay, vermiculite speeds up the reaction by improving the mixing in the reactor. In one of these reactions, the vermiculite was added when the reactor temperature was 120°C. In the other reaction, it was added when the temperature was 150°C. Addition of vermiculite at 120°C enhanced the reaction rate - the PCB concentration was reduced to less than 10 ppm in 4.5 hours compared with 5.5 hours for the reaction without vermiculite. Addition of vermiculite at 150°C did not change the initial reaction rate and seemed to slow the reaction after the 6th hour. Figure 4 shows the progress of the four initial reactions.


Figure 4. New Bedford Initial Reactions - Low PCB Soil



Similar reaction conditions were tried without success on the "high PCB" soil. In the pair of reactions done using the original reagent formulation (with and without vermiculite), the PCB concentration remained well above 50 ppm after 12 hours of reaction and the reaction curve seemed to level off. Vermiculite did not seem to have a significant impact on the reaction.

The reaction was stopped and the reagent was analyzed for PEG, TMH, DMSO, and KOH. All of the reagent components were still present in their original concentrations except KOH, which was reduced to 50% of its original concentration. Additional KOH was added to the reactor and heating was resumed. The PCB concentration was further reduced, but still failed to reach 10 ppm after 24 hours of reaction at 150°C. A new reaction was run using 3 times the usual amount of KOH with a reaction temperature maximum of 178°C. That reaction reduced the PCB concentration to less than 2 ppm within 6 hours, but 15% of the total PCB originally present ended up in the condensate along with some oil that distilled over. Figure 5 shows the results of the high PCB soil initial reactions.

Figure 5. New Bedford Initial Reactions - High PCB Soil




Long reactions were cooled, analyzed, fortified
and reheated between 12th and 13th hour.

During this series of small reactions, GRC's analytical method was refined to meet the requirements of this sediment. Advance testing verified that pressure filtration is not useful for separating reagent and wash from this sediment. Centrifugation was selected as the separation method for all subsequent work. It was also determined that Vermiculite did not help the reaction rate for this sediment as it had for some other soils and that treatment of this sediment required much more KOH than was anticipated. Based on the PCB results of these initial reactions, the reagent formulation chosen for the larger reactions was 1:1:2:6 PEG:TMH:DMSO:KOH. Since increasing the reaction temperature to 178°C caused more rapid reaction with no damaging effects except increased distillation of PCB contaminated oil from the reactor, the gallon size reactions could be run as hot as the lab apparatus would allow.

As a final advance test, a "practice" one gallon reaction was done using the low PCB sediment. The original condenser system was found to be inadequate when foam containing reagent and soil was forced into the condensate receiver. As a result of that test, a second condenser and additional space for vapor expansion and condensation were added to the reaction apparatus. The additional glassware solved the problem and the final reactions proceeded smoothly. The following page is a diagram of the apparatus actually used for the gallon size reactions.

EQUIPMENT FOR "1 GALLON" SOIL REACTIONS



5. Procedures for Documentation

During all testing, GRC personnel entered observations and data into bound laboratory notebooks. Whenever samples are generated, sample numbers are assigned and recorded in the notebook along with other raw data, such as sample weights and brief descriptions of unusual procedures. Copies of the notebook pages are in Appendix E.

When samples were analyzed by GC or HPLC, peak areas, sample weights, extract volumes and injection volumes were typed into the various spreadsheets used for calculations. Copies of these spreadsheets are in Appendix D. The contents of the spreadsheets are explained in that appendix.

In addition, the sample log for this project contains a record of each sample collected, along with extraction and analysis dates and final results of each analysis. A copy of the sample log is in Appendix C.


6. Results of Bench Testing

The final reactions for this study were done using 6 lb of wet soil, 1 lb of PEG, 1 lb of TMH, 2 lb of DMSO and 3 lb of dry KOH at 165°C ($\pm 2^\circ\text{C}$). Complete data sheets for the reactions are presented in Appendix A.

6.1. PCB Results.

Total PCB in sediment results from monitoring the one gallon final reactions are shown in Figure 6.

Figure 6. New Bedford Gallon Reactions



The PCB concentrations in the final dried soil agreed with the concentrations in the final monitoring samples. The concentration of PCB in the reagents was close to the concentration in the finished soils: 2.8 ppm for the high soil's reagent and 0.6 ppm for the low soil's reagent. The washes contained less than 1 ppm PCB. The low PCB concentrations in reagent and wash water will not interfere with recycling.

The concentrations of PCB in the condensates were several times the concentration of PCB in the finished soil. Transfer of PCB from the reactor to the condensate receiver probably occurs by co-distillation of PCBs with volatile organic compounds from the sediment or by droplet transfer. The condensate had two liquid phases. A small amount of organic liquid was seen floating on top of the condensate - not enough to collect and analyze separately. Analysis of a similar 2-phase condensate from the Bengart and Memel site showed that 99.98% of the PCB remained with the organic phase of the condensate even though there was only about a gallon of organic phase in a 55 gallon drum of condensate. Separation of the organic phase from the water will remove most of the PCBs and make the water suitable for recycling. If PCB removal is not adequate, it will be necessary to treat the

condensates with activated carbon to remove the PCBs before the water can be recycled or disposed of. The cost of such treatment is included in the cost estimate for soil processing.

Table 2 lists the samples analyzed for PCB for each reaction and gives concentrations by homolog (chlorination level).

Table 2. GRC's PCB Results from Gallon Reactions: By Homolog

PCB concentrations in ppm ($\mu\text{g/g}$ sample) except traps. ND = Not Detected
 Soil results, including monitoring samples, are calculated using the dry weight of the soil.
 Detection limit /homolog - soil ,reagent, and condensate: 0.1 ppm, wash water :0.01 ppm, traps: 0.1 μg

REACTION WITH "HIGH PCB" SEDIMENT

| Sample Description | total PCB | 1-Cl | 2-Cl | 3-Cl | 4-Cl | 5-Cl | 6-Cl | 7-Cl | 8-Cl |
|----------------------|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|------|
| Initial Soil | 7300 | 29 | 800 | 2400 | 2100 | 1100 | 730 | 88 | 4.3 |
| Monitoring, 1 hour | 9400 | 32 | 940 | 2900 | 3300 | 1700 | 500 | 42 | 1.5 |
| Monitoring, 2 hour | 5700 | 49 | 750 | 2200 | 1900 | 590 | 170 | 23 | ND |
| Monitoring, 3 hour | 3500 | 27 | 550 | 1700 | 1000 | 160 | 60 | 21 | 2.7 |
| Monitoring, 4 hour | 1600 | 28 | 510 | 720 | 250 | 11 | 32 | 5.8 | 1.3 |
| Monitoring, 5 hour | 480 | 16 | 280 | 160 | 12 | 1.1 | 5.4 | 0.3 | ND |
| Monitoring, 6 hour | 500 | 31 | 370 | 84 | 5.9 | 0.7 | 4.7 | 8 | 1.6 |
| Monitoring, 7 hour | 80 | 8.0 | 61 | 7.0 | 1.7 | 0.3 | 0.6 | 0.4 | 0.2 |
| Monitoring, 8 hour | 23 | 5.0 | 16 | 1.0 | 0.5 | ND | ND | 0.2 | 0.1 |
| Monitoring, 9 hour | 5.6 | 2.7 | 2.6 | 0.1 | ND | ND | ND | ND | ND |
| Monitoring, 10 hour | 6.8 | 5.0 | 1.5 | ND | 0.1 | ND | ND | ND | ND |
| Monitoring, 11 hour | 3.3 | 2.7 | 0.5 | ND | ND | ND | ND | ND | ND |
| Monitoring, 12 hour | 3.7 | 2.8 | 0.5 | ND | ND | ND | 0.2 | ND | ND |
| Final Soil - 4/28/88 | 3.6* | * | 0.6 | 0.3 | 1.8 | 0.6 | 0.1 | ND | ND |
| Final Soil 9/9/88 | 2.8 | 1.3 | 1.1 | 0.1 | ND | ND | ND | ND | ND |
| Reagent | 2.8 | 2.4 | 0.08 | 0.07 | 0.16 | 0.05 | ND | ND | ND |
| Wash 1 | 0.57 | 0.49 | 0.03 | 0.02 | ND | ND | ND | 0.03 | ND |
| Wash 2 | 0.05 | 0.031 | 0.011 | 0.004 | 0.006 | ND | ND | ND | ND |
| Condensate | 330 | 3.4 | 120 | 160 | 42 | 5.5 | 4.0 | 2.1 | 0.8 |
| Adsorbent Trap | 2.0 μg | 0.2 μg | 0.5 μg | 0.2 μg | 0.2 μg | 0.2 μg | 0.5 μg | 0.3 μg | ND |

REACTION WITH "LOW PCB" SEDIMENT

| Sample Description | total PCB | 1-Cl | 2-Cl | 3-Cl | 4-Cl | 5-Cl | 6-Cl | 7-Cl | 8-Cl |
|----------------------|-----------|------|------|------|------|------|-------|------|------|
| Initial Soil | 440 | 0.2 | 49 | 140 | 140 | 56 | 41 | 3.2 | 0.4 |
| Monitoring, 1 hour | 460 | 4.6 | 51 | 150 | 150 | 57 | 34 | 1.0 | 0.2 |
| Monitoring, 2 hour | 130 | 0.7 | 20 | 56 | 46 | 8.0 | 1.8 | 0.4 | 0.8 |
| Monitoring, 3 hour | 92 | 0.5 | 18 | 46 | 26 | 1.1 | 0.1 | 0.2 | ND |
| Monitoring, 5 hour | 17 | 0.6 | 12 | 3.9 | ND | ND | ND | ND | ND |
| Monitoring, 6 hour | 2.7 | 0.2 | 2.3 | 0.2 | ND | ND | ND | ND | ND |
| Monitoring, 7 hour | 2.3 | 0.3 | 1.3 | 0.3 | 0.3 | ND | 0.1 | ND | ND |
| Monitoring, 8 hour | 0.6 | 0.2 | 0.3 | ND | ND | ND | ND | ND | ND |
| Monitoring, 9 hour | 0.5 | 0.2 | 0.1 | ND | ND | ND | ND | ND | ND |
| Final Soil - 4/28/88 | 0.7* | * | 0.2 | ND | 0.2 | 0.1 | 0.1 | ND | ND |
| Final Soil - 9/9/88 | 0.5 | 0.1 | 0.3 | ND | ND | ND | ND | ND | ND |
| Reagent | 0.62 | 0.34 | 0.23 | 0.02 | ND | ND | ND | 0.02 | ND |
| Wash 1 | 0.28 | 0.08 | 0.15 | 0.04 | ND | ND | ND | ND | ND |
| Wash 2 | 0.15 | ND | ND | ND | ND | ND | 0.005 | 0.13 | ND |
| Condensate | 27 | 0.6 | 8.9 | 12 | 4.0 | 0.6 | 0.8 | 0.2 | ND |
| Adsorbent Trap | ND | ND | ND | ND | ND | ND | ND | ND | ND |

*Final soil results of 4/28/88 do not include monochlorobiphenyl.

6.2. Results of Reagent Recovery Study

The reagents, wash waters and soil recovered from processing were analyzed for the components of the reagent: PEG (polyethylene glycol with an average molecular weight of 400), TMH (triethylene glycol methyl ether and higher homologs), DMSO (dimethyl sulfoxide), and KOH (potassium hydroxide). The percentage of the original reagent input found in the various samples were calculated. The results are presented in Table 3.

Table 3. Reagent Recoveries as Percentage of Input

| High PCB Soil Reagent | PEG | TMH | DMSO | KOH |
|-----------------------|-------|------|------|------|
| Wash 1 | 28.5 | 5.5 | 5.8 | 15.1 |
| Wash 2 | 1.3 | 1.1 | 1.3 | 5.1 |
| Soil Residual | 0.9 | 0.3 | 0.3 | 1.1 |
| Total % Recovery | 110.8 | 87.0 | 78.6 | 80.0 |

| Low PCB Soil Reagent | PEG | TMH | DMSO | KOH |
|----------------------|------|------|------|------|
| Wash 1 | 5.6 | 12.8 | 11.9 | 29.8 |
| Wash 2 | 3.7 | 1.2 | 1.5 | 4.3 |
| Soil Residual | 0.2 | 0.4 | 0.4 | 1.2 |
| Total % Recovery | 94.2 | 85.2 | 75.5 | 75.9 |

Of the four reagent components, KOH washed out slowest, although overall recovery of KOH agreed with recovery of DMSO. The PEG recoveries are higher than those of TMH. Since PEG analysis has a large inherent error associated with it and tends to be biased toward false high results, the difference between PEG and TMH recoveries may not be significant. DMSO recoveries were lower than TMH and since the two analyses have a similar level of uncertainty, the difference is significant. DMSO is the most expensive component of the reagent, and its lower recovery will have an impact on process cost.

During pilot studies for another site with fine grained soil, significant amounts of DMSO were found in the process condensate. PEG and TMH were found in the condensate only when reactor foaming carried reagent through the distillation line. Design changes for the full scale unit include measures to recover the DMSO from the condensate either by reverse osmosis or by fractional distillation (using a taller column than was used in the pilot reactor). If it is necessary to treat the condensate with activated carbon to remove PCBs, the carbon treatment should be done before DMSO recovery. PEG, TMH, and DMSO are water soluble and should not adsorb to carbon as strongly as PCB. They should not interfere with carbon treatment. Carbon treatment should be tested at the pilot stage to check the effect of reagent components and verify costs. Based on GRC's experience at the other site, it can be assumed that the missing DMSO from the New Bedford reactions is in the condensate. The missing KOH was probably consumed in side reactions with the soil.

In general, laboratory recovery of reagent is less than pilot test recoveries. In studies preceding treatment of the Bengart & Memel site, 98+% reagent recoveries were actually achieved in pilot tests. That soil was extremely rocky and does not resemble New Bedford sediment. Since reagent recovery analysis was not done during lab testing for that site, data to compare with the pilot study results do not exist.

In recent lab and pilot studies for a fine grained soil site, reagent recoveries from pilot tests were 10 - 18% higher than they had been for lab tests. For example, the average recovery for DMSO was 64% in the lab and 89% in the pilot. The soil from the other site was not quite as finely divided as New Bedford sediment. It required centrifugation in the pilot study because it clogged filters similar to those used in the lab study. Based on the improvement in recovery seen at the other site, reagent recoveries for New Bedford sediment are expected to improve substantially as the process is scaled up.

6.3. Results of Soil Washing Test


Samples of the soil were taken after each stage of reagent removal and washing so that the number of washes required can be estimated. The results are in Table 4.

Table 4. Results of Soil Washing Test

| | Concentrations in mg/g wet soil | | | |
|----------------------|---------------------------------|------|------|-----|
| | PEG | TMH | DMSO | KOH |
| High PCB Soil | | | | |
| After Reagent Drain | 15.8 | 12.3 | 30.6 | 133 |
| After Wash 1 | 18.3 | 4.1 | 15.3 | 71 |
| After Wash 2 | 5.8 | 2.1 | 4.3 | 22 |
| Low PCB Soil | | | | |
| After Reagent Drain | 2 | 7.6 | 18.2 | 162 |
| After Wash 1 | 1.9 | 4.1 | 12.7 | 62 |
| After Wash 2 | 1.4 | 2.3 | 4.4 | 21 |

Since PEG, TMH, and DMSO are relatively non-toxic and there are no guidelines set for allowable concentrations in soil or sediment, the major concern for soil washing is reducing the pH of the processed soil to an acceptable level. In order for the pH of the treated soil to be below 9, as required for the soil to be classified as non-caustic, the concentration of KOH in the soil would have to be less than 0.00056 mg/g (10^{-5} M). To achieve this low KOH concentration without neutralizing would require roughly 14 washes as shown in the Figure 7.

Figure 7. KOH Removal by Washing Alone



This large number of washes is impractical, and would probably be less costly to neutralize the KOH with acid to achieve the desired pH. the cost of such neutralization is included in the estimate of processing costs (see Section 8.)

The residual levels of PEG/TMH/DMSO indicate a potential recovery of 99.4-99.8% for a full scale operation.

6.4. Results of CLP Lab Analysis

In addition to the analyses done by GRC, samples from the gallon reactions were analyzed by another lab according to EPA's Contract Laboratory Protocol (CLP). A copy of the CLP results is in Appendix B. Some of the CLP analyses duplicated analyses done by GRC. The results of these analyses are shown in Table 5.

Table 5. Comparison of Galson and CLP Results

PCB results are in ppm (ug/g) based on dry soil.

| Analysis | Untreated High Soil | | Treated High Soil | | |
|---------------------|---------------------|------|-------------------|----------|-----|
| | Galson (GRC) | CLP | GRC 4/88 | GRC 9/88 | CLP |
| Total PCB | 7300 | | *3.5 | 2.8 | |
| Aroclor 1242 | | 8500 | | | ND |
| Aroclor 1254 | | 3200 | | | ND |
| Monochlorobiphenyl | 29 | 47 | * | 1.3 | 110 |
| Dichlorobiphenyl | 800 | 1600 | 0.6 | 1.1 | 40 |
| Trichlorobiphenyl | 2400 | 4200 | 0.3 | 0.1 | ND |
| Tetrachlorobiphenyl | 2100 | 4600 | 1.8 | ND | ND |
| Pentachlorobiphenyl | 1100 | 2000 | 0.6 | ND | ND |
| Hexachlorobiphenyl | 730 | 440 | 0.1 | ND | ND |
| % Solids | 32 | 31.2 | 55 | | 60 |

| Analysis | Untreated Low Soil | | Treated Low Soil | | |
|---------------------|--------------------|------|------------------|----------|-----|
| | Galson (GRC) | CLP | GRC 4/88 | GRC 9/88 | CLP |
| Total PCB | 440 | | *0.7 | 0.5 | |
| Aroclor 1242 | | 100 | | | ND |
| Aroclor 1254 | | 51 | | | ND |
| Monochlorobiphenyl | 0.2 | ND | * | 0.1 | 5.8 |
| Dichlorobiphenyl | 49 | ND | 0.2 | 0.3 | ND |
| Trichlorobiphenyl | 140 | ND | ND | ND | ND |
| Tetrachlorobiphenyl | 140 | ND | 0.2 | ND | ND |
| Pentachlorobiphenyl | 56 | ND | 0.1 | ND | ND |
| Hexachlorobiphenyl | 41 | ND | 0.1 | ND | ND |
| % Solids | 38.8 | 40.7 | 55 | | 55 |

*Final soil results of 4/28 do not include monochlorobiphenyl

GRC'S results for monochlorobiphenyl (1-Cl) in the 4/28 analysis of the final soil were not reportable because the results did not pass QA criteria. These samples were be re-analyzed and the results are reported above.

The PCB results did not agree well between the two labs. It is interesting to note that the contract lab found more monochlorobiphenyl in the treated high soil than they found in the untreated high soil. Since converting more highly chlorinated PCBs to monochlorobiphenyl is highly unlikely in KPEG processing (see reactions in Section 1), the results reported for as monochlorobiphenyl by the contract lab are probably the result of interference. The contract lab also found pesticides in the reagent and wash waters from the gallon reactions. These pesticides were not found in the untreated soil and their chemical structures are unlikely to be generated during processing. The detection method for these "pesticides" was GC/ECD (gas chromatography with electron capture detection) and it is quite possible that the peaks that were quantified and reported as pesticides were actually interfering compounds. It is equally likely that some of the peaks reported as PCB were interfering compounds. One such compound might be the sulfur that GRC found in its advance testing reactions.

It is fairly normal to have some lab to lab variation in PCB results, especially when the matrix contains severe interferences as this sediment does. Contract Lab Protocols are designed to meet the widest variety of situations and are not specifically tailored to any one type of matrix. GRC has had a great deal of experience with PCB analysis in association with KPEG treatment and uses extraction and cleanup methods tailored to the demands of KPEG processing. GRC has also found, identified, and removed one of the sources or interference for this sediment. Because of GRC's greater analytical flexibility and the unusual problems in analyzing KPEG treated soils by "generic" methods, GRC's results are more likely to be accurate than the results from the contract lab.

7. Effects of Varying Operating Parameters

The series of small reactions done for this project indicated that KOH concentration is the most important parameter for the reagent formulation. Reactions of the high PCB soil done without adequate KOH failed to reduce the PCB concentrations to <10 ppm even after 24 hours of reaction. The reagent recovery results suggest that some of the KOH is consumed by the soil. The need for increased amounts of KOH will increase the cost of processing somewhat.

GRC's previous experience indicates that temperatures under 120°C result in very slow reactions because water is distilled out of the reaction slurry very slowly at that temperature. Generally, the reaction temperature should be as hot as possible while minimizing the loss of DMSO, which boils at 190°C. There was some loss of DMSO at 165°C, but it is uncertain whether the loss was due to volatilization or decomposition. Analysis of condensates for DMSO was not possible in this project because the entire condensate was needed for PCB analysis. DMSO has been found in condensates from other projects, but quantitative relationship between reaction temperature and DMSO distillation has not been established. Since condensate water will be recycled, DMSO in the condensate is not lost from the processing system and is ultimately returned to the reagent. For that reason, distillation of DMSO will not have a strong effect on process costs, but decomposition of DMSO will increase process costs. This is a factor that will need investigation at the pilot stage.

Heatup should be done as quickly as possible without causing violent boiling. GRC's experience with other soils indicates that slow heating results in sluggish reaction rates. The maximum possible heatup rate will be strongly dependent on the equipment design. For example, using two condensers (for the final gallon reactions) instead of one (as in the practice gallon reaction) facilitated control of the reaction so that more rapid heating could be done.

8. Estimate of Full Scale Processing Cost

Estimation of full scale processing costs from laboratory data requires the use of a great many assumptions about site conditions, processing rates, interest rates, maintenance costs etc. This is unavoidable, and accounts for much of the uncertainty in these numbers. The estimated costs of processing for the New Bedford site are divided into 3 sections; pre-treatment costs, reagent/waste disposal costs, and summary of costs for operation of both a 50,000 cubic yard site and a 500,000 cubic yard site.

8.1. Pre-treatment Costs

If it is assumed that the sediments for processing are to be dredged from the harbor, they will be accumulated and stockpiled at a much faster rate than they can be processed. The dredged material will presumably have a moisture content of about 60%, as did the samples supplied to GRC. Allowing this material to stand and drain should reduce this to an estimated 30% moisture level. This should not result in any additional costs over the existing costs of excavation. No additional pre-treatment is planned or required.

8.2 Reagent/Waste Disposal Costs

The reagent consumed by the process is essentially the reagent used to react the PCBs plus the reagent remaining in the soil following treatment. At an average concentration of 5000 ppm and a density of 3000 lb/cubic yard, each yard of soil would contain 15 lb of PCB. Assuming an average 50% chlorine level in the PCB, there would be about 7.5 lb chloride per cubic yard of soil. This 0.21 lb-mols of chloride would take approximately 8.2 bl of potassium for reaction, giving a consumption of 11.8 lb of KOH/cubic yard soil. At a cost of \$.17/lb KOH, this gives a cost of \$2.00/cubic yard soil for KOH consumed by the PCB.

Residual soil concentrations and associated costs for the reagent components are listed in the table below. The hydrochloric acid (HCl) listed is used to neutralize the residual KOH to form KCl (salt substitute) and water.

| Component | mg/g | lb/cubic yard | \$/lb reagent | \$/cubic yard soil |
|-----------|---------|---------------|---------------|--------------------|
| PEG 400 | 1.4-5.8 | 4.2-17.4 | 0.61 | 2.56-10.61 |
| TMH | 2.1-2.3 | 6.3-6.9 | 0.57 | 3.59-3.93 |
| DMSO | 4.3-4.4 | 12.9-13.2 | 0.82 | 10.58-10.82 |
| KOH | 21-22 | 63-66 | 0.17 | 10.71-11.22 |
| HCl | | 40-42 | 0.09 | 3.6-3.8 |
| Total | | | | 31.04-40.38 |

As shown in the table above, the bulk of the residual reagent is inorganic salt, and it will probably not be possible to distinguish the KCl formed during processing from the KCl naturally occurring in the sea water saturating the untreated soil.

The remaining organics in the treated soil amount to less than 1% of the soil mass and are essentially non-toxic. Indeed, the glycols and sulfoxide (LD₅₀ about 13,000 mg/kg) are three times less toxic than the NaCl present in the salt water (LD₅₀ about 3500 mg/kg). The total cost of residual reagent in the soil plus the KOH used by the PCB comes to 33-43\$/cubic yard of soil. A budget figure of \$50/cubic yard of soil is used for purposes of calculation.

Waste disposal for this process is primarily the off-site disposal of any oils distilled from the soil during processing and the periodic removal and off-site incineration of accumulated salts and humic acids from the reagent recycle tank. The volume of such material is small, and a nominal figure of \$10/ton soil is used for estimation purposes.

8.3 Operating Cost Summaries

The following table gives a summary of the assumptions and cost factors for a cleanup of 50,000 cubic yards of contaminated soil at the New Bedford site. Changes in any of these assumptions would give a change in the estimated processing costs.

ASSUMPTIONS

| | | |
|--|-----------|--|
| Nominal processing rate, yards/batch | 60 | (double reactor unit) |
| estimated average cycle time, hours | 8 | (assumes 10 ppm cleanup goal) |
| processing hours/day | 24 | 365 day operation |
| estimated % processing time | 80% | |
| Average processing rate, yards/hour | 6.00 | yards/year= 52,560 |
| depreciation, %/year | 20% | |
| maintenance costs, % of capital/year | 20% | |
| capital cost, \$ | \$2400000 | includes engineering and construction] |
| average soil moisture level | 30% | |
| fuel oil costs, \$/million btu | \$10 | |
| office overhead factor | 2.5 | |
| field overhead factor | 1.5 | |
| salaries, \$/hour | | |
| field manager/chemist | \$20.0 | |
| field operator | \$15.0 | |
| Total cubic yards to be processed | 50000 | yrs cleanup = 0.95 |
| Permitting handled by prime contractor | | |

Reagent costs as noted below (bulk cost used for estimate)

| | Bulk cost | Drum cost |
|----------------|-----------|-----------|
| KOH cost \$/# | \$0.17 | \$0.19 |
| TMH cost \$/# | \$0.57 | \$0.65 |
| DMSO cost \$/# | \$0.82 | \$0.94 |
| PEG cost \$/# | \$0.61 | \$0.69 |
| HCl cost \$/# | | \$0.09 |

| Costs for processing (no profit) | # units | cost/unit | unit | total cost \$ | Comments |
|--|---------|-----------|------------|---------------|-------------------------------|
| 1. Electrical power/phone service | | | project | \$150,000 | |
| 2. personal protective equipment | 1389 | \$40 | man-day | \$55,556 | |
| 3. reagent | 50000 | \$50 | cubic yard | \$2,500,000 | to be confirmed during pilot |
| 4. waste disposal | 50000 | \$10 | cubic yard | \$500,000 | to be confirmed during pilot |
| 5. field labor | | | | | |
| field manager | 9167 | \$30 | hour | \$275,000 | |
| field operator | 9167 | \$23 | hour | \$206,250 | includes 10% training time |
| 6. office support | | | | | |
| senior scientist/chemist | 1375 | \$75 | hour | \$103,125 | |
| travel/per diem | 115 | \$600 | trip | \$68,750 | |
| 7. fuel costs | 50000 | \$6 | cubic yard | \$300,000 | |
| 8. depreciation | | | project | \$456,621 | |
| 9. maintenance | | | project | \$480,000 | |
| 10. Per diem/travel | 50 | \$2,200 | week | \$109,127 | |
| 11. Pilot testing | | | | — | separate line item for budget |
| 12. Demurrage on tank trucks | | | project | \$40,000 | |
| 13. Mobilization/demobilization | | | project | \$200,000 | |
| estimated processing cost | | | | \$5,444,429 | |
| contingency and misc.(15% of est cost) | | | | \$816,664 | |
| profit (20% of est cost) | | | | \$1,088,886 | |
| Total job cost | | | | \$7,349,979 | |

$$\$/\text{Cubic Yard SOIL} = \$147 \\ \$/\text{ton} = 98$$

Raising the volume of soil to be treated to 500,000 cubic yards significantly reduces the costs of processing, as shown in the following table.

ASSUMPTIONS

| | | |
|--|-----------|---------------------------------------|
| Nominal processing rate, yards/batch | 180 | (twin triple reactor units) |
| estimated average cycle time, hours | 8 | (assumes 10 ppm cleanup goal) |
| processing hours/day | 24 | 365 day operation |
| estimated % processing time | 80% | |
| Average processing rate, yards/hour | 18.00 | yards/year= 157,680 |
| depreciation, %/year | 20% | |
| maintenance costs, % of capital/year | 20% | |
| capital cost, \$ | \$8500000 | includes engineering and construction |
| average soil moisture level | 30% | |
| fuel oil costs, \$/million btu | \$10 | |
| office overhead factor | 2.5 | |
| field overhead factor | 1.5 | |
| salaries, \$/hour | | |
| field manager/chemist | \$20.0 | |
| field operator | \$15.0 | |
| Total cubic yards to be processed | 500000 | yrs cleanup = 3.17 |
| Permitting handled by prime contractor | | |

Reagent costs as noted below (bulk cost used for estimate)

| | Bulk cost | Drum cost |
|-------------|-----------|-----------|
| KOH cost/# | \$0.17 | \$0.19 |
| TMH cost/# | \$0.57 | \$0.65 |
| DMSO cost/# | \$0.82 | \$0.94 |
| PEG cost/# | \$0.61 | \$0.69 |

| Costs for processing (no profit) | # units | cost/unit | units | total cost \$ |
|--|---------|-----------|------------|---------------------------------|
| 1. Electrical power/phone service | | | \$750,000 | |
| 2. personal protective equipment | 4630 | \$40 | man-day | \$185,185 |
| 3. reagent | 500000 | \$50 | cubic yard | \$25,000,000 |
| 4. waste disposal | 500000 | \$10 | cubic yard | \$5,000,000 |
| 5. field labor | | | | to be confirmed during pilot |
| field manager | 30556 | \$30 | hour | \$916,667 |
| field operator | 30556 | \$23 | hour | \$687,500 |
| support chemist | 15278 | \$26 | hour | \$401,042 |
| 6. office support | | | | includes 10% training time |
| senior scientist/chemist | 4583 | \$75 | hour | \$343,750 |
| travel/per diem | 382 | \$600 | trip | \$229,167 |
| 7. fuel costs | 500000 | \$6 | cubic yard | \$3,000,000 |
| 8. depreciation | | | project | \$5,390,665 |
| 9. maintenance | | | project | \$1,700,000 |
| 10. Per diem/travel | 248 | \$2,200 | week | \$545,635 |
| 12. Demurrage | | | project | \$40,000 |
| 14. Mobilization/demobilization | | | project | \$400,000 |
| estimated processing cost | | | | \$44,589,610 est \$/yard = \$89 |
| contingency and misc.(15% of est cost) | | | | \$6,688,441 |
| profit (20% of est cost) | | | | \$8,917,922 |
| Total job cost | | | | \$60,195,973 |

\$/Cubic Yard SOIL = \$120
\$/ton = \$80

9. Process Optimization

The primary tool for process optimization is the pilot plant. During pilot testing a 1/100 size reactor (40 gallon) is used to simulate the operation of the full scale process. This equipment is large enough to allow quantitative scaleup to the full size equipment, but small enough to allow inexpensive operation. Using the pilot plant, it is possible to test a wide variety of equipment and procedure modifications at relatively low cost. Pilot testing of the KPEG process was done during the summer of 1988 at a site with fine grained soil. Since that soil was slightly different from New Bedford sediment, a pilot study using New Bedford sediment would be necessary to optimize the process for the New Bedford site.

10. Information Specific to KPEG Processing

10.1. Destruction and Removal Efficiencies

Table 6 shows the data used to calculate the PCB destruction and removal efficiencies for the gallon reactions.

Table 6. Calculation of Destruction & Removal Efficiencies

| <u>High Soil Reaction</u> | Pounds | Kilograms | PCB, mg/kg | mg PCB |
|-------------------------------|--------|-----------|------------|--------|
| Input | | | | |
| Initial Soil (dry basis) | 2.0 | 0.9 | 7300.0 | 6477.1 |
| Outputs | | | | |
| Final Soil (dry basis) | 0.8 | 0.4 | 27.0 | 10.1 |
| Reagent | 8.9 | 4.0 | 2.8 | 11.3 |
| Wash 1 | 7.3 | 3.3 | 0.6 | 1.9 |
| Wash 2 | 6.1 | 2.8 | 0.1 | 0.1 |
| Condensate | 3.4 | 1.5 | 330.0 | 510.0 |
| Vent trap | NA | NA | NA | 0.0 |
| Sum of Outputs | | | | 533.5 |
| Destruction Efficiency | | | 91.8% | |
| Removal efficiency | | | 99.8% | |
| <u>Low Soil Reaction</u> | Pounds | Kilograms | PCB, mg/kg | mg PCB |
| Input | | | | |
| Initial Soil - dry basis | 2.3 | 1.0 | 440.0 | 460.0 |
| Outputs | | | | |
| Final Soil - dry basis | 0.9 | 0.4 | 1.9 | 0.8 |
| Reagent | 7.3 | 3.3 | 0.6 | 2.1 |
| Wash 1 | 8.5 | 3.9 | 0.3 | 1.1 |
| Wash 2 | 6.1 | 2.8 | 0.2 | 0.4 |
| Condensate | 2.9 | 1.3 | 27.0 | 35.6 |
| Vent trap | NA | NA | NA | ND |
| Sum of Outputs | | | | 39.9 |
| Destruction Efficiency | | | 91.3% | |
| Removal efficiency | | | 99.8% | |

Destruction efficiency is defined as the percentage of PCB destroyed by the process. It is calculated by dividing the total mg of PCB in all process outputs by the mg of PCB in the untreated soil and multiplying by 100. Destruction efficiencies were 91.8 % for the high PCB soil reaction and 91.3 % for the low PCB soil reaction. Most of the PCB that was not destroyed was in the condensate.

Removal efficiency is defined as the percentage of PCB removed from the soil by the process. Removal efficiency was calculated by dividing the mg of PCB in the finished soil by the mg PCB in the untreated soil and multiplying by 100. Total removal was the sum of destruction, distillation and washing effects. Removal efficiencies were 99.8 % for both high and low soil reactions.

Since destruction and removal efficiencies were calculated based on the analysis of each reaction compartment, and since total mass recoveries were 95% or greater for both reactions (see Appendix A), it is not necessary to correct the figures for "lost" material. The mass balance shows that the non-recovered sediment remained in the reagents and washes. Its PCB content was therefore included in the PCB analysis of the liquid containing it.

10.2. Toxicity of Reaction Products

Both pure reaction products and treated soil from KPEG processing have been subjected to acute oral toxicity testing (using guinea pigs) and Ames testing for mutagenicity. The reaction products and treated soil are non-toxic and non mutagenic

10.3. Reagent Residuals in Processed Soil

After two washes, 4 mg/g of PEG, 2 mg/g of TMH, 4 mg/g of DMSO and 20 mg/g of KOH remained in the soil (see Section 6.3). Of these components, the major hazard is the KOH, which can be neutralized with acid to form a harmless salt. PEG, TMH, and DMSO are relatively non-toxic and there are no current guidelines for concentrations of these compounds in soil or water. If lower concentrations are desired, the number of washes could be increased. Table 7. provides estimates of residual concentrations of the reagent components as the number of washes is increased. The concentrations after the first two washes are taken from the soil washing study described in section 6.3.

Table 7. Estimated Reagent Residuals with Increased Washing

| | Reagent concentrations in mg/g wet soil | | | |
|----------------------|---|------|------|-------|
| | PEG | TMH | DMSO | KOH |
| After Reagent Drain* | 8.9 | 9.95 | 24.4 | 147.5 |
| After Wash 1* | 10.1 | 4.1 | 14 | 66.5 |
| After Wash 2* | 3.6 | 2.2 | 4.35 | 21.5 |
| After Wash 3 | 2.8 | 1 | 2 | 8.7 |
| After Wash 4 | 1.8 | 0.5 | 0.9 | 3.3 |
| After Wash 5 | 1.1 | 0.2 | 0.4 | 1.3 |
| After Wash 6 | 0.7 | 0.1 | 0.2 | 0.5 |
| After Wash 7 | 0.5 | 0.05 | 0.06 | 0.2 |

*averages of high and low soil results from Section 6.3

The number of washes selected will depend on client wishes and on the requirements of the various regulatory agencies governing the New Bedford Harbor remediation. Each additional wash will increase the cycle time and labor and will therefore increase the cost of processing.

10.4. Separation of Fine Grained Sediment from Reagent and Wash Water

The separation method used for this project was centrifugation at 2200 G (2200 x normal gravity). Materials were fed into the centrifuge by pouring from a gallon jar into a funnel positioned at the centrifuge inlet. The liquid recovered was fed through the centrifuge a second time in an attempt to improve the separation. The feed rate was approximately half a gallon per minute. Although GRC recovered more than 95% of the total mass of soil reagent and wash water, the recovery of soil (on a dry weight basis) averaged only 43%. This indicates that substantial quantities of fine particles were left with the reagent and wash water. As this process is scaled up, it will be necessary to improve the recovery of fine grained sediments. This could be accomplished by using coagulation aids such as ferrous sulfate, by using settling tanks and holding the reagent and wash water for longer time periods, or by improving the efficiency of centrifugation by controlling the feed rate and/or increasing the G force applied.

During recent pilot scale work at another site with fine grained soil, reagent, condensate and wash water were recycled through a series of reactions. The first reaction had the lowest soil recovery: 60%. The other reactions had higher recoveries - up to 84%. Apparently, soil particles and humic acids are suspended or dissolved in reagents and washes. After a few reactions, they build up to an equilibrium concentration. When the equilibrium concentration is reached, the solids no longer accumulate in the system. Also, portions of the soil may actually react with the reagent to form water soluble salts such as calcium hydroxide. Such reactions would result in a loss of soil mass that would not be recovered until the salts build up to their solubility point, which could take dozens of reactions. If water is recovered by distillation or reverse osmosis, solids recovery would be accelerated. In the pilot study, dark brown solids were seen in the bottom of the still used to reclaim reagent from wash water after the fifth reaction. The solids were largely soluble in water. They were probably accumulated potassium salts of humic acid and other salts from processing.

After the recent pilot study, a 50 lb sample of reaction slurry was sent to the centrifuge manufacturer for optimization tests. GRC's pilot study soil recoveries ranged from 60 to 84% for reaction, reagent removal and three washes. At the same centrifuge speed, using varied feed rates, the manufacturer obtained recoveries between 81 and 95% for the reagent removal and three washes. These data clearly show the importance of controlling the feed rate during centrifuge operations.

10.5. Effect of Water on KPEG Processing

Water quenches the KPEG dechlorination of PCBs, but in this project, GRC has demonstrated wet soils can be treated by the KPEG process because water is removed as the reaction is heated. There is a cost involved in the energy required to boil off large quantities of water, and if some of the water can be drained off before processing, some energy, and therefore some money could be saved.

Appendix A.

Data Sheets for Gallon Reactions

Data for 1 Gallon Reaction with New Bedford "High PCB" Soil

| A | B | C | D | E | F | G |
|----------------|---|--------------------|------------|-------------------|------------------------|-------|
| Inputs | pounds | Outputs | pounds | | Other Parameters | |
| Untreated Soil | 6.1 | Treated Soil | 1.5 | | Max temp, °C | 167°C |
| Reagent | 7.0 | Reagent | 8.9 | | Sulfoxide used | DMSO |
| water (at end) | 3.5 | condensate | 3.4 | | | |
| | | Slurry samps | 0.2 | list below | | |
| | | Soil samps | 0.4 | lines 45 & 50 | | |
| Wash 1 | 6.0 | Wash 1 | 7.3 | | | |
| Wash 2 | 6.0 | Wash 2 | 6.1 | | | |
| Total Inputs | 28.6 | Total Outputs | 27.8 | 97% Mass Recovery | | |
| 10 | | | | | | |
| 11 | Sample number | g slurry | g dry soil | ppm PCB | Reaction time (hours) | |
| 12 | R70078803310700SJR | 9.8 | 1.1 | 9400 | 1 | |
| 13 | R70078803310800SJR | 8.1 | 0.9 | 5700 | 2 | |
| 14 | R70078803310900SJR | 6.9 | 0.9 | 3500 | 3 | |
| 15 | R70078803311000SJR | 8.3 | 1.1 | 1600 | 4 | |
| 16 | R70078803311100SJR | 8.6 | 1.3 | 480 | 5 | |
| 17 | R70078803311200SJR | 7.2 | 1.0 | 500 | 6 | |
| 18 | R70078803311300SJR | 8.9 | 1.4 | 80 | 7 | |
| 19 | R70078803311400SJR | 7.2 | 1.2 | 23 | 8 | |
| 20 | R70078803311500SJR | 9.9 | 1.8 | 5.6 | 9 | |
| 21 | R70078803311600STG | 9.9 | 1.5 | 6.8 | 10 | |
| 22 | R70078803311700STG | 8.6 | 1.2 | 3.3 | 11 | |
| 23 | R70078803311800STG | 6.9 | 1.0 | 3.7 | 12 | |
| 24 | total g | 100.3 | 14.4 | | | |
| 25 | total pounds | 0.22066 | 0.03168 | | | |
| 26 | | | | | | |
| 27 | INITIAL SOIL, SAMPLE # | R70078803300940SJR | | 7300 | 0 | |
| 28 | CONDENSATE, SAMPLE # | R70078803311800CRG | | 330 | | |
| 29 | ADSORBENT TRAP, SAMPLE # | R70078803311800DRG | 2 µg total | | | |
| 30 | DRIED FINAL SOIL, SAMPLE# | R70078804251025SRG | | 3.5 | 4/28/88, without mono- | |
| 31 | FINAL SOIL, SAMPLE# | R70078804251025SRG | | 2.8 | 9/9/88, with mono- | |
| 32 | | | | | | |
| 33 | GROSS MASS BALANCE FOR REACTION | | | | | |
| 34 | | | | | | |
| 35 | Total mass weighed into reactor (in pounds) | 16.6 | | | | |
| 36 | Total mass of samples removed from reactor | 0.2 | | | | |
| 37 | Total mass in reactor at end of reaction | 12.5 | | | | |
| 38 | Mass of condensate collected from reactor | 3.4 | | | | |
| 39 | Mass lost during reaction and sampling | 0.5 | | | | |
| 40 | | | | | | |
| 41 | GROSS MASS BALANCE FOR SOIL WASHING | | | | | |
| 42 | | | | | | |
| 43 | Mass in reactor after reaction | 12.5 | | | | |
| 44 | Mass of reagent recovered | 8.9 | | | | |
| 45 | Mass in apparatus after reagent removal | 3.6 | | | | |
| 46 | Sample taken after reagent drain | 0.1 | | | | |
| 47 | | | | | | |
| 48 | Mass of wash 1 added | 6.0 | | | | |
| 49 | Mass of wash 1 recovered | 7.3 | | | | |
| 50 | Mass in apparatus after Wash #1 | 2.3 | | | | |
| 51 | Sample taken after wash 1# | 0.2 | | | | |
| 52 | | | | | | |
| 53 | Mass of wash 2 added | 6.0 | | | | |
| 54 | Mass of wash 2 recovered | 6.1 | | | | |
| 55 | Mass in apparatus after Wash #2 | 2.2 | | | | |
| 56 | | | | | | |
| 57 | Dry soil recovered | 1.5 | | | | |
| 58 | Mass lost in filtration and soil drying | 0.7 | | | | |

Data for 1 Gallon Reaction with New Bedford "Low PCB" Sediment

| A | B | C | D | E | F | G |
|--|--------------------|----------------------|-----------|------------------------|------------------|------|
| 1 Inputs | pounds | Outputs | pounds | | Other Parameters | |
| 2 Untreated Soil | 6.0 | Treated Soil | 1.7 | | Max temp, °C | 164 |
| 3 Reagent | 7.0 | Reagent | 7.3 | | Sulfoxide used | DMSO |
| 4 Water (at end) | 3.4 | condensate | 2.9 | | | |
| 5 | | Slurry samps | 0.2 | list below | | |
| 6 | | Soil samps | 0.3 | lines 42 &47 | | |
| 7 Wash 1 | 6.0 | Wash 1 | 8.5 | | | |
| 8 Wash 2 | 6.0 | Wash 2 | 6.1 | | | |
| 9 Total Inputs | 28.4 | Total Outputs | 27.0 | 95% Mass Recovery | | |
| 10 | | | | | | |
| 11 Sample number | g slurry | g dry soil | ppm PCB | Reaction time (hours) | | |
| 12 R70078804050700SJR | 10.4 | 1.3 | 460 | 1 | | |
| 13 R70078804050800SJR | 9.6 | 1.2 | 130 | 2 | | |
| 14 R70078804050900SJR | 9.9 | 1.4 | 92 | 3 | | |
| 15 R70078804051000SJR | 9.6 | lost | lost | 4 | | |
| 16 R70078804051100SJR | 8.5 | 1.6 | Not Valid | 5 | | |
| 17 R70078804051200SJR | 10.1 | 1.8 | 2.7 | 6 | | |
| 18 R70078804051300SJR | 7.4 | 1 | 2.3 | 7 | | |
| 19 R70078804051400SJR | 9.8 | 1.6 | 0.59 | 8 | | |
| 20 R70078804051500SJR | 8.5 | 1.5 | 0.48 | 9 | | |
| 21 total g | 83.8 | 11.4 | | | | |
| 22 total pounds | 0.18436 | 0.02508 | | | | |
| 23 | | | | | | |
| 24 INITIAL SOIL SAMPLE# | R70078804041200SJR | | 440 | 0 | | |
| 25 CONDENSATE SAMPLE# | R70078804051500CRG | | 27 | | | |
| 26 ADSORBENT TRAP, SAMPLE# | R70078804051800DRG | N.D. (<1 ug in trap) | | | | |
| 27 DRIED FINAL SOIL SAMPLE# | R70078804221059SRG | | 0.7 | 4/28/88, without mono- | | |
| 28 FINAL SOIL SAMPLE# | R70078804221120SRG | | 0.5 | 9/8/88, with mono- | | |
| 29 | | | | | | |
| 30 GROSS MASS BALANCE FOR REACTION | | | | | | |
| 31 | | | | | | |
| 32 Total mass weighed into reactor (in pounds) | 16.4 | | | | | |
| 33 Total mass of samples removed from reactor | 0.2 | | | | | |
| 34 Total mass in reactor at end of reaction | 12.6 | | | | | |
| 35 Mass of condensate collected from reactor | 2.9 | | | | | |
| 36 Mass lost during reaction and sampling | 0.7 | | | | | |
| 37 | | | | | | |
| 38 GROSS MASS BALANCE FOR SOIL WASHING | | | | | | |
| 39 | | | | | | |
| 40 Mass in reactor after reaction | 12.6 | | | | | |
| 41 Mass of reagent recovered | 7.3 | | | | | |
| 42 Mass in apparatus after reagent removal | 5.3 | | | | | |
| 43 Sample taken after reagent drain step | 0.1 | | | | | |
| 44 | | | | | | |
| 45 Mass of wash 1 added | 6.0 | | | | | |
| 46 Mass of wash 1 recovered | 8.5 | | | | | |
| 47 Mass in apparatus after Wash #1 | 2.7 | | | | | |
| 48 Sample taken after wash #1 | 0.2 | | | | | |
| 49 | | | | | | |
| 50 Mass of wash 2 added | 6.0 | | | | | |
| 51 Mass of wash 2 recovered | 6.1 | | | | | |
| 52 Mass in apparatus after Wash #2 | 2.6 | | | | | |
| 53 | | | | | | |
| 54 Wet soil recovered | 1.7 | | | | | |
| 55 Mass lost in soil washing | 0.9 | | | | | |

Appendix B.

Results of CLP Analysis

SUMMARY TABLE

PROJECT: NEW BEDFORD HARBOR

| SAMPLE LOCATION: | | | PRE-TEST SEDIMENT RESULTS (GALSON) | | POST-TEST RESULTS (GALSON) | | | | | |
|---------------------------------|---------------|------------|------------------------------------|---------------|-----------------------------|-----------------------------|-----------------------------|-----------------------------|-----------------------------|-----------------------------|
| | SMO NUMBER: | UNITS: | G-LL ug/kg | G-LL ug/kg | HS/WASH 1 AK350 ug/kg | LS/WASH 1 AK351 ug/kg | HS/WASH 2 AK352 ug/kg | LS/WASH 2 AK353 ug/kg | HS/REAGENT AK354 ug/l | LS/REAGENT AK355 ug/l |
| SEMI-VOLATILE ORGANIC COMPOUNDS | CRDL ug/kg | | | | | | | | | |
| 1,3 - Dichlorobenzene | 330 | 22000 J | 430 J | | NR | NR | NR | NR | NR | NR |
| 1,4 - Dichlorobenzene | 330 | 60000 J | 620 J | | NR | NR | NR | NR | NR | NR |
| 4-Methylphenol | 330 | - | - | | NR | NR | NR | NR | NR | NR |
| 1,2,4 - Trichlorobenzene | 330 | 60000 J | - | | NR | NR | NR | NR | NR | NR |
| Naphthalene | 330 | - | 230 J | | NR | NR | NR | NR | NR | NR |
| 2-Methylnaphthalene | 330 | - | 180 J | | NR | NR | NR | NR | NR | NR |
| Acenaphthylene | 330 | - | 740 J | | NR | NR | NR | NR | NR | NR |
| Acenaphthene | 330 | - | 520 J | | NR | NR | NR | NR | NR | NR |
| Dibenzofuran | 330 | - | 250 J | | NR | NR | NR | NR | NR | NR |
| Fluorene | 330 | - | 670 J | | NR | NR | NR | NR | NR | NR |
| Phenanthrene | 330 | - | 6600 | | NR | NR | NR | NR | NR | NR |
| Anthracene | 330 | - | 7000 | | NR | NR | NR | NR | NR | NR |
| Di-n-Butylphthalate | 330 | - | - | | NR | NR | NR | NR | NR | NR |
| Fluoranthene | 330 | - | 13000 | | NR | NR | NR | NR | NR | NR |
| Pyrene | 330 | 16000 J | 23000 | | NR | NR | NR | NR | NR | NR |
| Butylbenzylphthalate | 330 | - | - | | NR | NR | NR | NR | NR | NR |
| Benzo (a) Anthracene | 330 | - | - | | NR | NR | NR | NR | NR | NR |
| bis (2-Ethylhexyl) Phthalate | 330 | 36000 J | 24000 | | NR | NR | NR | NR | NR | NR |
| Chrysene | 330 | - | 6300 | | NR | NR | NR | NR | NR | NR |
| Benzo (b) Fluoranthene | 330 | - | 14000 | | NR | NR | NR | NR | NR | NR |
| Benzo (k) Fluoranthene | 330 | - | - | | NR | NR | NR | NR | NR | NR |
| Benzo (a) Pyrene | 330 | - | 8700 | | NR | NR | NR | NR | NR | NR |
| Indeno (1,2,3-cd) Pyrene | 330 | - | - | | NR | NR | NR | NR | NR | NR |
| Benzo (a,h) Anthracene | 330 | - | - | | NR | NR | NR | NR | NR | NR |
| Benzo (g,h,i,) Perylene | 330 | - | - | | NR | NR | NR | NR | NR | NR |
| 2,4 - Dinitrotoluene | 330 | - | - | | NR | NR | NR | NR | NR | NR |
| N - Nitrosodiphenylamine (1) | 330 | - | - | | NR | NR | NR | NR | NR | NR |
| PESTICIDES/PCB | CRDL ug/kg | | | | | | | | | |
| Aroclor-1242 | 80 | 8500000 J | 100000 J | | - | - | - | - | - | - |
| Aroclor-1248 | 80 | - | - | | - | - | - | - | - | - |
| Aroclor-1254 | 160 | 3200000 DJ | 51000 DJ | | - | - | - | - | - | - |
| Heptachlor | 0.05 | - | - | | - | - | - | 57 J | 2400 | 130 |
| Dieldrin | 0.10 | - | - | | - | - | - | - | 6600 | 590 |
| 4,4-DDE | 0.10 | - | - | | - | - | - | - | 3100 | - |
| Endrin Aldehyde | 0.10 | - | - | | - | - | - | - | 1700 | - |

SUMMARY TABLE

| SAMPLE LOCATION: SMO NUMBER: UNITS: | HSH20/WASH 1 AK356 ug/l | LSH20/WASH1 AK357 ug/l | HSH20/WASH2 AK358 ug/l | LSH20/WASH2 AK359 ug/l |
|---|-------------------------------|------------------------------|------------------------------|------------------------------|
| SEMI-VOLATILE ORGANIC COMPOUNDS | | | | |
| CRDL ug/kg | | | | |
| 1,3 - Dichlorobenzene | 330 | NR | NR | NR |
| 1,4 - Dichlorobenzene | 330 | NR | NR | NR |
| 4-Methylphenol | 330 | NR | NR | NR |
| 1,2,4 - Trichlorobenzene | 330 | NR | NR | NR |
| Naphthalene | 330 | NR | NR | NR |
| 2-Methylnaphthalene | 330 | NR | NR | NR |
| Acenaphthylene | 330 | NR | NR | NR |
| Acenaphthene | 330 | NR | NR | NR |
| Dibenzofuran | 330 | NR | NR | NR |
| Fluorene | 330 | NR | NR | NR |
| Phenanthrone | 330 | NR | NR | NR |
| Anthracene | 330 | NR | NR | NR |
| Di-n-Butylphthalate | 330 | NR | NR | NR |
| Fluoranthene | 330 | NR | NR | NR |
| Pyrene | 330 | NR | NR | NR |
| Butylbenzylphthalate | 330 | NR | NR | NR |
| Benzo (a) Anthracene | 330 | NR | NR | NR |
| bis (2-Ethylhexyl) Phthalate | 330 | NR | NR | NR |
| Chrysene | 330 | NR | NR | NR |
| Benzo (b) Fluoranthene | 330 | NR | NR | NR |
| Benzo (k) Fluoranthene | 330 | NR | NR | NR |
| Benzo (a) Pyrene | 330 | NR | NR | NR |
| Indeno (1,2,3-cd) Pyrene | 330 | NR | NR | NR |
| Dibenzo (a,h) Anthracene | 330 | NR | NR | NR |
| Benzo (g,h,i,) Perylene | 330 | NR | NR | NR |
| 2,4 - Dinitrotoluene | 330 | NR | NR | NR |
| N - Nitrosodiphenylamine (1) | 330 | NR | NR | NR |
| PESTICIDES/PCB | | | | |
| CRDL ug/kg | | | | |
| Aroclor-1242 | 80 | - | - | - |
| Aroclor-1248 | 80 | - | - | - |
| Aroclor-1254 | 160 | - | - | - |
| Heptachlor | 0.05 | 37 | 15 | 14 |
| Dieldrin | 0.10 | 12 | - | - |
| 4,4-DDE | 0.10 | - | - | - |
| Endrin Aldehyde | 0.10 | - | - | - |

Appendix C.

Sample Log

New Bedford Sample Log

| SAMPLES CREATED AND ANALYZED FOR NEW BEDFORD LAB, JOB #R7007 | | | | | | | |
|--|------------------------------|------------|-------------|------------|----------|-----------|-------|
| | | generation | Analyzed | extraction | analysis | | |
| Sample No | Description | Date | for | prep date | date | RESULT | units |
| R70078802171410SJRA | Initial sample low PCB soil | 2/17/88 | PCB | 2/17/88 | 2/22/88 | 460 | ug/g |
| R70078802171410SJRB | Initial sample low PCB soil | 2/17/88 | | 2/17/88 | | | ug/g |
| R70078802171433SJR | Untreated soil (low PCB) | 2/17/88 | % moisture | | 2/29/88 | 61 | % |
| R70078802171610SJRA | Initial sample high PCB soil | 2/17/88 | PCB | 2/17/88 | 2/22/88 | 6100 | ug/g |
| R70078802171610SJRC | Initial sample high PCB soil | 2/17/88 | PCB | 2/17/88 | 2/22/88 | 6100 | ug/g |
| R70078802171620SJR | Untreated soil (high PCB) | 2/17/88 | % moisture | | 2/29/88 | 68 | % |
| R70078802191600DEM | DMSO Rxn trap (reactor 1) | 2/22/88 | weight gain | | 2/23/88 | 6.6 | g |
| R70078802191602DEM | SFLN Rxn trap (reactor 2) | 2/22/88 | weight gain | | 2/23/88 | 3.1 | g |
| R70078802220700SJR | Reactor 1 initial sample | 2/22/88 | PCB | | 3/01/88 | 400 | ug/g |
| R70078802220702SJR | Reactor 2 initial sample | 2/22/88 | PCB | | 3/01/88 | 780 | ug/g |
| R70078802220800SJR | Reactor 1 1hr sample | 2/22/88 | PCB | 2/22/88 | 2/22/88 | 810 | ug/g |
| R70078802220802SJR | Reactor 2 1hr sample | 2/22/88 | PCB | 2/22/88 | 2/22/88 | 250 | ug/g |
| R70078802220900SJR | Reactor 1 2hr sample | 2/22/88 | PCB | | 3/01/88 | 400 | ug/g |
| R70078802220902SJR | Reactor 2 2hr sample | 2/22/88 | PCB | | 3/01/88 | 270 | ug/g |
| R70078802221000SJR | Reactor 1 3hr sample | 2/22/88 | PCB | 2/22/88 | 3/07/88 | 48 | ug/g |
| R70078802221002SJR | Reactor 2 3hr sample | 2/22/88 | PCB | 3/01/88 | 3/01/88 | 820 | ug/g |
| R70078802221002SJR | Reactor 2 3hr sample | 2/22/88 | PCB | 3/01/88 | 3/07/88 | Not Valid | ug/g |
| R70078802221100SJR | Reactor 1 4hr sample | 2/22/88 | PCB | | 3/01/88 | Not Valid | ug/g |
| R70078802221102SJR | Reactor 2 4hr sample | 2/22/88 | PCB | 2/22/88 | 2/22/88 | Not Valid | |
| R70078802221200SJR | Reactor 1 5hr sample | 2/22/88 | PCB | 2/22/88 | 3/07/88 | 4.2 | ug/g |
| R70078802221202SJR | Reactor 2 5hr sample | 2/22/88 | PCB | 3/01/88 | 3/07/88 | 120 | ug/g |
| R70078802221202SJR | Reactor 2 5hr sample | 2/22/88 | PCB | 3/01/88 | 3/07/88 | 130 | ug/g |
| R70078802221300SJR | Reactor 1 6hr sample | 2/22/88 | PCB | 3/01/88 | 3/01/88 | 430 | ug/g |
| R70078802221302SJR | Reactor 2 6hr sample | 2/22/88 | PCB | 2/22/88 | 2/22/88 | Not Valid | |
| R70078802221400SJR | Reactor 1 7hr sample | 2/22/88 | PCB | 2/22/88 | 3/07/88 | 3.8 | ug/g |
| R70078802221402SJR | Reactor 2 7hr sample | 2/22/88 | PCB | 3/02/88 | 3/07/88 | 11 | ug/g |
| R70078802221500SJR | Reactor 1 8hr sample | 2/22/88 | PCB | 2/22/88 | 3/01/88 | Not Valid | ug/g |
| R70078802221502SJR | Reactor 2 8hr sample | 2/22/88 | PCB | 2/22/88 | 2/22/88 | Not Valid | |
| R70078802221600STG | Reactor 1 9hr sample | 2/22/88 | PCB | 3/07/88 | 3/07/88 | 2.2 | ug/g |
| R70078802221602STG | Reactor 2 9hr sample | 2/22/88 | PCB | | 3/07/88 | 15 | ug/g |
| R70078802221622STG | Reactor 2 9hr 20min sample | 2/22/88 | PCB | | 3/01/88 | 18 | ug/g |
| R70078802222000CRG | Condensate | 3/14/88 | PCB | 3/14/88 | | | |

New Bedford Sample Log

| Sample No | Description | generation Date | Analyzed for | extraction prep date | analysis date | RESULT | units |
|--------------------|------------------------|-----------------|--------------|----------------------|---------------|-----------|-------|
| R70078803090700STG | Reactor 1 1hr sample | 3/09/88 | | | | | |
| R70078803090702STG | Reactor 2 1 hr sample | 3/09/88 | | | | | |
| R70078803090800STG | Reactor 1 2hr sample | 3/09/88 | PCB | 3/09/88 | 3/09/88 | 16000 | ug/g |
| R70078803090802STG | Reactor 2 2hr sample | 3/09/88 | PCB | 3/09/88 | 3/09/88 | Not Valid | ug/g |
| R70078803090900STG | Reactor 1 3hr sample | 3/09/88 | | | | | |
| R70078803090902STG | Reactor 2 3hr sample | 3/09/88 | | | | | |
| R70078803091000STG | Reactor 1 4hr sample | 3/09/88 | PCB | 3/09/88 | 3/09/88 | 5900 | ug/g |
| R70078803091002STG | Reactor 2 4hr sample | 3/09/88 | PCB | 3/09/88 | 3/09/88 | 6400 | ug/g |
| R70078803091100STG | Reactor 1 5hr sample | 3/09/88 | | | | | |
| R70078803091102STG | Reactor 2 5hr sample | 3/09/88 | | | | | |
| R70078803091200SJR | Reactor 1 6hr sample | 3/09/88 | PCB | 3/09/88 | 3/09/88 | 260 | ug/g |
| R70078803091202SJR | Reactor 2 6hr sample | 3/09/88 | PCB | 3/09/88 | 3/09/88 | 1500 | ug/g |
| R70078803091300STG | Reactor 1 7hr sample | 3/09/88 | | | | | |
| R70078803091302STG | Reactor 2 7hr sample | 3/09/88 | | | | | |
| R70078803091400RJR | Reactor 1 wash water | 3/09/88 | KOH | 3/09/88 | 3/09/88 | 60.8 | mg/q |
| R70078803091400SJR | Reactor 1 8hr sample | 3/09/88 | PCB | 3/09/88 | 3/09/88 | 240 | ug/g |
| R70078803091402RJR | Reactor 2 wash water | 3/09/88 | KOH | 3/09/88 | 3/09/88 | 133 | mg/q |
| R70078803091402SJR | Reactor 2 8hr sample | 3/09/88 | PCB | 3/09/88 | 3/09/88 | 200 | ug/g |
| R70078803091500SJR | Reactor 1 9hr sample | 3/09/88 | PCB | 3/09/88 | 3/09/88 | 280 | ug/g |
| R70078803091502SJR | Reactor 2 9hr sample | 3/09/88 | | | | | |
| R70078803091600SJR | Reactor 1 10hr sample | 3/09/88 | PCB | 3/09/88 | 3/09/88 | 150 | ug/g |
| R70078803091602SJR | Reactor 2 10hr sample | 3/09/88 | PCB | 3/09/88 | 3/09/88 | 51 | ug/g |
| R70078803091700SJR | Reactor 1 11hr sample | 3/09/88 | | | | | |
| R70078803091702SJR | Reactor 2 11hr sample | 3/09/88 | | | | | |
| R70078803091800SJR | Reactor 1 12hr sample | 3/09/88 | PCB | 3/09/88 | 3/09/88 | 210 | ug/g |
| R70078803091802SJR | Reactor 2 12hr sample | 3/09/88 | PCB | 3/09/88 | 3/09/88 | 140 | ug/g |
| R70078803092000CRG | Condensate | 3/14/88 | PCB | 3/14/88 | | | |
| R70078803092002CRG | Condensate | 3/14/88 | PCB | 3/14/88 | | | |
| R70078803101140RRG | Reagent from reactor 1 | 3/10/88 | PEG | 3/10/88 | 3/10/88 | 260 | mg/g |
| R70078803101140RRG | Reagent from reactor 1 | 3/10/88 | TMH | 3/10/88 | 3/10/88 | 160 | mg/g |
| R70078803101140RRG | Reagent from reactor 1 | 3/10/88 | DMSO | 3/10/88 | 3/10/88 | 270 | mg/g |
| R70078803101140RRG | Reagent from reactor 1 | 3/10/88 | KOH | 3/10/88 | 3/10/88 | 14.2 | mg/g |
| R70078803101140RRG | Reactor 1 reagent | 3/10/88 | | | | | |
| R70078803101145RRG | Reagent from reactor 2 | 3/10/88 | PEG | 3/10/88 | 3/10/88 | 240 | mg/g |

New Bedford Sample Log

| Sample No | Description | generation Date | Analyzed for | extraction prep date | analysis date | RESULT | units |
|--------------------|----------------------------------|-----------------|----------------------------|----------------------|---------------|-----------|-------|
| R70078803210900SJR | Reactor 3hr sample | 3/21/88 | | | | | |
| R70078803211000SJR | Reactor 4hr sample | 3/21/88 | PCB | 3/21/88 | 3/21/88 | Not Valid | ug/g |
| R70078803211100SJR | Reactor 5hr sample | 3/21/88 | | | | | |
| R70078803211200SJR | Reactor 6hr sample | 3/21/88 | PCB | 3/21/88 | 3/21/88 | 1.8 | ug/g |
| R70078803211300SJR | Reactor 7hr sample | 3/21/88 | PCB | 3/21/88 | 3/21/88 | 0.8 | ug/g |
| R70078803211400SJR | Reactor 8hr sample | 3/21/88 | | | | | |
| R70078803211430CRG | Condensate | 3/21/88 | PCB | 3/24/88 | 3/21/88 | 1100 | ug/g |
| R70078803280700SJR | Reactor 1 hr sample | 3/28/88 | | | | | |
| R70078803291240CRG | Condensate: 1 gal practice rxn | 3/29/88 | PCB | 4/13/88 | 4/28/88 | 260 | ug/g |
| R70078803291300SJR | Reactor 7hr sample | 3/29/88 | PCB | 3/29/88 | 3/29/88 | 52 | ug/g |
| R70078803300940SJR | High PCB starting soil | 3/30/88 | PCB | | 3/31/88 | 7300 | ug/g |
| R70078803310700SJR | Reactor 1hr sample | 3/31/88 | PCB | 4/01/88 | 4/01/88 | 9400 | ug/g |
| R70078803310800SJR | Reactor 2hr sample | 3/31/88 | PCB | 3/31/88 | 3/31/88 | 5700 | ug/g |
| R70078803310900SJR | Reactor 3hr sample | 3/31/88 | PCB | 4/01/88 | 4/01/88 | 3500 | ug/g |
| R70078803311000SJR | Reactor 4hr sample | 3/31/88 | PCB | 3/31/88 | 3/31/88 | 1600 | ug/g |
| R70078803311100SJR | Reactor 5hr sample | 3/31/88 | PCB | 4/01/88 | 4/01/88 | 480 | ug/g |
| R70078803311200SJR | Reactor 6hr sample | 3/31/88 | PCB | 3/31/88 | 3/31/88 | 500 | ug/g |
| R70078803311300SJR | Reactor 7hr sample | 3/31/88 | PCB | 3/31/88 | 3/31/88 | 80 | ug/g |
| R70078803311400SJR | Reactor 8hr sample | 3/31/88 | PCB | 3/31/88 | 3/31/88 | 23 | ug/g |
| R70078803311500SJR | Reactor 9hr sample | 3/31/88 | PCB | 3/31/88 | 3/31/88 | 5.6 | ug/g |
| R70078803311600STG | Reactor 10hr sample | 3/31/88 | PCB | 3/31/88 | 3/31/88 | 6.8 | ug/g |
| R70078803311700STG | Reactor 11hr sample | 3/31/88 | PCB | 3/31/88 | 3/31/88 | 3.3 | ug/g |
| R70078803311800CRG | Condensate: 1 gal high soil rxn | 3/30/88 | PCB | 4/13/88 | 4/28/88 | 330 | ug/g |
| R70078803311800DRG | Drying tube: 1 gal high soil rxn | 3/31/88 | weight gain | | 4/01/88 | 1 | g |
| R70078803311800DRG | Trap: high soil gallon reaction | 3/31/88 | PCB | 7/19/88 | 7/20/88 | 2 | ug/g |
| R70078803311800STG | Reactor 12hr sample | 3/31/88 | PCB | 3/31/88 | 3/31/88 | 3.7 | ug/g |
| R70078804010805CRG | Condensor 1 condensate | 4/05/88 | Part of R70078803311800CRG | | | | |
| R70078804010807CRG | Condensor 2 condensate | 4/05/88 | Part of R70078803311800CRG | | | | |
| R70078804010810CRG | Reactor burp flask | 4/05/88 | | | | | |
| R70078804041200SJR | NB Low starting soil | 4/04/88 | PCB | 4/05/88 | 4/05/88 | 440 | ug/g |
| R70078804050700SJR | Reaction 1hr sample | 4/05/88 | PCB | 4/05/88 | 4/05/88 | 460 | ug/g |
| R70078804050800SJR | Reaction 2hr sample | 4/05/88 | PCB | 4/05/88 | 4/05/88 | 130 | ug/g |
| R70078804050900SJR | Reaction 3hr sample | 4/05/88 | PCB | 4/05/88 | 4/05/88 | 92 | ug/g |
| R70078804051000SJR | Reaction 4hr sample | 4/05/88 | | | | | |

New Bedford Sample Log

| Sample No | Description | generation | Analyzed for | extraction prep date | analysis date | RESULT | units |
|--------------------|------------------------------------|------------|--------------|----------------------|---------------|--------|-------|
| R70078804221120SRG | low soil (gal.) after second wash | 4/22/88 | KOH | 7/20/88 | 7/20/88 | 21 | mg/g |
| R70078804221120SRG | low soil (gal.) after second wash | 4/22/88 | PEG | 7/20/88 | 7/21/88 | 1.4 | mg/g |
| R70078804221120SRG | low soil (gal.) after second wash | 4/22/88 | TMH | 7/20/88 | 7/21/88 | 2.3 | mg/g |
| R70078804221120SRG | low soil (gal.) after second wash | 4/22/88 | DMSO | 7/20/88 | 7/21/88 | 4.4 | mg/g |
| R70078804250840RRG | Reagent from high soil gallon rxn | 4/25/88 | KOH | 6/17/88 | 6/17/88 | 198 | mg/g |
| R70078804250840RRG | Reagent from high soil gallon rxn | 4/25/88 | PCB | 6/18/88 | 6/18/88 | 2.8 | ug/g |
| R70078804250840RRG | Reagent from high soil gallon rxn | 4/25/88 | PEG | 6/15/88 | 6/19/88 | 90 | mg/g |
| R70078804250840RRG | Reagent from high soil gallon rxn | 4/25/88 | TMH | 6/15/88 | 6/19/88 | 90 | mg/g |
| R70078804250840RRG | Reagent from high soil gallon rxn | 4/25/88 | DMSO | 6/15/88 | 6/19/88 | 160 | mg/g |
| R70078804250925SRG | high soil (gal.) after reag. drain | 4/25/88 | KOH | 7/20/88 | 7/20/88 | 133 | mg/g |
| R70078804250925SRG | high soil (gal.) after reag. drain | 4/25/88 | PEG | 7/20/88 | 7/21/88 | 15.8 | mg/g |
| R70078804250925SRG | high soil (gal.) after reag. drain | 4/25/88 | TMH | 7/20/88 | 7/21/88 | 12.3 | mg/g |
| R70078804250925SRG | high soil (gal.) after reag. drain | 4/25/88 | DMSO | 7/20/88 | 7/21/88 | 30.6 | mg/g |
| R70078804250925SRG | NB High soil after reagent decant | 4/25/88 | % moisture | | 4/26/88 | 26 | % |
| R70078804250938WRG | Wash 1 from high soil gallon rxn | 4/25/88 | KOH | 6/17/88 | 6/17/88 | 62 | mg/g |
| R70078804250938WRG | Wash 1 from high soil gallon rxn | 4/25/88 | PCB | 6/18/88 | 6/18/88 | 0.57 | ug/g |
| R70078804250938WRG | Wash 1 from high soil gallon rxn | 4/25/88 | PEG | 6/15/88 | 6/19/88 | 39 | mg/g |
| R70078804250938WRG | Wash 1 from high soil gallon rxn | 4/25/88 | TMH | 6/15/88 | 6/19/88 | 7.6 | mg/g |
| R70078804250938WRG | Wash 1 from high soil gallon rxn | 4/25/88 | DMSO | 6/15/88 | 6/19/88 | 16 | mg/g |
| R70078804250938WRG | Wash 1 from high soil gallon rxn | 4/25/88 | PCB | 6/19/88 | 6/20/88 | 0.35 | ug/g |
| R70078804250955SRG | high soil (gal.) after first wash | 4/25/88 | KOH | 7/20/88 | 7/20/88 | 71 | mg/g |
| R70078804250955SRG | high soil (gal.) after first wash | 4/25/88 | PEG | 7/20/88 | 7/21/88 | 18.3 | mg/g |
| R70078804250955SRG | high soil (gal.) after first wash | 4/25/88 | TMH | 7/20/88 | 7/21/88 | 4.1 | mg/g |
| R70078804250955SRG | high soil (gal.) after first wash | 4/25/88 | DMSO | 7/20/88 | 7/21/88 | 15.3 | mg/g |
| R70078804250955SRG | NB High soil wash 1 | 4/25/88 | % moisture | | 4/26/88 | 35 | % |
| R70078804251000WRG | Wash 2 from high soil gallon rxn | 4/25/88 | KOH | 6/17/88 | 6/17/88 | 25 | mg/g |
| R70078804251000WRG | Wash 2 from high soil gallon rxn | 4/25/88 | PEG | 6/15/88 | 6/19/88 | 2.1 | mg/g |
| R70078804251000WRG | Wash 2 from high soil gallon rxn | 4/25/88 | TMH | 6/15/88 | 6/19/88 | 1.8 | mg/g |
| R70078804251000WRG | Wash 2 from high soil gallon rxn | 4/25/88 | DMSO | 6/15/88 | 6/19/88 | 4.2 | mg/g |
| R70078804251000WRG | Wash 2 from high soil gallon rxn | 4/25/88 | PCB | 6/19/88 | 6/20/88 | 0.054 | ug/g |
| R70078804251025SRG | high soil (gal.) after second wash | 4/25/88 | KOH | 7/20/88 | 7/20/88 | 22 | mg/g |
| R70078804251025SRG | high soil (gal.) after second wash | 4/25/88 | PEG | 7/20/88 | 7/21/88 | 5.8 | mg/g |
| R70078804251025SRG | high soil (gal.) after second wash | 4/25/88 | TMH | 7/20/88 | 7/21/88 | 2.1 | mg/g |
| R70078804251025SRG | high soil (gal.) after second wash | 4/25/88 | DMSO | 7/20/88 | 7/21/88 | 4.3 | mg/g |

New Bedford Sample Log

| Sample No | Description | generation | Analyzed for | extraction prep date | analysis date | RESULT | units |
|--------------------|-------------------------------|------------|--------------|----------------------|---------------|--------|-------|
| R70078809081420SEM | Spiked dup. of ...04221120SRG | 9/08/88 | MCB** | 9/09/88 | 9/09/88 | 0.12 | ug/g |
| R70078809081430SEM | Duplicate of ...04251025SRG | 9/08/88 | PCB | 9/09/88 | 9/09/88 | 2.8 | ug/g |
| R70078809081430SEM | Duplicate of ...04251025SRG | 9/08/88 | MCB** | 9/09/88 | 9/09/88 | 1.5 | ug/g |
| R70078809081440SEM | Duplicate of ...04251025SRG | 9/08/88 | PCB | 9/09/88 | 9/09/88 | 2.7 | ug/g |
| R70078809081440SEM | Duplicate of ...04251025SRG | 9/08/88 | MCB** | 9/09/88 | 9/09/88 | 1.4 | ug/g |
| R70078809081450SEM | Spiked dup. of ...04251025SRG | 9/08/88 | PCB | 9/09/88 | 9/09/88 | 7.1 | ug/g |
| R70078809081450SEM | Spiked dup. of ...04251025SRG | 9/08/88 | MCB** | 9/09/88 | 9/09/88 | 1.3 | ug/g |

**MCB = monochlorobiphenyl

Appendix D.

Analytical Spreadsheets

Contents

| | |
|---|------|
| Understanding Webb McCall Spreadsheets | D-1 |
| Webb McCall Spreadsheets (for PCB calculations) | D-4 |
| Understanding Reagent Spreadsheets | D-81 |
| Reagent Calculation Spreadsheets | D-82 |

Understanding Webb-McCall Spreadsheets

The concentration of PCB in samples is calculated according to the procedure of Webb and McCall as described in one of the EPA method for PCB analysis (EPA 600/4-81-045). Each PCB peak is treated as a separate compound and is quantified individually. The total PCB concentration in a sample is the sum of the concentrations represented by the various peaks.

As a general rule for gas chromatography, standards should bracket samples. In other words, it is best to have a standard of higher concentration and a standard of lower concentration for calculation of sample concentration. That way the sample concentration can be calculated by linear interpolation, which will greatly reduce inaccuracy caused by nonlinear detector response. The nanograms (ng) of PCB represented by each peak in a sample is calculated by linear interpolation between two standards having the same peak at higher and lower concentrations. The equation for this calculation is:

$$ng_{is} = ng_{ih} - [(A_{ih}-A_{il})(ng_{ih}-ng_{il})/(A_{ih}-A_{il})]$$

where i refers to a peak name,
s refers to the sample,
h refers to the higher standard,
l refers to the lower standard, and
A is a peak area.

The nanograms of PCB represented by a given peak (ng_i) within our 1:1 1242:1260 standard is calculated as follows.

$$ng_{ix} = C_x * V_l * M_i / 100$$

where C_x is the concentration of Aroclor in standard x in ng/ μ L,
 V_l is the injection volume of the standard in μ L, and
 M_i is the mean weight percent of peak i in the standard, given in the table below.

| Composition of a 1:1 Mixture of Aroclors 1242 and 1260 | | | | | |
|--|---------|---------|---------|---------|---------|
| Peak | Percent | Peak | Percent | Peak | Percent |
| 11 | 0.55 | 58 | 2.8 | 203 | 4.65 |
| 16 | 1.45 | 70 | 6.5 | 232+244 | 4.9 |
| 21 | 5.65 | 78 | 1.8 | 280 | 5.5 |
| 28 | 5.5 | 84 | 3.7 | 332 | 2.1 |
| 32 | 3.05 | 98+104 | 3.45 | 372 | 2 |
| 37 | 5.75 | 117+125 | 7.8 | 448 | 0.3 |
| 40 | 5.55 | 146 | 7.55 | 528 | 0.75 |
| 47 | 4.4 | 160 | 2.45 | | |
| 54 | 3.4 | 174 | 6.2 | Total | 97.75 |

(These percentages were obtained by adding up the Aroclor 1242 and 1260 percentages, taken from Tables 3 and 6 of the EPA method 600/4-81-045 and dividing by 2.)

Row 31 is where all the peak contributions are added up.

Row 36, column 2 for the sample is where the final soil concentration in soil is calculated. The equation for this calculation is;

$$\text{ppm in soil} = \frac{\text{total ng/injection} \times \text{extract volume}}{\text{injection volume} \times \text{soil mass} \times \text{dilution}}$$

Dilution in this example is equal to .01 if a 1/100 dilution was used.

The purpose of column 3 for the sample is to indicate how the ng/injection for each peak was calculated. If the peak area is lower than that of the lowest standard for that peak, a "0" will be printed in column 10. If the peak area is higher than that of the highest standard, a "2" will be printed. If the peak area is within the range of the standards, a "1" will be printed. Samples with more than one or two 2's should be diluted further and re-injected. Samples with 0's that account for more than 25% of the total ng should be injected in a more concentrated form unless the soil concentration is below the desired detection limit.

NBWM2/22, Webb McCall Calculations for New Bedford

| K | L | M | N | O | P | Q | R | S | T | U | V | |
|----|----------------------------|--------------|-----------------------------|--------------|---------------|--------------|---------------|--------------|---|----------|-------------|------------|
| 1 | SAMPLE # | R70078802 | SAMPLE # | R7007880217 | SAMPLE # | R7007880222 | SAMPLE # | R7007880222 | | | | |
| 2 | | 171610SJRA | | 1610SJRC | | 0800SJR | | 0802SJR | | | | |
| 3 | dilution used | 0.01 | dilution used | 0.002 | dilution used | 0.01 | dilution used | 0.005 | | | | |
| 4 | inj.vol | 2 | inj.vol | 2 | inj.vol | 2 | inj.vol | 2 | | | | |
| 5 | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | | | | |
| 6 | 1955.49 | 0.2749966 | 2 | 443.61 | 0.0565328 | 1 | 111.02 | 0.00864507 | 1 | 49.6 | 0.00172713 | 0 |
| 7 | 2691.39 | 0.7014136 | 2 | 601.78 | 0.13107893 | 1 | 128.48 | 0.00584896 | 1 | 91.38 | 0.00413194 | 0 |
| 8 | 19968 | 3.0512099 | 2 | 4550.03 | 0.6300216 | 1 | 1530.52 | 0.15584748 | 1 | 444.88 | 0.02166359 | 0 |
| 9 | 31836 | 3.3167717 | 2 | 7321.6 | 0.69316197 | 1 | 2277.27 | 0.15330159 | 1 | 651.97 | 0.02919725 | 1 |
| 10 | 23362 | 1.7234311 | 2 | 5471.78 | 0.35615712 | 1 | 1322.52 | 0.04629056 | 1 | 351.05 | 0.00652082 | 0 |
| 11 | 75425 | 3.8524967 | 2 | 16240 | 0.75442459 | 1 | 9265.96 | 0.38936455 | 1 | 3120.89 | 0.08638653 | 1 |
| 12 | 47828 | 3.0605569 | 2 | 10529 | 0.61685739 | 1 | 1612.68 | 0.0590964 | 1 | 390.67 | 0.01136651 | 0 |
| 13 | 43107 | 3.110657 | 2 | 10100 | 0.67121311 | 1 | 5502.01 | 0.33139009 | 1 | 1951.2 | 0.07657699 | 1 |
| 14 | 31234 | 2.1519202 | 2 | 7165.72 | 0.44765372 | 1 | 2657.52 | 0.12842966 | 1 | 775.05 | 0.02520019 | 1 |
| 15 | 29393 | 1.4762392 | 2 | 6634.52 | 0.30516139 | 1 | 2596.52 | 0.09737896 | 1 | 759.99 | 0.01937077 | 1 |
| 16 | 73337 | 4.5495503 | 2 | 15774 | 0.88053253 | 1 | 5875.76 | 0.24962695 | 1 | 2165.12 | 0.0635197 | 1 |
| 17 | 21462 | 0.8806595 | 2 | 4589.85 | 0.16599587 | 1 | 2000 | 0.05629606 | 1 | 1708.14 | 0.04393358 | 1 |
| 18 | 31926 | 2.3574932 | 2 | 7737.58 | 0.52272464 | 1 | 2332.6 | 0.11273973 | 1 | 1538.9 | 0.06022436 | 1 |
| 19 | 43586 | 2.0666154 | 2 | 10265.97 | 0.43693919 | 1 | 4202.59 | 0.14038044 | 1 | 1638.72 | 0.03568301 | 1 |
| 20 | 39298 | 1.7874014 | 2 | 9490.54 | 0.30969101 | 1 | 3731.41 | 0.0754048 | 1 | 1050.92 | 0.01442517 | 0 |
| 21 | 24273 | 0.9307229 | 1 | 6147.69 | 0.13785663 | 1 | 2589.18 | 0.04489511 | 1 | 0 | 0 | |
| 22 | 3214.78 | 0.0672387 | 1 | 831.61 | 0.0105052 | 1 | | | 0 | 0 | 669.39 | 0.00821862 |
| 23 | 20950 | 0.657582 | 1 | 5534.72 | 0.11056669 | 1 | 1718.29 | 0.02234318 | 0 | 440.06 | 0.00572217 | 0 |
| 24 | 10662 | 0.1711239 | 1 | 3255.94 | 0.03354283 | 1 | 1034.41 | 0.00859344 | 0 | 195.81 | 0.00162671 | 0 |
| 25 | 9459.63 | 0.1461162 | 1 | 2950.81 | 0.02930964 | 1 | 469.7 | 0.00397273 | 0 | 222.02 | 0.00187785 | 0 |
| 26 | 8106.28 | 0.0741358 | 1 | 2496.14 | 0.01576244 | 0 | 421.33 | 0.00266058 | 0 | 137.71 | 0.0008696 | 0 |
| 27 | 6190.09 | 0.0508789 | 1 | 2307.31 | 0.01144501 | 1 | 235.47 | 0.00099918 | 0 | 0 | 0 | |
| 28 | 3243.41 | 0.0178919 | 1 | 1961.79 | 0.00822153 | 1 | | | 0 | 0 | 0 | |
| 29 | 1432.28 | 0.003855 | 1 | 1019.35 | 0.00247567 | 1 | | | 0 | 0 | 0 | |
| 30 | 1845.79 | 0.0054338 | 1 | 1803.27 | 0.00526718 | 1 | | | 0 | 0 | 0 | |
| 31 | DCB area | DCB ng/inj. | | DCB area | DCB ng/inj. | | DCB area | DCB ng/inj. | | DCB area | DCB ng/inj. | |
| 32 | | 0 | 0 | | 0 | 0 | 1948.71 | 0.00568867 | 1 | 1466.32 | 0.00273007 | |
| 33 | | | | | | | | | | | | |
| 34 | Total ng PCB | 36.486392 | Total ng PCB | 7.3430987 | Total ng PCB | 2.09350554 | Total ng PCB | 0.51607476 | | | | |
| 35 | | | | | | | | | | | | |
| 36 | g used* | 3 | g used* | 3 | g used | 1.3 | g used | 2.1 | | | | |
| 37 | mL total vol. | 10 | mL total vol. | 10 | mL total vol. | 10 | mL total vol. | 10 | | | | |
| 38 | *as received, 68% moisture | | *as received, 68% moisture. | | | | | | | | | |
| 39 | ppm PCB | 6081.0653 | ✓ | ppm PCB | 6119.24892 | ✓ | ppm PCB | 805.194437 | ✓ | ppm PCB | 245.749885 | |
| 40 | | | | | | | | | | | | |
| 41 | ul DCB used | | ul DCB used | | ul DCB used | 5 | ul DCB used | 5 | | | | |
| 42 | conc (ng/ul) | | conc (ng/ul) | | conc (ng/ul) | 484 | conc (ng/ul) | 484 | | | | |
| 43 | DCB %R | #DIV/0! | DCB %R | #DIV/0! | DCB %R | 117.534587 | DCB %R | 112.812716 | | | | |
| 44 | | | | | | | | | | | | |
| 45 | Homolog | ppm | Homolog | ppm | Homolog | ppm | Homolog | ppm | | | | |
| 46 | mono | 45.832771 | mono | 47.11067 | mono | 3.32502709 | mono | 0.8224423 | | | | |
| 47 | di | 763.63607 | di | 778.659189 | di | 76.9314776 | di | 15.7594482 | | | | |
| 48 | tri | 1972.36662 | tri | 1995.8636 | tri | 250.811342 | tri | 64.0418393 | | | | |
| 49 | tetra | 1689.9205 | tetra | 1722.89705 | tetra | 287.826198 | tetra | 95.3930313 | | | | |
| 50 | penta | 911.19708 | penta | 954.55819 | penta | 115.502464 | penta | 50.5489917 | | | | |
| 51 | hexa | 619.55755 | hexa | 532.667179 | hexa | 65.0404994 | hexa | 15.3112704 | | | | |
| 52 | hepta | 74.025029 | hepta | 74.1893944 | hepta | 5.7574289 | hepta | 3.87286217 | | | | |
| 53 | octa | 4.5301185 | octa | 13.3036522 | octa | 0 | octa | 0 | | | | |

NBWM2/22, Webb McCall Calculations for New Bedford

| | AI | AJ | AK | AL | AM | AN | AO | AP | AQ | AR | AS | AT |
|----|---------------|--------------|---------------|--------------|-------------------------------|--------------|---------------|-----------------|---------------|--------------|-----------|-----------|
| 1 | SAMPLE # | R7007880222 | SAMPLE # | R7007880222 | SAMPLE # | R7007880222 | SAMPLE # | R7007880222 | SAMPLE # | R7007880222 | | |
| 2 | | 1200SJR | | | 1302SJR | | | 1200SJR 2nd ini | | | 1302SJR | |
| 3 | dilution used | 0.1 | dilution used | 0.1 | dilution used | 0.1 | dilution used | 0.1 | dilution used | 0.1 | | |
| 4 | inj.vol | 2 | inj.vol | 2 | inj.vol | 2 | inj.vol | 2 | inj.vol | 2 | | |
| 5 | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | | |
| 6 | 326.19 | 0.0395658 | 1 | | 0 | 0 | 147.03 | 0.0136776 | 1 | 33.23 | 0.0011571 | 0 |
| 7 | 565.22 | 0.1211003 | 1 | | 0 | 0 | 256.15 | 0.0367433 | 1 | 289.67 | 0.0458922 | 1 |
| 8 | 1122.99 | 0.0976577 | 1 | | 0 | 0 | 805.1 | 0.0614446 | 1 | 1695.43 | 0.1817444 | 1 |
| 9 | 6066.11 | 0.5587954 | 1 | | 0 | 0 | 8241.25 | 0.7915859 | 1 | 2447.43 | 0.1715127 | 1 |
| 10 | | 0 | 0 | | 0 | 0 | | | 0 | 0 | 4570.42 | 0.28727 |
| 11 | | 0 | 0 | | 0 | 0 | | | 0 | 0 | 5316.52 | 0.1826289 |
| 12 | | 0 | 0 | | 0 | 0 | | | 0 | 0 | 2752.68 | 0.1086008 |
| 13 | | 0 | 0 | | 0 | 0 | | | 0 | 0 | | 0 |
| 14 | | 0 | 0 | | 0 | 0 | | | 0 | 0 | 5075.39 | 0.2996382 |
| 15 | | 0 | 0 | | 0 | 0 | | | 0 | 0 | | 0 |
| 16 | 122873 | 7.7069331 | 2 | | 1 | 0 | 0 | 98198 | 6.1341698 | 2 | 76660 | 4.7613555 |
| 17 | | 0 | 0 | | 0 | 0 | | | 0 | 0 | | 0 |
| 18 | | 0 | 0 | | 0 | 0 | | | 0 | 0 | | 0 |
| 19 | | 0 | 0 | | x | 0 | 0 | | 0 | 0 | | 0 |
| 20 | | 0 | 0 | | x | 0 | 0 | | 0 | 0 | | 0 |
| 21 | 1091.18 | 0.0162601 | 0 | | 0 | 0 | | | 0 | 0 | | 0 |
| 22 | | 0 | 0 | | 0 | 0 | | | 0 | 0 | | 0 |
| 23 | | 0 | 0 | | x | 0 | 0 | | 0 | 0 | | 0 |
| 24 | | 0 | 0 | | x | 0 | 0 | | 0 | 0 | | 0 |
| 25 | 135.61 | 0.001147 | 0 | | 0 | 0 | | | 0 | 0 | | 0 |
| 26 | | 0 | 0 | | 0 | 0 | | | 0 | 0 | | 0 |
| 27 | | 0 | 0 | | 0 | 0 | | | 0 | 0 | | 0 |
| 28 | | 0 | 0 | | 0 | 0 | | | 0 | 0 | | 0 |
| 29 | | 0 | 0 | | 0 | 0 | | | 0 | 0 | | 0 |
| 30 | | 0 | 0 | | 0 | 0 | | | 0 | 0 | | 0 |
| 31 | DCB area | DCB ng/inj. | DCB area | DCB ng/inj. | DCB area | DCB ng/inj. | DCB area | DCB ng/inj. | | | | |
| 32 | 2188.14 | 0.0071572 | 1 | | 0 | 0 | 1783.99 | 0.0046784 | 1 | 2021.42 | 0.0061346 | 1 |
| 33 | | | | | | | | | | | | |
| 34 | Total ng PCB | 8.54146 | Total ng PCB | 0 | Total ng PCB | 7.037621 | Total ng PCB | 6.0397997 | | | | |
| 35 | | | | | | | | | | | | |
| 36 | g used | 1.3 | g used | 2.1 | g used | 1.3 | g used | 2.1 | | | | |
| 37 | mL total vol. | 10 | mL total vol. | 10 | mL total vol. | 10 | mL total vol. | 10 | | | | |
| 38 | | | | | | | | | | | | |
| 39 | ppm PCB | 328.51769 | ppm PCB | 0 | ppm PCB | 270.67773 | ppm PCB | 143.80476 | | | | |
| 40 | | | | | florisil slurry cleanup tried | | | | | | | |
| 41 | ul DCB used | 5 | ul DCB used | 5 | ul DCB used | 5 | ul DCB used | 5 | | | | |
| 42 | conc (ng/ul) | 96.8 | conc (ng/ul) | 96.8 | conc (ng/ul) | 96.8 | conc (ng/ul) | 96.8 | | | | |
| 43 | DCB %R | 73.937521 | DCB %R | 0 | DCB %R | 48.330674 | DCB %R | 63.374182 | | | | |
| 44 | | | | | DCB recovery not acceptable | | | | | | | |
| 45 | Homolog | ppm | Homolog | ppm | Homolog | ppm | Homolog | ppm | | | | |
| 46 | mono | 1.5217629 | mono | 0 | mono | 0.5260596 | mono | 0.0275502 | | | | |
| 47 | di | 13.7868 | di | 0 | di | 11.387858 | di | 6.4408271 | | | | |
| 48 | tri | 16.119098 | tri | 0 | tri | 22.834208 | tri | 19.190827 | | | | |
| 49 | tetra | 210.45857 | tetra | 0 | tetra | 167.51002 | tetra | 85.269524 | | | | |
| 50 | penta | 85.993223 | penta | 0 | penta | 68.419586 | penta | 32.876026 | | | | |
| 51 | hexa | 0.5985295 | hexa | 0 | hexa | 0 | hexa | 0 | | | | |
| 52 | hepta | 0.0397035 | hepta | 0 | hepta | 0 | hepta | 0 | | | | |
| 53 | octa | 0 | octa | 0 | octa | 0 | octa | 0 | | | | |

NBWM2/22, Webb McCall Calculations for New Bedford

| | BG | BH | BI | BJ | BK | BL | BM | BN | BO | BP | BQ | BR |
|----|---------------|---------------|---------|---------------|--------------|---------|---------------|--------------|--------|---------------|--------------|----|
| 1 | SAMPLE # | R7007880222 | | SAMPLE # | R7007880222 | | SAMPLE # | R7007880222 | | SAMPLE # | R7007880222 | |
| 2 | | 1502SJR-REINT | | | 1502SJR | | | 1502SJR | | | 1600STG | |
| 3 | dilution used | 1 | | dilution used | 0.1 | | dilution used | 1 | | dilution used | 1 | |
| 4 | inj.vol | 2 | | inj.vol | 2 | | inj.vol | 2 | | inj.vol | 2 | |
| 5 | Peak Area | ng/injection | | Peak Area | ng/injection | | Peak Area | ng/injection | | Peak Area | ng/injection | |
| 6 | 683.92 | 0.09125715 | 1 | 109.43 | 0.00843086 | 1 | 43.1697 | 0.00150322 | 0 | 415.8 | 0.05251431 | 1 |
| 7 | 0 | 0 | 582.39 | 0.12578666 | 1 | 1424.39 | 0.35560073 | 2 | 930.04 | 0.22067367 | 1 | |
| 8 | 4664.08 | 0.64793164 | 1 | 501.91 | 0.02690606 | 1 | 10468 | 1.55936053 | 2 | 217.42 | 0.01058734 | 0 |
| 9 | 4109.04 | 0.34934349 | 1 | 975.35 | 0.050603 | 1 | 14645 | 1.47693574 | 2 | 195.58 | 0.00792055 | 0 |
| 10 | 14796 | 1.0687679 | 2 | 476.68 | 0.00885442 | 0 | 29470 | 2.19023979 | 2 | 1443.23 | 0.05247185 | 1 |
| 11 | 4620.42 | 0.14619115 | 1 | 1111.45 | 0.022844 | 0 | 28160 | 1.37838369 | 2 | 1181.32 | 0.02497203 | 1 |
| 12 | 0 | 0 | 875.86 | 0.02710007 | 1 | | | 0 | 0 | | 0 | 0 |
| 13 | 3010.03 | 0.14721566 | 1 | 1927.18 | 0.07551189 | 1 | 51293 | 3.71565857 | 2 | | 0 | 0 |
| 14 | 0 | 0 | | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 15 | 0 | 0 | 3664.06 | 0.15231112 | 1 | | 0 | 0 | | 0 | 0 | |
| 16 | 275806 | 17.454756 | 2 | 32823 | 1.96722162 | 2 | 410720 | 26.0540621 | 2 | 54858 | 3.37171419 | 2 |
| 17 | 0 | 0 | 907.48 | 0.01990806 | 1 | | 0 | 0 | | 0 | 0 | |
| 18 | 0 | 0 | | | 0 | 0 | | 0 | 0 | 1365.75 | 0.05179531 | 1 |
| 19 | 0 | 0 | 1027.06 | 0.01723143 | 1 | | | 0 | 0 | 2405.83 | 0.05882397 | 1 |
| 20 | 0 | 0 | | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 21 | 0 | 0 | 903.98 | 0.01347054 | 0 | | | 0 | 0 | | 0 | 0 |
| 22 | 0 | 0 | | | 0 | 0 | | 0 | 0 | 972.08 | 0.01346928 | 1 |
| 23 | 0 | 0 | | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 24 | 0 | 0 | | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 25 | 0 | 0 | 488.67 | 0.00413318 | 0 | | 0 | 0 | 0 | 459.94 | 0.00389018 | 0 |
| 26 | 0 | 0 | | | 0 | 0 | | 0 | 0 | 435.33 | 0.00274899 | 0 |
| 27 | 0 | 0 | | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 28 | 0 | 0 | 147.84 | 0.00061204 | 0 | | 0 | 0 | 0 | 235.83 | 0.0009763 | 0 |
| 29 | 0 | 0 | | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 30 | 0 | 0 | | | 0 | 0 | | 0 | 0 | 25.8906 | 6.3415E-05 | 0 |
| 31 | DCB area | DCB ng/ini. | | DCB area | DCB ng/ini. | | DCB area | DCB ng/ini. | | DCB area | DCB ng/ini. | |
| 32 | 7647.37 | 0.05417944 | 1 | 2198.24 | 0.0072191 | 1 | 7963.93 | 0.0573563 | 1 | 2797.3 | 0.01089327 | 1 |
| 33 | | | | | | | | | | | | |
| 34 | Total ng PCB | 19.905463 | | Total ng PCB | 2.52092492 | | Total ng PCB | 36.7317444 | | Total ng PCB | 3.87262139 | |
| 35 | | | | | | | | | | | | |
| 36 | g used | 1.7 | | g used | 1.7 | | g used | 1.7 | | g used | 1.2 | |
| 37 | mL total vol. | 10 | | mL total vol. | 10 | | mL total vol. | 10 | | mL total vol. | 10 | |
| 38 | | | | | | | | | | | | |
| 39 | ppm PCB | 58.5454793 | | ppm PCB | 74.1448507 | | ppm PCB | 108.034542 | | ppm PCB | 16.1359225 | |
| 40 | | | | | | | | | | | | |
| 41 | ul DCB used | 5 | | ul DCB used | 5 | | ul DCB used | 5 | | ul DCB used | 5 | |
| 42 | conc (ng/ul) | 96.8 | | conc (ng/ul) | 96.8 | | conc (ng/ul) | 96.8 | | conc (ng/ul) | 96.8 | |
| 43 | DCB %R | 55.9704946 | | DCB %R | 74.5774545 | | DCB %R | 59.2523771 | | DCB %R | 11.2533752 | |
| 44 | | | | | | | | | | | | |
| 45 | Homolog | ppm | | Homolog | ppm | | Homolog | ppm | | Homolog | ppm | |
| 46 | mono | 0.26840338 | | mono | 0.24796657 | | mono | 0.00442123 | | mono | 0.21880963 | |
| 47 | di | 2.16255152 | | di | 4.86304327 | | di | 6.71822115 | | di | 0.97183811 | |
| 48 | tri | 4.34401963 | | tri | 2.84560982 | | tri | 13.7538979 | | tri | 0.34743458 | |
| 49 | tetra | 36.8826247 | | tetra | 48.3664238 | | tetra | 65.3354197 | | tetra | 9.97465448 | |
| 50 | penta | 14.8878801 | | penta | 17.1740898 | | penta | 22.2225824 | | penta | 4.47134235 | |
| 51 | hexa | 0 | | hexa | 0.52030877 | | hexa | 0 | | hexa | 0.09340786 | |
| 52 | hepta | 0 | | hepta | 0.10940759 | | hepta | 0 | | hepta | 0.05410328 | |
| 53 | octa | 0 | | octa | 0.01800111 | | octa | 0 | | octa | 0.00433217 | |

NBWM2/22-70, Webb McCall Calculations for New Bedford

| A | B | C | D | E | F | G | H | I | J |
|----|--|--------------|--------------|--------------|--------------|--------------|-----------------------------|-------------|--------------|
| 1 | STANDARDS (1:1 mixtures of aroclors 1242 and 1260) | | | | | | SAMPLE # | R70078802 | |
| 2 | | | | | | | | 171410SJRA | |
| 3 | Total PCB Conc (ng/ul) | 0.2 | | 1 | | 10 | dilution used | 0.01 | |
| 4 | inj. Vol. | 2 | | 2 | | 2 | inj.vol | 2 | |
| 5 | peak ID | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection |
| 6 | 11 | 63.18 | 0.0022 | 128.5 | 0.011 | 813.63 | 0.11 | 161.42 | 0.0157569 |
| 7 | 16 | 128.27 | 0.0058 | 227.78 | 0.029 | 1184.04 | 0.29 | 1000 | 0.2397684 |
| 8 | 21 | 464.11 | 0.0226 | 1257.67 | 0.113 | 7733.86 | 1.13 | 1505.84 | 0.1519718 |
| 9 | 28 | 543.24 | 0.022 | 1872.67 | 0.11 | 11123 | 1.1 | 3315.33 | 0.2643981 |
| 10 | 32 | 656.79 | 0.0122 | 1609.77 | 0.061 | 8793.21 | 0.61 | 1619.78 | 0.061765 |
| 11 | 37 | 1119.04 | 0.023 | 4024.55 | 0.115 | 23797 | 1.15 | 11928 | 0.5287105 |
| 12 | 40 | 763.02 | 0.0222 | 2807.93 | 0.111 | 18056 | 1.11 | 2199.4 | 0.0845746 |
| 13 | 47 | 621.16 | 0.0176 | 2208.81 | 0.088 | 12925 | 0.88 | 6937.09 | 0.4374523 |
| 14 | 54 | 496.14 | 0.0136 | 1804.11 | 0.068 | 10447 | 0.68 | 3381.33 | 0.1796824 |
| 15 | 58 | 529.7 | 0.0112 | 1792.37 | 0.056 | 11587 | 0.56 | 3376.38 | 0.137508 |
| 16 | 70 (deleted) | | | | | | | | |
| 17 | 78 | 423.1 | 0.0072 | 1520.84 | 0.036 | 9170 | 0.36 | 2500 | 0.0774749 |
| 18 | 84 | 605.79 | 0.0148 | 1821.88 | 0.074 | 10602 | 0.74 | 2873.23 | 0.1537482 |
| 19 | 98+104 | 913.31 | 0.0138 | 2743.16 | 0.069 | 15440 | 0.69 | 5233.01 | 0.1907781 |
| 20 | 117+125 | 2273.02 | 0.0312 | 6390.38 | 0.156 | 34711 | 1.56 | 4759.37 | 0.106563 |
| 21 | 146 | 2026.66 | 0.0302 | 6650.81 | 0.151 | 37365 | 1.51 | 2705 | 0.0479208 |
| 22 | 160 | 798.19 | 0.0098 | 2655.91 | 0.049 | 16169 | 0.49 | | 0 0 |
| 23 | 174 | 1907.23 | 0.0248 | 6102.88 | 0.124 | 37156 | 1.24 | 2149.94 | 0.0305385 |
| 24 | 203 | 2238.92 | 0.0186 | 7302.64 | 0.093 | 43294 | 0.93 | 1331.45 | 0.0110611 |
| 25 | 232+244 | 2317.33 | 0.0196 | 7432.33 | 0.098 | 44594 | 0.98 | 846.4 | 0.0071589 |
| 26 | 280 | 3483.92 | 0.022 | 11286 | 0.11 | 70030 | 1.1 | 959.85 | 0.0060612 |
| 27 | 332 | 1979.57 | 0.0084 | 5596 | 0.042 | 30888 | 0.42 | 989.31 | 0.004198 |
| 28 | 372 | 1932.43 | 0.008 | 6173.43 | 0.04 | 38892 | 0.4 | 468.79 | 0.0019407 |
| 29 | 448 | 637.46 | 0.0012 | 2074.41 | 0.006 | 13261 | 0.06 | | 0 0 |
| 30 | 528 | 1224.81 | 0.003 | 4286.55 | 0.015 | 25641 | 0.15 | 127.76 | 0.0003129 |
| 31 | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | DCB area | DCB ng/ini. | |
| 32 | DCB | 1083.15 | 0.00038 | 4177.77 | 0.01936 | 21540 | 0.1936 | | 0 0 |
| 33 | | | | | | | | | |
| 34 | The detection limit for this analysis is 0.1 ng/injection | | | | | | Total ng PCB | 2.7393445 | |
| 35 | These analyses are accurate to no more than 2 significant digits | | | | | | | | |
| 36 | | | | | | | g used* | 3.6 | |
| 37 | | 1083.15 | 0.00038 | 1083.15 | | | mL total vol. | 10 | |
| 38 | | 4177.77 | 0.01936 | 4177.77 | | | *as received, 61% moisture. | | |
| 39 | | 21540 | 0.1936 | 21540 | | | ppm PCB | 380.46451 | |
| 40 | | | | | | | | | |
| 41 | | | | | | | ul DCB used | | |
| 42 | | | | | | | conc (ng/ul) | | |
| 43 | | | | | | | DCB %R | #DIV/0! | |
| 44 | | | | | | | | | |
| 45 | Homolog | ng/inj | Homolog | ng/inj | Homolog | ng/inj | Homolog | ppm | |
| 46 | mono | 0.0022 | mono | 0.011 | mono | 0.11 | mono | 2.1884553 | |
| 47 | di | 0.0339 | di | 0.1695 | di | 1.695 | di | 63.588857 | |
| 48 | tri | 0.078388 | tri | 0.39194 | tri | 3.9194 | tri | 129.53388 | |
| 49 | tetra | 0.045112 | tetra | 0.22556 | tetra | 2.2556 | tetra | 107.33645 | |
| 50 | penta | 0.030266 | penta | 0.15133 | penta | 1.5133 | penta | 43.070502 | |
| 51 | hexa | 0.093254 | hexa | 0.46627 | hexa | 4.6627 | hexa | 30.730967 | |
| 52 | hepta | 0.06968 | hepta | 0.3484 | hepta | 3.484 | hepta | 3.7023831 | |
| 53 | octa | 0.0122 | octa | 0.061 | octa | 0.61 | octa | 0.313008 | |

NBWM2/22-70, Webb McCall Calculations for New Bedford

| | W | X | Y | Z | AA | AB | AC | AD | AE | AF | AG | AH |
|----|---------------|--------------|---|---------------|--------------|----|---------------|--------------|----|---------------|--------------|----|
| 1 | SAMPLE # | R7007880222 | | SAMPLE # | HXBKF22B | | SAMPLE # | HXBKF22A | | SAMPLE # | R7007880222 | |
| 2 | | 1000SJR | | | | | | | | | 1102SJR | |
| 3 | dilution used | 0.1 | | dilution used | 1 | | dilution used | 1 | | dilution used | 0.1 | |
| 4 | inj.vol | 2 | | inj.vol | 2 | | inj.vol | 2 | | inj.vol | 2 | |
| 5 | Peak Area | ng/injection | | Peak Area | ng/injection | | Peak Area | ng/injection | | Peak Area | ng/injection | |
| 6 | 301.59 | 0.0360112 | 1 | | 0 | 0 | 189.78 | 0.0198548 | 1 | 136.43 | 0.0121459 | 1 |
| 7 | 347.69 | 0.061728 | 1 | 70.17 | 0.0031729 | 0 | 35.35 | 0.0015984 | 0 | | 0 | 0 |
| 8 | 4681.38 | 0.6506484 | 1 | | 0 | 0 | 128.58 | 0.0062612 | 0 | 2310.43 | 0.278322 | 1 |
| 9 | 5447.91 | 0.4926337 | 1 | | 0 | 0 | 174.32 | 0.0070596 | 0 | 4050.75 | 0.3431051 | 1 |
| 10 | 4847.28 | 0.3084292 | 1 | | 0 | 0 | 1090.24 | 0.034396 | 1 | 1834.59 | 0.078182 | 1 |
| 11 | 2436.49 | 0.0647157 | 1 | | 0 | 0 | 254.87 | 0.0052384 | 0 | 12023 | 0.5336834 | 1 |
| 12 | 6665.45 | 0.3637312 | 1 | | 0 | 0 | 514.17 | 0.0149597 | 0 | 2838.23 | 0.1129851 | 1 |
| 13 | 4737.95 | 0.2749208 | 1 | 59.05 | 0.0016731 | 0 | 127.77 | 0.0036202 | 0 | 7270.64 | 0.462104 | 1 |
| 14 | | 0 | 0 | 32.17 | 0.0008818 | 0 | 120.32 | 0.0032982 | 0 | 5420.2 | 0.3240541 | 1 |
| 15 | 6665.45 | 0.3067529 | 1 | 101.89 | 0.0021544 | 0 | 218.08 | 0.0046111 | 0 | 929.24 | 0.0253758 | 1 |
| 16 | | | | | | | | | | | | |
| 17 | 500 | 0.0092175 | 1 | | 0 | 0 | 50 | 0.0008509 | 0 | 500 | 0.0092175 | 1 |
| 18 | 691.84 | 0.018989 | 1 | | 0 | 0 | 54.77 | 0.0013381 | 0 | 445.19 | 0.0108764 | 0 |
| 19 | 1451.27 | 0.0300283 | 1 | | 0 | 0 | 265.1 | 0.0040056 | 0 | 924.93 | 0.0141505 | 1 |
| 20 | 677.68 | 0.009302 | 0 | 99.94 | 0.0013718 | 0 | 754.06 | 0.0103504 | 0 | 1007.04 | 0.0138229 | 0 |
| 21 | 828.5 | 0.0123458 | 0 | | 0 | 0 | 233.51 | 0.0034796 | 0 | | 0 | 0 |
| 22 | | 0 | 0 | | 0 | 0 | 555.88 | 0.006825 | 0 | | 0 | 0 |
| 23 | | 0 | 0 | | 0 | 0 | | | 0 | 771.2 | 0.010028 | 0 |
| 24 | | 0 | 0 | 16.92 | 0.0001406 | 0 | 1403.57 | 0.0116603 | 0 | 867.39 | 0.0072059 | 0 |
| 25 | | 0 | 0 | | 0 | 0 | | | 0 | 498.37 | 0.0042152 | 0 |
| 26 | | 0 | 0 | | 0 | 0 | | | 0 | 370.55 | 0.0023399 | 0 |
| 27 | | 0 | 0 | | 0 | 0 | 580.94 | 0.0024651 | 0 | 523.19 | 0.0022201 | 0 |
| 28 | | 0 | 0 | | 0 | 0 | 589.52 | 0.0024405 | 0 | | 0 | 0 |
| 29 | | 0 | 0 | | 0 | 0 | 217.14 | 0.0004088 | 0 | | 0 | 0 |
| 30 | | 0 | 0 | | 0 | 0 | | | 0 | 0 | 0 | 0 |
| 31 | DCB area | DCB ng/inj. | | DCB area | DCB ng/inj. | | DCB area | DCB ng/inj. | | DCB area | DCB ng/inj. | |
| 32 | 6583.14 | 0.0434993 | 1 | | 0 | 0 | | | 0 | 2103.8 | 0.0066399 | 1 |
| 33 | | | | | | | | | | | | |
| 34 | Total ng PCB | 2.6394537 | | Total ng PCB | 0.0093946 | | Total ng PCB | 0.144722 | | Total ng PCB | 2.2440339 | |
| 35 | | | | | | | | | | | | |
| 36 | g used | 1.4 | | g used | 1 | | g used | 1 | | g used | 0.9 | |
| 37 | mL total vol. | 10 | | mL total vol. | 1 | | mL total vol. | 1 | | mL total vol. | 10 | |
| 38 | | | | | | | | | | | | |
| 39 | ppm PCB | 94.266203 | | ppm PCB | 0.0046973 | | ppm PCB | 0.072361 | | ppm PCB | 124.66855 | |
| 40 | | | | | | | | | | | | |
| 41 | ul DCB used | 5 | | ul DCB used | | | ul DCB used | | | ul DCB used | 5 | |
| 42 | conc (ng/ul) | 484 | | conc (ng/ul) | | | conc (ng/ul) | | | conc (ng/ul) | 96.8 | |
| 43 | DCB %R | 89.874538 | | DCB %R | #DIV/0! | | DCB %R | #DIV/0! | | DCB %R | 68.593759 | |
| 44 | | | | | | | | | | | | |
| 45 | Homolog | ppm | | Homolog | ppm | | Homolog | ppm | | Homolog | ppm | |
| 46 | mono | 1.2861136 | | mono | 0 | | mono | 0.0099274 | | mono | 0.6747706 | |
| 47 | di | 29.84053 | | di | 0.0015864 | | di | 0.0048123 | | di | 20.227684 | |
| 48 | tri | 39.512548 | | tri | 0.0001455 | | tri | 0.0304886 | | tri | 60.506512 | |
| 49 | tetra | 21.10326 | | tetra | 0.0022092 | | tetra | 0.005646 | | tetra | 39.656309 | |
| 50 | penta | 1.5336947 | | penta | 8.231E-05 | | penta | 0.0028591 | | penta | 1.2781408 | |
| 51 | hexa | 0.9900575 | | hexa | 0.0006106 | | hexa | 0.009017 | | hexa | 1.5007446 | |
| 52 | hepta | 0 | | hepta | 6.325E-05 | | hepta | 0.0081859 | | hepta | 0.8243896 | |
| 53 | octa | 0 | | octa | 0 | | octa | 0.0014246 | | octa | 0 | |

NBWM2/22-70, Webb McCall Calculations for New Bedford

| | AU | AV | AW | AX | AY | AZ | BA | BB | BC | BD | BE | BF |
|----|---------------|--------------|---------------|--------------|---------------|--------------|---------------|---------------|--------------|-------------|------------|----|
| 1 | SAMPLE # | R7007880222 | SAMPLE # | R7007880222 | SAMPLE # | | HXBKF22C | | SAMPLE # | R7007880222 | | |
| 2 | | 1302SJR | | | 1400SJR | | | | | 1400SJRA | | |
| 3 | dilution used | 1 | dilution used | 0.1 | dilution used | | 1 | dilution used | | 1 | | |
| 4 | inj.vol | 2 | inj.vol | 2 | inj.vol | | 2 | inj.vol | | 2 | | |
| 5 | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | | Peak Area | ng/injection | | | |
| 6 | | 0 0 | 117.14 | 0.00946957 | 1 | | 0 0 | 1284.9 | 0.17809763 | 2 | | |
| 7 | 10067 | 2.7145002 | 2 | 95.83 | 0.00433316 | 0 | 55.44 | 0.00250684 | 0 | 1039.63 | 0.25058498 | 1 |
| 8 | 42115 | 6.52910339 | 2 | 247.79 | 0.01206622 | 0 | 206.16 | 0.01003903 | 0 | 1791.58 | 0.19684351 | 1 |
| 9 | 83627 | 8.85961074 | 2 | 90.14 | 0.00365047 | 0 | | 0 0 | 804 | 0.03926069 | 1 | |
| 10 | 67159 | 5.07065098 | 2 | 188.73 | 0.0035057 | 0 | 47.18 | 0.00087638 | 0 | 4700.3 | 0.29719616 | 1 |
| 11 | 80793 | 4.13348763 | 2 | 71.13 | 0.00146196 | 0 | 11.73 | 0.00024109 | 0 | | 0 0 | |
| 12 | 52645 | 3.37614981 | 2 | 58.65 | 0.00170642 | 0 | 13.82 | 0.00040209 | 0 | | 0 0 | |
| 13 | | 0 0 | 321.56 | 0.00911111 | 0 | | | 0 0 | | | 0 0 | |
| 14 | 50773 | 3.53546987 | 2 | | 0 0 | 121.23 | 0.00332311 | 0 | | | 0 0 | |
| 15 | | 0 0 | | 0 0 | 257.03 | 0.00543465 | 0 | | | | 0 0 | |
| 16 | | | | | | | | | | | | |
| 17 | | 0 0 | 168.43 | 0.00286622 | 0 | | | 0 0 | 1500 | 0.03545325 | 1 | |
| 18 | | 0 0 | 184.81 | 0.00451508 | 0 | | | 0 0 | 1816.94 | 0.07375952 | 1 | |
| 19 | | 0 0 | 526 | 0.00794779 | 0 | | | 0 0 | 2775.98 | 0.07060522 | 1 | |
| 20 | | 0 0 | 251.71 | 0.00345503 | 0 | | | 0 0 | 2362.65 | 0.03391675 | 1 | |
| 21 | | 0 0 | 988.04 | 0.01472314 | 0 | 794.87 | 0.01184465 | 0 | 1397.32 | 0.02082198 | 0 | |
| 22 | | 0 0 | | 0 0 | 506.18 | 0.00621477 | 0 | | | 0 0 | | |
| 23 | | 0 0 | 289.73 | 0.0037674 | 0 | | | 0 0 | 382.75 | 0.00497696 | 0 | |
| 24 | | 0 0 | 419.55 | 0.00348544 | 0 | 108.85 | 0.00090428 | 0 | | 0 0 | | |
| 25 | | 0 0 | 200.48 | 0.00169566 | 0 | | | 0 0 | 217.19 | 0.001837 | 0 | |
| 26 | | 0 0 | | 0 0 | | | | 0 0 | | 0 0 | | |
| 27 | | 0 0 | | 0 0 | 417.76 | 0.0017727 | 0 | 61.47 | 0.00026084 | 0 | | |
| 28 | | 0 0 | | 0 0 | 133.23 | 0.00055155 | 0 | 34.66 | 0.00014349 | 0 | | |
| 29 | | 0 0 | | 0 0 | | | | 0 0 | | 0 0 | | |
| 30 | | 0 0 | | 0 0 | | | | 0 0 | | 0 0 | | |
| 31 | DCB area | DCB ng/inj. | DCB area | DCB ng/inj. | DCB area | DCB ng/inj. | | DCB area | DCB ng/inj. | | | |
| 32 | 7156.67 | 0.04925498 | 1 | 1978.8 | 0.00587322 | 1 | | 0 0 | 7579.45 | 0.05349782 | 1 | |
| 33 | | | | | | | | | | | | |
| 34 | Total ng PCB | 34.2189726 | Total ng PCB | 0.08776036 | Total ng PCB | 0.04411114 | | Total ng PCB | 1.20375795 | | | |
| 35 | | | | | | | | | | | | |
| 36 | g used | 2.1 | g used | 0.5 | g used | 1 | g used | 0.5 | | | | |
| 37 | mL total vol. | 10 | mL total vol. | 10 | mL total vol. | 1 | mL total vol. | 10 | | | | |
| 38 | | | | | | | | | | | | |
| 39 | ppm PCB | 81.4737444 | ppm PCB | 8.77603595 | ppm PCB | 0.02205557 | ppm PCB | 12.0375795 | | | | |
| 40 | | | | | | | | | | | | |
| 41 | ul DCB used | 5 | ul DCB used | 5 | ul DCB used | | ul DCB used | 5 | | | | |
| 42 | conc (ng/ul) | 96.8 | conc (ng/ul) | 96.8 | conc (ng/ul) | | conc (ng/ul) | 96.8 | | | | |
| 43 | DCB %R | 50.8832448 | DCB %R | 60.6737888 | DCB %R | #DIV/0! | DCB %R | 55.2663454 | | | | |
| 44 | | | | | | | | | | | | |
| 45 | Homolog | ppm | Homolog | ppm | Homolog | ppm | Homolog | ppm | | | | |
| 46 | mono | 0 | mono | 0.94695652 | mono | 0 | mono | 1.78097631 | | | | |
| 47 | di | 27.2821578 | di | 1.73119949 | di | 0.00627294 | di | 4.57243655 | | | | |
| 48 | tri | 48.5516703 | tri | 0.94119216 | tri | 0.00130809 | tri | 3.26641682 | | | | |
| 49 | tetra | 5.63991622 | tetra | 1.19773243 | tetra | 0.00383057 | tetra | 0.35453248 | | | | |
| 50 | penta | 0 | penta | 1.15472048 | penta | 0.00029612 | penta | 1.31118489 | | | | |
| 51 | hexa | 0 | hexa | 2.33793536 | hexa | 0.00722511 | hexa | 0.73145626 | | | | |
| 52 | hepta | 0 | hepta | 0.46629951 | hepta | 0.00284697 | hepta | 0.01914134 | | | | |
| 53 | octa | 0 | octa | 0 | octa | 0.00027578 | octa | 0.00143488 | | | | |

NBWM2/22-70, Webb McCall Calculations for New Bedford

| | BS | BT | BU | BV | BW | BX | BY | BZ | CA | CB | CC | CD |
|----|---------------|--------------|----|---------------|--------------|----|---------------|---------------|------------|---------------|--------------|----|
| 1 | SAMPLE # | HEXANE | | SAMPLE # | R7007880222 | | SAMPLE # | R700788022 | | SAMPLE # | | |
| 2 | | | | | 1502SJR | | | 1600STG-REINT | | | | |
| 3 | dilution used | | 1 | dilution used | 0.1 | | dilution used | 1 | | dilution used | | |
| 4 | inj.vol | | 4 | inj.vol | 2 | | inj.vol | 2 | | inj.vol | | |
| 5 | Peak Area | ng/injection | | Peak Area | ng/injection | | Peak Area | ng/injection | | Peak Area | ng/injection | |
| 6 | 34.9418 | 0.00121671 | 0 | 109.43 | 0.00843086 | 1 | 402.86 | 0.05064451 | 1 | | 0 | 0 |
| 7 | 322.82 | 0.05494006 | 1 | 533.02 | 0.11231169 | 1 | 786.87 | 0.18159709 | 1 | | 0 | 0 |
| 8 | 113.85 | 0.00554397 | 0 | 418.67 | 0.02038728 | 0 | 73.7645 | 0.00359199 | 0 | | 0 | 0 |
| 9 | | 0 | 0 | 623.52 | 0.02731404 | 1 | 21.0192 | 0.00085123 | 0 | | 0 | 0 |
| 10 | 189.08 | 0.0035122 | 0 | 763.3 | 0.01765414 | 1 | 739.83 | 0.01645229 | 1 | | 0 | 0 |
| 11 | 196.14 | 0.00403133 | 0 | 299.74 | 0.00616066 | 0 | 162.25 | 0.00333478 | 0 | | 0 | 0 |
| 12 | 61.2022 | 0.00178067 | 0 | 434.71 | 0.01264785 | 0 | | | 0 | 0 | 0 | 0 |
| 13 | 17.7359 | 0.00050253 | 0 | 148.92 | 0.00421951 | 0 | | | 0 | 0 | 0 | 0 |
| 14 | 66.7408 | 0.00182947 | 0 | | | 0 | | | 0 | 0 | 0 | 0 |
| 15 | 275.66 | 0.00582857 | 0 | | | 0 | | | 0 | 0 | 0 | 0 |
| 16 | | | | | | | | | | | | |
| 17 | | 0.00348973 | 0 | | | 0 | 0 | | 0 | 0 | 0 | 0 |
| 18 | 205.07 | 0.00501005 | 0 | | | 0 | 0 | 85.2812 | 0.0020835 | 0 | 0 | 0 |
| 19 | 290.85 | 0.00439471 | 0 | | | 0 | 0 | 75.8802 | 0.00114654 | 0 | 0 | 0 |
| 20 | 731.21 | 0.01003676 | 0 | | | 0 | 0 | | 0 | 0 | 0 | 0 |
| 21 | 833.78 | 0.01242446 | 0 | | | 0 | 0 | | 0 | 0 | 0 | 0 |
| 22 | | 0 | 0 | | | 0 | 0 | | 0 | 0 | 0 | 0 |
| 23 | | 0 | 0 | | | 0 | 0 | | 0 | 0 | 0 | 0 |
| 24 | 481.63 | 0.00400118 | 0 | | | 0 | 0 | | 0 | 0 | 0 | 0 |
| 25 | 707.94 | 0.00598776 | 0 | | | 0 | 0 | 112.96 | 0.00095542 | 0 | 0 | 0 |
| 26 | | 0 | 0 | | | 0 | 0 | 200.97 | 0.00126907 | 0 | 0 | 0 |
| 27 | | 0 | 0 | | | 0 | 0 | | 0 | 0 | 0 | 0 |
| 28 | 338.54 | 0.00140151 | 0 | | | 0 | 0 | 134.48 | 0.00055673 | 0 | 0 | 0 |
| 29 | | 0 | 0 | | | 0 | 0 | | 0 | 0 | 0 | 0 |
| 30 | | 0 | 0 | | | 0 | 0 | 25.8906 | 6.3415E-05 | 0 | 0 | 0 |
| 31 | DCB area | DCB ng/ini. | | DCB area | DCB ng/ini. | | DCB area | DCB ng/ini. | | DCB area | DCB ng/ini. | |
| 32 | 201.32 | 7.0629E-05 | 0 | 2198.24 | 0.0072191 | 1 | 2797.3 | 0.01089327 | 1 | | 0 | 0 |
| 33 | | | | | | | | | | | | |
| 34 | Total ng PCB | 0.12593166 | | Total ng PCB | 0.20912604 | | Total ng PCB | 0.26254655 | | Total ng PCB | 0 | |
| 35 | | | | | | | | | | | | |
| 36 | g used | 1.53 | | g used | 1.7 | | g used | 1.2 | | g used | | |
| 37 | mL total vol. | 10 | | mL total vol. | 10 | | mL total vol. | 10 | | mL total vol. | | |
| 38 | | | | | | | | | | | | |
| 39 | ppm PCB | 0.20577069 | | ppm PCB | 6.15076575 | | ppm PCB | 1.09394397 | | ppm PCB | #DIV/0! | |
| 40 | | | | | | | | | | | | |
| 41 | ul DCB used | 5 | | ul DCB used | 5 | | ul DCB used | 5 | | ul DCB used | | |
| 42 | conc (ng/ul) | 96.8 | | conc (ng/ul) | 96.8 | | conc (ng/ul) | 96.8 | | conc (ng/ul) | | |
| 43 | DCB %R | 0.03648183 | | DCB %R | 74.5774545 | | DCB %R | 11.2533752 | | DCB %R | #DIV/0! | |
| 44 | | | | | | | | | | | | |
| 45 | Homolog | ppm | | Homolog | ppm | | Homolog | ppm | | Homolog | ppm | |
| 46 | mono | 0.00198809 | | mono | 0.24796657 | | mono | 0.21101877 | | mono | #DIV/0! | |
| 47 | di | 0.0988301 | | di | 4.10374958 | | di | 0.77250784 | | di | #DIV/0! | |
| 48 | tri | 0.0162221 | | tri | 1.6749463 | | tri | 0.08510623 | | tri | #DIV/0! | |
| 49 | tetra | 0.01804996 | | tetra | 0.12410329 | | tetra | 0 | | tetra | #DIV/0! | |
| 50 | penta | 0.01648327 | | penta | 0 | | penta | 0.0122164 | | penta | #DIV/0! | |
| 51 | hexa | 0.03721749 | | hexa | 0 | | hexa | 0.00164018 | | hexa | #DIV/0! | |
| 52 | hepta | 0.01468962 | | hepta | 0 | | hepta | 0.00887061 | | hepta | #DIV/0! | |
| 53 | octa | 0.00229005 | | octa | 0 | | octa | 0.00258394 | | octa | #DIV/0! | |

NBWM2/24, Webb McCall Calculations for New Bedford

| K | L | M | N | O | P | Q | R | S | T | U | V | |
|----|---------------|-----------------------|---------------|--------------|---------------|--------------|---------------|--------------|---------------|--------------|------------|---|
| 1 | SAMPLE # | R7007880224 | SAMPLE # | R7007880224 | SAMPLE # | R7007880224 | SAMPLE # | R7007880224 | SAMPLE # | R7007880224 | | |
| 2 | | 0700STG | | 0802STG | | 0900STG | | | | 1002SJR | | |
| 3 | dilution used | 0.01 | dilution used | 0.01 | dilution used | 0.01 | dilution used | 0.01 | dilution used | 0.02 | | |
| 4 | inj.vol | 2 | inj.vol | 2 | inj.vol | 2 | inj.vol | 2 | inj.vol | 2 | | |
| 5 | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | | |
| 6 | 90.76 | 0.0082932 | 1 | 88.3317 | 0.00805506 | 1 | 68.49 | 0.00610915 | 1 | 166 | 0.0175692 | 1 |
| 7 | | 0 | 0 | | 0 | 0 | 210.03 | 0.02092422 | 1 | 598.77 | 0.11286833 | 1 |
| 8 | 1721.98 | 0.2133465 | 1 | 1715.31 | 0.21240425 | 1 | 1021.03 | 0.11433066 | 1 | 826.67 | 0.08831439 | 1 |
| 9 | 2274.51 | 0.1837154 | 1 | 2325.55 | 0.18856701 | 1 | 1827.67 | 0.14124087 | 1 | 1283.22 | 0.09163702 | 1 |
| 10 | 1055.72 | 0.0453107 | 1 | 1006.06 | 0.04243953 | 1 | 839.07 | 0.03278465 | 1 | 592.94 | 0.01855411 | 1 |
| 11 | 8776.58 | 0.363473 | 1 | 9761.23 | 0.40745252 | 1 | 8711.71 | 0.36057557 | 1 | 3946.05 | 0.14771676 | 1 |
| 12 | 1466.2 | 0.066776 | 1 | 1658.06 | 0.07704098 | 1 | 1539.88 | 0.07071808 | 1 | 914 | 0.03723202 | 1 |
| 13 | 4909.24 | 0.3000526 | 1 | 5772.75 | 0.35745132 | 1 | 5648.44 | 0.34918826 | 1 | 2593.26 | 0.14610602 | 1 |
| 14 | 2298.58 | 0.1223779 | 1 | 2722.03 | 0.14845061 | 1 | 2715.18 | 0.14802885 | 1 | | 0 | 0 |
| 15 | 2270.72 | 0.0964404 | 1 | 2716.5 | 0.11732154 | 1 | 2778.9 | 0.12024447 | 1 | 2189.44 | 0.0926331 | 1 |
| 16 | 5703.63 | 0.2673113 | 1 | 7111.36 | 0.34362201 | 1 | 50233 | 0.51284089 | 1 | 9943.62 | 0.49715408 | 1 |
| 17 | 2000 | 0.06529 | 1 | 2500 | 0.08296063 | 1 | 2000 | 0.06529005 | 1 | | 0 | 0 |
| 18 | 1929.26 | 0.1071261 | 1 | 2315.61 | 0.13512865 | 1 | 1987.64 | 0.11135749 | 1 | | 0 | 0 |
| 19 | 3750.07 | 0.1435019 | 1 | 4587.23 | 0.18046929 | 1 | 4088.97 | 0.15846706 | 1 | 467.24 | 0.00821746 | 0 |
| 20 | 3260.35 | 0.084756 | 1 | 4003.67 | 0.11451035 | 1 | 2208.55 | 0.0426535 | 1 | 488.54 | 0.00792878 | 0 |
| 21 | 2350.85 | 0.0447724 | 1 | 2640.3 | 0.05484803 | 1 | 1755.03 | 0.02743058 | 0 | 313.06 | 0.00489303 | 0 |
| 22 | | 0 | 0 | | 0 | 0 | | 0 | 0 | 329.46 | 0.0041614 | 0 |
| 23 | 1697.28 | 0.0227761 | 0 | 1918.85 | 0.02693834 | 1 | 754.7 | 0.01012746 | 0 | 329.46 | 0.00442109 | 0 |
| 24 | 1016.06 | 0.0087979 | 0 | 1067.62 | 0.00924437 | 0 | 879.98 | 0.00761962 | 0 | 47.82 | 0.00041407 | 0 |
| 25 | 562.42 | 0.0050359 | 0 | 455.18 | 0.00407571 | 0 | 380.69 | 0.00340872 | 0 | 145.56 | 0.00130335 | 0 |
| 26 | 605.87 | 0.0041099 | 0 | 443.6 | 0.00300917 | 0 | 570.19 | 0.0038679 | 0 | 42 | 0.00028491 | 0 |
| 27 | 295.35 | 0.0017686 | 0 | 137.87 | 0.00082557 | 0 | 313.49 | 0.00187719 | 0 | | 0 | 0 |
| 28 | 141.48 | 0.0020345 | 0 | | 0 | 0 | 327.28 | 0.00470627 | 0 | 52.95 | 0.00076142 | 0 |
| 29 | | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 30 | 111.44 | 0.0002998 | 0 | 36.45 | 9.8073E-05 | 0 | | 0 | 0 | | 0 | 0 |
| 31 | DCB area | DCB ng/inj. | DCB area | DCB ng/inj. | DCB area | DCB ng/inj. | DCB area | DCB ng/inj. | | | | |
| 32 | 1057.31 | 0.002516 | 0 | 2645.59 | 0.01049731 | 1 | 1444.77 | 0.00343807 | 0 | 2244.27 | 0.00678564 | 1 |
| 33 | | | | | | | | | | | | |
| 34 | Total ng PCB | 2.1573662 | Total ng PCB | 2.51491304 | Total ng PCB | 2.31379149 | Total ng PCB | 1.28217054 | | | | |
| 35 | | | | | | | | | | | | |
| 36 | g used | 1.4 | g used | 1.3 | g used | 1.8 | g used | 2.4 | | | | |
| 37 | mL total vol. | 10 | mL total vol. | 10 | mL total vol. | 10 | mL total vol. | 10 | mL total vol. | 10 | | |
| 38 | | | | | | | | | | | | |
| 39 | ppm PCB | 770.48794 | ppm PCB | 967.274244 | ppm PCB | 642.719858 | ppm PCB | 133.559431 | | | | |
| 40 | | | | | | | | | | | | |
| 41 | ul DCB used | 5 | ul DCB used | 10 | ul DCB used | 5 | ul DCB used | 5 | | | | |
| 42 | conc (ng/ul) | 484 | conc (ng/ul) | 484 | conc (ng/ul) | 484 | conc (ng/ul) | 484 | conc (ng/ul) | 484 | | |
| 43 | DCB %R | 51.984365 | DCB %R | 108.443333 | DCB %R | 71.0344658 | DCB %R | 70.0995994 | | | | |
| 44 | | should have used 5 ul | | | | | | | | | | |
| 45 | Homolog | ppm | Homolog | ppm | Homolog | ppm | Homolog | ppm | | | | |
| 46 | mono | 2.9618618 | mono | 3.09810183 | mono | 1.69698602 | mono | 1.83012541 | | | | |
| 47 | di | 92.598321 | di | 99.8253861 | di | 47.3791956 | di | 23.3429138 | | | | |
| 48 | tri | 233.47536 | tri | 275.902691 | tri | 171.905131 | tri | 28.3573601 | | | | |
| 49 | tetra | 261.98831 | tetra | 346.602704 | tetra | 277.227537 | tetra | 61.6373453 | | | | |
| 50 | penta | 108.30254 | penta | 148.003829 | penta | 106.621365 | penta | 15.7762197 | | | | |
| 51 | hexa | 63.781791 | hexa | 87.7181157 | hexa | 32.2294035 | hexa | 2.12872662 | | | | |
| 52 | hepta | 6.5460623 | hepta | 6.08569703 | hepta | 4.352942583 | hepta | 0.40742583 | | | | |
| 53 | octa | 0.8336847 | octa | 0.03772024 | octa | 1.30729763 | octa | 0.07931444 | | | | |

NBWM2/24, Webb McCall Calculations for New Bedford

| AH | AI | AJ | AK | AL | AM | AN | AO | AP | AQ | AR |
|----|---------------|--------------|---------------|-------------------------|---------------|-------------------------|---------------|---------------|------------|--------|
| 1 | 4 | SAMPLE # | R7007880224 | SAMPLE # | R7007880224 | SAMPLE # | R7007880224 | SAMPLE # | | |
| 2 | | | 1300SJR | | 1700SJR | | 1702SJR | | | |
| 3 | dilution used | 0.1 | dilution used | | 1 | dilution used | 1 | dilution used | | |
| 4 | inj.vol | 2 | inj.vol | | 2 | inj.vol | 2 | inj.vol | | |
| 5 | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | | | |
| 6 | 1 | 300.42 | 0.03610473 | 1 | 10241 | 1.40683726 | 2 | 5564.82 | 0.76202659 | 2 |
| 7 | 1 | 254.46 | 0.02664408 | 1 | 4497.25 | 1.11577925 | 2 | 6000.03 | 1.50237979 | 2 |
| 8 | 1 | 299.76 | 0.02026193 | 0 | 1751.88 | 0.21757011 | 1 | 13433.96 | 1.86777392 | 2 |
| 9 | 1 | 107.46 | 0.00508533 | 0 | 1435.08 | 0.10455978 | 1 | 6630.39 | 0.59776487 | 1 |
| 10 | 0 | 1077.28 | 0.04655727 | 1 | 9869.27 | 0.65014616 | 2 | 19401 | 1.30753988 | 2 |
| 11 | 0 | | 0 0 | | 0 0 | | | 0 | 0 | |
| 12 | 0 | | 0 0 | | 0 0 | | | 0 | 0 | |
| 13 | 0 | | 0 0 | | 0 0 | | | 0 | 0 | |
| 14 | 0 | | 0 0 | | 0 0 | | | 0 | 0 | |
| 15 | 0 | | 0 0 | | 0 0 | | | 0 | 0 | |
| 16 | 2 | 36190 | 1.91992642 | 2 | 254822 | 13.7716013 | 2 | 384395 | 20.7955368 | 2 |
| 17 | 0 | | 0 0 | | 0 0 | | | 0 | 0 | 200 |
| 18 | 0 | | 0 0 | | 0 0 | | | 0 | 0 | 277.62 |
| 19 | 0 | | 0 0 | | 0 0 | | | 0 | 0 | |
| 20 | 0 | 226.26 | 0.0036721 | 0 | 3240.49 | 0.08396102 | 1 | 4593.91 | 0.13813706 | 1 |
| 21 | 0 | 114.62 | 0.00179148 | 0 | 2597.88 | 0.05337141 | 1 | 5408.93 | 0.15124243 | 1 |
| 22 | 0 | | 0 0 | | 0 0 | | | 0 | 0 | |
| 23 | 0 | | 0 0 | | 908.19 | 0.01218717 | 0 | 1561.05 | 0.02094802 | 0 |
| 24 | 0 | | 0 0 | | 0 0 | | | 1378.46 | 0.01193589 | 0 |
| 25 | 0 | | 0 0 | | 689.88 | 0.00617723 | 0 | 1726.02 | 0.01545489 | 0 |
| 26 | 0 | | 0 0 | | 250.8 | 0.00170131 | 0 | 923.52 | 0.00626472 | 0 |
| 27 | 0 | | 0 0 | | 149.78 | 0.00089689 | 0 | 528.16 | 0.00316263 | 0 |
| 28 | 0 | | 0 0 | | 0 0 | | | 866.28 | 0.01048605 | 1 |
| 29 | 0 | | 0 0 | | 0 0 | | | 0 | 0 | |
| 30 | 0 | | 0 0 | | 461.19 | 0.00124088 | 0 | 593.04 | 0.00159564 | 0 |
| 31 | DCB area | DCB ng/inj. | DCB area | DCB ng/inj. | DCB area | DCB ng/inj. | DCB area | | | |
| 32 | 0 | 2066.26 | 0.00513929 | 1 | 8114.25 | 0.06766353 | 1 | 7706.1 | 0.06192655 | 1 |
| 33 | | | | | | | | | | |
| 34 | Total ng PCB | 2.06004334 | Total ng PCB | 17.4260298 | Total ng PCB | 27.1922492 | Total ng PCB | | | |
| 35 | | | | | | | | | | |
| 36 | g used | 0.7 | g used | 1.7 | g used | 1.6 | g used | | | |
| 37 | mL total vol. | 10 | mL total vol. | 10 | mL total vol. | 10 | mL total vol. | | | |
| 38 | | | | | | | | | | |
| 39 | ppm PCB | 147.145953 | ppm PCB | 51.2530288 | ppm PCB | 84.9757789 | ppm PCB | | | |
| 40 | | | | INVALID, NEEDS DILUTION | | INVALID, NEEDS DILUTION | | | | |
| 41 | ul DCB used | 5 | ul DCB used | 5 | ul DCB used | 5 | ul DCB used | | | |
| 42 | conc (ng/ul) | 96.8 | conc (ng/ul) | 96.8 | conc (ng/ul) | 96.8 | conc (ng/ul) | | | |
| 43 | DCB %R | 53.0918051 | DCB %R | 69.9003363 | DCB %R | 63.9737104 | DCB %R | | | |
| 44 | | | | | | | | | | |
| 45 | Homolog | ppm | Homolog | ppm | Homolog | ppm | Homolog | | | |
| 46 | mono | 2.5789092 | mono | 4.13775664 | mono | 2.38133309 | mono | | | |
| 47 | di | 3.44123886 | di | 3.99849796 | di | 10.9987342 | di | | | |
| 48 | tri | 3.59794794 | tri | 2.14284115 | tri | 5.48707352 | tri | | | |
| 49 | tetra | 97.3676973 | tetra | 28.7583439 | tetra | 46.1400974 | tetra | | | |
| 50 | penta | 39.8077778 | penta | 11.7838479 | penta | 18.9213883 | penta | | | |
| 51 | hexa | 0.35238188 | hexa | 0.40409831 | hexa | 0.90290006 | hexa | | | |
| 52 | hepta | 0 | hepta | 0.02399324 | hepta | 0.10649707 | hepta | | | |
| 53 | octa | 0 | octa | 0.00364965 | octa | 0.03775528 | octa | | | |

WMNB07/20, Webb McCall Calculations for New Bedford

| K | L | M | N | O | P | Q | R | S | T | U | V |
|----|-------------------|-----------------|-------------------|-------------------|---------------|--------------|---------------|---------------|---|---|---|
| 1 | SAMPLE # | R70078804 | SAMPLE # | HXBKL20 | SAMPLE # | | | SAMPLE # | | | |
| 2 | | 051800DRG | | hexane blank | | | | | | | |
| 3 | dilution used | 1 | dilution used | 1 | dilution used | | | dilution used | | | |
| 4 | inj.vol | 2 | inj.vol | 2 | inj.vol | | | inj.vol | | | |
| 5 | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | | | |
| 6 | 37.01 | 0.0030821 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| 7 | 194.91 | 0.0058205 | 1 | 180.17 | 0.00581834 | 1 | 0 | 0 | 0 | 0 | |
| 8 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| 9 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| 10 | 38.54 | 0.0020027 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| 11 | | 0 | 0 | 50.25 | 0.0029792 | 0 | 0 | 0 | 0 | 0 | |
| 12 | | 0 | 0 | | 0 | 0 | 0 | 0 | 0 | 0 | |
| 13 | | 0 | 0 | | 0 | 0 | 0 | 0 | 0 | 0 | |
| 14 | | 0 | 0 | | 0 | 0 | 0 | 0 | 0 | 0 | |
| 15 | | 0 | 0 | 28.31 | 0.00091155 | 0 | 0 | 0 | 0 | 0 | |
| 16 | | 0 | 0 | | 0 | 0 | 0 | 0 | 0 | 0 | |
| 17 | | 0 | 0 | | 0 | 0 | 0 | 0 | 0 | 0 | |
| 18 | 73.81 | 0.0023288 | 0 | | 0 | 0 | 0 | 0 | 0 | 0 | |
| 19 | | 0 | 0 | 51.19 | 0.00104657 | 0 | 0 | 0 | 0 | 0 | |
| 20 | | 0 | 0 | | 0 | 0 | 0 | 0 | 0 | 0 | |
| 21 | | 0 | 0 | 225.38 | 0.00631592 | 0 | 0 | 0 | 0 | 0 | |
| 22 | | 0 | 0 | | 0 | 0 | 0 | 0 | 0 | 0 | |
| 23 | | 0 | 0 | | 0 | 0 | 0 | 0 | 0 | 0 | |
| 24 | 234.48 | 0.0034349 | 0 | 345.18 | 0.00505659 | 0 | 0 | 0 | 0 | 0 | |
| 25 | 334.44 | 0.0045542 | 0 | 332.14 | 0.0045229 | 0 | 0 | 0 | 0 | 0 | |
| 26 | 65.56 | 0.0007574 | 0 | 263.97 | 0.00304948 | 0 | 0 | 0 | 0 | 0 | |
| 27 | | 0 | 0 | | 0 | 0 | 0 | 0 | 0 | 0 | |
| 28 | 103.17 | 0.0006636 | 0 | 553.91 | 0.00356267 | 0 | 0 | 0 | 0 | 0 | |
| 29 | | 0 | 0 | | 0 | 0 | 0 | 0 | 0 | 0 | |
| 30 | 69.89 | 0.0002842 | 0 | | 0 | 0 | 0 | 0 | 0 | 0 | |
| 31 | DCB area | DCB ng/inj. | DCB area | DCB ng/ini. | DCB area | DCB ng/ini. | DCB area | DCB ng/ini. | | | |
| 32 | 6475.62 | 0.0866038 | 1 | 537.37 | 0.00175787 | 0 | 0 | 0 | 0 | 0 | |
| 33 | | | | | | | | | | | |
| 34 | Total ng PCB | 0.0229283 | Total ng PCB | 0.0332632 | Total ng PCB | 0 | Total ng PCB | 0 | | | |
| 35 | | | | | | | | | | | |
| 36 | | 1 | | 1 | g used | | g used | | | | |
| 37 | mL extract | 30 | mL extract | 30 | mL total vol. | | mL total vol. | | | | |
| 38 | | | | | | | | | | | |
| 39 | total μ g PCB | 0.3439252 | total μ g PCB | 0.49894796 | ppm PCB | #DIV/0! | ppm PCB | #DIV/0! | | | |
| 40 | | Reported | | | | | | | | | |
| 41 | ul DCB used | 5 | ul DCB used | n.a. | ul DCB used | | ul DCB used | | | | |
| 42 | conc (ng/ul) | 296 | conc (ng/ul) | | conc (ng/ul) | | conc (ng/ul) | | | | |
| 43 | DCB %R | 87.774129 | DCB %R | #VALUE! | DCB %R | #DIV/0! | DCB %R | #DIV/0! | | | |
| 44 | | | | | | | | | | | |
| 45 | Homolog | μ g in trap | Homolog | μ g "in trap" | Homolog | ppm | Homolog | ppm | | | |
| 46 | mono | 0.0462308 | mono | 0 | mono | #DIV/0! | mono | #DIV/0! | | | |
| 47 | di | 0.0873079 | di | 0.08727504 | di | #DIV/0! | di | #DIV/0! | | | |
| 48 | tri | 0.0300401 | tri | 0.04468797 | tri | #DIV/0! | tri | #DIV/0! | | | |
| 49 | tetra | 0 | tetra | 0.01367318 | tetra | #DIV/0! | tetra | #DIV/0! | | | |
| 50 | penta | 0.0349324 | penta | 0.01635383 | penta | #DIV/0! | penta | #DIV/0! | | | |
| 51 | hexa | 0.0119837 | hexa | 0.10845268 | hexa | #DIV/0! | hexa | #DIV/0! | | | |
| 52 | hepta | 0.1192141 | hepta | 0.17506527 | hepta | #DIV/0! | hepta | #DIV/0! | | | |
| 53 | octa | 0.0142162 | octa | 0.05343999 | octa | #DIV/0! | octa | #DIV/0! | | | |

NBWM2/24-70, Webb McCall Calculations for New Bedford

| A | B | C | D | E | F | G | H | I | J |
|----|--|--------------|--------------|--------------|--------------|--------------|---------------|-------------|--------------|
| 1 | STANDARDS (1:1 mixtures of aroclors 1242 and 1260) | | | | | | SAMPLE # | HXBKF24B | |
| 2 | | | | | | | | | |
| 3 | Total PCB Conc (ng/uL) | 0.2 | | 1 | | 10 | dilution used | 1 | |
| 4 | inj. Vol. | 2 | | 2 | | 2 | inj.vol | 2 | |
| 5 | peak ID | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection |
| 6 | 11 | 28.63 | 0.0022 | 118.36 | 0.011 | 836.31 | 0.11 | | 0 0 |
| 7 | 16 | 92.55 | 0.0058 | 272.76 | 0.029 | 1287.31 | 0.29 | 100.23 | 0.0067887 1 |
| 8 | 21 | 334.35 | 0.0226 | 1011.61 | 0.113 | 8211.13 | 1.13 | | 0 0 |
| 9 | 28 | 464.89 | 0.022 | 1499.01 | 0.11 | 11914 | 1.1 | | 0 0 |
| 10 | 32 | 483.04 | 0.0122 | 1327.08 | 0.061 | 9287.18 | 0.61 | 53.89 | 0.0013611 0 |
| 11 | 37 | 965.12 | 0.023 | 3213.56 | 0.115 | 26386 | 1.15 | | 0 0 |
| 12 | 40 | 633.04 | 0.0222 | 2292.78 | 0.111 | 19450 | 1.11 | | 0 0 |
| 13 | 47 | 477.77 | 0.0176 | 1719.11 | 0.088 | 13634 | 0.88 | 44.94 | 0.0016555 0 |
| 14 | 54 | 409.7 | 0.0136 | 1415.42 | 0.068 | 11355 | 0.68 | 25.25 | 0.0008382 0 |
| 15 | 58 | 404.73 | 0.0112 | 1407.38 | 0.056 | 12167 | 0.56 | 59.45 | 0.0016451 0 |
| 16 | 70 (deleted) | | | | | | | | |
| 17 | 78 | 366.66 | 0.0072 | 1171.22 | 0.036 | 10339 | 0.36 | | 0 0 |
| 18 | 84 | 519.54 | 0.0148 | 1472.22 | 0.074 | 10661 | 0.74 | | 0 0 |
| 19 | 98+104 | 784.66 | 0.0138 | 2062.91 | 0.069 | 16126 | 0.69 | | 0 0 |
| 20 | 117+125 | 1922.42 | 0.0312 | 5040.16 | 0.156 | 36548 | 1.56 | 542.77 | 0.0088089 0 |
| 21 | 146 | 1932.22 | 0.0302 | 5402.52 | 0.151 | 41336 | 1.51 | 225.12 | 0.0035186 0 |
| 22 | 160 | 775.87 | 0.0098 | 2151.52 | 0.049 | 17006 | 0.49 | | 0 0 |
| 23 | 174 | 1848.1 | 0.0248 | 5130.27 | 0.124 | 40352 | 1.24 | | 0 0 |
| 24 | 203 | 2148.09 | 0.0186 | 5916.03 | 0.093 | 44977 | 0.93 | 329.76 | 0.0028553 0 |
| 25 | 232+244 | 2188.95 | 0.0196 | 6020.8 | 0.098 | 46441 | 0.98 | 183.65 | 0.0016444 0 |
| 26 | 280 | 3243.15 | 0.022 | 9126.42 | 0.11 | 73859 | 1.1 | 190.17 | 0.00129 0 |
| 27 | 332 | 1402.8 | 0.0084 | 3996.79 | 0.042 | 32499 | 0.42 | 53.07 | 0.0003178 0 |
| 28 | 372 | 556.33 | 0.008 | 4545.95 | 0.04 | 36900 | 0.4 | | 0 0 |
| 29 | 448 | 556.51 | 0.0012 | 1232.53 | 0.006 | 11247 | 0.06 | | 0 0 |
| 30 | 528 | 1114.99 | 0.003 | 2473.54 | 0.015 | 22427 | 0.15 | | 0 0 |
| 31 | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | DCB area | DCB ng/ini. | |
| 32 | DCB | 2033.9 | 0.00484 | 6743.77 | 0.0484 | 37734 | 0.484 | | 0 0 |
| 33 | | | | | | | | | |
| 34 | The detection limit for this analysis is 0.1 ng/injection | | | | | | Total ng PCB | 0.0307236 | |
| 35 | These analyses are accurate to no more than 2 significant digits | | | | | | | | |
| 36 | | | | | | | g used | 1 | |
| 37 | | 1067.01 | 0.0038 | 1067.01 | | | mL total vol. | 1 | |
| 38 | | 2164.91 | 0.01936 | 2164.91 | | | | | |
| 39 | | 18598 | 0.1936 | 18598 | | | ppm PCB | 0.0153618 | |
| 40 | | | | | | | | | |
| 41 | | | | | | | ul DCB used | | |
| 42 | | | | | | | conc (ng/uL) | | |
| 43 | | | | | | | DCB %R | #DIV/0! | |
| 44 | | | | | | | | | |
| 45 | Homolog | ng/inj | Homolog | ng/inj | Homolog | ng/inj | Homolog | ppm | |
| 46 | mono | 0.0022 | mono | 0.011 | mono | 0.11 | mono | 0 | |
| 47 | di | 0.0339 | di | 0.1695 | di | 1.695 | di | 0.0033944 | |
| 48 | tri | 0.078388 | tri | 0.39194 | tri | 3.9194 | tri | 0.0008188 | |
| 49 | tetra | 0.045112 | tetra | 0.22556 | tetra | 2.2556 | tetra | 0.0019311 | |
| 50 | penta | 0.030266 | penta | 0.15133 | penta | 1.5133 | penta | 0.0006165 | |
| 51 | hexa | 0.093254 | hexa | 0.46627 | hexa | 4.6627 | hexa | 0.0057722 | |
| 52 | hepta | 0.06968 | hepta | 0.3484 | hepta | 3.484 | hepta | 0.0028288 | |
| 53 | octa | 0.0122 | octa | 0.061 | octa | 0.61 | octa | 0 | |

NBWM2/24-70, Webb McCall Calculations for New Bedford

| | W | X | Y | Z | AA | AB | AC | AD | AE | AF | AG |
|----|---------------|--------------|---|---------------|--------------|----|---------------|--------------|----|---------------|--------------|
| 1 | SAMPLE # | R7007880224 | | SAMPLE # | DCBMB | | SAMPLE # | HXBKF24C | | SAMPLE # | R700788022 |
| 2 | | 1100DJR | | | 484PPM | | | | | | 1202SJR |
| 3 | dilution used | 0.1 | | dilution used | 0.01 | | dilution used | | 1 | dilution used | 0.1 |
| 4 | inj.vol | 2 | | inj.vol | 2 | | inj.vol | | 2 | inj.vol | 2 |
| 5 | Peak Area | ng/injection | | Peak Area | ng/injection | | Peak Area | ng/injection | | Peak Area | ng/injection |
| 6 | 376.97 | 0.04666041 | 1 | 37.28 | 0.00304832 | 1 | | 0 | 0 | 230.89 | 0.02651706 |
| 7 | 408.12 | 0.0638223 | 1 | 176.82 | 0.01664881 | 1 | 177.71 | 0.01676339 | 1 | 808.32 | 0.16677651 |
| 8 | 1556.53 | 0.18997508 | 1 | | 0 | 0 | 63.13 | 0.0042672 | 0 | 1515.01 | 0.18410999 |
| 9 | 259.39 | 0.01227512 | 0 | | 0 | 0 | | 0 | 0 | 4964.22 | 0.43938658 |
| 10 | 663.2 | 0.02261634 | 1 | 26.69 | 0.0006741 | 0 | 310.37 | 0.00783892 | 0 | | 0 |
| 11 | 400 | 0.00953249 | 0 | 40 | 0.00095325 | 0 | | 0 | 0 | | 0 |
| 12 | 16.44 | 0.00057653 | 0 | 5.23 | 0.00018341 | 0 | | 0 | 0 | | 0 |
| 13 | | 0 | 0 | | 0 | 0 | 38.31 | 0.00141126 | 0 | | 0 |
| 14 | | 0 | 0 | 80.87 | 0.00268448 | 0 | | 0 | 0 | | 0 |
| 15 | | 0 | 0 | 46.25 | 0.00127987 | 0 | | 0 | 0 | | 0 |
| 16 | | | | | | | | | | | |
| 17 | | 0 | 0 | 20 | 0.00039273 | 0 | | 0 | 0 | | 0 |
| 18 | | 0 | 0 | 23.66 | 0.000674 | 0 | | 0 | 0 | | 0 |
| 19 | | 0 | 0 | 80.51 | 0.00141595 | 0 | | 0 | 0 | | 0 |
| 20 | 547.95 | 0.00889298 | 0 | 97.79 | 0.00158709 | 0 | 135.82 | 0.0022043 | 0 | | 0 |
| 21 | 240.37 | 0.00375691 | 0 | 22.17 | 0.00034651 | 0 | | 0 | 0 | 824.5 | 0.01288668 |
| 22 | | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 |
| 23 | 92.5 | 0.00124127 | 0 | 77.25 | 0.00103663 | 0 | 93.43 | 0.00125375 | 0 | | 0 |
| 24 | 81.45 | 0.00070526 | 0 | | 0 | 0 | | 0 | 0 | | 0 |
| 25 | | 0 | 0 | | 0 | 0 | | 0 | 0 | 215.54 | 0.00192996 |
| 26 | | 0 | 0 | | 0 | 0 | | 0 | 0 | 95.22 | 0.00064593 |
| 27 | | 0 | 0 | | 0 | 0 | | 0 | 0 | 46.42 | 0.00027796 |
| 28 | | 0 | 0 | | 0 | 0 | | 0 | 0 | 100.96 | 0.0014518 |
| 29 | | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 |
| 30 | | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 |
| 31 | DCB area | DCB ng/ini. | | DCB area | DCB ng/ini. | | DCB area | DCB ng/ini. | | DCB area | DCB ng/ini. |
| 32 | 2091.77 | 0.00537522 | 1 | 2033.9 | 0.00484 | 1 | | 0 | 0 | 2004.75 | 0.00477063 |
| 33 | | | | | | | | | | | |
| 34 | Total ng PCB | 0.3600547 | | Total ng PCB | 0.03092515 | | Total ng PCB | 0.03373882 | | Total ng PCB | 0.83398246 |
| 35 | | | | | | | | | | | |
| 36 | g used | 2.1 | | g used | 1 | | g used | 1 | | g used | 2.8 |
| 37 | mL total vol. | 10 | | mL total vol. | 10 | | mL total vol. | 1 | | mL total vol. | 10 |
| 38 | | | | | | | | | | | |
| 39 | ppm PCB | 8.57273086 | | ppm PCB | 15.4625745 | | ppm PCB | 0.01686941 | | ppm PCB | 14.892544 |
| 40 | | | | | | | | | | | |
| 41 | ul DCB used | 5 | | ul DCB used | 5 | | ul DCB used | | | ul DCB used | 5 |
| 42 | conc (ng/ul) | 96.8 | | conc (ng/ul) | 484 | | conc (ng/ul) | | | conc (ng/ul) | 96.8 |
| 43 | DCB %R | 55.5291335 | | DCB %R | 100 | | DCB %R | #DIV/0! | | DCB %R | 49.2833964 |
| 44 | | | | | | | | | | | |
| 45 | Homolog | ppm | | Homolog | ppm | | Homolog | ppm | | Homolog | ppm |
| 46 | mono | 1.1109621 | | mono | 1.52416137 | | mono | 0 | | mono | 0.47351885 |
| 47 | di | 6.11586088 | | di | 8.32440486 | | di | 0.01051529 | | di | 8.22737762 |
| 48 | tri | 0.99837393 | | tri | 1.34831995 | | tri | 0.00391946 | | tri | 5.88464165 |
| 49 | tetra | 0 | | tetra | 1.73560125 | | tetra | 0.00070563 | | tetra | 0 |
| 50 | penta | 0.02988102 | | penta | 0.96478697 | | penta | 0.00013226 | | penta | 0.01150596 |
| 51 | hexa | 0.30254013 | | hexa | 1.56530008 | | hexa | 0.00159677 | | hexa | 0.22205967 |
| 52 | hepta | 0.01511279 | | hepta | 0 | | hepta | 0 | | hepta | 0.04751527 |
| 53 | octa | 0 | | octa | 0 | | octa | 0 | | octa | 0.025925 |

NBWM2/24-70, Webb McCall Calculations for New Bedford

| | AS | AT | AU | AV | AW |
|----|--------------|----|---------------|--------------|----|
| 1 | R7007880224 | | SAMPLE # | R7007880224 | |
| 2 | 1700SJR | | | 1702SJR | |
| 3 | 0.1 | | dilution used | 0.1 | |
| 4 | 2 | | inj.vol | 2 | |
| 5 | ng/injection | | Peak Area | ng/injection | |
| 6 | 0.1576874 | 2 | 639.61 | 0.08287652 | 1 |
| 7 | 0.08645576 | 1 | 665.2 | 0.1299579 | 1 |
| 8 | 0.01261977 | 0 | 2056.29 | 0.26057089 | 1 |
| 9 | 0.00304334 | 0 | 326.89 | 0.01546942 | 0 |
| 10 | 0.0095382 | 0 | 594.66 | 0.01865355 | 1 |
| 11 | 0 | 0 | 1000 | 0.02442719 | 1 |
| 12 | 0 | 0 | 14.73 | 0.00051656 | 0 |
| 13 | 0 | 0 | | 0 | 0 |
| 14 | 0 | 0 | 2722.02 | 0.14845 | 1 |
| 15 | 0 | 0 | | 0 | 0 |
| 16 | | | | | |
| 17 | 0.00392734 | 0 | | 0 | 0 |
| 18 | 0.00790849 | 0 | | 0 | 0 |
| 19 | 0 | 0 | 1077.76 | 0.02645724 | 1 |
| 20 | 0.00637188 | 0 | 1298.44 | 0.02107309 | 0 |
| 21 | 0.00253201 | 0 | 842.28 | 0.01316458 | 0 |
| 22 | 0 | 0 | 172.75 | 0.002182 | 0 |
| 23 | 0.00205314 | 0 | 172.75 | 0.00231816 | 0 |
| 24 | 0 | 0 | 320.54 | 0.00277551 | 0 |
| 25 | 0 | 0 | 111.42 | 0.00099766 | 0 |
| 26 | 0 | 0 | 206.25 | 0.0013991 | 0 |
| 27 | 0 | 0 | 141.47 | 0.00084713 | 0 |
| 28 | 0 | 0 | 169.29 | 0.00243438 | 0 |
| 29 | 0 | 0 | | 0 | 0 |
| 30 | 0 | 0 | | 0 | 0 |
| 31 | DCB ng/inj. | | DCB area | DCB ng/inj. | |
| 32 | 0.0063086 | 1 | 2126.86 | 0.00569976 | 1 |
| 33 | | | | | |
| 34 | 0.29213733 | | Total ng PCB | 0.7545709 | |
| 35 | | | | | |
| 36 | 1.7 | | g used | 1.7 | |
| 37 | 10 | | mL total vol. | 10 | |
| 38 | | | | | |
| 39 | 8.59227436 | | ppm PCB | 22.1932618 | |
| 40 | | | | | |
| 41 | 5 | | ul DCB used | 5 | |
| 42 | 96.8 | | conc (ng/ul) | 96.8 | |
| 43 | 65.1714379 | | DCB %R | 58.8817738 | |
| 44 | | | | | |
| 45 | ppm | | Homolog | ppm | |
| 46 | 4.63786475 | | mono | 2.43754481 | |
| 47 | 2.93636366 | | di | 11.5998867 | |
| 48 | 0.34766774 | | tri | 3.06434933 | |
| 49 | 0.11551012 | | tetra | 2.92533821 | |
| 50 | 0.25881513 | | penta | 0.66956938 | |
| 51 | 0.29605296 | | hexa | 1.22694209 | |
| 52 | 0 | | hepta | 0.19803187 | |
| 53 | 0 | | octa | 0.07159948 | |

WMNB 3/01, Webb McCall Calculations for New Bedford

| K | L | M | N | O | P | Q | R | S | T | U | V | |
|----|---------------|--------------|---------------|--------------|---------------|--------------|---------------|--------------|---------------|--------------|------------|---|
| 1 | SAMPLE # | R7007880222 | | |
| 2 | | 0702SJR | | 0900SJR | | 0902SJR | | | | 1002SJR | | |
| 3 | dilution used | 0.01 | dilution used | 0.02 | | |
| 4 | inj.vol | 2 | | |
| 5 | Peak Area | ng/injection | | |
| 6 | 161.83 | 0.003821 | 1 | 87.08 | 0.00128153 | 0 | 48.97 | 0.00072068 | 0 | 85.42 | 0.0012571 | 0 |
| 7 | 422.8 | 0.0040407 | 0 | | 0 | 572.51 | 0.00547143 | 0 | 500 | 0.00477846 | 0 | |
| 8 | 1187.8 | 0.1138924 | 1 | 1335.4 | 0.1368812 | 1 | | 0 | 0 | 825.87 | 0.07575162 | 1 |
| 9 | 1439.47 | 0.0964824 | 1 | 1833.36 | 0.1309393 | 1 | 451.1 | 0.02633435 | 1 | 1706.53 | 0.11788453 | 1 |
| 10 | 720.27 | 0.0293535 | 1 | 851.94 | 0.03607332 | 1 | 197.12 | 0.00626006 | 0 | 764.82 | 0.03162712 | 1 |
| 11 | 5955.55 | 0.2335223 | 1 | 7720.36 | 0.3206135 | 1 | 1887.41 | 0.05449893 | 1 | 8164.38 | 0.34252533 | 1 |
| 12 | 924.06 | 0.0334672 | 1 | 1456.68 | 0.05849903 | 1 | 371.61 | 0.01205539 | 0 | 1358.84 | 0.05390079 | 1 |
| 13 | 3564.38 | 0.1993422 | 1 | 4867.03 | 0.29267842 | 1 | 1175.02 | 0.04571414 | 1 | 5072.12 | 0.30737333 | 1 |
| 14 | 1559.21 | 0.0675329 | 1 | 2424.57 | 0.1254688 | 1 | 535.94 | 0.0203044 | 1 | 2401.55 | 0.12392195 | 1 |
| 15 | 1559.48 | 0.0519235 | 1 | 2368.46 | 0.09238007 | 1 | 539.97 | 0.01151038 | 1 | 2342.38 | 0.09103644 | 1 |
| 16 | 3169.97 | 0.1141345 | 1 | 4560.58 | 0.18894114 | 1 | 1054.96 | 0.02840212 | 1 | 4444.95 | 0.18212039 | 1 |
| 17 | 1500 | 0.0449245 | 1 | 1800 | 0.05648774 | 1 | 400 | 0.01032702 | 1 | 1500 | 0.04492451 | 1 |
| 18 | 1274.86 | 0.0567556 | 1 | 1564.72 | 0.07136672 | 1 | 347.72 | 0.01162917 | 0 | 1785.79 | 0.08675122 | 1 |
| 19 | 2755.47 | 0.0832452 | 1 | 3463.05 | 0.11655863 | 1 | 855.86 | 0.01471504 | 1 | 3490.23 | 0.11783829 | 1 |
| 20 | 2715.48 | 0.0479109 | 1 | 2013.22 | 0.02828855 | 0 | 644.81 | 0.00906048 | 0 | 1793.08 | 0.02519528 | 0 |
| 21 | 1531.07 | 0.0267704 | 0 | 1450.35 | 0.025359 | 0 | 362.22 | 0.00633332 | 0 | 699.73 | 0.0122346 | 0 |
| 22 | | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 23 | 1031.87 | 0.0180806 | 0 | 458.88 | 0.00804057 | 0 | 200.53 | 0.00351372 | 0 | 312.99 | 0.00548426 | 0 |
| 24 | 595.8 | 0.0068863 | 0 | 510.63 | 0.00590192 | 0 | 153.33 | 0.0017722 | 0 | 298.82 | 0.00345379 | 0 |
| 25 | 432.01 | 0.0048842 | 0 | 291.24 | 0.00329271 | 0 | 144.46 | 0.00163324 | 0 | 177.92 | 0.00201153 | 0 |
| 26 | 611.61 | 0.0037315 | 0 | 459.01 | 0.00280046 | 0 | 247.95 | 0.00151277 | 0 | 259.63 | 0.00158403 | 0 |
| 27 | 656.42 | 0.0033996 | 0 | 349.71 | 0.00181114 | 0 | | 0 | 0 | | 0 | 0 |
| 28 | 275.6 | 0.0016943 | 0 | 277.93 | 0.00170858 | 0 | 101.35 | 0.00062305 | 0 | 169.42 | 0.00104151 | 0 |
| 29 | | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 30 | 51.15 | 0.0002572 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 31 | DCB area | DCB ng/inj. | | | | |
| 32 | 632.17 | 0.0047971 | 1 | 606.72 | 0.00459 | 1 | 425.49 | 0.00311509 | 1 | 2777.2 | 0.02225401 | 1 |
| 33 | | | | | | | | | | | | |
| 34 | Total ng PCB | 1.2460529 | Total ng PCB | 1.70537233 | Total ng PCB | 0.27239188 | Total ng PCB | 1.63269607 | | | | |
| 35 | | | | | | | | | | | | |
| 36 | g used | 0.8 | g used | 2.1 | g used | 0.5 | g used | 0.5 | | | | |
| 37 | mL total vol. | 10 | | | | |
| 38 | | | | | | | | | | | | |
| 39 | ppm PCB | 778.78306 | ppm PCB | 406.041032 | ppm PCB | 272.391878 | ppm PCB | 816.348036 | | | | |
| 40 | | | | | | | | | | | | |
| 41 | ul DCB used | 5 | ul DCB used | 5 | ul DCB used | 5 | ul DCB used | 10 | | | | |
| 42 | conc (ng/ul) | 484 | | | | |
| 43 | DCB %R | 99.113956 | DCB %R | 94.8346233 | DCB %R | 64.3614056 | DCB %R | 114.948392 | | | | |
| 44 | | | | | | | | | | | | |
| 45 | Homolog | ppm | Homolog | ppm | Homolog | ppm | Homolog | ppm | | | | |
| 46 | mono | 2.3881363 | mono | 0.30512632 | mono | 0.72067697 | mono | 0.6285504 | | | | |
| 47 | di | 88.783571 | di | 40.3847687 | di | 12.0550204 | di | 55.0006068 | | | | |
| 48 | tri | 244.36918 | tri | 132.094054 | tri | 99.2655863 | tri | 278.680437 | | | | |
| 49 | tetra | 264.04543 | tetra | 157.085365 | tetra | 101.320989 | tetra | 327.833727 | | | | |
| 50 | penta | 99.089953 | penta | 51.6846696 | penta | 32.1588341 | penta | 115.200816 | | | | |
| 51 | hexa | 67.809301 | hexa | 21.0119651 | hexa | 21.670055 | hexa | 35.2317324 | | | | |
| 52 | hepta | 11.077858 | hepta | 3.06827801 | hepta | 4.5776659 | hepta | 3.25141019 | | | | |
| 53 | octa | 1.2196363 | octa | 0.40680412 | octa | 0.62305009 | octa | 0.52075553 | | | | |
| 54 | | | | | | | | | | | | |

WMNB 3/01, Webb McCall Calculations for New Bedford

| | AI | AJ | AK | AL | AM | AN | AO | AP | AQ | AR | AS | AT |
|----|---------------|--------------|---------------|--------------|---------------|---------------|--------------|---------------|--------------|-------------|-----------|----|
| 1 | SAMPLE # | R7007880222 | SAMPLE # | R7007880222 | SAMPLE # | R7007880222 | SAMPLE # | R7007880222 | SAMPLE # | R7007880222 | | |
| 2 | | 1402SJR | | | 1500SJR | | | 1622S/TG | | | 1622STG | |
| 3 | dilution used | 0.2 | dilution used | 0.2 | dilution used | | 1 | dilution used | | 0.2 | | |
| 4 | inj.vol | 2 | inj.vol | 2 | inj.vol | | 2 | inj.vol | | 2 | | |
| 5 | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | | | | |
| 6 | 103.33 | 0.00152068 | 0 | 139.21 | 0.00204871 | 0 | 554.79 | 0.06652318 | 1 | 145.72 | 0.0021445 | 0 |
| 7 | | 0 | 0 | 705.47 | 0.05849005 | 1 | 8563.9 | 3.12026173 | 2 | | 0 | 0 |
| 8 | 1632.17 | 0.18310324 | 1 | 128.32 | 0.00913137 | 0 | | 0 | 0 | 2289.05 | 0.2854125 | 1 |
| 9 | 1750.83 | 0.12244439 | 1 | 983.62 | 0.06412914 | 1 | 11433.27 | 1.11907007 | 2 | 2525.84 | 0.2022171 | 1 |
| 10 | 666.04 | 0.02658584 | 1 | | | 0 | 8319.81 | 0.58261244 | 1 | 892.38 | 0.0381372 | 1 |
| 11 | 2338.73 | 0.07088466 | 1 | | | 0 | 7448.35 | 0.30719015 | 1 | 2638.85 | 0.0817809 | 1 |
| 12 | 327.97 | 0.01063966 | 0 | | | 0 | 3686.76 | 0.18061255 | 1 | 606.81 | 0.0196855 | 0 |
| 13 | 1026.6 | 0.03820158 | 1 | | | 0 | 8882.76 | 0.58040972 | 1 | 1701.92 | 0.0723842 | 1 |
| 14 | 334.69 | 0.01165093 | 0 | | | 0 | | 0 | 0 | 926.86 | 0.0383471 | 1 |
| 15 | 212.69 | 0.00447651 | 0 | | | 0 | 6420.02 | 0.30111492 | 1 | 1117.74 | 0.034413 | 1 |
| 16 | 2937.69 | 0.10471899 | 1 | 47218 | 2.70520595 | 2 | 135089 | 7.88851766 | 2 | 25741 | 1.4383263 | 2 |
| 17 | | 0 | 0 | | 0 | 0 | | 0 | 0 | 200 | 0.0048943 | 0 |
| 18 | | 0 | 0 | | 0 | 0 | | 0 | 0 | 279.89 | 0.0093439 | 0 |
| 19 | 217.43 | 0.00361972 | 0 | 954.12 | 0.01805499 | 1 | 4820.5 | 0.18046842 | 1 | 227.62 | 0.0037894 | 0 |
| 20 | 307.64 | 0.00432277 | 0 | 1246.04 | 0.0175086 | 0 | 3942.97 | 0.0893453 | 1 | 725.25 | 0.0101908 | 0 |
| 21 | 133.82 | 0.00233981 | 0 | 638.73 | 0.01116803 | 0 | | 0 | 0 | 338.66 | 0.0059214 | 0 |
| 22 | | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 23 | 107.07 | 0.0018761 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 24 | 171.14 | 0.00197805 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 25 | 201.84 | 0.00228197 | 0 | 169.91 | 0.00192097 | 0 | 392.93 | 0.0044424 | 0 | 92.15 | 0.0010418 | 0 |
| 26 | 183.39 | 0.00111888 | 0 | 173.73 | 0.00105994 | 0 | 237.88 | 0.00145133 | 0 | 104.35 | 0.0006366 | 0 |
| 27 | 108.76 | 0.00056327 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 28 | 113.68 | 0.00069885 | 0 | 115.36 | 0.00070918 | 0 | 169.57 | 0.00104243 | 0 | 103.07 | 0.0006336 | 0 |
| 29 | | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 30 | | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 31 | DCB area | DCB ng/inj. | DCB area | DCB ng/inj. | DCB area | DCB ng/inj. | DCB area | DCB ng/inj. | | | | |
| 32 | 2348.69 | 0.01876667 | 1 | 2602.46 | 0.02083192 | 1 | 8967.34 | 0.08735141 | 1 | 2800.71 | 0.0224453 | 1 |
| 33 | | | | | | | | | | | | |
| 34 | Total ng PCB | 0.59302589 | Total ng PCB | 2.88942693 | Total ng PCB | 14.4230623 | Total ng PCB | 2.2493002 | | | | |
| 35 | | | | | | | | | | | | |
| 36 | g used | 1.5 | g used | ~ | 0.4 | g used | 1.1 | g used | | 1.1 | | |
| 37 | mL total vol. | 10 | mL total vol. | | 10 | mL total vol. | 10 | mL total vol. | | 10 | | |
| 38 | | | | | | | | | | | | |
| 39 | ppm PCB | 9.88976487 | ppm PCB | 180.589183 | ppm PCB | 65.5593741 | ppm PCB | 51.120459 | | | | |
| 40 | | | | | | | | | | | | |
| 41 | ul DCB used | 5 | ul DCB used | 5 | ul DCB used | 5 | ul DCB used | 5 | ul DCB used | 5 | | |
| 42 | conc (ng/ul) | 96.8 | conc (ng/ul) | 96.8 | conc (ng/ul) | 96.8 | conc (ng/ul) | 96.8 | conc (ng/ul) | 96.8 | | |
| 43 | DCB %R | 96.9352618 | DCB %R | 107.602906 | DCB %R | 90.2390569 | DCB %R | 115.93667 | | | | |
| 44 | | | | | | | | | | | | |
| 45 | Homolog | ppm | Homolog | ppm | Homolog | ppm | Homolog | ppm | Homolog | ppm | | |
| 46 | mono | 0.02534462 | mono | 0.12804452 | mono | 0.30237807 | mono | 0.048739 | | | | |
| 47 | di | 3.56190556 | di | 5.22835663 | di | 15.4546784 | di | 7.6356095 | | | | |
| 48 | tri | 3.39647101 | tri | 3.00605341 | tri | 8.68053499 | tri | 6.9072948 | | | | |
| 49 | tetra | 2.08057824 | tetra | 120.043514 | tetra | 29.4653281 | tetra | 26.33172 | | | | |
| 50 | penta | 0.56138045 | penta | 50.0331157 | penta | 11.0542645 | penta | 9.7904918 | | | | |
| 51 | hexa | 0.15450143 | hexa | 1.93147457 | hexa | 0.57268135 | hexa | 0.356423 | | | | |
| 52 | hepta | 0.09193609 | hepta | 0.17430115 | hepta | 0.02477039 | hepta | 0.0357795 | | | | |
| 53 | octa | 0.01164748 | octa | 0.04432354 | octa | 0.00473833 | octa | 0.0144005 | | | | |
| 54 | | | | | | | | | | | | |

WMNB 3/01, Webb McCall Calculations for New Bedford

| | BG | BH | BI | BJ | BK | BL | BM | BN | BO |
|----|-------------------|--------------|----|------------------------|--------------|----|------------------|--------------|----|
| 1 | SAMPLE # | R7007880222 | | SAMPLE # | R7007880224 | | SAMPLE # | R50M07 | |
| 2 | | 1600STG | | | 1702SJR | | (1 ppm standard) | | |
| 3 | dilution used | 1 | | dilution used | 1 | | dilution used | 1 | |
| 4 | inj.vol | 2 | | inj.vol | 2 | | inj.vol | 2 | |
| 5 | Peak Area | ng/injection | | Peak Area | ng/injection | | Peak Area | ng/injection | |
| 6 | 1451.94 | 0.21376274 | 2 | 614.61 | 0.07634079 | 1 | 135.38 | 0.0019923 | 0 |
| 7 | 652.21 | 0.03773909 | 1 | | 0 | 0 | 319.77 | 0.003056 | 0 |
| 8 | 2807 | 0.36608343 | 1 | 9877 | 1.46723846 | 2 | 1395.4 | 0.1462262 | 1 |
| 9 | 1252.01 | 0.08317771 | 1 | 5027.82 | 0.45974908 | 1 | 1962.58 | 0.1442401 | 1 |
| 10 | 2522.57 | 0.14935301 | 1 | 276.58 | 0.00878352 | 0 | 1410.33 | 0.0662292 | 1 |
| 11 | 1500 | 0.04043353 | 1 | 177.86 | 0.00401128 | 0 | 4206.71 | 0.1472193 | 1 |
| 12 | 221.06 | 0.0071714 | 0 | 75.06 | 0.00243502 | 0 | 3049.13 | 0.1407313 | 1 |
| 13 | 6707.57 | 0.42455506 | 1 | 993.01 | 0.03650136 | 1 | 2207.36 | 0.1021102 | 1 |
| 14 | | 0 | 0 | 235.64 | 0.00820289 | 0 | 1764.81 | 0.0811355 | 1 |
| 15 | | 0 | 0 | 149.68 | 0.00315033 | 0 | 1697.38 | 0.0578063 | 1 |
| 16 | 133635 | 7.80274948 | 2 | 58.4 | 0.00152496 | 0 | 3873.85 | 0.1484325 | 1 |
| 17 | | 0 | 0 | 25 | 0.00061179 | 0 | 1450.79 | 0.0430278 | 1 |
| 18 | | 0 | 0 | 22.17 | 0.00074145 | 0 | 1707.37 | 0.0808284 | 1 |
| 19 | 3843.4 | 0.1344658 | 1 | 251.09 | 0.00418009 | 0 | 2358.44 | 0.0657892 | 1 |
| 20 | 3030.45 | 0.05854286 | 1 | 266.41 | 0.00374343 | 0 | 5888.81 | 0.1550278 | 1 |
| 21 | 2152.57 | 0.0428785 | 1 | 47.54 | 0.00083122 | 0 | 6049.28 | 0.1619114 | 1 |
| 22 | | 0 | 0 | | 0 | 0 | 2257.81 | 0.0468958 | 1 |
| 23 | 506.14 | 0.00887323 | 0 | | 0 | 0 | 5621.04 | 0.1343896 | 1 |
| 24 | 769.05 | 0.00888888 | 0 | 347.97 | 0.00402187 | 0 | 6601.59 | 0.1031406 | 1 |
| 25 | 1040.58 | 0.01176461 | 0 | | 0 | 0 | 6831.35 | 0.1090653 | 1 |
| 26 | 474.07 | 0.00289235 | 0 | 511.56 | 0.00312108 | 0 | 10584 | 0.1208914 | 1 |
| 27 | 272.01 | 0.00140874 | 0 | | 0 | 0 | 4590.51 | 0.0440374 | 1 |
| 28 | 275.58 | 0.00169413 | 0 | 188.06 | 0.0011561 | 0 | 4951.47 | 0.0419046 | 1 |
| 29 | | 0 | 0 | | 0 | 0 | 1219.78 | 0.0061556 | 1 |
| 30 | | 0 | 0 | | 0 | 0 | 2822.57 | 0.0175197 | 1 |
| 31 | DCB area | DCB ng/inj. | | DCB area | DCB ng/inj. | | DCB area | DCB ng/inj. | |
| 32 | 9293.28 | 0.09161543 | 1 | 8499.51 | 0.08123115 | 1 | 6149.27 | 0.0504848 | 1 |
| 33 | | | | | | | | | |
| 34 | Total ng PCB | 9.39643454 | | Total ng PCB | 2.08634471 | | Total ng PCB | 2.1697637 | |
| 35 | | | | | | | | | |
| 36 | g used | 1.2 | | g used | 1.6 | | g used | 1 | |
| 37 | mL total vol. | 10 | | mL total vol. | 10 | | mL total vol. | 1 | |
| 38 | | | | | | | | | |
| 39 | ppm PCB | 39.1518106 | | ppm PCB | 6.51982723 | | ppm PCB | 1.0848818 | |
| 40 | | | | | | | | | |
| 41 | ul DCB used | 5 | | ul DCB used | 5 | | ul DCB used | 5 | |
| 42 | conc (ng/ul) | 96.8 | | conc (ng/ul) | 96.8 | | conc (ng/ul) | 5 | |
| 43 | DCB %R | 94.6440365 | | DCB %R | 83.9164774 | | DCB %R | 100.96957 | |
| 44 | | | | | | | | | |
| 45 | Homolog | ppm | | Homolog | ppm | | Homolog | ppm | |
| 46 | mono | 0.89067808 | | mono | 0.23856496 | | mono | 0.0009962 | |
| 47 | di | 1.76923728 | | di | 4.94429916 | | di | 0.0926711 | |
| 48 | tri | 1.08058843 | | tri | 1.13358929 | | tri | 0.2445673 | |
| 49 | tetra | 24.8521133 | | tetra | 0.14638166 | | tetra | 0.1813461 | |
| 50 | penta | 9.88112964 | | penta | 0.01489916 | | penta | 0.0996284 | |
| 51 | hexa | 0.57563322 | | hexa | 0.01741529 | | hexa | 0.2432018 | |
| 52 | hepta | 0.09537176 | | hepta | 0.02106489 | | hepta | 0.189681 | |
| 53 | octa | 0.00705888 | | octa | 0.00361281 | | octa | 0.03279 | |
| 54 | 1X HG CLĒAN 1X AW | | | EXCESS COPPER & AW 3/7 | | | | | |

WMNB 3/07, Webb McCall Calculations for New Bedford

| | K | L | M | N | O | P | Q | R | S | T | U | V |
|----|---------------|--------------|-------|---------------|--------------|---|---------------|--------------|--------|---------------|--------------|---|
| 1 | SAMPLE # | R7007880222 | | SAMPLE # | R7007880222 | | SAMPLE # | R7007880222 | | SAMPLE # | R7007880222 | |
| 2 | | 1200SJR | | | 1400SJR | | | 1600STG | | | 1002SJR | |
| 3 | dilution used | 1 | | dilution used | 1 | | dilution used | 1 | | dilution used | 0.1 | |
| 4 | inj.vol | 2 | | inj.vol | 2 | | inj.vol | 2 | | inj.vol | 2 | |
| 5 | Peak Area | ng/injection | | Peak Area | ng/injection | | Peak Area | ng/injection | | Peak Area | ng/injection | |
| 6 | 393.95 | 0.0605393 | 1 | 326.22 | 0.04756292 | 1 | 597.18 | 0.09947599 | 1 | 139.72 | 0.0118315 | 1 |
| 7 | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 | |
| 8 | 5362.05 | 0.8195142 | 1 | 2105.19 | 0.23942323 | 1 | 2396.1 | 0.29123825 | 1 | 4407.88 | 0.64956357 | 1 |
| 9 | 2140.79 | 0.130935 | 1 | 542.84 | 0.02863583 | 1 | 739.62 | 0.03991314 | 1 | 8382.89 | 0.85247004 | 1 |
| 10 | 216.86 | 0.0079158 | 0 | 461.4 | 0.01796703 | 1 | 515.17 | 0.02040544 | 1 | 3985.52 | 0.27854835 | 1 |
| 11 | 610.64 | 0.0135056 | 0 | 221.59 | 0.00490093 | 0 | 257.34 | 0.00569161 | 0 | 38650 | 1.98590703 | 2 |
| 12 | 164.69 | 0.0048101 | 0 | 116.94 | 0.00341547 | 0 | 143.41 | 0.00418859 | 0 | 6725.31 | 0.36984814 | 1 |
| 13 | 941.79 | 0.0295176 | 1 | 735.49 | 0.01998445 | 1 | 1192.68 | 0.04111134 | 1 | 22801 | 1.70661125 | 2 |
| 14 | 0 | 0 | | 0 | 0 | | 0 | 0 | | 10965 | 0.74586991 | 2 |
| 15 | 117.72 | 0.0026664 | 0 | 124.04 | 0.00280951 | 0 | 183.38 | 0.00415357 | 0 | 10335 | 0.58168888 | 2 |
| 16 | 35.13 | 0.0008761 | 0 | 38.57 | 0.00096192 | 0 | | 0 | 0 | 19110 | 1.11677816 | 1 |
| 17 | 25 | 0.0005532 | 0 | 25 | 0.0005532 | 0 | 18.29 | 0.00040472 | 0 | 10000 | 0.39822245 | 2 |
| 18 | 21.51 | 0.0011458 | 0 | 23.5 | 0.00125175 | 0 | 15 | 0.00079899 | 0 | 4595 | 0.32928298 | 1 |
| 19 | 115.46 | 0.0040296 | 0 | 80.37 | 0.00280495 | 0 | 124.24 | 0.00433604 | 0 | 15293.47 | 0.76425355 | 2 |
| 20 | 232.41 | 0.0065607 | 0 | 209 | 0.00589984 | 0 | 55.98 | 0.00158025 | 0 | 7778.55 | 0.25624847 | 1 |
| 21 | 185.23 | 0.002785 | 0 | 148.89 | 0.00223861 | 0 | 273.88 | 0.00411788 | 0 | 3132.39 | 0.06379678 | 1 |
| 22 | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 | |
| 23 | 0 | 0 | 62.85 | 0.00133199 | 0 | | 0 | 0 | 762.76 | 0.01616528 | 0 | |
| 24 | 0 | 0 | | 0 | 0 | | 0 | 0 | 266.64 | 0.00320997 | 0 | |
| 25 | 152.37 | 0.0017932 | 0 | 135.3 | 0.00159233 | 0 | 91.53 | 0.00107721 | 0 | 54.75 | 0.00064435 | 0 |
| 26 | 265.73 | 0.0023663 | 0 | 160.95 | 0.00143323 | 0 | 148.98 | 0.00132664 | 0 | 204.58 | 0.00182174 | 0 |
| 27 | 128.09 | 0.0010662 | 0 | 117.39 | 0.00097717 | 0 | 115.14 | 0.00095844 | 0 | 489.39 | 0.00407376 | 0 |
| 28 | 190.07 | 0.0013687 | 0 | 125.7 | 0.00090519 | 0 | 135.04 | 0.00097245 | 0 | 131.72 | 0.00094854 | 0 |
| 29 | 130.94 | 0.0005847 | 0 | | 0 | 0 | | 0 | 0 | 0 | 0 | |
| 30 | 0 | 0 | | 0 | 0 | | 0 | 0 | 0 | 0 | 0 | |
| 31 | DCB area | DCB ng/inj. | | DCB area | DCB ng/inj. | | DCB area | DCB ng/inj. | | DCB area | DCB ng/inj. | |
| 32 | 9418.15 | 0.0866449 | 1 | 10568 | 0.10009781 | 1 | 9222.38 | 0.08435446 | 1 | 9060.97 | 0.08246601 | 1 |
| 33 | | | | | | | | | | | | |
| 34 | Total ng PCB | 1.0925334 | | Total ng PCB | 0.38464956 | | Total ng PCB | 0.52175054 | | Total ng PCB | 10.1377847 | |
| 35 | | | | | | | | | | | | |
| 36 | g used | 1.3 | | g used | 0.5 | | g used | 1.2 | | g used | 0.5 | |
| 37 | mL total vol. | 10 | | mL total vol. | 10 | | mL total vol. | 10 | | mL total vol. | 10 | |
| 38 | | | | | | | | | | | | |
| 39 | ppm PCB | 4.2020516 | ✓ | ppm PCB | 3.84649564 | ✓ | ppm PCB | 2.17396057 | ✓ | ppm PCB | 1013.77847 | ✓ |
| 40 | | | | | | | | | | | | |
| 41 | ul DCB used | 5 | | ul DCB used | 5 | | ul DCB used | 5 | | ul DCB used | 5 | |
| 42 | conc (ng/ul) | 96.8 | | conc (ng/ul) | 96.8 | | conc (ng/ul) | 96.8 | | conc (ng/ul) | 484 | |
| 43 | DCB %R | 89.509204 | | DCB %R | 103.406825 | | DCB %R | 87.1430363 | | DCB %R | (170.38432) | |
| 44 | | | | | | | | | | | | |
| 45 | Homolog | ppm | | Homolog | ppm | | Homolog | ppm | | Homolog | ppm | |
| 46 | mono | 0.2328434 | | mono | 0.47562925 | | mono | 0.41448331 | | mono | 1.18314981 | |
| 47 | di | 3.2778767 | | di | 2.46582191 | | di | 1.2550689 | | di | 86.2631086 | |
| 48 | tri | 0.4785873 | | tri | 0.47760299 | | tri | 0.2509187 | | tri | 351.979313 | |
| 49 | tetra | 0.1283048 | | tetra | 0.24030126 | | tetra | 0.1902901 | | tetra | 397.916791 | |
| 50 | penta | 0.0204164 | | penta | 0.04426287 | | penta | 0.0183466 | | penta | 125.263593 | |
| 51 | hexa | 0.0371006 | | hexa | 0.09539052 | | hexa | 0.02724042 | | hexa | 50.1362225 | |
| 52 | hepta | 0.0194093 | | hepta | 0.03843496 | | hepta | 0.01356069 | | hepta | 0.93643929 | |
| 53 | octa | 0.007513 | | octa | 0.00905188 | | octa | 0.00405186 | | octa | 0.09485386 | |

WMNB 3/07, Webb McCall Calculations for New Bedford

| | AI | AJ | AK | AL | AM | AN | AO | AP | AQ | AR | AS | AT |
|----|---------------|--------------|---------------|--------------|---------------|--------------|---------------|--------------|---------------|--------------|-------------|----|
| 1 | SAMPLE # | R7007880222 | SAMPLE # | R7007880224 | SAMPLE # | R7007880224 | SAMPLE # | R7007880224 | SAMPLE # | HXBKM07A | | |
| 2 | | 1202SJR | | | 1002SJR | | | 1202SJR | | | | |
| 3 | dilution used | 0.1 | dilution used | 0.1 | dilution used | | | 1 | dilution used | 1 | | |
| 4 | inj.vol | 2 | inj.vol | 2 | inj.vol | | | 2 | inj.vol | 2 | | |
| 5 | Peak Area | ng/injection | | |
| 6 | 226.73 | 0.02850169 | 1 | 86.47 | 0.00697147 | 1 | 355.36 | 0.05314584 | 1 | 32.07 | 0.00249075 | 1 |
| 7 | 0 | 0 | | 0 | 0 | | 0 | 0 | 253.15 | 0.02151207 | 1 | |
| 8 | 3556.72 | 0.49796043 | 1 | 2578.22 | 0.3236763 | 1 | 9185 | 1.50043348 | 2 | 122.15 | 0.00869505 | 0 |
| 9 | 4427.36 | 0.39954677 | 1 | 6169.11 | 0.60415654 | 1 | 9065.4 | 0.94439437 | 1 | 71.21 | 0.00366847 | 0 |
| 10 | 2029.84 | 0.11333532 | 1 | 2937.24 | 0.18999116 | 1 | 876.61 | 0.03679636 | 1 | 183.67 | 0.00670429 | 0 |
| 11 | 8598.27 | 0.35354285 | 1 | 19605 | 0.95141165 | 1 | 1453.72 | 0.03502151 | 1 | 304.98 | 0.00674527 | 0 |
| 12 | 1967.19 | 0.0690277 | 1 | 4622.22 | 0.22176482 | 1 | 502.48 | 0.01467597 | 0 | | 0 | 0 |
| 13 | 4501.37 | 0.26830374 | 1 | 11437 | 0.81342781 | 1 | 867.66 | 0.02609207 | 1 | 137.96 | 0.00355042 | 0 |
| 14 | 2316.12 | 0.10862052 | 1 | 7276.67 | 0.47411379 | 1 | | 0 | 0 | 282.65 | 0.00872218 | 0 |
| 15 | 1499.04 | 0.04861316 | 1 | 925.37 | 0.02724778 | 1 | | 0 | 0 | 52.73 | 0.00119434 | 0 |
| 16 | 3405.83 | 0.11280876 | 1 | 1049.27 | 0.02624794 | 1 | | 0 | 0 | | 0 | 0 |
| 17 | 200 | 0.00442559 | 0 | 250 | 0.00553199 | 0 | | 0 | 0 | | 0 | 0 |
| 18 | 233.78 | 0.01245256 | 0 | 208.39 | 0.01110013 | 0 | | 0 | 0 | | 0 | 0 |
| 19 | 423.69 | 0.01459523 | 1 | 156.52 | 0.00546262 | 0 | 100.87 | 0.00352041 | 0 | 60.73 | 0.00211951 | 0 |
| 20 | 1089.64 | 0.03075935 | 0 | 443.34 | 0.012515 | 0 | 291.04 | 0.00821574 | 0 | 703.97 | 0.0198723 | 0 |
| 21 | | 0 | 0 | | 0 | 0 | | 0 | 0 | 168.53 | 0.00253391 | 0 |
| 22 | | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 23 | | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 24 | 94.55 | 0.00113825 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 25 | 212.13 | 0.00249653 | 0 | 280.42 | 0.00330023 | 0 | 47.08 | 0.00055408 | 0 | 166.81 | 0.00196317 | 0 |
| 26 | 444.57 | 0.0039588 | 0 | 258.89 | 0.00230536 | 0 | 168.73 | 0.00150251 | 0 | 251.37 | 0.0022384 | 0 |
| 27 | 714.58 | 0.00594828 | 0 | 283.56 | 0.0023604 | 0 | 366.99 | 0.00305489 | 0 | 476.7 | 0.00396813 | 0 |
| 28 | 200.08 | 0.00144081 | 0 | 129.51 | 0.00093262 | 0 | 107.8 | 0.00077629 | 0 | 124.41 | 0.0008959 | 0 |
| 29 | 127.8 | 0.00057064 | 0 | | 0 | 0 | | 0 | 0 | 121.85 | 0.00054407 | 0 |
| 30 | | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 31 | DCB area | DCB ng/inj. | | DCB area | DCB ng/inj. | | DCB area | DCB ng/inj. | | DCB area | DCB ng/inj. | |
| 32 | 1017.11 | 0.00734729 | 1 | 5060.61 | 0.03969169 | 1 | 9754.97 | 0.0905856 | 1 | | 0 | 0 |
| 33 | | | | | | | | | | | | |
| 34 | Total ng PCB | 2.07804697 | | Total ng PCB | 3.68251763 | | Total ng PCB | 2.62818351 | | Total ng PCB | 0.09741821 | |
| 35 | | | | | | | | | | | | |
| 36 | g used | 0.8 | g used | 1.3 | g used | 2.8 | g used | 1 | | | | |
| 37 | mL total vol. | 10 | mL total vol. | 1 | | |
| 38 | | | | | | | | | | | | |
| 39 | ppm PCB | 129.877936 | ✓ | ppm PCB | 141.635294 | ✓ | ppm PCB | 4.69318484 | ✓ | ppm PCB | 0.04870911 | |
| 40 | | | | | | | | | | | | |
| 41 | ul DCB used | 5 | ul DCB used | | | |
| 42 | conc (ng/ul) | 96.8 | conc (ng/ul) | 484 | conc (ng/ul) | 96.8 | conc (ng/ul) | 96.8 | conc (ng/ul) | | | |
| 43 | DCB %R | 75.90177 | DCB %R | 82.0076233 | DCB %R | 93.5801667 | DCB %R | #DIV/0! | | | | |
| 44 | | | | | | | | | | | | |
| 45 | Homolog | ppm | | |
| 46 | mono | 1.78135583 | mono | 0.26813351 | mono | 0.09490329 | mono | 0.00124538 | | | | |
| 47 | di | 37.3654448 | di | 18.2582858 | di | 3.10095014 | di | 0.01556212 | | | | |
| 48 | tri | 54.4631692 | tri | 75.8747151 | tri | 1.41926717 | tri | 0.00953961 | | | | |
| 49 | tetra | 29.6382788 | tetra | 45.4807638 | tetra | 0.04659298 | tetra | 0.00529431 | | | | |
| 50 | penta | 3.72866817 | penta | 0.93292991 | penta | 0.00641249 | penta | 0.0020399 | | | | |
| 51 | hexa | 1.9516539 | hexa | 0.49090416 | hexa | 0.01464387 | hexa | 0.01032111 | | | | |
| 52 | hepta | 0.82364932 | hepta | 0.29369104 | hepta | 0.00902868 | hepta | 0.00398669 | | | | |
| 53 | octa | 0.12571579 | octa | 0.03587015 | octa | 0.00138623 | octa | 0.00071999 | | | | |

WMNB 3/07, Webb McCall Calculations for New Bedford

| | BG | BH | BI | BJ | BK | BL | BM | BN | BO | BP | BQ | BR |
|----|---------------|--------------|----|---------------|--------------|----|---------------|--------------|----|---------------|--------------|----|
| 1 | SAMPLE # | R7007880224 | | SAMPLE # | R7007880224 | | SAMPLE # | R50M07A | | SAMPLE # | | |
| 2 | | 1400SJR | | | 1600SJR | | | | | | | |
| 3 | dilution used | 1 | | dilution used | 1 | | dilution used | 1 | | dilution used | | |
| 4 | inj.vol | 2 | | inj.vol | 2 | | inj.vol | 2 | | inj.vol | | |
| 5 | Peak Area | ng/injection | |
| 6 | 456 | 0.0724274 | 1 | 889.34 | 0.15545076 | 2 | 116.03 | 0.00940621 | 1 | | 0 | 0 |
| 7 | | 0 | 0 | | 0 | 0 | 259.79 | 0.02225839 | 1 | | 0 | 0 |
| 8 | 1942.27 | 0.21040497 | 1 | 2247.19 | 0.26471536 | 1 | 1327.59 | 0.10731305 | 1 | | 0 | 0 |
| 9 | 539.97 | 0.02847136 | 1 | 694.71 | 0.03733938 | 1 | 1835.6 | 0.10272288 | 1 | | 0 | 0 |
| 10 | 207.59 | 0.00757741 | 0 | 160.64 | 0.00586365 | 0 | 1471.84 | 0.06619628 | 1 | | 0 | 0 |
| 11 | 522.66 | 0.01155972 | 0 | 353.39 | 0.00781596 | 0 | 4183.92 | 0.11433792 | 1 | | 0 | 0 |
| 12 | 120.5 | 0.00351945 | 0 | 225.34 | 0.00658152 | 0 | 3074.98 | 0.11282016 | 1 | | 0 | 0 |
| 13 | 514.52 | 0.01324124 | 0 | 1000.37 | 0.03222463 | 1 | 2300.23 | 0.09529936 | 1 | | 0 | 0 |
| 14 | 289.88 | 0.00894529 | 0 | 327.85 | 0.01011699 | 0 | 1738.77 | 0.06693015 | 1 | | 0 | 0 |
| 15 | 161.84 | 0.00366569 | 0 | 200.8 | 0.00454813 | 0 | 1701.97 | 0.05626406 | 1 | | 0 | 0 |
| 16 | | 0 | 0 | 61.75 | 0.00154002 | 0 | 3706.88 | 0.12386688 | 1 | | 0 | 0 |
| 17 | 25 | 0.0005532 | 0 | 25 | 0.0005532 | 0 | 1350.85 | 0.03344247 | 1 | | 0 | 0 |
| 18 | 23.03 | 0.00122672 | 0 | 24.54 | 0.00130715 | 0 | 1658.49 | 0.07197576 | 1 | | 0 | 0 |
| 19 | 84.31 | 0.00294246 | 0 | 82.45 | 0.00287754 | 0 | 2282.7 | 0.06687021 | 1 | | 0 | 0 |
| 20 | 317.84 | 0.00897228 | 0 | 433.44 | 0.01223554 | 0 | 5561.75 | 0.14746722 | 1 | | 0 | 0 |
| 21 | 125.22 | 0.00188273 | 0 | 129.82 | 0.00195189 | 0 | 8052.81 | 0.24551624 | 1 | | 0 | 0 |
| 22 | | 0 | 0 | | 0 | 0 | 2179.85 | 0.04730572 | 1 | | 0 | 0 |
| 23 | | 0 | 0 | | 0 | 0 | 5251.93 | 0.11577332 | 1 | | 0 | 0 |
| 24 | | 0 | 0 | | 0 | 0 | 6056.35 | 0.08497758 | 1 | | 0 | 0 |
| 25 | 86.25 | 0.00101507 | 0 | 88.78 | 0.00104484 | 0 | 6322.26 | 0.09027388 | 1 | | 0 | 0 |
| 26 | 229.64 | 0.0020449 | 0 | 196.14 | 0.00174659 | 0 | 9667.12 | 0.10005531 | 1 | | 0 | 0 |
| 27 | 258.99 | 0.00215588 | 0 | 222.93 | 0.00185571 | 0 | 4233.74 | 0.03865285 | 1 | | 0 | 0 |
| 28 | 130.29 | 0.00093824 | 0 | 153.06 | 0.00110221 | 0 | 4686 | 0.03778806 | 1 | | 0 | 0 |
| 29 | | 0 | 0 | | 0 | 0 | 1146.18 | 0.00562853 | 1 | | 0 | 0 |
| 30 | | 0 | 0 | | 0 | 0 | 2550.16 | 0.01353573 | 1 | | 0 | 0 |
| 31 | DCB area | DCB ng/inj. | |
| 32 | 7553.71 | 0.06483152 | 1 | 9192.93 | 0.0840099 | 1 | 5926.25 | 0.04661604 | 1 | | 0 | 0 |
| 33 | | | | | | | | | | | | |
| 34 | Total ng PCB | 0.38154398 | | Total ng PCB | 0.55087107 | | Total ng PCB | 1.9766782 | | Total ng PCB | 0 | |
| 35 | | | | | | | | | | | | |
| 36 | g used | 1.4 | | g used | 1.5 | | g used | 1 | | g used | | |
| 37 | mL total vol. | 10 | | mL total vol. | 10 | | mL total vol. | 1 | | mL total vol. | | |
| 38 | | | | | | | | | | | | |
| 39 | ppm PCB | 1.36265706 | / | ppm PCB | 1.83623689 | / | ppm PCB | 0.9883391 | | ppm PCB | #DIV/0! | |
| 40 | | | | | | | | | | | | |
| 41 | ul DCB used | 5 | | ul DCB used | 5 | | ul DCB used | | | ul DCB used | | |
| 42 | conc (ng/ul) | 96.8 | | conc (ng/ul) | 96.8 | | conc (ng/ul) | | | conc (ng/ul) | | |
| 43 | DCB %R | 66.9747148 | | DCB %R | 86.7870899 | | DCB %R | #DIV/0! | | DCB %R | #DIV/0! | |
| 44 | | | | | | | | | | | | |
| 45 | Homolog | ppm | |
| 46 | mono | 0.25866928 | | mono | 0.51816919 | | mono | 0.00470311 | | mono | #DIV/0! | |
| 47 | di | 0.77686717 | | di | 0.91350068 | | di | 0.07762608 | | di | #DIV/0! | |
| 48 | tri | 0.16772157 | | tri | 0.17201424 | | tri | 0.19624173 | | tri | #DIV/0! | |
| 49 | tetra | 0.08376239 | | tetra | 0.15065921 | | tetra | 0.15889729 | | tetra | #DIV/0! | |
| 50 | penta | 0.0163391 | | penta | 0.01816333 | | penta | 0.09367649 | | penta | #DIV/0! | |
| 51 | hexa | 0.03768121 | | hexa | 0.04491404 | | hexa | 0.26867458 | | hexa | #DIV/0! | |
| 52 | hepta | 0.01826547 | | hepta | 0.01514216 | | hepta | 0.16004367 | | hepta | #DIV/0! | |
| 53 | octa | 0.00335086 | | octa | 0.00367404 | | octa | 0.02847616 | | octa | #DIV/0! | |

WMNB 3/09 Webb McCall Calculations for New Bedford

| | K | L | M | N | O | P | Q | R | S | T | U | V |
|----|---------------|--------------|---|---------------|--------------|---|---------------|--------------|---|---------------|--------------|---|
| 1 | SAMPLE # | R7007880308 | | SAMPLE # | R7007880309 | | SAMPLE # | R7007880309 | | SAMPLE # | R7007880309 | |
| 2 | | 1402SRG | | | 0800STG | | | 0802STG | | | 0802STG | |
| 3 | dilution used | 0.002 | | dilution used | 0.002 | | dilution used | 0.002 | | dilution used | 0.001 | |
| 4 | inj.vol | 2 | |
| 5 | Peak Area | ng/injection | |
| 6 | 372.49 | 0.0428935 | 1 | 229.41 | 0.02361866 | 1 | 420.81 | 0.04940293 | 1 | 166.21 | 0.01510474 | 1 |
| 7 | 681.37 | 0.1434853 | 1 | 489.07 | 0.09551596 | 1 | 953.87 | 0.21146053 | 1 | 308.55 | 0.05048517 | 1 |
| 8 | 5432.49 | 0.7117669 | 1 | 4425.76 | 0.56597366 | 1 | 5790.14 | 0.76356123 | 1 | 3058.04 | 0.36790241 | 1 |
| 9 | 10792 | 0.9803969 | 1 | 9610.15 | 0.86519479 | 1 | 13267 | 1.22165012 | 2 | 7370.65 | 0.64689716 | 1 |
| 10 | 7642.65 | 0.4996713 | 1 | 6720.16 | 0.4351696 | 1 | 9357.61 | 0.61958341 | 2 | 5572.53 | 0.35492587 | 1 |
| 11 | 25446 | 1.1157245 | 1 | 23541 | 1.02676692 | 1 | 32383 | 1.43966077 | 2 | 18197 | 0.77721878 | 1 |
| 12 | 16332 | 0.91444842 | 1 | 15134 | 0.84230307 | 1 | 20905 | 1.19001385 | 2 | 11722 | 0.63672532 | 1 |
| 13 | 15627 | 0.9888343 | 2 | 14580 | 0.91827731 | 2 | 20118 | 1.29148108 | 2 | 11878 | 0.70249571 | 1 |
| 14 | 10931 | 0.6491482 | 1 | 10437 | 0.61778856 | 1 | 14152 | 0.85362071 | 2 | 8062.66 | 0.46706292 | 1 |
| 15 | 10346 | 0.4639539 | 1 | 9925.35 | 0.44382343 | 1 | 13537 | 0.61666099 | 2 | 7727.71 | 0.33865412 | 1 |
| 16 | 27086 | 1.4388865 | 2 | 23194 | 1.21924153 | 1 | 31076 | 1.6640621 | 2 | 17390 | 0.89169287 | 1 |
| 17 | 7663.91 | 0.2662546 | 1 | 7075.18 | 0.244501 | 1 | 9589.58 | 0.33556054 | 1 | 5444.55 | 0.18424925 | 1 |
| 18 | 12423 | 0.8450071 | 2 | 11573 | 0.78276441 | 2 | 15598 | 1.07750198 | 2 | 9174.63 | 0.60713963 | 1 |
| 19 | 16619.13 | 0.7012083 | 2 | 15411.35 | 0.64687066 | 1 | 20560.12 | 0.8785121 | 2 | 11779.72 | 0.48348484 | 1 |
| 20 | 15626 | 0.598453 | 1 | 13887 | 0.51760733 | 1 | 18753 | 0.74382634 | 1 | 9638.43 | 0.32009247 | 1 |
| 21 | 10337 | 0.3359137 | 1 | 9263.21 | 0.29339351 | 1 | 10847 | 0.35610873 | 1 | 6198.97 | 0.17205515 | 1 |
| 22 | 1064.17 | 0.0225987 | 1 | 956.52 | 0.02032238 | 1 | 1025.21 | 0.02177486 | 1 | 557.41 | 0.01188303 | 1 |
| 23 | 8238.51 | 0.217178 | 1 | 7710.32 | 0.19878891 | 1 | 8909.82 | 0.24054991 | 1 | 5005.7 | 0.11124798 | 1 |
| 24 | 4186.07 | 0.0554353 | 1 | 4138.41 | 0.05476181 | 1 | 4375.03 | 0.05810545 | 1 | 2434.72 | 0.03068724 | 1 |
| 25 | 3830.46 | 0.0503319 | 1 | 3384.27 | 0.04398883 | 1 | 3436.55 | 0.04473205 | 1 | 1879.17 | 0.0225922 | 1 |
| 26 | 3374.99 | 0.0302234 | 1 | 2981.42 | 0.02610518 | 1 | 2850.35 | 0.02473368 | 1 | 1482.19 | 0.01259441 | 0 |
| 27 | 2126.61 | 0.0176562 | 1 | 1728.32 | 0.01419475 | 1 | 1688.53 | 0.01384894 | 1 | 677.41 | 0.00536032 | 0 |
| 28 | 1292.78 | 0.0085333 | 1 | 1072.21 | 0.0070433 | 0 | 747.81 | 0.00491233 | 0 | 299.7 | 0.00196872 | 0 |
| 29 | 494.02 | 0.0019092 | 1 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 30 | 689.68 | 0.0033909 | 1 | | 0 | 0 | 247.31 | 0.00122793 | 0 | | 0 | 0 |
| 31 | DCB area | DCB ng/inj. | |
| 32 | 543.06 | 0.002536 | 1 | 2900.46 | 0.01785809 | 1 | 3163.93 | 0.01957053 | 1 | 165.65 | 0.00076326 | 0 |
| 33 | | | | | | | | | | | | |
| 34 | Total ng PCB | 11.103339 | | Total ng PCB | 9.90401556 | | Total ng PCB | 13.7225526 | | Total ng PCB | 7.21252029 | |
| 35 | | | | | | | | | | | | |
| 36 | g used | 1.1 | | g used | 1.3 | | g used | 1.4 | | g used | 1.4 | |
| 37 | mL total vol. | 10 | |
| 38 | | | | | | | | | | | | |
| 39 | ppm PCB | 25234.861 | | ppm PCB | 19046.1838 | | ppm PCB | 24504.5581 | | ppm PCB | 25759.001 | |
| 40 | | | | | | | | | | | | |
| 41 | ul DCB used | 5 | |
| 42 | conc (ng/ul) | 484 | |
| 43 | DCB %R | 261.98525 | | DCB %R | 1844.8441 | | DCB %R | 2021.7499 | | DCB %R | 157.698825 | |
| 44 | | | | | | | | | | | | |
| 45 | Homolog | ppm | |
| 46 | mono | 97.485338 | | mono | 45.4205077 | | mono | 88.2195197 | | mono | 53.9454884 | |
| 47 | di | 2500.7986 | | di | 1688.05447 | | di | 2286.48979 | | di | 2071.82809 | |
| 48 | tri | 7907.7194 | | tri | 6071.16521 | | tri | 7941.41152 | | tri | 8600.62003 | |
| 49 | tetra | 7217.2305 | | tetra | 5550.34916 | | tetra | 7137.70105 | | tetra | 7755.1185 | |
| 50 | penta | 4249.519 | | penta | 3253.48326 | | penta | 4137.93489 | | penta | 4537.58282 | |
| 51 | hexa | 2879.8291 | | hexa | 2156.21119 | | hexa | 2648.22268 | | hexa | 2476.27592 | |
| 52 | hepta | 350.83965 | | hepta | 267.955174 | | hepta | 253.613922 | | hepta | 256.599058 | |
| 53 | octa | 31.43946 | | octa | 13.5448031 | | octa | 10.9647555 | | octa | 7.03112628 | |

WMNB 3/09 Webb McCall Calculations for New Bedford

| | AI | AJ | AK | AL | AM | AN | AO | AP | AQ | AR | AS | AT |
|----|---------------|--------------|---------------|--------------|---------------|--------------|---------------|--------------|---------------|--------------|-------------|----|
| 1 | SAMPLE # | R7007880309 | SAMPLE # | R50M09A | | |
| 2 | | 1202SJR | | | 1400SJR | | | 1402SJR | | | | |
| 3 | dilution used | 0.01 | dilution used | 0.05 | dilution used | 0.05 | dilution used | 0.05 | dilution used | | 1 | |
| 4 | ini.vol | 2 | ini.vol | 2 | ini.vol | | ini.vol | 2 | ini.vol | | 2 | |
| 5 | Peak Area | ng/injection | | |
| 6 | 572.83 | 0.06988216 | 1 | 407.5 | 0.04760989 | 1 | 808.56 | 0.1016383 | 1 | 149.28 | 0.01282403 | 1 |
| 7 | 417.84 | 0.07774761 | -1 | | 0 | 0 | | 0 | 0 | 257.25 | 0.03768836 | 1 |
| 8 | 9378.3 | 1.28319343 | x2 | 5535.63 | 0.72670345 | 1 | 9682.76 | 1.32728489 | 2 | 1416.77 | 0.13021603 | 1 |
| 9 | 14095 | 1.3023603 | 2 | 5282.73 | 0.44337495 | 1 | 6642.65 | 0.57593459 | 1 | 2150.65 | 0.13807213 | 1 |
| 10 | 8070.17 | 0.52956399 | 1 | 1353.18 | 0.0601723 | 1 | 872.28 | 0.03478703 | 1 | 1626.68 | 0.0790271 | 1 |
| 11 | 10683 | 0.4263384 | 1 | 1201.69 | 0.02276415 | 0 | 1020.7 | 0.01933558 | 0 | 4668.65 | 0.14548699 | 1 |
| 12 | 4186.26 | 0.1826865 | 1 | 495.34 | 0.0124446 | 0 | 753.1 | 0.0189204 | 0 | 3459.67 | 0.13890844 | 1 |
| 13 | 4186.26 | 0.21784701 | 1 | 717.91 | 0.01834019 | 1 | 655.43 | 0.01644344 | 0 | 2667.46 | 0.11549564 | 1 |
| 14 | 1961.23 | 0.07973765 | 1 | 333.57 | 0.00955325 | 0 | 390.36 | 0.01117968 | 0 | 2092.91 | 0.08809684 | 1 |
| 15 | 580.68 | 0.01467119 | 1 | 289.52 | 0.00680537 | 0 | 337.11 | 0.00792401 | 0 | 2110.19 | 0.06982452 | 1 |
| 16 | 1070.79 | 0.02747303 | 1 | 832.98 | 0.02102178 | 0 | 869.63 | 0.02194671 | 0 | 4552.55 | 0.16721154 | 1 |
| 17 | 304.15 | 0.00657306 | 0 | 260.74 | 0.00563491 | 0 | 712.9 | 0.01714925 | 1 | 1681.38 | 0.04520018 | 1 |
| 18 | 575.14 | 0.01643593 | 1 | 536.64 | 0.01477192 | 0 | 266.34 | 0.00733146 | 0 | 2195.96 | 0.09611447 | 1 |
| 19 | 914.55 | 0.02086137 | 1 | 765.12 | 0.01650778 | 1 | 485.09 | 0.009959 | 0 | 2999.04 | 0.08844498 | 1 |
| 20 | 714.91 | 0.01363231 | 0 | 608.17 | 0.01159693 | 0 | 666.84 | 0.01271569 | 0 | 6581.3 | 0.17796733 | 1 |
| 21 | 458.75 | 0.00836998 | 0 | 454.34 | 0.00828952 | 0 | 434.87 | 0.00793429 | 0 | 6661.59 | 0.19037406 | 1 |
| 22 | | 0 | 0 | | 0 | 0 | | 0 | 0 | 2446.26 | 0.05328321 | 1 |
| 23 | 87.25 | 0.00175438 | 0 | 214.26 | 0.00430824 | 0 | 91.66 | 0.00184305 | 0 | 5931.78 | 0.13686844 | 1 |
| 24 | 145.56 | 0.00171427 | 0 | 493.21 | 0.00580857 | 0 | 167.37 | 0.00197113 | 0 | 7073.81 | 0.09819344 | 1 |
| 25 | 141.94 | 0.00166719 | 0 | 528.09 | 0.00620281 | 0 | 123.14 | 0.00144637 | 0 | 7373.15 | 0.10228848 | 1 |
| 26 | 153.15 | 0.00130134 | 0 | 827.8 | 0.00703395 | 0 | 244.25 | 0.00207543 | 0 | 11187 | 0.1129644 | 1 |
| 27 | | 0 | 0 | | 0 | 0 | | 0 | 0 | 5006.81 | 0.04306085 | 1 |
| 28 | | 0 | 0 | | 0 | 0 | | 0 | 0 | 5673.89 | 0.03971262 | 1 |
| 29 | | 0 | 0 | | 0 | 0 | | 0 | 0 | 1549.46 | 0.00585009 | 1 |
| 30 | | 0 | 0 | | 0 | 0 | | 0 | 0 | 3279.53 | 0.01533974 | 1 |
| 31 | DCB area | DCB ng/inj. | | DCB area | DCB ng/inj. | | DCB area | DCB ng/inj. | | DCB area | DCB ng/inj. | |
| 32 | 705.79 | 0.00359369 | 1 | 790.53 | 0.00414446 | 1 | 641.21 | 0.00317395 | 1 | 6792.11 | 0.04315212 | 1 |
| 33 | | | | | | | | | | | | |
| 34 | Total ng PCB | 4.28381111 | | Total ng PCE | 1.44894456 | | Total ng PCB | 2.1978203 | | Total ng PCB | 2.32851392 | |
| 35 | | | | | | | | | | | | |
| 36 | g used (est.) | 1.4 | g used | 0.6 | g used | 1.1 | g used | | | | | 1 |
| 37 | mL total vol. | 10 | mL total vol. | | | 1 |
| 38 | | | | | | | | | | | | |
| 39 | ppm PCB | 1529.93254 | ✓ | ppm PCB | 241.490761 | ✓ | ppm PCB | 199.801846 | ✓ | ppm PCB | 1.16425696 | |
| 40 | | | | | | | | | | | | |
| 41 | ul DCB used | 5 | ul DCB used | | 5 | |
| 42 | conc (ng/ul) | 484 | conc (ng/ul) | 96.8 | conc (ng/ul) | 96.8 | conc (ng/ul) | 96.8 | conc (ng/ul) | | 5 | |
| 43 | DCB %R | 74.2498219 | DCB %R | 85.6294315 | DCB %R | 65.5774689 | DCB %R | 86.3042431 | | | | |
| 44 | | | | | | | | | | | | |
| 45 | Homolog | ppm | | |
| 46 | mono | 24.957914 | mono | 7.9349812 | mono | 9.23984542 | mono | 0.00641201 | | | | |
| 47 | di | 602.332539 | di | 139.591198 | di | 133.751685 | di | 0.10121121 | | | | |
| 48 | tri | 764.883049 | tri | 71.8441397 | tri | 46.2439313 | tri | 0.24802429 | | | | |
| 49 | tetra | 111.436192 | tetra | 8.68443605 | tetra | 5.87175021 | tetra | 0.2041327 | | | | |
| 50 | penta | 14.9624652 | penta | 5.815017 | penta | 2.08984212 | penta | 0.12046494 | | | | |
| 51 | hexa | 9.80871582 | hexa | 4.64695738 | hexa | 2.13650226 | hexa | 0.27201027 | | | | |
| 52 | hepta | 1.55166253 | hepta | 2.97403164 | hepta | 0.46828915 | hepta | 0.18155029 | | | | |
| 53 | octa | 0 | octa | 0 | octa | | octa | 0 | octa | 0.03045123 | | |

WMNB 3/09 Webb McCall Calculations for New Bedford

| | BG | BH | BI | BJ | BK | BL | BM | BN | BO | BP | BQ | BR |
|----|---------------|--------------|----|---------------|--------------|----|---------------|--------------|----|---------------|--------------|----|
| 1 | SAMPLE # | R7007880309 | | SAMPLE # | | | SAMPLE # | | | SAMPLE # | | |
| 2 | | 1802SJR | | | | | | | | | | |
| 3 | dilution used | 0.1 | | dilution used | | | dilution used | | | dilution used | | |
| 4 | inj.vol | 2 | | inj.vol | | | inj.vol | | | inj.vol | | |
| 5 | Peak Area | ng/injection | |
| 6 | 2218.52 | 0.29157971 | 2 | | | 0 | 0 | | 0 | 0 | | 0 |
| 7 | | 0 | 0 | | | 0 | 0 | | 0 | 0 | | 0 |
| 8 | 23663 | 3.35188327 | 2 | | | 0 | 0 | | 0 | 0 | | 0 |
| 9 | 10097 | 0.91265101 | 1 | | | 0 | 0 | | 0 | 0 | | 0 |
| 10 | 521.07 | 0.01624771 | 1 | | | 0 | 0 | | 0 | 0 | | 0 |
| 11 | 1304.82 | 0.02597774 | 1 | | | 0 | 0 | | 0 | 0 | | 0 |
| 12 | 269.69 | 0.00677552 | 0 | | | 0 | 0 | | 0 | 0 | | 0 |
| 13 | 2188.43 | 0.08479072 | 1 | | | 0 | 0 | | 0 | 0 | | 0 |
| 14 | 397.74 | 0.01139104 | 0 | | | 0 | 0 | | 0 | 0 | | 0 |
| 15 | 341.79 | 0.00803402 | 0 | | | 0 | 0 | | 0 | 0 | | 0 |
| 16 | 842.56 | 0.02126355 | 0 | | | 0 | 0 | | 0 | 0 | | 0 |
| 17 | 206.7 | 0.00446704 | 0 | | | 0 | 0 | | 0 | 0 | | 0 |
| 18 | 458.43 | 0.01261906 | 0 | | | 0 | 0 | | 0 | 0 | | 0 |
| 19 | 722.28 | 0.01525965 | 1 | | | 0 | 0 | | 0 | 0 | | 0 |
| 20 | 468.19 | 0.00892772 | 0 | | | 0 | 0 | | 0 | 0 | | 0 |
| 21 | 575.88 | 0.01050704 | 0 | | | 0 | 0 | | 0 | 0 | | 0 |
| 22 | | 0 | 0 | | | 0 | 0 | | 0 | 0 | | 0 |
| 23 | 74.94 | 0.00150686 | 0 | | | 0 | 0 | | 0 | 0 | | 0 |
| 24 | 54.62 | 0.00064326 | 0 | | | 0 | 0 | | 0 | 0 | | 0 |
| 25 | | 0 | 0 | | | 0 | 0 | | 0 | 0 | | 0 |
| 26 | 125.3 | 0.00106469 | 0 | | | 0 | 0 | | 0 | 0 | | 0 |
| 27 | | 0 | 0 | | | 0 | 0 | | 0 | 0 | | 0 |
| 28 | | 0 | 0 | | | 0 | 0 | | 0 | 0 | | 0 |
| 29 | | 0 | 0 | | | 0 | 0 | | 0 | 0 | | 0 |
| 30 | | 0 | 0 | | | 0 | 0 | | 0 | 0 | | 0 |
| 31 | DCB area | DCB ng/ini. | |
| 32 | 1073.08 | 0.00598092 | 1 | | | 0 | 0 | | 0 | 0 | | 0 |
| 33 | | | | | | | | | | | | |
| 34 | Total ng PCB | 4.7855896 | | Total ng PCB | 0 | | Total ng PCB | 0 | | Total ng PCE | 0 | |
| 35 | | | | | | | | | | | | |
| 36 | g used | 1.7 | | g used | | | g used | | | g used | | |
| 37 | mL total vol. | 10 | | mL total vol. | | | mL total vol. | | | mL total vol. | | |
| 38 | | | | | | | | | | | | |
| 39 | ppm PCB | 140.752635 | | ppm PCB | #DIV/0! | | ppm PCB | #DIV/0! | | ppm PCB | #DIV/0! | |
| 40 | | | | | | | | | | | | |
| 41 | ul DCB used | 5 | | ul DCB used | | | ul DCB used | | | ul DCB used | | |
| 42 | conc (ng/ul) | 96.8 | | conc (ng/ul) | | | conc (ng/ul) | | | conc (ng/ul) | | |
| 43 | DCB %R | 61.7863272 | | DCB %R | #DIV/0! | | DCB %R | #DIV/0! | | DCB %R | #DIV/0! | |
| 44 | | | | | | | | | | | | |
| 45 | Homolog | ppm | |
| 46 | mono | 8.5758737 | | mono | #DIV/0! | | mono | #DIV/0! | | mono | #DIV/0! | |
| 47 | di | 105.295471 | | di | #DIV/0! | | di | #DIV/0! | | di | #DIV/0! | |
| 48 | tri | 21.6837727 | | tri | #DIV/0! | | tri | #DIV/0! | | tri | #DIV/0! | |
| 49 | tetra | 3.53002628 | | tetra | #DIV/0! | | tetra | #DIV/0! | | tetra | #DIV/0! | |
| 50 | penta | 0.93159726 | | penta | #DIV/0! | | penta | #DIV/0! | | penta | #DIV/0! | |
| 51 | hexa | 0.68755217 | | hexa | #DIV/0! | | hexa | #DIV/0! | | hexa | #DIV/0! | |
| 52 | hepta | 0.04834211 | | hepta | #DIV/0! | | hepta | #DIV/0! | | hepta | #DIV/0! | |
| 53 | octa | 0 | | octa | #DIV/0! | | octa | #DIV/0! | | octa | #DIV/0! | |

WMNB 3/11, Webb-McCall Calculations for New Bedford

| | K | L | M | N | O | P | Q | R | S | T | U | V |
|----|---------------|--------------|---|---------------|--------------|---|---------------|--------------|---|---------------|--------------|---|
| 1 | SAMPLE # | R7007880311 | |
| 2 | | 0800SJR | | | 0802SJR | | | 1000SJR | | | 1002SJR | |
| 3 | dilution used | 0.1 | |
| 4 | inj.vol | 2 | |
| 5 | Peak Area | ng/injection | |
| 6 | 1626.08 | 0.2003308 | 2 | 1274.79 | 0.15405489 | 2 | 591.05 | 0.06398495 | 1 | 977.89 | 0.11494387 | 2 |
| 7 | | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 8 | 25937 | 3.732654 | 2 | 12265 | 1.72715516 | 2 | 7413.49 | 1.0155038 | 1 | 9439.05 | 1.31262625 | 2 |
| 9 | 15665 | 1.4865776 | 2 | 4827.1 | 0.40172795 | 1 | 3769.84 | 0.29589858 | 1 | 3214.22 | 0.24028226 | 1 |
| 10 | 1114.84 | 0.0482999 | 1 | 391.72 | 0.01532669 | 1 | 122.03 | 0.00460704 | 0 | 112.76 | 0.00425707 | 0 |
| 11 | 2153.93 | 0.0525126 | 1 | 444 | 0.00804779 | 0 | 64.7 | 0.00117273 | 0 | 108.05 | 0.00195848 | 0 |
| 12 | 2210.63 | 0.0777691 | 1 | 77.78 | 0.00195697 | 0 | 98.25 | 0.00247201 | 0 | 71.03 | 0.00178714 | 0 |
| 13 | 740.26 | 0.0186508 | 1 | 838.51 | 0.02280205 | 1 | 482.34 | 0.01186651 | 0 | 553.93 | 0.01362777 | 0 |
| 14 | 587.82 | 0.0173341 | 1 | 617.04 | 0.01850477 | 1 | 274.68 | 0.00755256 | 0 | 262.32 | 0.00721271 | 0 |
| 15 | | 0 | 0 | | 0 | 0 | | 0 | 0 | 120.62 | 0.00243164 | 0 |
| 16 | 356.42 | 0.0075656 | 0 | 82.71 | 0.00175566 | 0 | 91.98 | 0.00195244 | 0 | 14.65 | 0.00031097 | 0 |
| 17 | 90 | 0.0018089 | 0 | 30 | 0.00060298 | 0 | 60.63 | 0.00121863 | 0 | 94.48 | 0.00189899 | 0 |
| 18 | 92.08 | 0.0023515 | 0 | 31.74 | 0.00081056 | 0 | 139.65 | 0.00356631 | 0 | 119.06 | 0.00304049 | 0 |
| 19 | 671.81 | 0.0105869 | 0 | 141.53 | 0.00223035 | 0 | 166.61 | 0.00262558 | 0 | 229.56 | 0.0036176 | 0 |
| 20 | 85.27 | 0.0016194 | 0 | 515.65 | 0.00979297 | 0 | 802.93 | 0.01524885 | 0 | 324.26 | 0.00615818 | 0 |
| 21 | 156.54 | 0.0025784 | 0 | 173.45 | 0.00285695 | 0 | | 0 | 0 | 173.92 | 0.00286469 | 0 |
| 22 | | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 23 | | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 24 | 415.75 | 0.0051531 | 0 | 44.53 | 0.00055194 | 0 | 761.19 | 0.00943473 | 0 | 199.03 | 0.00246692 | 0 |
| 25 | | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 26 | 243.02 | 0.0021895 | 0 | 160.6 | 0.00144691 | 0 | 465.56 | 0.00419442 | 0 | 278.63 | 0.00251029 | 0 |
| 27 | 73.7 | 0.0006011 | 0 | 135.07 | 0.00110166 | 0 | 509.43 | 0.00415502 | 0 | 201.46 | 0.00164315 | 0 |
| 28 | | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 29 | | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 30 | | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 31 | DCB area | DCB ng/inj. | |
| 32 | 1279.98 | 0.0087809 | 1 | 1193.98 | 0.00809814 | 1 | 1251.49 | 0.00855471 | 1 | 985.98 | 0.00644685 | 1 |
| 33 | | | | | | | | | | | | |
| 34 | Total ng PCB | 5.6685834 | | Total ng PCB | 2.37072625 | | Total ng PCB | 1.44545415 | | Total ng PCB | 1.72363847 | |
| 35 | | | | | | | | | | | | |
| 36 | g used | 1.2 | | g used | 1.4 | | g used | 2.1 | | g used (est.) | 2.2 | |
| 37 | mL total vol. | 10 | |
| 38 | | | | | | | | | | | | |
| 39 | ppm PCB | 236.19097 | ✓ | ppm PCB | 84.6687946 | ✓ | ppm PCB | 34.415575 | ✓ | ppm PCB | 39.1736016 | ✓ |
| 40 | | | | | | | | | | | | |
| 41 | ul DCB used | 5 | |
| 42 | conc (ng/ul) | 96.8 | |
| 43 | DCB %R | 90.71167 | | DCB %R | 83.6585096 | | DCB %R | 88.3751055 | | DCB %R | 66.5997034 | |
| 44 | | | | | | | | | | | | |
| 45 | Homolog | ppm | |
| 46 | mono | 8.3471152 | | mono | 5.50196029 | | mono | 1.52345121 | | mono | 2.61236078 | |
| 47 | di | 171.01243 | | di | 65.2709697 | | di | 25.9399629 | | di | 31.1976548 | |
| 48 | tri | 54.134796 | | tri | 11.8833568 | | tri | 5.53971569 | | tri | 4.33169486 | |
| 49 | tetra | 1.5602156 | | tetra | 1.32320515 | | tetra | 0.46503769 | | tetra | 0.52299317 | |
| 50 | penta | 0.5292962 | | penta | 0.15314866 | | penta | 0.18822158 | | penta | 0.15204348 | |
| 51 | hexa | 0.2976037 | | hexa | 0.42739281 | | hexa | 0.35821687 | | hexa | 0.21199833 | |
| 52 | hepta | 0.3095155 | | hepta | 0.10876122 | | hepta | 0.40096903 | | hepta | 0.14485616 | |
| 53 | octa | 0 | |

WMNB 3/11, Webb-McCall Calculations for New Bedford

| | AI | AJ | AK | AL | AM | AN | AO | AP | AQ | AR | AS | AT | |
|----|---------------|--------------|----|---------------|--------------|----|---------------|--------------|----|------------------------|--------------|------------|---|
| 1 | SAMPLE # | R7007880311 | | SAMPLE # | R7007880311 | | SAMPLE # | HXBKM14 | | SAMPLE # | R50M11A | | |
| 2 | | 1600SJR | | | 1602SJR | | | hexane blank | | | | | |
| 3 | dilution used | 0.2 | | dilution used | 0.2 | | dilution used | 1 | | dilution used | 1 | | |
| 4 | inj.vol | 2 | | inj.vol | 2 | | inj.vol | 2 | | inj.vol | 2 | | |
| 5 | Peak Area | ng/injection | | Peak Area | ng/injection | | Peak Area | ng/injection | | Peak Area | ng/injection | | |
| 6 | 2238.62 | 0.28102144 | 2 | 984.4 | 0.11580145 | 2 | 82 | 0.00171125 | 0 | 162.94 | 0.00826853 | 1 | |
| 7 | | 0 | 0 | | 0 | 0 | 413 | 0.06546168 | 1 | 257.46 | 0.03075391 | 0 | |
| 8 | 23559 | 3.3838333 | 2 | 4349.37 | 0.56603854 | 1 | 100 | 0.00710893 | 0 | 1297.71 | 0.118401 | 1 | |
| 9 | 7190.54 | 0.63830303 | 1 | 822.26 | 0.04528113 | 1 | | | 0 | 1818.73 | 0.1044244 | 1 | |
| 10 | 255.12 | 0.00963164 | 0 | | 0 | 0 | 67 | 0.00252948 | 0 | 1321.55 | 0.05772557 | 1 | |
| 11 | | 0 | 0 | | 0 | 0 | | | 0 | 3880.62 | 0.11009296 | 1 | |
| 12 | 2267.61 | 0.0801529 | 1 | 591.41 | 0.01488009 | 0 | 104.42 | 0.00262725 | 0 | 2821.5 | 0.10332493 | 1 | |
| 13 | | 0 | 0 | | 0 | 0 | 419.24 | 0.01031413 | 0 | 2154.55 | 0.07840714 | 1 | |
| 14 | | 0 | 0 | | 0 | 0 | 66.8 | 0.00183672 | 0 | 1706.53 | 0.0621553 | 1 | |
| 15 | | 0 | 0 | | 0 | 0 | | | 0 | 1689.94 | 0.04905176 | 1 | |
| 16 | 694.18 | 0.01473518 | 0 | | 0 | 0 | | | 0 | 3727.83 | 0.12075111 | 1 | |
| 17 | | 0 | 0 | | 0 | 0 | | | 0 | 1359.59 | 0.03372685 | 1 | |
| 18 | | 0 | 0 | 197.44 | 0.00504212 | 0 | | | 0 | 1762.28 | 0.06437427 | 1 | |
| 19 | 417.83 | 0.00658451 | 0 | 124.08 | 0.00195535 | 0 | 101.3 | 0.00159637 | 0 | 2368.27 | 0.06122845 | 1 | |
| 20 | | 0 | 0 | 510.33 | 0.00969193 | 0 | 797.07 | 0.01513756 | 0 | 5759.67 | 0.149913 | 1 | |
| 21 | | 0 | 0 | 197.03 | 0.00324534 | 0 | | | 0 | 6055.32 | 0.1536133 | 1 | |
| 22 | | 0 | 0 | | 0 | 0 | | | 0 | 2307.31 | 0.04910543 | 1 | |
| 23 | 190.44 | 0.00387543 | 0 | | 0 | 0 | | | 0 | 5475.03 | 0.12710606 | 1 | |
| 24 | | 0 | 0 | | 0 | 0 | | | 0 | 6593.97 | 0.09214161 | 1 | |
| 25 | | 0 | 0 | 365.39 | 0.00422324 | 0 | 354.04 | 0.00409205 | 0 | 6801.79 | 0.09626286 | 1 | |
| 26 | | 0 | 0 | 386.44 | 0.0034816 | 0 | 297351 | 4.87378374 | 2 | 10334 | 0.11021576 | 1 | |
| 27 | | 0 | 0 | 647.5 | 0.00528115 | 0 | 296.28 | 0.00241652 | 0 | 4531.81 | 0.04113114 | 1 | |
| 28 | | 0 | 0 | | 0 | 0 | 79 | 0.0004817 | 0 | 5141.22 | 0.03738636 | 1 | |
| 29 | | 0 | 0 | | 0 | 0 | | | 0 | 1315.4 | 0.00479426 | 1 | |
| 30 | | 0 | 0 | | 0 | 0 | | | 0 | 2677.08 | 0.01275092 | 1 | |
| 31 | DCB area | DCB ng/ini. | | DCB area | DCB ng/ini. | | DCB area | DCB ng/ini. | | DCB area | DCB ng/ini. | | |
| 32 | 2210.81 | 0.01617066 | 1 | 1935.77 | 0.01398714 | 1 | | | 0 | 0 | 6770.04 | 0.05378334 | 1 |
| 33 | | | | | | | | | | | | | |
| 34 | Total ng PCB | 4.41813742 | | Total ng PCB | 0.77492195 | | Total ng PCB | 4.98909737 | | Total ng PCB | 1.87710689 | | |
| 35 | | | | | | | | | | | | | |
| 36 | g used (est.) | 0.7 | | g used | 0.7 | | g used | 1 | | g used | 1 | | |
| 37 | mL total vol. | 10 | | mL total vol. | 10 | | mL total vol. | 1 | | mL total vol. | 1 | | |
| 38 | | | | | | | | | | | | | |
| 39 | ppm PCB | 157.790622 | ✓ | ppm PCB | 27.6757839 | ✓ | ppm PCB | 2.49454868 | | ppm PCB | 0.93855344 | | |
| 40 | | | | | | | | | | | | | |
| 41 | ul DCB used | 5 | | ul DCB used | 5 | | ul DCB used | | | ul DCB used | 1000 | | |
| 42 | conc (ng/ul) | 96.8 | | conc (ng/ul) | 96.8 | | conc (ng/ul) | | | conc (ng/ul) | 0.0242 | | |
| 43 | DCB %R | 83.5261442 | | DCB %R | 72.2476488 | | DCB %R | #DIV/0! | | DCB %R | 111.122612 | | |
| 44 | | | | | | | | | | *ul per ml of standard | | | |
| 45 | Homolog | ppm | | Homolog | ppm | | Homolog | ppm | | Homolog | ppm | | |
| 46 | mono | 10.0364799 | | mono | 4.13576589 | | mono | 0.00085563 | | mono | 0.00413426 | | |
| 47 | di | 126.550323 | | di | 20.619958 | | di | 0.0362853 | | di | 0.0876305 | | |
| 48 | tri | 20.3039931 | | tri | 1.74431933 | | tri | 0.00288142 | | tri | 0.1849865 | | |
| 49 | tetra | 0.37364207 | | tetra | 0 | | tetra | 0.00577237 | | tetra | 0.14428155 | | |
| 50 | penta | 0.32663352 | | penta | 0.27908517 | | penta | 0.00149891 | | penta | 0.08518569 | | |
| 51 | hexa | 0.19955016 | | hexa | 0.44795338 | | hexa | 0.00707266 | | hexa | 0.23213735 | | |
| 52 | hepta | 0 | | hepta | 0.44870218 | | hepta | 2.43994156 | | hepta | 0.17273182 | | |
| 53 | octa | 0 | | octa | 0 | | octa | 0.00024085 | | octa | 0.02746577 | | |

WMNB 3/21/88, Webb McCall Calculations for New Bedford

| STANDARDS (1:1 mixtures of aroclors 1242 and 1260) | | | | | | SAMPLE # | R7007880321 |
|--|--------------|--------------|--------------|------------------------|--------------|---------------|-------------|
| | | | | | | 0800SJR | |
| Total PCB Conc (ng/uL) | 0.2 | | 1 | | 10 | dilution used | 0.002 |
| ini. Vol. | 2 | | 2 | | 2 | ini.vol | 2 |
| peak ID | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area |
| 11 | 65.23 | 0.0022 | 136.82 | 0.011 | 839.91 | 0.11 | 130.83 |
| 16 | 123.65 | 0.0058 | 199.31 | 0.029 | 1374.54 | 0.29 | 202.03 |
| 21 | 285.16 | 0.0226 | 1099.38 | 0.113 | 9350.84 | 1.13 | 1468.98 |
| 28 | 391.63 | 0.022 | 1674.02 | 0.11 | 13910 | 1.1 | 3053.56 |
| 32 | 275.81 | 0.0122 | 1196.36 | 0.061 | 10673 | 0.61 | 2031.8 |
| 37 | 1047.9 | 0.023 | 3820.44 | 0.115 | 31343 | 1.15 | 8203.86 |
| 40 | 732.15 | 0.0222 | 2768.41 | 0.111 | 23359 | 1.11 | 4757.21 |
| 47 | 551.81 | 0.0176 | 1944.8 | 0.088 | 16112 | 0.88 | 4670.66 |
| 54 | 410.09 | 0.0136 | 1601.71 | 0.068 | 13401 | 0.68 | 3410.76 |
| 58 | 372.77 | 0.0112 | 1544.67 | 0.056 | 14489 | 0.56 | 2376.97 |
| 70 | 955.37 | 0.026 | 3601.02 | 0.13 | 29583 | 1.3 | 5716.45 |
| 78 | 293.63 | 0.0072 | 1287.57 | 0.036 | 12194 | 0.36 | 1300 |
| 84 | 399.52 | 0.0148 | 1568.75 | 0.074 | 12801 | 0.74 | 1047.72 |
| 98+104 | 495.78 | 0.0138 | 1934.69 | 0.069 | 18456 | 0.69 | 1249.51 |
| 117+125 | 1592.9 | 0.0312 | 5280.69 | 0.156 | 43378 | 1.56 | 353.61 |
| 146 | 3874.49 | 0.0302 | 6361.07 | 0.151 | 49169 | 1.51 | 434.01 |
| 160 | 526.7 | 0.0098 | 2322.7 | 0.049 | 19556 | 0.49 | |
| 174 | 1384.45 | 0.0248 | 5775.85 | 0.124 | 46845 | 1.24 | 71.87 |
| 203 | 1562.24 | 0.0186 | 6548.81 | 0.093 | 51732 | 0.93 | |
| 232+244 | 1571.88 | 0.0196 | 6577.56 | 0.098 | 53861 | 0.98 | |
| 280 | 2642.73 | 0.022 | 10639 | 0.11 | 87633 | 1.1 | 151.42 |
| 332 | 1092.41 | 0.0084 | 4518.88 | 0.042 | 37713 | 0.42 | 304.74 |
| 372 | 1182.16 | 0.008 | 4971.62 | 0.04 | 42780 | 0.4 | |
| 448 | 278.38 | 0.0012 | 1144.57 | 0.006 | 12093 | 0.06 | |
| 528 | 623.37 | 0.003 | 2690.95 | 0.015 | 24651 | 0.15 | |
| Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | DCB area | DCB ng/ini. |
| DCB | 504.41 | 0.00242 | 7041.22 | 0.0484 | 57602 | 0.484 | 343.15 |
| The detection limit for this analysis is 0.1 ng/injection | | | | Total ng PCB 1.8745565 | | | |
| These analyses are accurate to no more than 2 significant digits | | | | | | | |
| | | | | q used 1.2 | | | |
| ALL SAMPLES USE COPPER IN CLEANUP. | | | | mL total vol. 10 | | | |
| Dry weights used. | | | | | | | |
| | | | | ppm PCB 3905.326 ✓ | | | |
| | | | | | | | |
| | | | | ul DCB used 10 | | | |
| | | | | conc (ng/uL) 484 | | | |
| | | | | DCB %R 85.03747 | | | |
| Homolog | ng/inj | Homolog | ng/inj | Homolog | ng/ini | Homolog | ppm |
| mono | 0.0022 | mono | 0.011 | mono | 0.11 | mono | 21.3827 |
| di | 0.0339 | di | 0.1695 | di | 1.695 | di | 507.42059 |
| tri | 0.078388 | tri | 0.39194 | tri | 3.9194 | tri | 1700.7243 |
| tetra | 0.063572 | tetra | 0.31786 | tetra | 3.1786 | tetra | 1319.8399 |
| penta | 0.037806 | penta | 0.18903 | penta | 1.8903 | penta | 303.23793 |
| hexa | 0.093254 | hexa | 0.46627 | hexa | 4.6627 | hexa | 45.212631 |
| hepta | 0.06968 | hepta | 0.3484 | hepta | 3.484 | hepta | 7.5079247 |
| octa | 0.0122 | octa | 0.061 | octa | 0.61 | octa | 0 |

WMNB 3/21/88, Webb McCall Calculations for New Bedford

| SAMPLE # | HXBKM21D | SAMPLE # | R50M21A | SAMPLE # | R7007880321 | SAMPLE # | R7007880321 |
|---------------|--------------|---------------|--------------|---------------|--------------|---------------|------------------|
| dilution used | 1 | dilution used | 1 | dilution used | 1 | dilution used | 30 0.001 |
| ini.vol | 2 | ini.vol | 2 | ini.vol | 2 | ini.vol | 2 |
| Peak Area | ng/injection |
| 79.23 | 0.00392091 | 1 | 146.48 | 0.0123602 | 1 | 1694.11 | 0.23027735 |
| 325.37 | 0.05699593 | 1 | 215.43 | 0.03258 | 1 | 178.16 | 0.02251467 |
| 106.56 | 0.00844528 | 0 | 1100.12 | 0.11309121 | 1 | 573.78 | 0.05464447 |
| 83.44 | 0.00468728 | 0 | 1608.06 | 0.1054737 | 1 | 336.36 | 0.01889518 |
| | 0 0 | 1173.64 | 0.05979557 | 1 | 190.51 | 0.0084269 | 0 |
| 148.53 | 0.00326003 | 0 | 3645.35 | 0.10919006 | 1 | 875.8 | 0.01922264 |
| 50.48 | 0.00153064 | 0 | 2670.82 | 0.10674416 | 1 | 508.69 | 0.01542432 |
| | 0 0 | 1942.58 | 0.0878878 | 1 | 638.59 | 0.02198575 | 1 |
| | 0 0 | 1544.61 | 0.06539326 | 1 | 364.52 | 0.01208874 | 0 |
| | 0 0 | 1515.27 | 0.05487608 | 1 | 281.68 | 0.00846317 | 0 |
| | 0 0 | 3361.24 | 0.12057429 | 1 | 522.29 | 0.01421391 | 0 |
| 40 | 0.00098083 | 0 | 1206.14 | 0.03364052 | 1 | 80 | 0.00196165 |
| 47.46 | 0.00175813 | 0 | 1458.51 | 0.06841837 | 1 | 80.4 | 0.00297837 |
| | 0 0 | 1821.18 | 0.06464549 | 1 | 66.77 | 0.00185854 | 0 |
| 500.94 | 0.00981187 | 0 | 5157.86 | 0.15184326 | 1 | 217.18 | 0.00425389 |
| | 0 0 | 5529.14 | 0.11058419 | 1 | 185.23 | 0.00144379 | 0 |
| | 0 0 | 2064.28 | 0.04335965 | 1 | | 0 0 | 0 0 |
| 43.26 | 0.00077493 | 0 | 5063.45 | 0.10790716 | 1 | 74.58 | 0.00133597 |
| | 0 0 | 5620.67 | 0.07915208 | 1 | 106.9 | 0.00127275 | 0 |
| | 0 0 | 5699.69 | 0.08425062 | 1 | 83 | 0.00103494 | 0 |
| 168.67 | 0.00140413 | 0 | 8876.42 | 0.09060258 | 1 | 329.61 | 0.00274391 |
| 249.41 | 0.00191782 | 0 | 3846.15 | 0.0354032 | 1 | 374.12 | 0.00287677 |
| | 0 0 | 4259.93 | 0.03399015 | 1 | | 0 0 | 76.58 0.00051824 |
| | 0 0 | 953.5 | 0.00494118 | 1 | 27.92 | 0.00012035 | 0 |
| | 0 0 | 2299.99 | 0.01273091 | 1 | 85.48 | 0.00041138 | 0 |
| DCB area | DCB ng/inj. |
| | 0 0 | 6005.77 | 0.04111663 | 1 | 8199.84 | 0.05838194 | 1 |
| Total ng PCB | 0.09548778 | Total ng PCB | 1.78943571 | Total ng PCE | 0.4484494 | Total ng PCB | 33.53535 |
| a used | 1 | a used | 1 | a used | 2.8 | a used | 220.4 |
| mL total vol. | 1 | mL total vol. | 1 | mL total vol. | 10 | mL total vol. | 10 |
| ppm PCB | 0.04774389 | ppm PCB | 0.89471785 | ppm PCB | 0.80080251 | ppm PCB | 760.783801 |
| ul DCB used | | ul DCB used | | ul DCB used | 5 | ul DCB used | (10) (20) |
| conc (ng/ul) | | conc (ng/ul) | | conc (ng/ul) | 96.8 | conc (ng/ul) | (20) |
| DCB %R | #DIV/0! | DCB %R | #DIV/0! | DCB %R | 60.3119256 | DCB %R | #DIV/0! |
| Homolog | ppm | Homolog | ppm | Homolog | ppm | Homolog | ppm |
| mono | 0.00196046 | mono | 0.0061801 | mono | 0.41120955 | mono | 25.0344548 |
| di | 0.03330652 | di | 0.08601981 | di | 0.14621953 | di | 285.583789 |
| tri | 0.00415307 | tri | 0.18820743 | tri | 0.10934737 | tri | 318.178589 |
| Tetra | 0.00049041 | tetra | 0.15291282 | tetra | 0.09036055 | tetra | 108.864442 |
| penta | 0.00146778 | penta | 0.08748649 | penta | 0.01617568 | penta | 19.8190239 |
| hexa | 0.00470469 | hexa | 0.20070607 | hexa | 0.0127946 | hexa | 3.21613813 |
| hepta | 0.00166097 | hepta | 0.14737402 | hepta | 0.01374571 | hepta | 0.07560733 |
| octa | 0 | octa | 0.02583112 | octa | 0.00094952 | octa | 0.01175676 |

WMNB 3/28/88, Webb McCall Calculations for New Bedford

| STANDARDS (1:1 mixtures of aroclors 1242 and 1260) | | | | | | SAMPLE # | R7007880329 |
|--|-----------|--------------|-----------|--------------|---------------|---------------|-------------|
| | | | | | | 1300SJR | |
| Total PCB Conc (ng/uL) | 0.2 | | 1 | | 10 | dilution used | 0.1 |
| inj. Vol. | | 2 | | 2 | | inj.vol | 2 |
| peak ID | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area |
| 11 | 48.1 | 0.0022 | 207.51 | 0.011 | 988.01 | 0.11 | 213.16 |
| 16 | 100.47 | 0.0058 | 416.36 | 0.029 | 1396.99 | 0.29 | |
| 21 | 362.83 | 0.0226 | 1442.62 | 0.113 | 9275.8 | 1.13 | 4125.1 |
| 28 | 429.01 | 0.022 | 2052.32 | 0.11 | 13265 | 1.1 | 6290.12 |
| 32 | 276.82 | 0.0122 | 1470.43 | 0.061 | 10331 | 0.61 | 2675.75 |
| 37 | 997.68 | 0.023 | 4371.49 | 0.115 | 27889 | 1.15 | 11007.53 |
| 40 | 686.55 | 0.0222 | 3249.72 | 0.111 | 21582 | 1.11 | 1980.33 |
| 47 | 663.55 | 0.0176 | 2532.43 | 0.088 | 15285 | 0.88 | 5361.55 |
| 54 | 425.35 | 0.0136 | 1961.29 | 0.068 | 12218 | 0.68 | 2439.3 |
| 58 | 423.32 | 0.0112 | 1982.78 | 0.056 | 13938 | 0.56 | 291.04 |
| 70 | 1029.45 | 0.026 | 4242.45 | 0.13 | 26294 | 1.3 | |
| 78 | 294.89 | 0.0072 | 1530.07 | 0.036 | 10626 | 0.36 | |
| 84 | 569.84 | 0.0148 | 2079.09 | 0.074 | 12600 | 0.74 | |
| 98+104 | 594.03 | 0.0138 | 2678.43 | 0.069 | 17399 | 0.69 | 24.94 |
| 117+125 | 1644.97 | 0.0312 | 6367.82 | 0.156 | 38978 | 1.56 | 109.31 |
| 146 | 4001.58 | 0.0302 | 6919.05 | 0.151 | 42873 | 1.51 | 39.97 |
| 160 | 665.98 | 0.0098 | 2643.09 | 0.049 | 17554 | 0.49 | |
| 174 | 1477.45 | 0.0248 | 6068.54 | 0.124 | 41282 | 1.24 | 45.08 |
| 203 | 1744.35 | 0.0186 | 7143.17 | 0.093 | 46463 | 0.93 | |
| 232+244 | 1734.46 | 0.0196 | 7358.42 | 0.098 | 48623 | 0.98 | |
| 280 | 2878.55 | 0.022 | 11062 | 0.11 | 77658 | 1.1 | 67.65 |
| 332 | 1062.21 | 0.0084 | 4904.49 | 0.042 | 33483 | 0.42 | |
| 372 | 1247.75 | 0.008 | 5766.56 | 0.04 | 41762 | 0.4 | |
| 448 | 264.18 | 0.0012 | 1604.8 | 0.006 | 13424 | 0.06 | |
| 528 | 676.75 | 0.003 | 3327.63 | 0.015 | 25970 | 0.15 | |
| DCB | 275.85 | 0.00242 | 6647.76 | 0.0484 | 43284 | 0.484 | 1510.99 |
| The detection limit for this analysis is 0.1 ng/injection | | | | | Total ng PCB | 1.9390646 | |
| These analyses are accurate to no more than 2 significant digits | | | | | a used | 1.9 | |
| | | | | | mL total vol. | 10 | |
| | | | | | ppm PCB | 51.028015 | |
| | | | | | ul DCB used | 5 | |
| | | | | | conc (ng/uL) | 96.8 | |
| | | | | | DCB %R | 117.07467 | |
| Homolog | ng/inj | Homolog | ng/inj | Homolog | ng/inj | Homolog | ppm |
| mono | 0.0022 | mono | 0.011 | mono | 0.11 | mono | 0.3083331 |
| di | 0.0339 | di | 0.1695 | di | 1.695 | di | 15.324067 |
| tri | 0.078388 | tri | 0.39194 | tri | 3.9194 | tri | 26.44033 |
| tetra | 0.063572 | tetra | 0.31786 | tetra | 3.1786 | tetra | 8.8440215 |
| penta | 0.037806 | penta | 0.18903 | penta | 1.8903 | penta | 0.0182268 |
| hexa | 0.093254 | hexa | 0.46627 | hexa | 4.6627 | hexa | 0.0794313 |
| hepta | 0.06968 | hepta | 0.3484 | hepta | 3.484 | hepta | 0.0136061 |
| octa | 0.0122 | octa | 0.061 | octa | 0.61 | octa | 0 |

WMNB 3/31/88, Webb McCall Calculations for New Bedford

| STANDARDS (1:1 mixtures of aroclors 1242 and 1260) | | | | | | | | SAMPLE # | R7007880330 |
|--|--------------|--------------|--------------|--------------|--------------|---------------|-------------|--------------|-------------|
| | | | | | | | | | 0940SJR |
| Total PCB Conc (ng/uL) | 0.2 | | 1 | | 10 | dilution used | 0.002 | | |
| ini. Vol. | 2 | | 2 | | 2 | ini.vol | 2 | | |
| peak ID | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | |
| 11 | 64.69 | 0.0022 | 129.4 | 0.011 | 808.53 | 0.11 | 365.02 | 0.0453474 | 1 |
| 16 | 53.85 | 0.0058 | 142.17 | 0.029 | 1188.23 | 0.29 | 625.21 | 0.1495222 | 1 |
| 21 | 280.37 | 0.0226 | 1217.58 | 0.113 | 8960.16 | 1.13 | 6634.22 | 0.8244841 | 1 |
| 28 | 635.7 | 0.022 | 1930.84 | 0.11 | 13391 | 1.1 | 13025 | 1.0683826 | 1 |
| 32 | 526.49 | 0.0122 | 1451.45 | 0.061 | 10218 | 0.61 | 9395.92 | 0.5585177 | 1 |
| 37 | 1334.8 | 0.023 | 4371.44 | 0.115 | 29002 | 1.15 | 30995 | 1.2337478 | 2 |
| 40 | 905.52 | 0.0222 | 3206.76 | 0.111 | 22326 | 1.11 | 19976 | 0.9872101 | 1 |
| 47 | 640.58 | 0.0176 | 2201.91 | 0.088 | 15404 | 0.88 | 18441 | 1.0621912 | 2 |
| 54 | 406.75 | 0.0136 | 1717.22 | 0.068 | 12522 | 0.68 | 13149 | 0.7155143 | 2 |
| 58 | 310.33 | 0.0112 | 1620.32 | 0.056 | 13974 | 0.56 | 12377 | 0.4948463 | 1 |
| 70 | 814.87 | 0.026 | 3727.43 | 0.13 | 27216 | 1.3 | 27145 | 1.2964634 | 1 |
| 78 | 224.69 | 0.0072 | 1263.53 | 0.036 | 10771 | 0.36 | 8319.06 | 0.2764416 | 1 |
| 84 | 461.47 | 0.0148 | 1762.13 | 0.074 | 12916 | 0.74 | 13798 | 0.7926644 | 2 |
| 98+104 | 295.58 | 0.0138 | 1994.22 | 0.069 | 17635 | 0.69 | 17589.35 | 0.6881875 | 1 |
| 117+125 | 1224.47 | 0.0312 | 5790 | 0.156 | 41606 | 1.56 | 15145 | 0.5227193 | 1 |
| 146 | 1100 | 0.0302 | 6237.93 | 0.151 | 42500 | 1.51 | 10407 | 0.307245 | 1 |
| 160 | 207.23 | 0.0098 | 2205.94 | 0.049 | 18185 | 0.49 | 2781.68 | 0.0648896 | 1 |
| 174 | 870.5 | 0.0248 | 5597.02 | 0.124 | 43568 | 1.24 | 7001.66 | 0.1652836 | 1 |
| 203 | 1156.89 | 0.0186 | 6562 | 0.093 | 49737 | 0.93 | 3045.33 | 0.0445939 | 1 |
| 232+244 | 1219.45 | 0.0196 | 6683.2 | 0.098 | 52039 | 0.98 | 2447.49 | 0.0372213 | 1 |
| 280 | 2213.79 | 0.022 | 10676 | 0.11 | 84166 | 1.1 | 2050.41 | 0.0203764 | 0 |
| 332 | 898.86 | 0.0084 | 4489.79 | 0.042 | 36019 | 0.42 | 1129.15 | 0.0105548 | 1 |
| 372 | 1104.45 | 0.008 | 5253.04 | 0.04 | 43343 | 0.4 | 659.73 | 0.0047787 | 0 |
| 448 | 189.47 | 0.0012 | 1149.06 | 0.006 | 12883 | 0.06 | 132.86 | 0.0008415 | 0 |
| 528 | 511.12 | 0.003 | 2762.78 | 0.015 | 25287 | 0.15 | 184.47 | 0.0010827 | 0 |
| DCB area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | DCB area | DCB ng/inj. | | |
| DCB | 436.37 | 0.00242 | 6712.4 | 0.0484 | 46898 | 0.484 | 284.01 | 0.001575 | 0 |
| The detection limit for this analysis is 0.1 ng/injection | | | | | | Total ng PCB | 11.373108 | | |
| These analyses are accurate to no more than 2 significant digits | | | | | | | | | |
| dry weights used | | | | | | g used | 3.9 | | |
| | | | | | | mL total vol. | 10 | | |
| | | | | | | ppm PCB | 7290.4535 | ✓ | |
| | | | | | | ul DCB used | 10 | | |
| | | | | | | conc (ng/uL) | 484 | | |
| | | | | | | DCB %R | 81.355845 | | |
| Homolog | ng/inj | Homolog | ng/inj | Homolog | ng/inj | Homolog | ppm | | |
| mono | 0.0022 | mono | 0.011 | mono | 0.11 | mono | 29.068875 | | |
| di | 0.0339 | di | 0.1695 | di | 1.695 | di | 795.5782 | | |
| tri | 0.078388 | tri | 0.39194 | tri | 3.9194 | tri | 2446.7194 | | |
| tetra | 0.063572 | tetra | 0.31786 | tetra | 3.1786 | tetra | 2072.6684 | | |
| penta | 0.037806 | penta | 0.18903 | penta | 1.8903 | penta | 1125.6321 | | |
| hexa | 0.093254 | hexa | 0.46627 | hexa | 4.6627 | hexa | 728.66309 | | |
| hepta | 0.06968 | hepta | 0.3484 | hepta | 3.484 | hepta | 87.826715 | | |
| octa | 0.0122 | octa | 0.061 | octa | 0.61 | octa | 4.2967354 | | |

WMNB 3/31/88, Webb McCall Calculations for New Bedford

| SAMPLE # | R7007880331 |
|---------------|--------------|---------------|--------------|---------------|--------------|---------------|--------------|
| | 1300SJR | | 1300SJR | | 1400SJR | | 1500SJR |
| dilution used | 0.02 | dilution used | 0.1 | dilution used | 0.2 | dilution used | 1 |
| inj.vol | 2 | inj.vol | 2 | inj.vol | 2 | inj.vol | 2 |
| Peak Area | ng/injection |
| 494.07 | 0.06415967 | 1 | 1595.18 | 0.2246737 | 2 | 1712.45 | 0.2417687 |
| | 0 0 | | 0 0 | | 0 0 | | 0 0 |
| 3080.52 | 0.35770008 | 1 | 13050 | 1.66720688 | 2 | 6290.37 | 0.77931891 |
| 182.14 | 0.00630341 | 0 | 2830.07 | 0.18768109 | 1 | 318.38 | 0.01101834 |
| 607.64 | 0.0164814 | 1 | 403.74 | 0.0093556 | 0 | 563.93 | 0.0141753 |
| 213.86 | 0.00368503 | 0 | 528.44 | 0.00910557 | 0 | 314.26 | 0.00541503 |
| 678.81 | 0.01664191 | 0 | 942.98 | 0.0236455 | 1 | 537.04 | 0.01316623 |
| | 0 0 | | 444.18 | 0.01220389 | 0 | 358.8 | 0.00985807 |
| | 0 0 | | 1059.66 | 0.04070349 | 1 | 668.3 | 0.02445742 |
| | 0 0 | | | 0 0 | | 499.74 | 0.01746018 |
| | 0 0 | | | 0 0 | | | 0 0 |
| 38.02 | 0.0012131 | 0 | 276.66 | 0.00882737 | 0 | | 0 0 |
| 30 | 0.00096132 | 0 | 105 | 0.00336464 | 0 | | 0 0 |
| 30.85 | 0.0009894 | 0 | 106.81 | 0.00342555 | 0 | | 0 0 |
| | 0 0 | | | 0 0 | | 37.58 | 0.00120524 |
| 181.28 | 0.00461909 | 0 | 207.46 | 0.00528617 | 0 | 60.68 | 0.00154615 |
| 76.79 | 0.00210823 | 0 | 470.12 | 0.01290693 | 0 | 75.31 | 0.0020676 |
| | 0 0 | | | 0 0 | | 491.78 | 0.0135016 |
| | 0 0 | | | 0 0 | | | 0 0 |
| | 0 0 | | | 0 0 | | | 0 0 |
| 763.12 | 0.01226549 | 0 | 420.24 | 0.00675444 | 0 | 281.28 | 0.00452096 |
| 505.62 | 0.0050247 | 0 | 437.27 | 0.00434546 | 0 | 298.77 | 0.00296909 |
| 348.12 | 0.00325324 | 0 | 190.92 | 0.00178418 | 0 | 235.87 | 0.00220425 |
| 119.03 | 0.00086218 | 0 | 96.76 | 0.00070087 | 0 | 118.59 | 0.000859 |
| 452.69 | 0.00251666 | 1 | 447.37 | 0.00249005 | 1 | 441.11 | 0.00245874 |
| 707.39 | 0.004046 | 1 | 616.95 | 0.00356401 | 1 | 631.61 | 0.00364214 |
| Peak Area | DCB ng/inj. | | DCB area | DCB ng/inj. | | DCB area | DCB ng/inj. |
| 1869.13 | 0.01291681 | 1 | 6549.63 | 0.0472075 | 1 | 2826.72 | 0.01993239 |
| Total ng PCB | 0.50283095 | | Total ng PCB | 2.22802539 | | Total ng PCB | 1.11944592 |
| | | | | | | Total ng PCB | 2.01006391 |
| g used | 1.4 | g used | 1.4 | g used | 1.2 | g used | 1.8 |
| mL total vol. | 10 |
| ppm PCB | 89.7912405 | ✓ | ppm PCB | 79.5723355 | ✓ | ppm PCB | 23.32179 |
| ul DCB used | 10.5 | ✓ | ul DCB used | 5 | ✓ | ul DCB used | 5 |
| conc (ng/ul) | 484 | ✓ | conc (ng/ul) | 484 | ✓ | conc (ng/ul) | 96.8 |
| DCB %R | 133.438137 | ✓ | DCB %R | 97.5361574 | ✓ | DCB %R | 102.956566 |
| Homolog | ppm | Homolog | ppm | Homolog | ppm | Homolog | ppm |
| mono | 11.4570848 | mono | 8.02406072 | mono | 5.036848 | mono | 2.69508297 |
| di | 64.1564175 | di | 61.218827 | di | 16.2931977 | di | 2.57032506 |
| tri | 7.4171245 | tri | 7.01070139 | tri | 1.02273469 | tri | 0.11331099 |
| tetra | 0.32546902 | tetra | 1.75383195 | tetra | 0.54676116 | tetra | 0.07454751 |
| penta | 0.35730451 | penta | 0.25947046 | penta | 0.00601913 | penta | 0.0204421 |
| hexa | 1.3025304 | hexa | 0.62817339 | hexa | 0.07868607 | hexa | 0.056341 |
| hepta | 3.44944396 | hepta | 0.43602284 | hepta | 0.19254586 | hepta | 0.03331329 |
| octa | 1.32586585 | octa | 0.24124769 | octa | 0.14499739 | octa | 0.02014796 |

WMNB 4/01/88, Webb McCall Calculations for NewBedford

| STANDARDS (1:1 mixtures of aroclors 1242 and 1260) | | | | | | SAMPLE # | R7007880331 |
|--|--------------|--------------|--------------|--------------|------------------|---------------|-------------|
| | | | | | | 0700SJR | |
| Total PCB Conc (ng/ul) | 0.2 | | 1 | | 10 dilution used | | 0.002 |
| inj. Vol. | | 2 | | 2 | 2 inj.vol | | 2 |
| peak ID | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area |
| 11 | 101.04 | 0.0022 | 170.64 | 0.011 | 1078.32 | 0.11 | 197.38 |
| 16 | 131.17 | 0.0058 | 259.71 | 0.029 | 1597.94 | 0.29 | 418.27 |
| 21 | 649.34 | 0.0226 | 1742.4 | 0.113 | 10719 | 1.13 | 3079.76 |
| 28 | 797.1 | 0.022 | 2523.65 | 0.11 | 15460 | 1.1 | 5680.65 |
| 32 | 769.95 | 0.0122 | 1995.45 | 0.061 | 12036 | 0.61 | 4020.18 |
| 37 | 1732.67 | 0.023 | 5398.05 | 0.115 | 33231 | 1.15 | 14298 |
| 40 | 1264.8 | 0.0222 | 4095.04 | 0.111 | 25360 | 1.11 | 8702.68 |
| 47 | 1046.72 | 0.0176 | 3056.86 | 0.088 | 17945 | 0.88 | 9075.96 |
| 54 | 599.65 | 0.0136 | 2288.44 | 0.068 | 14358 | 0.68 | 5710.56 |
| 58 | 530.76 | 0.0112 | 2315.83 | 0.056 | 16087 | 0.56 | 5556.05 |
| 70 | 1147.25 | 0.026 | 4850.18 | 0.13 | 30988 | 1.3 | 13445 |
| 78 | 316.99 | 0.0072 | 1692.7 | 0.036 | 12463 | 0.36 | 11215 |
| 84 | 542.27 | 0.0148 | 2345.49 | 0.074 | 14429 | 0.74 | 8568.95 |
| 98+104 | 522.89 | 0.0138 | 2834.44 | 0.069 | 20169 | 0.69 | 7551.29 |
| 117+125 | 1771.28 | 0.0312 | 7096.32 | 0.156 | 45164 | 1.56 | 0 |
| 146 | 2095.51 | 0.0302 | 7240.1 | 0.151 | 47568 | 1.51 | 5659.74 |
| 160 | 456.39 | 0.0098 | 2635.53 | 0.049 | 19325 | 0.49 | 0 |
| 174 | 1314.41 | 0.0248 | 6444.79 | 0.124 | 46339 | 1.24 | 2493.98 |
| 203 | 1660.09 | 0.0186 | 7576.07 | 0.093 | 52144 | 0.93 | 1125.27 |
| 232+244 | 1721.97 | 0.0196 | 7843.88 | 0.098 | 55052 | 0.98 | 387.74 |
| 280 | 2823.5 | 0.022 | 12080 | 0.11 | 88865 | 1.1 | 384.15 |
| 332 | 1174.01 | 0.0084 | 5265.81 | 0.042 | 38583 | 0.42 | 0 |
| 372 | 1368.31 | 0.008 | 6156.67 | 0.04 | 46654 | 0.4 | 65.26 |
| 448 | 298.93 | 0.0012 | 1542.66 | 0.006 | 14277 | 0.06 | 0 |
| 528 | 712.69 | 0.003 | 3260.9 | 0.015 | 28152 | 0.15 | 62.61 |
| Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | DCB area | DCB ng/inj. |
| DCB | 483.98 | 0.00242 | 7679.98 | 0.0484 | 51667 | 0.484 | 174.15 |
| | | | | | | | 0.0008708 |
| The detection limit for this analysis is 0.1 ng/injection | | | | | | Total ng PCB | 4.133723 |
| These analyses are accurate to no more than 2 significant digits | | | | | | g used | 1.1 |
| dry weights | | | | | | mL total vol. | 10 |
| | | | | | | ppm PCB | 9394.825 |
| | | | | | | ul DCB used | 5 |
| | | | | | | conc (ng/ul) | 484 |
| | | | | | | DCB %R | 89.95723 |
| Homolog | ng/inj | Homolog | ng/inj | Homolog | ng/inj | Homolog | ppm |
| mono | 0.0022 | mono | 0.011 | mono | 0.11 | mono | 31.628437 |
| di | 0.0339 | di | 0.1695 | di | 1.695 | di | 937.13709 |
| tri | 0.078388 | tri | 0.39194 | tri | 3.9194 | tri | 2928.471 |
| tetra | 0.063572 | tetra | 0.31786 | tetra | 3.1786 | tetra | 3255.7176 |
| penta | 0.037806 | penta | 0.18903 | penta | 1.8903 | penta | 1700.1919 |
| hexa | 0.093254 | hexa | 0.46627 | hexa | 4.6627 | hexa | 498.59412 |
| hepta | 0.06968 | hepta | 0.3484 | hepta | 3.484 | hepta | 41.618698 |
| octa | 0.0122 | octa | 0.061 | octa | 0.61 | octa | 1.4661403 |

| STANDARDS (1:1 mixtures of aroclors 1242 and 1260) | | | | | | SAMPLE # | R7007880405 |
|--|--------------|--------------|--------------|---------------|--------------|---------------|-------------|
| | | | | | | | 0800SJR |
| Total PCB Conc (ng/uL) | 0.2 | | 1 | | 10 | dilution used | 0.01 |
| inj. Vol. | 2 | | 2 | | 2 | inj.vol | 2 |
| Peak ID | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area |
| 11 | 104.28 | 0.0022 | 188.08 | 0.011 | 1183.49 | 0.11 | 143.81 |
| 16 | 41.36 | 0.0058 | 251.51 | 0.029 | 1589.59 | 0.29 | 182.53 |
| 21 | 315.65 | 0.0226 | 1411.43 | 0.113 | 11169 | 1.13 | 582.42 |
| 28 | 467.61 | 0.022 | 2155.88 | 0.11 | 16326 | 1.1 | 789.85 |
| 32 | 314.92 | 0.0122 | 1565.54 | 0.061 | 12598 | 0.61 | 344.23 |
| 37 | 1011.89 | 0.023 | 4326.56 | 0.115 | 34140 | 1.15 | 3200.79 |
| 40 | 735.17 | 0.0222 | 3454.01 | 0.111 | 26495 | 1.11 | 505.86 |
| 47 | 617.13 | 0.0176 | 2639.92 | 0.088 | 18721 | 0.88 | 1978.16 |
| 54 | 430.35 | 0.0136 | 1940.09 | 0.068 | 14917 | 0.68 | 827.32 |
| 58 | 390.04 | 0.0112 | 2002.77 | 0.056 | 16676 | 0.56 | 682.55 |
| 70 | 981.03 | 0.026 | 4118.86 | 0.13 | 32135 | 1.3 | 1071.04 |
| 78 | 298.5 | 0.0072 | 1388.09 | 0.036 | 12697 | 0.36 | 250 |
| 84 | 504.16 | 0.0148 | 2102.03 | 0.074 | 15262 | 0.74 | 266.71 |
| 98+104 | 540.87 | 0.0138 | 2627.51 | 0.069 | 20965 | 0.69 | 710.87 |
| 117+125 | 1125.44 | 0.0312 | 6346.9 | 0.156 | 46552 | 1.56 | 235.01 |
| 146 | 1232.94 | 0.0302 | 6170.52 | 0.151 | 48407 | 1.51 | 64.2 |
| 160 | 437.84 | 0.0098 | 2456.41 | 0.049 | 20347 | 0.49 | |
| 174 | 1124.13 | 0.0248 | 5746.28 | 0.124 | 47898 | 1.24 | 37.76 |
| 203 | 1536.51 | 0.0186 | 6946.91 | 0.093 | 53943 | 0.93 | 219.54 |
| 232+244 | 1643.8 | 0.0196 | 7305.7 | 0.098 | 57051 | 0.98 | 317.4 |
| 280 | 2572.36 | 0.022 | 10893 | 0.11 | 91675 | 1.1 | 274.55 |
| 332 | 1004.24 | 0.0084 | 4626.99 | 0.042 | 39619 | 0.42 | 92.99 |
| 372 | 1220.33 | 0.008 | 6136.47 | 0.04 | 49554 | 0.4 | 149 |
| 448 | 247.03 | 0.0012 | 1641.19 | 0.006 | 15733 | 0.06 | |
| 528 | 564 | 0.003 | 2915.81 | 0.015 | 31014 | 0.15 | 111.84 |
| Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | DCB area | DCB ng/ini. |
| DCB | 362.6 | 0.00242 | 7223.56 | 0.0484 | 52007 | 0.484 | 2368.39 |
| The detection limit for this analysis is 0.1 ng/injection | | | | Total ng PCB | 0.41693004 | | |
| These analyses are accurate to no more than 2 significant digits | | | | g used | 1.2 | | |
| All weights used are based on 1/2 wet soil weight. | | | | mL total vol. | 10 | | |
| | | | | ppm PCB | 173.720851 | | |
| | | | | ul DCB used | 10 | | |
| | | | | conc (ng/uL) | 484 | | |
| | | | | DCB %R | 163.865443 | | |
| Homolog | ng/ini | Homolog | ng/ini | Homolog | ng/ini | Homolog | ppm |
| mono | 0.0022 | mono | 0.011 | mono | 0.11 | mono | 2.64630072 |
| di | 0.0339 | di | 0.1695 | di | 1.695 | di | 31.5383355 |
| tri | 0.078388 | tri | 0.39194 | tri | 3.9194 | tri | 62.7852698 |
| tetra | 0.063572 | tetra | 0.31786 | tetra | 3.1786 | tetra | 54.0042035 |
| penta | 0.037806 | penta | 0.18903 | penta | 1.8903 | penta | 12.7645734 |
| hexa | 0.093254 | hexa | 0.46627 | hexa | 4.6627 | hexa | 5.6090366 |
| hepta | 0.06968 | hepta | 0.3484 | hepta | 3.484 | hepta | 3.71826554 |
| octa | 0.0122 | octa | 0.061 | octa | 0.61 | octa | 0.65486608 |

WMNB 4/5/88, Webb McCall Calculations for New Bedford

5

| SAMPLE # | R7007880404 | SAMPLE # | R7007880404 | SAMPLE # | R7007880405 | SAMPLE # | R7007880405 |
|---------------|--------------|---------------|--------------|---------------|--------------|---------------|--------------|
| | 1300SJR | | 1200SJR | | 1400SJR | | 0700SJR |
| dilution used | 1 | dilution used | 0.01 | dilution used | 1 | dilution used | 0.01 |
| inj.vol | 2 | inj.vol | 2 | inj.vol | 2 | inj.vol | 2 |
| Peak Area | ng/injection |
| 582.42 | 0.05021968 | 1 | 65.4 | 0.00137975 | 0 | 598.79 | 0.05184778 |
| | 0 | 0 | 102.96 | 0.01260048 | 1 | 0 | 0 |
| 2705.88 | 0.24791634 | 1 | 2597.76 | 0.23664734 | 1 | 1023.46 | 0.08099313 |
| 532.78 | 0.02539694 | 1 | 4292.99 | 0.25930988 | 1 | 203.57 | 0.00957751 |
| 144.16 | 0.00558476 | 0 | 1955.65 | 0.08041275 | 1 | 0 | 0 |
| 1225.72 | 0.02893494 | 1 | 15455 | 0.50133366 | 1 | 119.22 | 0.00270984 |
| 289.56 | 0.00874387 | 0 | 2820.25 | 0.09030077 | 1 | 215.43 | 0.00650536 |
| 824.93 | 0.02483215 | 1 | 8878.97 | 0.39527585 | 1 | 153.31 | 0.00437227 |
| 314.98 | 0.00995406 | 0 | 4199.13 | 0.17453788 | 1 | 472.61 | 0.01512274 |
| 245.26 | 0.00704264 | 0 | 4172.79 | 0.13053642 | 1 | 135.14 | 0.00388055 |
| 401.43 | 0.010639 | 0 | 7088.34 | 0.25401036 | 1 | 99.2 | 0.00262907 |
| 200 | 0.00482412 | 0 | 3150 | 0.08647868 | 1 | 109.14 | 0.00263252 |
| 184.74 | 0.00542318 | 0 | 3178.59 | 0.12848257 | 1 | 74.4 | 0.00218407 |
| 342.54 | 0.00873972 | 0 | 6024.46 | 0.18403788 | 1 | 0 | 0.2766.72 |
| 418.06 | 0.01158966 | 0 | 4864.65 | 0.12057221 | 1 | 117.32 | 0.0032524 |
| 212.62 | 0.00520798 | 0 | 2844.43 | 0.06962579 | 1 | 0 | 0 |
| | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 138.27 | 0.00305044 | 0 | 1763.73 | 0.03852701 | 1 | 0 | 0 |
| 125.21 | 0.00151571 | 0 | 912.26 | 0.01104323 | 0 | 93.06 | 0.00112652 |
| | 0 | 0 | 434.82 | 0.00518462 | 0 | 129.28 | 0.00154148 |
| 94.14 | 0.00080513 | 0 | 482.9 | 0.00412998 | 0 | 0 | 0 |
| | 0 | 0 | 218.05 | 0.00182389 | 0 | 0 | 0 |
| | 0 | 0 | 261.95 | 0.00171724 | 0 | 161 | 0.00105545 |
| | 0 | 0 | 40.47 | 0.00019659 | 0 | 0 | 0 |
| | 0 | 0 | 77.85 | 0.0004141 | 0 | 0 | 0 |
| DCB area | DCB ng/ini. |
| 10840 | 0.08357642 | 1 | 1318.67 | 0.00882728 | 1 | 10338 | 0.07869357 |
| Total ng PCB | 0.46042033 | Total ng PCB | 2.78857893 | Total ng PCB | 0.1894307 | Total ng PCB | 1.18369156 |
| g used | 1 | g used | 3.2 | g used | 1.6 | g used | 1.3 |
| mL total vol. | 10 |
| ppm PCB | 2.30210166 | ppm PCB | 435.715457 | ppm PCB | 0.59197094 | ppm PCB | 455.265984 |
| ul DCB used | 5 | ul DCB used | 10 | ul DCB used | 5 | ul DCB used | 10 |
| conc (ng/ul) | 96.8 | conc (ng/ul) | 484 | conc (ng/ul) | 96.8 | conc (ng/ul) | 484 |
| DCB %R | 86.3392808 | DCB %R | 91.1909193 | DCB %R | 81.2950055 | DCB %R | 90.0700485 |
| Homolog | ppm | Homolog | ppm | Homolog | ppm | Homolog | ppm |
| mono | 0.25109839 | mono | 0.21558544 | mono | 0.16202432 | mono | 4.6370108 |
| di | 1.27132789 | di | 49.0742639 | di | 0.26058596 | di | 50.9982846 |
| tri | 0.32798057 | tri | 144.394858 | tri | 0.06684012 | tri | 154.438891 |
| tetra | 0.2546091 | tetra | 142.121671 | tetra | 0.07151316 | tetra | 153.676058 |
| penta | 0.08313522 | penta | 55.6693058 | penta | 0.01042746 | penta | 56.6319082 |
| hexa | 0.10310413 | hexa | 40.6637017 | hexa | 0.00977786 | hexa | 33.6895976 |
| hepta | 0.01084634 | hepta | 3.21233306 | hepta | 0.00750377 | hepta | 0.99337946 |
| octa | 0 | octa | 0.3637387 | octa | 0.00329829 | octa | 0.20085362 |

WMNB 4/28/88, Webb McCall Calculations for New Bedford

| A | B | C | D | E | F | G | H | I | J |
|----|--|--------------|--------------|--------------|--------------|--------------|---------------|-------------|--------------|
| 1 | STANDARDS (1:1 mixtures of aroclors 1242 and 1260) | | | | | | SAMPLE # | R70078803 | |
| 2 | | | | | | | | 291240CRG | |
| 3 | Total PCB Conc (ng/uL) | 0.2 | | 1 | | 10 | dilution used | 0.00001 | |
| 4 | inj. Vol. | | 2 | | 2 | | inj.vol | | 2 |
| 5 | peak ID | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection |
| 6 | 11 | 196.99 | 0.0022 | 556.64 | 0.011 | 1111.32 | 0.11 | 176.72 | 0.0019736 0 |
| 7 | 16 | 138.44 | 0.0058 | 408 | 0.029 | 2160.28 | 0.29 | 127.15 | 0.005327 0 |
| 8 | 21 | 496.31 | 0.0226 | 2442.56 | 0.113 | 15412 | 1.13 | 762.38 | 0.0349585 1 |
| 9 | 28 | 956.9 | 0.022 | 3768.35 | 0.11 | 23269 | 1.1 | 1210.73 | 0.029945 1 |
| 10 | 32 | 658.33 | 0.0122 | 2793.16 | 0.061 | 18029 | 0.61 | 486.13 | 0.0090088 0 |
| 11 | 37 | 2026.17 | 0.023 | 7281.34 | 0.115 | 49473 | 1.15 | 3597.57 | 0.0505098 1 |
| 12 | 40 | 1497.41 | 0.0222 | 5762.21 | 0.111 | 38009 | 1.11 | | 0 0 |
| 13 | 47 | 1641.19 | 0.0176 | 4417.69 | 0.088 | 46533 | 0.88 | 1508.82 | 0.0161805 0 |
| 14 | 54 | 904.65 | 0.0136 | 3264.16 | 0.068 | 21303 | 0.68 | 535.38 | 0.0080486 0 |
| 15 | 58 | 934.83 | 0.0112 | 3449.68 | 0.056 | 23173 | 0.56 | 430.43 | 0.0051569 0 |
| 16 | 70 | 1790.75 | 0.026 | 6919.68 | 0.13 | 45640 | 1.3 | 776.59 | 0.0112754 0 |
| 17 | 78 | 562.25 | 0.0072 | 2501.94 | 0.036 | 18504 | 0.36 | | 0 0 |
| 18 | 84 | 873.15 | 0.0148 | 3424.27 | 0.074 | 20731 | 0.74 | 335.05 | 0.0056791 0 |
| 19 | 98+104 | 1146.93 | 0.0138 | 4366.71 | 0.069 | 28916 | 0.69 | 220.4538 | 0.0026525 0 |
| 20 | 117+125 | 2541.2 | 0.0312 | 9892.8 | 0.156 | 64990 | 1.56 | 92.3272 | 0.0011336 0 |
| 21 | 146 | 2868.41 | 0.0302 | 10208 | 0.151 | 69181 | 1.51 | 435.48 | 0.0045849 0 |
| 22 | 160 | 1007.74 | 0.0098 | 4058.84 | 0.049 | 28717 | 0.49 | | 0 0 |
| 23 | 174 | 2466.39 | 0.0248 | 9719.7 | 0.124 | 70198 | 1.24 | 81.3248 | 0.0008177 0 |
| 24 | 203 | 2741.31 | 0.0186 | 10751 | 0.093 | 75407 | 0.93 | | 0 0 |
| 25 | 232+244 | 2750.56 | 0.0196 | 11172 | 0.098 | 78587 | 0.98 | 161.44 | 0.0011504 0 |
| 26 | 280 | 4043.64 | 0.022 | 17269 | 0.11 | 129522 | 1.1 | 19566 | 0.1302581 1 |
| 27 | 332 | 1774.2 | 0.0084 | 7461.71 | 0.042 | 54862 | 0.42 | | 0 0 |
| 28 | 372 | 2130.28 | 0.008 | 9246.08 | 0.04 | 65529 | 0.4 | | 0 0 |
| 29 | 448 | 533.34 | 0.0012 | 2647.79 | 0.006 | 19552 | 0.06 | | 0 0 |
| 30 | 528 | 1145.61 | 0.003 | 5153.45 | 0.015 | 38719 | 0.15 | | 0 0 |
| 31 | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | DCB area | DCB ng/inj. | |
| 32 | DCB | 1180.5 | 0.00296 | 6257.75 | 0.0296 | 45264 | 0.296 | | 0 0 |
| 33 | | | | | | | | | |
| 34 | The detection limit for this analysis is 0.1 ng/injection | | | | | | Total ng PCB | 0.3186605 | |
| 35 | These analyses are accurate to no more than 2 significant digits | | | | | | | | |
| 36 | | | | | | | g used | 1527.8 | |
| 37 | | | | | | | mL total vol. | 25 | |
| 38 | | | | | | | ppm PCB | 260.71844 ✓ | |
| 39 | | | | | | | | | |
| 40 | | | | | | | | | |
| 41 | | | | | | | ul DCB used | | |
| 42 | | | | | | | conc (ng/uL) | | |
| 43 | | | | | | | DCB %R | #DIV/0! | |
| 44 | | | | | | | | | |
| 45 | Homolog | ng/inj | Homolog | ng/inj | Homolog | ng/inj | Homolog | ppm | |
| 46 | mono | 0.0022 | mono | 0.011 | mono | 0.11 | mono | 1.614759 | |
| 47 | di | 0.0339 | di | 0.1695 | di | 1.695 | di | 39.085413 | |
| 48 | tri | 0.078388 | tri | 0.39194 | tri | 3.9194 | tri | 69.244555 | |
| 49 | tetra | 0.063572 | tetra | 0.31786 | tetra | 3.1786 | tetra | 28.419483 | |
| 50 | penta | 0.037806 | penta | 0.18903 | penta | 1.8903 | penta | 9.2266132 | |
| 51 | hexa | 0.093254 | hexa | 0.46627 | hexa | 4.6627 | hexa | 5.7072772 | |
| 52 | hepta | 0.06968 | hepta | 0.3484 | hepta | 3.484 | hepta | 107.42034 | |
| 53 | octa | 0.0122 | octa | 0.061 | octa | 0.61 | octa | 0 | |

WMNB 4/28/88, Webb McCall Calculations for New Bedford

| | W | X | Y | Z | AA | AB | AC | AD | AE | AF | AG | AH |
|----|---------------|--------------|---|---------------|--------------|----|---------------|--------------|----|---------------|--------------|----|
| 1 | SAMPLE # | R70078804 | | SAMPLE # | R70078804 | | SAMPLE # | R70078804 | | SAMPLE # | R70078804 | |
| 2 | | 271345SRG | | | 271350SRG | | | 271400SRG | | | 271405SRG | |
| 3 | dilution used | 1 | | dilution used | 1 | | dilution used | 1 | | dilution used | 1 | |
| 4 | inj.vol | 2 | | inj.vol | 2 | | inj.vol | 2 | | inj.vol | 2 | |
| 5 | Peak Area | ng/injection | | Peak Area | ng/injection | | Peak Area | ng/injection | | Peak Area | ng/injection | |
| 6 | 3231.67 | 0.4884428 | 2 | 3568.96 | 0.54864275 | 2 | 67896 | 12.0298156 | 2 | 69054 | 12.2364969 | 2 |
| 7 | | 0 | 0 | | 0 | 0 | 21.6876 | 0.00090861 | 0 | 81.2722 | 0.00340493 | 0 |
| 8 | 1754.99 | 0.08106354 | 1 | 2039.05 | 0.09425765 | 1 | 4665.82 | 0.28733717 | 1 | 4775.84 | 0.2959644 | 1 |
| 9 | 654.39 | 0.01504502 | 0 | 3193.26 | 0.09199935 | 1 | 2701.3 | 0.07660072 | 1 | 2860.13 | 0.08157219 | 1 |
| 10 | 159.25 | 0.00295118 | 0 | 1952.73 | 0.04178864 | 1 | 760.6 | 0.01453779 | 1 | 1002.96 | 0.02007788 | 1 |
| 11 | 876.9 | 0.00995451 | 0 | 9529.92 | 0.17015972 | 1 | 3072.31 | 0.04131432 | 1 | 3879.65 | 0.05544808 | 1 |
| 12 | 330.73 | 0.00490327 | 0 | 6006.18 | 0.11855815 | 1 | 1917.49 | 0.03094674 | 1 | 2747.36 | 0.04822597 | 1 |
| 13 | 909.51 | 0.00975352 | 0 | 10176 | 0.19628797 | 1 | 13426 | 0.25740589 | 1 | 17367 | 0.33151841 | 1 |
| 14 | 600.62 | 0.00902938 | 0 | 6749.7 | 0.1862532 | 1 | 1962.18 | 0.03798203 | 1 | 2158.03 | 0.04249747 | 1 |
| 15 | 2673.67 | 0.04217602 | 1 | 10318 | 0.23150966 | 1 | 15622 | 0.36704547 | 1 | 17742 | 0.4212189 | 1 |
| 16 | 1774.14 | 0.02575884 | 0 | 18340 | 0.4750843 | 1 | 10676 | 0.24350357 | 1 | 12723 | 0.30535714 | 1 |
| 17 | 787.08 | 0.01053822 | 1 | | 0 | 0 | 2630.88 | 0.0386107 | 1 | 2958.65 | 0.04524719 | 1 |
| 18 | 1687.37 | 0.03369438 | 1 | 13091 | 0.44599645 | 1 | 5190.67 | 0.14197485 | 1 | 6058.19 | 0.17535888 | 1 |
| 19 | 2903.03 | 0.04390663 | 1 | 10551 | 0.22543809 | 1 | 4100.27 | 0.06443215 | 1 | 3657.59 | 0.05684283 | 1 |
| 20 | 2041.19 | 0.02506105 | 0 | 5479.33 | 0.08107739 | 1 | 2217.41 | 0.02722462 | 0 | 2566.22 | 0.03162474 | 1 |
| 21 | 3417.83 | 0.03924273 | 1 | 5342.08 | 0.07091336 | 1 | | 0 | 0 | | 0 | 0 |
| 22 | | 0 | 0 | | 0 | 0 | 2556.52 | 0.02969845 | 1 | 2450.17 | 0.02833209 | 1 |
| 23 | | 0 | 0 | 2710.36 | 0.02813666 | 1 | | 0 | 0 | | 0 | 0 |
| 24 | 3150.83 | 0.02240393 | 1 | 2044.88 | 0.01387467 | 0 | 1742.54 | 0.01182327 | 0 | 2381.17 | 0.01615642 | 0 |
| 25 | | 0 | 0 | 2646.14 | 0.01885592 | 0 | 1564.89 | 0.01115113 | 0 | 1709 | 0.01217803 | 0 |
| 26 | 3703.47 | 0.02014926 | 0 | 3406.59 | 0.01853404 | 0 | 938.48 | 0.00510593 | 0 | 1240.59 | 0.00674961 | 0 |
| 27 | 2107.14 | 0.01036669 | 1 | 1946.92 | 0.00942037 | 1 | | 0 | 0 | 901.75 | 0.00426936 | 0 |
| 28 | 3135.67 | 0.01252127 | 1 | 2773.29 | 0.01089164 | 1 | 728.6 | 0.00273617 | 0 | | 0 | 0 |
| 29 | 3277.58 | 0.00801185 | 1 | 1590.77 | 0.00360047 | 1 | | 0 | 0 | 237.93 | 0.00053534 | 0 |
| 30 | | 0 | 0 | 2921.39 | 0.00831692 | 1 | | 0 | 0 | | 0 | 0 |
| 31 | DCB area | DCB ng/inj. | | DCB area | DCB ng/inj. | | DCB area | DCB ng/inj. | | DCB area | DCB ng/inj. | |
| 32 | 13418 | 0.07850218 | 1 | 13092 | 0.0762757 | 1 | 11324 | 0.06420084 | 1 | 10932 | 0.06152361 | 1 |
| 33 | | | | | | | | | | | | |
| 34 | Total ng PCB | 0.91497387 | | Total ng PCB | 3.08959737 | | Total ng PCB | 13.7201552 | | Total ng PCB | 14.2190768 | |
| 35 | | | | | | | | | | | | |
| 36 | g used | 2.3 | | g used | 2.5 | | g used | 2.6 | | g used | 2.6 | |
| 37 | mL total vol. | 10 | | mL total vol. | 10 | | mL total vol. | 10 | | mL total vol. | 10 | |
| 38 | | | | | | | | | | | | |
| 39 | ppm PCB | 1.99907363 | | ppm PCB | 6.17919474 | | ppm PCB | 26.3849138 | | ppm PCB | 27.3443764 | |
| 40 | | | | | | | | | | | | |
| 41 | ul DCB used | 5 | | ul DCB used | 5 | | ul DCB used | 5 | | ul DCB used | 5 | |
| 42 | conc (ng/ul) | 88.8 | | conc (ng/ul) | 88.8 | | conc (ng/ul) | 88.8 | | conc (ng/ul) | 88.8 | |
| 43 | DCB %R | 88.4033542 | | DCB %R | 85.8960637 | | DCB %R | 72.2982428 | | DCB %R | 69.2833413 | |
| 44 | | | | | | | | | | | | |
| 45 | Homolog | ppm | | Homolog | ppm | | Homolog | ppm | | Homolog | ppm | |
| 46 | mono | 1.06183216 | | mono | 1.0972855 | | mono | 29.1342608 | | mono | 23.5317249 | |
| 47 | di | 0.18440174 | | di | 0.23451497 | | di | 0.59114607 | | di | 0.61492765 | |
| 48 | tri | 0.06972177 | | tri | 0.92193917 | | tri | 0.30150665 | | tri | 0.38260623 | |
| 49 | tetra | 0.18870916 | | tetra | 1.77979426 | | tetra | 1.65653374 | | tetra | 2.00627188 | |
| 50 | penta | 0.17092349 | | penta | 1.52774008 | | penta | 0.50680313 | | penta | 0.59571367 | |
| 51 | hexa | 0.15867485 | | hexa | 0.45747883 | | hexa | 0.11126286 | | hexa | 0.11463152 | |
| 52 | hepta | 0.11017325 | | hepta | 0.11482389 | | hepta | 0.07813869 | | hepta | 0.09747311 | |
| 53 | octa | 0.04463722 | | octa | 0.04561805 | | octa | 0.00526186 | | octa | 0.00102949 | |

Ok except none

Ok except none

Ok except none

Ok except none

WMNB06/18, Webb McCall Calculations for New Bedford

| A | B | C | D | E | F | G | H | I | J |
|----|--|--------------|--------------|--------------|--------------|--------------|----------------------------|-------------|--------------|
| 1 | STANDARDS (1:1 mixtures of aroclors 1242 and 1260) | | | | | | SAMPLE # | R50U18B | |
| 2 | | | | | | | 1 ppm std to check RT's | | |
| 3 | Total PCB Conc (ng/uL) | 0.2 | | 1 | | 10 | dilution used | 1 | |
| 4 | inj. Vol. | 2 | | 2 | | 2 | inj.vol | 2 | |
| 5 | peak ID | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection |
| 6 | 11 | 62.5416 | 0.011 | 62.5416 | 0.011 | 606.06 | 0.11 | 53.98 | 0.0094942 |
| 7 | 16 | 102.44 | 0.029 | 102.44 | 0.029 | 830.16 | 0.29 | 96 | 0.0271769 |
| 8 | 21 | 239.87 | 0.0226 | 809.63 | 0.113 | 5661.71 | 1.13 | 733.68 | 0.1009495 |
| 9 | 28 | 305.87 | 0.022 | 1196.16 | 0.11 | 8097.93 | 1.1 | 1095.43 | 0.1000434 |
| 10 | 32 | 202.41 | 0.0122 | 867.01 | 0.061 | 6315.35 | 0.61 | 787.79 | 0.0551831 |
| 11 | 37 | 585.32 | 0.023 | 2506.14 | 0.115 | 17483 | 1.15 | 2322.23 | 0.1061914 |
| 12 | 40 | 354.03 | 0.0222 | 1788.21 | 0.111 | 12903 | 1.11 | 1625.12 | 0.100902 |
| 13 | 47 | 289.44 | 0.0176 | 1320.14 | 0.088 | 9187.29 | 0.88 | 1191.6 | 0.0792203 |
| 14 | 54 | 204.56 | 0.0136 | 1068.49 | 0.068 | 7530.82 | 0.68 | 981.72 | 0.0625363 |
| 15 | 58 | 199.76 | 0.0112 | 1105.33 | 0.056 | 8147.77 | 0.56 | 990.75 | 0.0503315 |
| 16 | 70 | 522.11 | 0.026 | 2362.54 | 0.13 | 15811 | 1.3 | 2189.06 | 0.1201969 |
| 17 | 78 | 874.59 | 0.036 | 874.59 | 0.036 | 6885.12 | 0.36 | 825.7 | 0.0339876 |
| 18 | 84 | 1167.37 | 0.074 | 1167.37 | 0.074 | 6782.73 | 0.74 | 1008.86 | 0.063952 |
| 19 | 98+104 | 328.43 | 0.0138 | 1407.85 | 0.069 | 10450 | 0.69 | 1214.47 | 0.0591108 |
| 20 | 117+125 | 805.54 | 0.0312 | 3114.1 | 0.156 | 21211 | 1.56 | 2791.23 | 0.1385458 |
| 21 | 146 | 625.73 | 0.0302 | 2846.95 | 0.151 | 18975 | 1.51 | 2617.52 | 0.1385226 |
| 22 | 160 | 260.01 | 0.0098 | 1245.54 | 0.049 | 8397.18 | 0.49 | 1105.69 | 0.0434374 |
| 23 | 174 | 673.12 | 0.0248 | 3034.1 | 0.124 | 20460 | 1.24 | 2787.04 | 0.1136194 |
| 24 | 203 | 669.17 | 0.0186 | 2933.44 | 0.093 | 18569 | 0.93 | 2638.68 | 0.0833147 |
| 25 | 232+244 | 764.4 | 0.0196 | 3421.49 | 0.098 | 22190 | 0.98 | 3098.78 | 0.0884781 |
| 26 | 280 | 1091.83 | 0.022 | 4748.65 | 0.11 | 32509 | 1.1 | 4322.09 | 0.099735 |
| 27 | 332 | 441.69 | 0.0084 | 2183.01 | 0.042 | 15595 | 0.42 | 2016.84 | 0.0387936 |
| 28 | 372 | 560.44 | 0.008 | 2682.34 | 0.04 | 18303 | 0.4 | 2280.77 | 0.033944 |
| 29 | 448 | 152.56 | 0.0012 | 754.59 | 0.006 | 6038.39 | 0.06 | 620.39 | 0.00493 |
| 30 | 528 | 267.99 | 0.003 | 1448 | 0.015 | 12037 | 0.15 | 1312.1 | 0.013618 |
| 31 | Peak Area | ng/injection | Peak Area | ng/injection | Peak Area | ng/injection | DCB area | DCB ng/ini. | |
| 32 | DCB | 390.16 | 0.00592 | 3263.21 | 0.0592 | 24948 | 0.592 | | 0 0 |
| 33 | | | | | | | | | |
| 34 | The detection limit for this analysis is 0.1 ng/injection | | | | | | Total ng PCB | 1.7662144 | |
| 35 | These analyses are accurate to no more than 2 significant digits | | | | | | | | |
| 36 | | | | | | | g used | 1 | |
| 37 | | | | | | | mL total vol. | 1 | |
| 38 | | | | | | | | | |
| 39 | | | | | | | ppm PCB | 0.8831072 | |
| 40 | | | | | | | | | |
| 41 | | | | | | | ul DCB used | | |
| 42 | | | | | | | conc (ng/uL) | | |
| 43 | | | | | | | DCB %R | #DIV/0! | |
| 44 | | | | | | | | | |
| 45 | Homolog | ng/inj | Homolog | ng/inj | Homolog | ng/ini | Homolog | ppm | % |
| 46 | mono | 0.011 | mono | 0.011 | mono | 0.11 | mono | 0.0047471 | 86 |
| 47 | di | 0.0571 | di | 0.1695 | di | 1.695 | di | 0.0765686 | 90 |
| 48 | tri | 0.078388 | tri | 0.39194 | tri | 3.9194 | tri | 0.178973 | 91 |
| 49 | tetra | 0.092372 | tetra | 0.31786 | tetra | 3.1786 | tetra | 0.1453893 | 91 |
| 50 | penta | 0.097006 | penta | 0.18903 | penta | 1.8903 | penta | 0.0830514 | 88 |
| 51 | hexa | 0.093254 | hexa | 0.46627 | hexa | 4.6627 | hexa | 0.2107014 | 90 |
| 52 | hepta | 0.06968 | hepta | 0.3484 | hepta | 3.484 | hepta | 0.1574304 | 90 |
| 53 | octa | 0.0122 | octa | 0.061 | octa | 0.61 | octa | 0.026246 | 86 |
| 54 | | | | | | | "%" = % of theoretical ppm | | |

WMNB06/18, Webb McCall Calculations for New Bedford

| | W | X | Y | Z | AA | AB | AC | AD | AE | AF | AG | AH |
|----|---------------|--------------|---------------|---------------|---------------|----|---------------|--------------|---------------|---------------|--------------|----|
| 1 | SAMPLE # | R70078804 | | SAMPLE # | R70078806 | | SAMPLE # | R70078806 | | SAMPLE # | R70078804 | |
| 2 | | 220925RRG | | | 181550RTG | | | 181540RTG | | | 221035WRG | |
| 3 | dilution used | 1 | dilution used | 1 | dilution used | 1 | dilution used | 1 | dilution used | 1 | | |
| 4 | inj.vol | 2 | inj.vol | 2 | inj.vol | 2 | inj.vol | 2 | inj.vol | 2 | | |
| 5 | Peak Area | ng/injection | | Peak Area | ng/injection | | Peak Area | ng/injection | | Peak Area | ng/injection | |
| 6 | 1519.86 | 0.27644552 | 2 | 1528.04 | 0.27793547 | 2 | 1677.25 | 0.30511356 | 2 | 308.78 | 0.0558515 | 1 |
| 7 | 467.94 | 0.16008819 | 1 | | 0 | 0 | 590.53 | 0.20405564 | 1 | 286.36 | 0.0949637 | 1 |
| 8 | 229.75 | 0.02164652 | 0 | 897.7 | 0.13145955 | 1 | 256.82 | 0.02528934 | 1 | 111.91 | 0.0105439 | 0 |
| 9 | 243.64 | 0.01752405 | 0 | 781.01 | 0.06896483 | 1 | 268.37 | 0.01930278 | 0 | 244.74 | 0.0176032 | 0 |
| 10 | | 0 | 0 | 490.97 | 0.03338828 | 1 | | | 0 | 86.9611 | 0.0052415 | 0 |
| 11 | 70.6517 | 0.00277624 | 0 | 1459.98 | 0.0648929 | 1 | 135.49 | 0.00532404 | 0 | 225.31 | 0.0088535 | 0 |
| 12 | 41.3858 | 0.00259516 | 0 | 965.99 | 0.06009067 | 1 | 89.0037 | 0.00558111 | 0 | | 0 | 0 |
| 13 | | 0 | 0 | 673.24 | 0.04381473 | 1 | | | 0 | 0 | 0 | 0 |
| 14 | 32.2865 | 0.00214654 | 0 | 577.43 | 0.0370789 | 1 | | | 0 | 0 | 0 | 0 |
| 15 | 106.58 | 0.00597565 | 0 | 658.84 | 0.03391142 | 1 | 127.06 | 0.00712391 | 0 | 45.3055 | 0.0025402 | 0 |
| 16 | | 0 | 0 | 1047.77 | 0.05570428 | 1 | | | 0 | 0 | 0 | 0 |
| 17 | | 0 | 0 | 715.83 | 0.0294651 | 0 | | | 0 | 0 | 0 | 0 |
| 18 | | 0 | 0 | | 0 | 0 | | | 0 | 0 | 0 | 0 |
| 19 | | 0 | 0 | 426.99 | 0.01884022 | 1 | | | 0 | 37.1354 | 0.0015604 | 0 |
| 20 | | 0 | 0 | 321.88 | 0.01246699 | 0 | | | 0 | 0 | 0 | 0 |
| 21 | | 0 | 0 | 119.38 | 0.00576171 | 0 | | | 0 | 0 | 0 | 0 |
| 22 | | 0 | 0 | | 0 | 0 | | | 0 | 0 | 0 | 0 |
| 23 | | 0 | 0 | 159.55 | 0.00587836 | 0 | | | 0 | 0 | 0 | 0 |
| 24 | | 0 | 0 | | 0 | 0 | | | 0 | 0 | 0 | 0 |
| 25 | 752.33 | 0.01929051 | 0 | 152.18 | 0.00390205 | 0 | | | 0 | 0 | 0 | 0 |
| 26 | | 0 | 0 | 177.97 | 0.00358603 | 0 | 89.0273 | 0.00179387 | 0 | 92.0563 | 0.0018549 | 0 |
| 27 | | 0 | 0 | | 0 | 0 | | | 0 | 0 | 0 | 0 |
| 28 | | 0 | 0 | 115.83 | 0.00165342 | 0 | 45.4583 | 0.00064889 | 0 | 46.2291 | 0.0006599 | 0 |
| 29 | | 0 | 0 | | 0 | 0 | | | 0 | 0 | 0 | 0 |
| 30 | | 0 | 0 | | 0 | 0 | | | 0 | 0 | 0 | 0 |
| 31 | DCB area | DCB ng/ini. | | DCB area | DCB ng/ini. | | DCB area | DCB ng/ini. | | DCB area | DCB ng/ini. | |
| 32 | 5786.43 | 0.12119606 | 1 | 5637.82 | 0.11754468 | 1 | 5508.13 | 0.11435817 | 1 | 6342.12 | 0.1348495 | 1 |
| 33 | | | | | | | | | | | | |
| 34 | Total ng PCB | 0.50848838 | / | Total ng PCB | 0.8887949 | / | Total ng PCB | 0.57423315 | v | Total ng PCE | 0.1996725 | v |
| 35 | | | | | | | | | | | | |
| 36 | g used | 4.1 | | g used | 4.1 | | g used | 4.2 | | g used | 3.6 | |
| 37 | mL total vol. | 10 | | mL total vol. | 10 | | mL total vol. | 10 | | mL total vol. | 10 | |
| 38 | | | | | | | | | | | | |
| 39 | ppm PCB | 0.62010778 | v | ppm PCB | 1.08389622 | v | ppm PCB | 0.68361089 | v | ppm PCB | 0.277323 | v |
| 40 | | | | | | | | | | | | |
| 41 | ul DCB used | 5 | | ul DCB used | 5 | | ul DCB used | 5 | | ul DCB used | 5 | |
| 42 | conc (ng/ul) | 118 | | conc (ng/ul) | 118 | | conc (ng/ul) | 118 | | conc (ng/ul) | 118 | |
| 43 | DCB %R | 102.708528 | | DCB %R | 99.6141385 | | DCB %R | 96.9137051 | | DCB %R | 114.27923 | |
| 44 | | | | | | | | | | | | |
| 45 | Homolog | ppm | | Homolog | ppm | | Homolog | ppm | | Homolog | ppm | |
| 46 | mono | 0.33712868 | | mono | 0.3389457 | | mono | 0.36323043 | | mono | 0.0775715 | |
| 47 | di | 0.22697039 | | di | 0.18134238 | | di | 0.27877461 | | di | 0.1526506 | |
| 48 | tri | 0.02344243 | | tri | 0.27113599 | | tri | 0.0302.695 | | tri | 0.037913 | |
| 49 | tetra | 0.00904126 | | tetra | 0.20924896 | | tetra | 0.00848084 | | tetra | 0.003528 | |
| 50 | penta | 0 | | penta | 0.0388782 | | penta | 0 | | penta | 0.0016037 | |
| 51 | hexa | 0.0023525 | | hexa | 0.03367267 | | hexa | 0 | | hexa | 0.0005635 | |
| 52 | hepta | 0.02117251 | | hepta | 0.00865595 | | hepta | 0.00213556 | | hepta | 0.0025763 | |
| 53 | octa | 0 | | octa | 0.00201636 | | octa | 0.00077249 | | octa | 0.0009165 | |
| 54 | | | | | | | | | | | | |

WMNB06/20, Webb McCall Calculations for New Bedford

| | K | L | M | N | O | P | Q | R | S | T | U | V |
|----|---------------|--------------|---------------|--------------|---------------|--------------|---------------|--------------|---------------|--------------|------------|---|
| 1 | SAMPLE # | R70078804 | | SAMPLE # | R70078804 | | SAMPLE # | R70078804 | | SAMPLE # | HEXU20A | |
| 2 | | 250938WRG | | | 221035WRG | | | 221050WRG | | | | |
| 3 | dilution used | 1 | | |
| 4 | inj.vol | 2 | | |
| 5 | Peak Area | ng/injection | | |
| 6 | 6721.86 | 1.2686599 | 2 | 1390.78 | 0.25906708 | 2 | 135.05 | 0.0212586 | 1 | | 0 | 0 |
| 7 | | 0 | 0 | | 0 | 0 | | 0 | 56.1354 | 0.01202629 | 1 | |
| 8 | 638.7 | 0.0824558 | 1 | 876.65 | 0.11908882 | 1 | 185.32 | 0.01818519 | 0 | | 0 | 0 |
| 9 | 355.71 | 0.0263926 | 1 | 417.85 | 0.03226007 | 1 | 113.68 | 0.00808875 | 0 | | 0 | 0 |
| 10 | 90.3868 | 0.0054859 | 0 | | 0 | 0 | 111.66 | 0.00677704 | 0 | | 0 | 0 |
| 11 | 64.5867 | 0.0024832 | 0 | 69.8721 | 0.0026864 | 0 | | 0 | 0 | 166.86 | 0.00641533 | 0 |
| 12 | 275.67 | 0.0169375 | 0 | 149.55 | 0.00918856 | 0 | | 0 | 0 | | 0 | 0 |
| 13 | 187.89 | 0.010495 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 14 | | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 15 | 292.88 | 0.0165258 | 1 | 74.2654 | 0.00419198 | 0 | 25.6042 | 0.00144525 | 0 | | 0 | 0 |
| 16 | 130.43 | 0.0059187 | 0 | 40.7215 | 0.00184788 | 0 | | 0 | 0 | | 0 | 0 |
| 17 | 100.55 | 0.003607 | 0 | 57.3076 | 0.00205578 | 0 | 119.43 | 0.00428427 | 0 | | 0 | 0 |
| 18 | | 0 | 0 | 42.8053 | 0.00171393 | 0 | | 0 | 0 | | 0 | 0 |
| 19 | | 0 | 0 | | 0 | 0 | | 0 | 67.0303 | 0.00207963 | 0 | |
| 20 | | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 | |
| 21 | | 0 | 0 | | 0 | 0 | | 0 | 0 | 74.0718 | 0.00293096 | 0 |
| 22 | 142.87 | 0.0047886 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 23 | | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 24 | | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 25 | | 0 | 0 | | 0 | 0 | 6098.62 | 0.22590397 | 1 | 188.06 | 0.00412791 | 0 |
| 26 | 93.4739 | 0.0015438 | 0 | 81.5104 | 0.00134623 | 0 | 12368 | 0.37577968 | 1 | 142.18 | 0.00234825 | 0 |
| 27 | | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 28 | | 0 | 0 | | 0 | 0 | | 0 | 0 | 53.677 | 0.00059907 | 0 |
| 29 | | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 30 | | 0 | 0 | | 0 | 0 | | 0 | 0 | | 0 | 0 |
| 31 | DCB area | DCB ng/ini. | | | | |
| 32 | 10874 | 0.250343 | 1 | 11394 | 0.26400713 | 1 | 14191 | 0.33750465 | 1 | | 0 | 0 |
| 33 | | | | | | | | | | | | |
| 34 | Total ng PCB | 1.4452938 | ✓ | Total ng PCB | 0.43344672 | ✓ | Total ng PCB | 0.66172276 | ✓ | Total ng PCB | 0.03052744 | |
| 35 | | | | | | | | | | | | |
| 36 | g used | 10.2 | g used | 11 | g used | 10.9 | g used | 10.9 | g used | 1 | | |
| 37 | mL total vol. | 5 | mL total vol. | 1 | | |
| 38 | | | | | | | | | | | | |
| 39 | ppm PCB | 0.3542387 | ✓ | ppm PCB | 0.09851062 | ✓ | ppm PCB | 0.15177127 | ✓ | ppm PCB | 0.01526372 | |
| 40 | | | | | | | | | | | | |
| 41 | ul DCB used | 5 | ul DCB used | | | |
| 42 | conc (ng/ul) | 118 | conc (ng/ul) | | | |
| 43 | DCB %R | 106.07752 | DCB %R | 111.867429 | DCB %R | 143.010447 | DCB %R | #DIV/0! | | | | |
| 44 | | | | | | | | | | | | |
| 45 | Homolog | ppm | Homolog | ppm | Homolog | ppm | Homolog | ppm | | | | |
| 46 | mono | 0.3109461 | mono | 0.05887888 | mono | 0.00487583 | mono | 0 | | 0 | | |
| 47 | di | 0.0218269 | di | 0.0288986 | di | 0.00463472 | di | 0.00601315 | | | | |
| 48 | tri | 0.0109561 | tri | 0.00819773 | tri | 0.00294578 | tri | 0.00320767 | | | | |
| 49 | tetra | 0.0085368 | tetra | 0.00171812 | tetra | 0.00131411 | tetra | 0 | | 0 | | |
| 50 | penta | 0.0004207 | penta | 0.00051132 | penta | 0 | penta | 0.00084274 | | | | |
| 51 | hexa | 0.0005868 | hexa | 0 | hexa | 0.00518128 | hexa | 0.00186895 | | | | |
| 52 | hepta | 0.0009652 | hepta | 0.00030596 | hepta | 0.13281955 | hepta | 0.00303168 | | | | |
| 53 | octa | 0 | octa | 0 | octa | 0 | octa | 0.00029954 | | | | |

Webb McCall Calculations for New Bedford Samples

| K | L | M | N | O | P | Q | R | S | T | U | V |
|----|---------------|--------------|---------------|--------------|---------------|--------------|---------------|--------------|---------------|-----------|------------|
| 1 | SAMPLE # | R70078809 | | | |
| 2 | | 081410SEM | | 071420SEM | | 081430SEM | | | | 081440SEM | |
| 3 | dilution used | 1 | dilution used | 1 | |
| 4 | inj.vol | 2 | inj.vol | 2 | inj.vol | 2 | inj.vol | 2 | inj.vol | 2 | |
| 5 | Peak Area | ng/injection | | | |
| 6 | 1351.32 | 0.0636207 | 1 | 1352 | 0.0636521 | 1 | 13823 | 0.76620607 | 1 | 14021 | 0.78017038 |
| 7 | 693.24 | 0.1311015 | 1 | 328.59 | 0.05678304 | 1 | 2009.19 | 0.39930198 | 2 | 2211.21 | 0.44047518 |
| 8 | 82.6224 | 0.0054999 | 0 | 3437.37 | 0.36667472 | 1 | 2017.8 | 0.18222666 | 1 | 1952.65 | 0.17376156 |
| 9 | 243.54 | 0.009434 | 0 | 5529.49 | 0.39741213 | 1 | 1190.41 | 0.05393452 | 1 | 1445.83 | 0.0670381 |
| 10 | 21.8019 | 0.0006867 | 0 | 4075.69 | 0.2044745 | 1 | 182.16 | 0.00573717 | 0 | 304.41 | 0.00958747 |
| 11 | 93.952 | 0.0021076 | 0 | 10136 | 0.38604872 | 1 | 442.93 | 0.00993591 | 0 | 527.89 | 0.01184176 |
| 12 | 37.2195 | 0.0010296 | 0 | 8378.04 | 0.38901043 | 1 | 545.09 | 0.01507913 | 0 | 104.1 | 0.00287978 |
| 13 | 96.1346 | 0.0023587 | 0 | 6161.9 | 0.2866923 | 1 | 349.1 | 0.0085652 | 0 | 874.24 | 0.02268555 |
| 14 | | 0 | 0 | 4724.98 | 0.23221608 | 1 | | | 0 | 0 | 0 |
| 15 | | 0 | 0 | 5272.07 | 0.18652296 | 1 | | | 0 | 61.6243 | 0.00159689 |
| 16 | | 0 | 0 | 7618.91 | 0.33052801 | 1 | 165.62 | 0.00466823 | 0 | 202.2 | 0.00569929 |
| 17 | | 0 | 0 | 5693.06 | 0.2189362 | 1 | | | 0 | 0 | 0 |
| 18 | | 0 | 0 | 3288.48 | 0.08845379 | 1 | | | 0 | 0 | 0 |
| 19 | | 0 | 0 | 1885.72 | 0.04331486 | 1 | 120.44 | 0.00258848 | 0 | 57.4514 | 0.00123474 |
| 20 | 124 | 0.003054 | 0 | 1183.78 | 0.02915572 | 0 | 123.94 | 0.00305256 | 0 | | 0 |
| 21 | | 0 | 0 | | 0 | 0 | | | 0 | 0 | 0 |
| 22 | | 0 | 0 | 327.79 | 0.00759823 | 0 | | | 0 | 0 | 0 |
| 23 | | 0 | 0 | 302.53 | 0.0050867 | 0 | | | 0 | 0 | 0 |
| 24 | 49.9379 | 0.0008035 | 0 | 244.64 | 0.00393615 | 0 | | | 0 | 0 | 0 |
| 25 | 178.04 | 0.0022506 | 0 | 344.89 | 0.00435983 | 0 | 79.5416 | 0.0010055 | 0 | 49.5416 | 0.00062627 |
| 26 | | 0 | 0 | 64.9109 | 0.00076047 | 0 | | | 0 | 0 | 0 |
| 27 | 101.97 | 0.0007664 | 0 | 252.89 | 0.00190075 | 0 | 80.2447 | 0.00060313 | 0 | 75.177 | 0.00056504 |
| 28 | 26.6927 | 0.000106 | 0 | 82.7976 | 0.00032882 | 0 | 65.4029 | 0.00025974 | 0 | 26.4293 | 0.00010496 |
| 29 | | 0 | 0 | 108.38 | 0.0006631 | 0 | 90.3145 | 0.00055257 | 0 | 18.279 | 0.00011184 |
| 30 | DCB area | DCB ng/inj. | | | |
| 31 | 13944 | 0.1393262 | 1 | 12382 | 0.12009439 | 1 | 19474 | 0.20741318 | 1 | 17505 | 0.18317027 |
| 32 | | | | | | | | | | | |
| 33 | Total ng PCB | 0.2228192 | Total ng PCB | 3.30450961 | Total ng PCB | 1.45371687 | Total ng PCB | 1.51837879 | | | |
| 34 | | | | | | | | | | | |
| 35 | g used | 2.42 | g used | 2.6 | g used | 2.6 | g used | 2.8 | | | |
| 36 | mL total vol. | 10 | mL total vol. | 10 | |
| 37 | | | | | | | | | | | |
| 38 | ppm PCB | 0.4603702 | ppm PCB | 6.35482618 | ppm PCB | 2.79560936 | ppm PCB | 2.7113907 | | | |
| 39 | | | | | | | | | | | |
| 40 | ul DCB used | 5 | ul DCB used | 5 | |
| 41 | conc (ng/ul) | 296 | conc (ng/ul) | 296 | |
| 42 | DCB %R | 47.06966 | DCB %R | 40.5724292 | DCB %R | 70.0720205 | DCB %R | 61.8818491 | | | |
| 43 | | | | | | | | | | | |
| 44 | Homolog | ppm | Homolog | ppm | Homolog | ppm | Homolog | ppm | | | |
| 45 | mono | 0.1314477 | mono | 0.12240788 | mono | 1.47347322 | mono | 1.39316139 | | | |
| 46 | di | 0.2871071 | di | 1.00540538 | di | 1.14425436 | di | 1.12677904 | | | |
| 47 | tri | 0.0225194 | tri | 2.60427703 | tri | 0.13692904 | tri | 0.13319209 | | | |
| 48 | tetra | 0.0048733 | tetra | 1.79946896 | tetra | 0.02284547 | tetra | 0.05058739 | | | |
| 49 | penta | 0.0003155 | penta | 0.60509952 | penta | 0.0034943 | penta | 0.00321601 | | | |
| 50 | hexa | 0.0061605 | hexa | 0.18714136 | hexa | 0.0099573 | hexa | 0.0019403 | | | |
| 51 | hepta | 0.0061442 | hepta | 0.0254632 | hepta | 0.00193366 | hepta | 0.00111833 | | | |
| 52 | octa | 0.0018025 | octa | 0.00556284 | octa | 0.00272201 | octa | 0.00139614 | | | |

Understanding Reagent Spreadsheets

The concentrations of reagents in samples are calculated by a procedure developed by GRC. The reagents DMSO, TMH and PEG 400 are injected together. They produce a distinctive peak pattern. DMSO produces only one peak. TMH produces 2 peaks, but only the largest one is used for quantitation. PEG 400 produces a series of peaks, the heights of the four largest peaks are summed and used for quantitation.

As a general rule for liquid chromatography, standards should bracket samples. In other words, it is best to have a standard of higher concentration and a standard of lower concentration for calculation of sample concentration. That way the sample concentration can be calculated by linear interpolation, which will greatly reduce inaccuracy caused by nonlinear detector response. The micrograms of reagent represented by each peak in a sample is calculated by linear interpolation between two standards having the same peak at higher and lower concentrations. The equation for the calculation is listed below:

$$ug_{ix} = ug_{ih} - [(H_{ih}-H_{il})(ug_{ih}-ug_{il})/(H_{ih}-H_{il})]$$

where i refers to a peak name,
x refers to the sample,
h refers to the higher standard,
l refers to the lower standard, and
H is a peak height.

The number of micrograms of analyte "i" in an injection is calculated from the concentration of that analyte in the standard and the injection volume as follows. (Remember that mg/mL = ug/uL)

$$ug_{is} = C_{is} \cdot V_{js}$$

where C_{is} = the concentration of "i" in the standard (in mg/mL)
 V_{js} = the injection volume for the standard.
 ug_{is} = the micrograms of analyte "i" in standard injection.

The concentration of analyte "i" in the reagent is calculated from the micrograms in the injection, the sample injection volume, the sample solution volume (usually 10 mL), and the sample weight. It is most useful to report concentrations in mg analyte per gram of reagent or wash water. The equation for that is given below.

$$"i" (\text{mg/g}) = (ug_{ix} \cdot V)/(V_{jx} \cdot W)$$

where V is the sample solution volume in mL (usually 10 mL)
 V_{jx} is the sample injection volume and
W is the sample weight in grams.

| | A | B | C | D | E | F | G | H | I | J |
|----|-----------------|--|--------------|-------------|--------------|-------------|--------------|---------------|--------------|---|
| 1 | STANDARDS | | | | | | | SAMPLE # | R70078806 | |
| 2 | | | | | | | | | 170900WTG | |
| 3 | Standard Number | | 3 | | 2 | | 0 | dilution used | 1 | |
| 4 | inj. Vol. | | 10 | | 10 | | 10 | inj.vol | 10 | |
| 5 | compound | Peak Height | µg/injection | Peak Height | µg/injection | Peak Height | µg/injection | Peak Height | µg/injection | |
| 6 | DMSO | 459920 | 22.02 | 1816256 | 110.1 | 3353320 | 220.2 | 760326 | 41.528264 | 1 |
| 7 | TMH | 180721 | 10.54 | 425775 | 52.7 | 3339838 | 527 | 244243 | 21.468561 | 1 |
| 8 | PEGa | 99092 | NA | 117680 | NA | 333013 | NA | 100843 | | |
| 9 | PEGb | 99431 | NA | 44212 | NA | 406573 | NA | 22412 | | |
| 10 | PEGc | 33472 | NA | 117275 | NA | 282619 | NA | 94280 | | |
| 11 | PEGd | 94297 | NA | 106762 | NA | 275791 | NA | 97530 | | |
| 12 | PEG SUM | 326292 | 11.25 | 385929 | 56.25 | 1297996 | 562.5 | 315065 | 10.862912 | 0 |
| 13 | | | | | | | | g used | 1.4 | |
| 14 | | | | | | | | mL prep vol | 10 | |
| 15 | | | | | | | | | | |
| 16 | | | | | | | | | | |
| 17 | | | | | | | | compound | samp mg/g | |
| 18 | | | | | | | | DMSO | 29.663046 | |
| 19 | | | | | | | | TMH | 15.334686 | |
| 20 | | Approximate detection limits; PEG: 10 mg/g, TMH: 1 mg/g, DMSO: 1 mg/g. | | | | | | PEG | 7.7592228 | |

| | W | X | Y | Z | AA | AB | AC | AD | AE | AF | AG | AH |
|----|---------------|--------------|---------------|--------------|---------------|--------------|---------------|--------------|---------------|--------------|----|----|
| 1 | SAMPLE # | R70078804 | | SAMPLE # | R70078804 | | SAMPLE # | R70078804 | | SAMPLE # | | |
| 2 | | 250840RRG | | | 250938WRG | | | 220925RRG | | | | |
| 3 | dilution used | 1 | | |
| 4 | inj.vol | 10 | | |
| 5 | Peak Height | µg/injection | | |
| 6 | 2901421 | 187.83044 | 1 | 431763 | 20.671902 | 0 | 2642954 | 169.31643 | 1 | | 0 | 0 |
| 7 | 763251 | 107.62842 | 1 | 168876 | 9.8491766 | 0 | 699422 | 97.239453 | 1 | | 0 | 0 |
| 8 | 145209 | | | 95158 | | | 147107 | | | | | |
| 9 | 65965 | | | 95078 | | | 73777 | | | | | |
| 10 | 142965 | | | 92012 | | | 146896 | | | | | |
| 11 | 126095 | | | 95780 | | | 125920 | | | | | |
| 12 | 480234 | 108.59474 | 1 | 378028 | 50.288181 | 1 | 493700 | 116.06915 | 1 | 0 | 0 | 0 |
| 13 | | | | | | | | | | | | |
| 14 | g used | 1.2 | g used | 1.3 | g used | | 1 | g used | | 2 | | |
| 15 | mL prep vol | 10 | mL prep vol | 10 | mL prep vol | | 10 | mL prep vol | | 10 | | |
| 16 | | | | | | | | | | | | |
| 17 | compound | samp mg/g | | | | |
| 18 | DMSO | 156.52537 | DMSO | 15.901463 | DMSO | 169.31643 | DMSO | | 0 | | | |
| 19 | TMH | 89.690347 | TMH | 7.5762897 | TMH | 97.239453 | TMH | | 0 | | | |
| 20 | PEG | 90.495613 | PEG | 38.683216 | PEG | 116.06915 | PEG | | 0 | | | |

| | N | O | P | Q | R | S | T | U | V | W | X | Y |
|----|---------------|--------------|---|--------------------|--------------|---|---------------|--------------|---|---------------|--------------|---|
| 1 | SAMPLE # | R70078807 | | SAMPLE # | R70078807 | | SAMPLE # | | | SAMPLE # | | |
| 2 | (spiked) | 191105SEM | | (spiked) | 191105SEM | | | | | | | |
| 3 | dilution used | 1 | | dilution used | 1 | | dilution used | 1 | | dilution used | 1 | |
| 4 | inj.vol | 10 | | inj.vol | 10 | | inj.vol | 10 | | inj.vol | 10 | |
| 5 | Peak Height | μg/injection | | Peak Height | μg/injection | | Peak Height | μg/injection | | Peak Height | μg/injection | |
| 6 | 1876957 | 120.80471 | 1 | 1830152 | 116.95365 | 1 | | 0 | 0 | | 0 | 0 |
| 7 | 420778 | 54.590005 | 1 | 416048 | 53.990466 | 1 | | 0 | 0 | | 0 | 0 |
| 8 | 34027 | | | 64639 | | | | | | | | |
| 9 | 47602 | | | 73364 | | | | | | | | |
| 10 | 45012 | | | 66418 | | | | | | | | |
| 11 | 33211 | | | 34646 | | | | | | | | |
| 12 | 159852 | 5.2390643 | 0 | 239067 | 7.8352937 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 13 | | | | | | | | | | | | |
| 14 | g used | 4 | | g used | 4 | | g used | 2 | | g used | 2 | |
| 15 | mL prep vol | 5 | | mL prep vol | 5 | | mL prep vol | 10 | | mL prep vol | 10 | |
| 16 | | | | after 2nd blow dow | | | | | | | | |
| 17 | compound | samp mg/g | | compound | samp mg/g | | compound | samp mg/g | | compound | samp mg/g | |
| 18 | DMSO | 15.100589 | | DMSO | 14.619207 | | DMSO | 0 | | DMSO | 0 | |
| 19 | TMH | 6.8237506 | | TMH | 6.7488083 | | TMH | 0 | | TMH | 0 | |
| 20 | PEG | 0.654883 | | PEG | 0.9794117 | | PEG | 0 | | PEG | 0 | |

See NBRG07/21
for final results

| | N | O | P | Q | R | S | T | U | V | W | X | Y | Z | AA | AB |
|----|---------------|--------------|---|---------------|--------------|---|---------------|--------------|---|---------------|--------------|---|---------------|--------------|----|
| 1 | SAMPLE # | R70078807 | | SAMPLE # | R70078804 | |
| 2 | (spiked) | 191105SEM | | | 220959SRG | | | 221050SRG | | | 221120SRG | | | 250925SRG | |
| 3 | dilution used | 1 | |
| 4 | inj.vol | 10 | |
| 5 | Peak Height | µg/injection | |
| 6 | 1772037 | 116.21535 | 1 | 1475974 | 94.567405 | 1 | 1176808 | 73.810235 | 1 | 574500 | 32.020028 | 1 | 2203977 | 152.80223 | 1 |
| 7 | 419954 | 55.761059 | 1 | 329573 | 39.776076 | 1 | 244881 | 23.579434 | 1 | 209637 | 16.839311 | 1 | 461535 | 61.343109 | 1 |
| 8 | 134863 | | | 110065 | | | 108566 | | | 105053 | | | 137449 | | |
| 9 | 141009 | | | 117126 | | | 110257 | | | 110029 | | | 141708 | | |
| 10 | 133689 | | | 115392 | | | 108620 | | | 115405 | | | 133229 | | |
| 11 | 58765 | | | 31274 | | | 54098 | | | 21647 | | | 43131 | | |
| 12 | 468326 | 85.834003 | 1 | 373857 | 10.57147 | 0 | 381541 | 10.788749 | 0 | 352134 | 9.9572141 | 0 | 455517 | 79.21748 | 1 |
| 13 | | | | | | | | | | | | | | | |
| 14 | g used | 4 | | g used | 2.6 | | g used | 2.9 | | g used | 3.6 | | g used | 2.5 | |
| 15 | mL prep vol | 5 | |
| 16 | | | | | | | | | | | | | | | |
| 17 | compound | samp mg/g | |
| 18 | DMSO | 14.526918 | | DMSO | 18.186039 | | DMSO | 12.725903 | | DMSO | 4.4472262 | | DMSO | 30.560445 | |
| 19 | TMH | 6.9701324 | | TMH | 7.6492455 | | TMH | 4.0654196 | | TMH | 2.3387932 | | TMH | 12.268622 | |
| 20 | PEG | 10.72925 | | PEG | 2.0329751 | | PEG | 1.8601292 | | PEG | 1.3829464 | | PEG | 15.843496 | |

D-89

Appendix E.

Copies of Notebook Pages

| <u>Notebook Used</u> | <u>Page</u> |
|----------------------|-------------|
| Lab 2 | E-1 |
| NB Harbor 1 | E-70 |
| Lab 3 | E-161 |

R7007

Notebook

New Bedford Harbor

"LAB 2"

02/17/88 Testing 0.5 hp mixer motor/1gal reactor flask combo:

- 1030 Set-up motor in home-fab bracket, connect all chucks for flex. blk shaft, connect motor to Variac Controller.
- 1045 Began agitating 1gal sand/1:1:2 mix \bar{c} Variac set @ 22%, hung \bar{c} on bottom, increased Variac to 28%. Something rubbing in motor shroud. Will agitate \times 1 hr. New Bedford soil arrived.
- 1105 Agitator stopped. Shaft freed, Variac turned up to 32%. Motor hot to touch. Small fan placed in hood blowing on motor.
- 1115 Speed varying \bar{c} apparent external cause.

Opened NB soil container, samples packed in 1gal + 1L glass containers \bar{c} plastic screwtop lids. Glass jars are wrapped in bubble packing + vermiculite. All containers intact + good condition, labeled as to date of collection, time of collection + high or low level contamination. One low level jar label slightly smudged, but still legible. Rec'd: High Level 1ea 1gal jar, 2ea 1L jar; low Level 2ea 1gal jars, 2ea 1L jars.

- 1130 Speed of motor varying considerably, Variac set @ 40%, motor still hot to touch, but doesn't appear to be hotter than 15 min earlier.
- 1140 Note on soil samples: All samples in clear glass jars. Soil jet black, \bar{c} free liquid evident on tops.
- 1145 Moved sm. fan up to blow directly into cooling shroud, RPMs increased suddenly, to violent mixing, splattering in reactor, Variac \downarrow 30%

1325 START 1JL BATH HEATER 1JL BATH 23.0°C SPFR :)

1341 TARE WT FOR BROWN PLASTIC PAN 387.2g

1405 O2L BATH 63.4°C CLOSE HOOD

R7007

1/7/88 New Bedford Soil

1520 Begin sieving + homogenizing "High Level" NB soil. Sieve thru a $\frac{1}{4}$ mesh ~~galvanized~~ screen into a plastic dish pan, beginning, tare wt: 427.4g

1525 Lg. amt free liquid on top of 1L sample jar "High Level" soil.
Decanted to a 400ml beaker
Tare wt. beaker: 152.7g
BEAKER + DECANT $\frac{185.5g}{32.8g}$

1525 OIL BATH TEMP 121.8°C

1550 TAKE WT AL. FOIL. 5.2g
FOIL + MAT NOT SIEVED $\frac{230.4g}{14g}$
MATERIAL NOT SIEVED $\frac{225.2g}{}$

1600 WT, plastic bucket + sieved soil: 14.2 lbs : 6446.8g
WT PLASTIC $= \frac{427.4g}{6019.4g}$

1605 OIL BATH 142.6°C

1610 TAKE SP # R70078802171610SJRA HIGH LEVEL SOIL

TAKE WT 8 AL VIAL 9.9g
VIAL + SOIL WT $\frac{12.9g}{3.0g}$
SOIL WT

R70078802171610SJRA
(QUICKJF) 1:1:2

TAKE WT 8 AL VIAL 9.8g
VIAL + SOIL WT $\frac{13.9g}{4.1g}$
SOIL WT

R70078802171610SJRB
36 HR 1:1:2

1600 MIX HIGH LEVEL MATERIAL WITH TROWEL FOR 10 MIN
SOIL SMELLS ~~WITH~~ WORSE WITH MORE STIRRING

2/18/88

R7007

0645 TURN ON OIL BATH HEATER 25.5°C 0725 : : OIL BATH TEMP 64.5°C 0745 OIL BATH TEMP 83.5°C STOP OIL LEAK~~1410
3/7/88~~
Replumbed Oil Bath heater for remote use, w/ 1/2" Cu tubing, in-line gate valve/faucet for flow adjustment.~~1530~~
Replumbing complete run @ 33°C setting to check for leaks & fittings etc. ~~some~~^{considerable} "fiddling" needed to regulate flow.~~1535~~
Temp setting ↑ to 173°C to test plumbing under heating condition.1600 Occasional adjustments needed to maintain proper level in small bath. Temp ~~87°C~~ 67°C 1650 Still "fiddling" w/ valves to maintain level. Opened outlet wide open, will control balance w/ inlet valve temp: 98°C . Thermometer placed to monitor temp drop in lg. pan.700 Temp: ~~100°~~ 120° smr pan 118° lg pan730 Temp 143° sm. pan 142° lg pan heater shut-off.

R7007

02/19/88 New Bedford Harbor

0845

(#1) → ~~Tare wt. rubber ring~~^{#12}
~~Ring + cond. flask wt.~~
Condensate flask wt: 115.3g

(#2) → ~~Tare wt. rubber ring~~
~~Ring + cond~~
Condensate flask wt: 118.1g

0850 Dry soil wts. taken for RS989 vermiculite reactions, refer to write-ups for soil wts, pgs 64-70 this notebook. Dry wts enter in blue ink.

1015 Weighing Low Level New Bedford soil into the reactors:

Tare wt. reactor + ring: 702.6 (beam balance)
Soil, reactor + ring: 1002.6
(#1) → Wet soil wt: 300.0

Tare wt. reactor + ring: 730.8g (beam balance)
Soil, reactor + ring: 1030.8g
(#2) → Wet soil wt: 300.0g

Note: beam balance used so contaminated soil could be weighed in hood. 300g aliquots of Low level soil used because % moisture test indicate that soil moisture is > 62%, hence will need 300g wet to be left = 100g dry soil ± sampling + water losses.

1355 Weighing reagents for reactions 02/22/88:

1:1:2 (PEG:TMH:DMSO) PEG: 99.9g
1st batch in 400ml beaker → TMH: 100.6g
DMSO: 200.2g
400.7g total 1:1:2

2nd batch 1:1:2:

PEG: 100.1g
TMH: 100.1g
DMSO 200.0g
400.2g total 1:1:2

2/22/88

(0.00)

0535

TARE BEAKER
BEAKER + 1:1:2 103.2
 1:1:2 303.2
 1:1:2 200.0

PEG: TMH: DMSO

0540

TARE BEAKER
BEAKER + 1:1:2 111.7
 1:1:2 311.7
 1:1:2 200.0

PEG: TMH: SULF

0545

TARE BEAKER
BEAKER + KOH 111.3
 45% KOH 211.3
 45% KOH 100.0

FOR #1 45% KOH

0548

TARE BEAKER
BEAKER + 45% KOH 70.7
 45% KOH 170.7
 45% KOH 100.0

FOR #2 45% KOH

0600

6 START REACTIONS

OIL BATH TEMP 22.4 °C

REACTOR #1 33 °C

REACTOR #2 31 °C

0620 some small adjustment problems w oil levels in two pans, easily corrected by adjusting oil level in small pan.

0630

Temps: Oil: 57.8 °C
Reactor #1: 36.0 °C
Reactor #2: 38.0 °C

0700

Temps: Oil: 99.5 °C
Reactor #1: 79 °C

R7007

02/22/88 New Bedford

0800 Wt p water wash x 3: 12.8g wet soil: 3.0g

Tare wt water wash vial: 19.4g

Water washes + vial wt: 36.5g

Water washes: 17.1g

0802 Collected sample # R70078802220802S^{j2}, Reactor #2 Extracted

Tare wt. vial: 9.6g

Slurry + vial wt: 15.9g

Slurry wt: 6.3g

Wt. p water wash x 3: 14.1g wet soil: 5.5g

Tare wt. water wash vial: 19.5g

Water washes + vial wt: ~~36.5g~~ 33.5gWater washes: ~~17.0g~~ 14.0g

0805 Sm. leak noted from condensate collector, Reactor #1, adjusted - leak stopped.

Extracting + water washing # R70078802220800S^{j2} and
R70078802220802S^{j2}
JR0900 TEMPS OIL BATH ~~166.5°C~~
REACTOR #1 122°C
REACTOR #2 120°Call gel SF.11 blue
weight of SF11 in Trap
R70078802191602DEM 24.6
DM50 LrnTrap
R70078802191600DEM 25.6gDREW SAMPLE # R70078802220900S^{j2} REACTOR #2TARE WT VIAL 9.7g
VIAL + SLURRY WT 17.1g
SLURRY WT 7.4g
WT AFTER 3 WATER WASHES 13.7g wet soil: 4.0gTARE WT WASH WATER VIAL 19.6g
VIAL + ~~WASH~~ WASH WATER 40.7g
WT WASH WATER 21.1g

R700752122/58

1102

Tare wt. water wash vial: 19.7g
 water washes + vial wt: 30.1g
 Water washes : 16.4g

1100

TEMPS OIL BATH: 172.6°C
 REACTOR #1: 157°C
 REACTOR #2: 146°C

DREW SAMPLE # R7007880222 1100 S^{IR}_{PL} REACTOR #1

TARE WT VIAL 7.8
 VIAL + SLURRY WT: 14.4g
 SLURRY WT 4.6g

WT AFTER 3 WATER WASHES 12.1g WET SOIL WT 2.3g

TARE WT WASH WATER VIAL 19.6g
 VIAL + 3 WATER WASHES 32.5g
 WATER WASH WT 12.9g

1102

DREW SAMPLE # R7007880222 1102 S^{IR}_{PL} Extracted

TARE WT VIAL 9.6g
 VIAL SLURRY WT 16.7g
 SLURRY WT 7.1g

WT AFTER 3 WATER WASHES 11.5g WET SOIL 1.9g

TARE WT WASH WATER VIAL 19.5g
 VIAL + 3 WATER WASHES 39.6g
 WATER WASH WT 19.9g

R7007

02/22/88

1230 spiking \in DCB, followed by 3ml of hexane. The vial is agitated thorou
Cont. on the vortex mixer and spun 1-2 min in a centrifuge. The hexane le
is drawn off + collected in a 10ml volumetric flask. 2 more aliquots of
hexane are run identically to the above steps. The 10ml flask is then
brought up to volume \in post. grd. hexane. A small amt. 1-2ml is pour
into a 4ml vial \in 1ml of conc. H_2SO_4 and mixed thoroughly to aci
wash the sample. The resulting washed extract is pipetted to an
ALS vial for dilution + injection.

1300 Temps Oil:
 Reactor #1:
 Reactor #2:

Drew sample # R70078802221300SJR

Tare wt. vial: 9.8g
vial + slurry: 12.8₅
Wt. \bar{p} water wash X3: 3.0_{12.4}₅ wet soil wt: 2.6₅

Tare wt. water wash vial: 19.8₅
vial + water washes: 35.7₅
Water washes wt: 15.9₅

1302 Drew sample # R70078802221302SJR Extracted

Tare wt. vial: 9.6₅
Slurry + vial: 14.9₅
Slurry: 4.4₅
Wt. \bar{p} water wash X3: 13.3₅ wet soil: 3.7₅

Tare wt. water wash vial: 19.7₅
vial + water washes: 33.3₅
Water washes wt: 13.6₅

1400 TEMPS OIL BATH 162.5°
 REACTOR #1 158°
 REACTOR #2 149°

32/22/88

- 1500
Cont.

Tare wt. wash water vial: 19.5g Extracted
Vial + water washes : 35.5g
Water washes:

1502 Drew sample # R700788022215025JR
Tare wt. vial: 9.6g
Vial + Slurry wt: 13.7g
Slurry wt: 4.1g
Wt. p water wash x 3: 12.4, Wet soil wt: 2.9

Tare wt water wash vial: 19.7g
Vial + water washes : 37.6g
Water washes :

Note: Water washes got to mixed-up on 1500 - 1502

1600 TEMPS OIL BATH 164.5
REACTOR #1 161
REACTOR #2 149

DREN SAMPLE R70078802221600STG

| | |
|----------------|-------------|
| TARE WT VIAL | 9.8g |
| VIAL SLURRY WT | <u>15.1</u> |
| SLURRY WT | 5.3gr |

WT AFTER 3 WATER WASHES 12.1gr WET SOIL WT 2.3g

| | |
|-------------------------|--------------|
| TARE WT WASH WATER VIAL | 19.4g |
| VIAL + WASH WATER | <u>37.7g</u> |
| WT WASH WATER | 18.3gr |

R7007

62/23/88

- 0905 Weighing water to replace distillate to Reactor #1: 142.7g
Water added to reactor, mixed in, water/soil slurry dumped in
→ thoroughly mixed.
- 0912 Slurry dumped into filter body for Reagent Filtering. Wash^{#1} Distillate replacement to sit x 10 min → pressurizing
- 0922 Opened tube clamp @ reactor bottom, very thin stream, to slow drip.
- 0923 Begin pressurizing @ 40psi, slow drip. Pressure ↑ 100 psi, slow drip.
- 0925 Weigh Wash #1, DMSO Rxn: 200.3g
- 0935 Only sm. amt. of filtrate in bottom of collection jar, no ↑ apparent flow now
- 0955 Pressure filtrate wt.: 200.5g jar + filtrate
Less Tare wt. 250ml jar: 177.6g
22.9g filtrate
- 1000 Decanting remainder of distillate to Reagent Filtering collection jar
 - Tare wt 250ml jar: 177.6g
 - Filtrate + decant + jar : 426.1g
 - Filtrate + decant wt: 248.5g
 - Less filtrate wt : 22.9g
 - Decant liq. wt: 225.6
- 1125²⁵ Wash^{#1}, DMSO rxn poured into filter body, stirred thoroughly + allow to sit x 10min
- 1126 Weighing Wash #2, DMSO Rxn: 200.3g
- 1135 Begin pressurizing Wash #1, DMSO Rxn @ 100psi. Sm. bolus of fines came out when stopcock opened, no obvious flow noted. Will leave x 10min.
- 1145 No flow & Wash^{#1} 10min @ 100psi. Pressure relieved. Will decant wash. Total 250ml jar + filtrate: 179.3g

2/23/85

R7007

| | |
|-----------------------|--------|
| TARE WT JAR | 177.0g |
| JAR + DELLANT WASH #1 | 508.9 |
| DECANT WASH #2 | |

includes all sed. rest

I tried to remove as much as possible from the reactor walls then allowed the solids to settle for 30 min. Decantation was done by removing liquid from the surface using a 10 ml wash tip pipette & pipette master. Decantation was done slowly to allow more settling. I spent a lot of time on careful decantation and prolonged settling time (up to 1 hour) I observed no liquid/solid interface. (It don't settle good.) The liquid at the bottom was much thicker than the liquid at the top, but still liquid.

Then I scraped around as much as possible from the reactor and poured it into the wash jar. Decant

| | | |
|----------------------|--------------|--------------------------|
| 12.1ng | 131.0 | |
| Dirty Reactor + Ring | 732.8 | 732.8 |
| Final Reactor + Ring | <u>730.8</u> | Final Reactor + R. 724.8 |
| Soil left in Reactor | 2.0 | 8.0 |

Final Clean Reactor weight

| | |
|----------------------|-------|
| Ring 131.0 | |
| + Reactor #1 (0.160) | 698.6 |
| #2 (SFLN) | 724.8 |

2/23/88

R7007

1455 TARE WT RING 131.0
 RING + REACTOR #1 702.5
 REACTOR #1 571.5

1457 TARE WT RING 131.0
 RING + REACTOR #2 724.5
 REACTOR #2 593.5

1567 TARE WT RING + REACTOR #1 701.4 TRIPLE BEAM
LOW LEVEL
 RING, REACTOR, + SOIL 1001.4
 SOIL 300.0

1511 TARE WT RING + REACTOR #2 723.4 TRIPLE BEAM
LOW LEVEL
 RING, REACTOR + SOIL 1023.4
 SOIL WT 300.0g

1521 Tare wt. "cold trap" # 1: 79.9g
 Tare wt. "cold trap" # 2: 80.9g

1525 Tare wt. cond. flask # 1: 105.8g
 Tare wt. cond. flask # 2: 120.3g

Drying tubes #1 (R70078802231630 DEM) 23.4g
 #2 R70078802231632 DEM 22.7g

1770 Reagents for Reactions on 2/24/87

Reaction #1

| | | | | |
|-------|----------------|---------------|--------------------|---------------|
| 1:1:2 | TMH:PEG:DMso | 200.2g | -1.3g ^u | <u>Actual</u> |
| KOH | | <u>100.0g</u> | -1.0g ^u | |
| | Total Reagents | 300.2g | 29.3 | |

Reaction #2

| | | | |
|-------|----------------|---------------------|--------------------|
| 1:1:2 | TMH: PEG: DMso | 200.0g ^u | -1.7g ^u |
| F-25 | KOH | <u>100.3g</u> | -1.5g ^u |

2/24/84

R7007

0700 TEMPS OIL BATH 103.7°C
 REACTOR #1 85°C
 REACTOR #2 85°C

DREW SAMPLE # R7007880224 0700 STG Extracted

TARE WT VIAL 9.6g
 VIAL + SLURRY WT 16.2g
 SLURRY WT 6.6g

WT AFTER 3 WATER WASHES 12.6g WET SOIL WT 3.0

| | | | | |
|---------|-----------------|--------------|--------------|--------------|
| TARE WT | WATER WASH VIAL | <u>19.6g</u> | <u>19.6g</u> | <u>19.6g</u> |
| VIAL + | WATER WASHES | <u>17.3g</u> | <u>33.5g</u> | <u>33.5g</u> |
| | WATER WASH WT | <u>8.2g</u> | | |

0702 DREW SAMPLE # R7007880224 0702 STG

TARE WT VIAL 9.7g
 VIAL + SLURRY 17.9g
 SLURRY WT 8.1g

WT AFTER 3 WATER WASHES 13.1g WET SOIL WT 3.4g

| | | | |
|---------|-----------------|--------------|--------------|
| TARE WT | WATER WASH VIAL | <u>19.5g</u> | <u>19.5g</u> |
| VIAL + | WATER WASHES | <u>35.5g</u> | <u>35.5g</u> |
| | WATER WASH WT | <u>14.4g</u> | |

0730 TEMPS OIL BATH 133.0°C
 REACTOR #1 111°C
 REACTOR #2 110°C

2/24/98

R7007

| | | | |
|------|----------------------|--------------|-------------------|
| 0835 | TARE WT BEAKER | 49.0g | |
| | BEAKER + VERMICULITE | <u>52.0g</u> | |
| | VERMICULITE | <u>3.0g</u> | |
| | | | ADD TO REACTOR #2 |
| | | | AT 150°C |

| | | |
|------|----------------|--------------------|
| 0900 | OIL Bath Temps | 168.3°C |
| | Oil bath | 168.3°C |
| | Reactor #1 | 125°C |
| | Reactor #2 | 119°C |

Drew Sample #R7007 880224 0900 STG Extracted

| | |
|---------------|--------------|
| Total wt vial | 9.7 |
| vial + slurry | <u>17.9g</u> |
| wt slurry | <u>8.2g</u> |

Vial wt after 3 washes 13.4g wt of vial 3.7g

| | |
|-----------------|--------------|
| wt of wash vial | 19.8g |
| vial + washes | <u>36.1g</u> |
| wt of washes | <u>16.3g</u> |

0902 Drew Sample #R7007 880224 0902 STG

| | |
|---------------|--------------|
| Total wt vial | 9.5g |
| vial + slurry | <u>18.0g</u> |
| wt slurry | <u>8.5g</u> |

Vial wt after 3 washes 13.9g wt of vial 4.4g

| | |
|-----------------|--------------|
| wt of wash vial | 19.6g |
| vial + washes | <u>33.3g</u> |
| wt of washes | <u>14.7g</u> |

| | | |
|------|----------------|---------|
| 0930 | OIL Bath Temps | |
| | Oil bath | 175.3°C |
| | Reactor #1 | 143°C |
| | Reactor #2 | 129°C |

2/24/88

R7005

1100

TEMPS

OIL BATH : 163.8°C
 REACTOR #1 152°C
 REACTOR #2 152°C

DREW SAMPLE # R7007880224 1100 SJR

TARE WT VIAL 9.6g
 VIAL + SLURRY WT ^{Extracted}
~~Forgot slurry wt.~~
 SLURRY WT

WT AFTER 3 WATER WASHES 13.7g WET SOIL WT 4.1g

| | |
|-------------------------|-------|
| TARE WT WATER WASH VIAL | 19.5g |
| VIAL + WASH WATER | 39.7g |
| WASH WATER WT | 19.2g |

1102

DREW SAMPLE # R7007880224 1102 SJR

TARE WT VIAL 9.6g
 VIAL + SLURRY WT ^{Forgot slurry wt}
 SLURRY WT

WT AFTER 3 WATER WASHES 13.2 WET SOIL WT: 3.

| | |
|---------------------|-------|
| TARE WT WASH VIAL | 19.6g |
| VIAL + WATER WASHES | 38.7g |
| WT WATER WASHES | 19.1g |

02/24/88

1302 Drew sample # R70078802241302SJR

Tare wt. vial: 9.6g

Slurry + vial wt: 16.6g

Slurry wt: 7.0g

Wet p water wash x 3: 13.8g

Wet soil wt: 4.2g

Tare wt. water wash vial: 19.4g

Vial + water washes: 38.4g

Water washes wt: 19.0g

1400 Tamps

oil: 166 °C

Reactor # 1: 160 °C

Reactor # 2: 152 °C

Drew sample # R70078802241400SJR

| | |
|------------------|-------|
| TARE WT VIAL | 9.8g |
| VIAL + SLURRY WT | 17.2g |
| SLURRY WT | 7.4g |

WT AFTER 3 WATER WASHES 12.3 WET SOIL WT 2.5

Note: Vial broke in centrifuge, most of soil salvaged.

| | |
|-------------------------------|-------|
| TARE WT WASH WATER VIAL | 19.5g |
| VIAL + WATER WASHES | 34.1g |
| Note: 3rd wash not recovered. | 14.6g |

1402 DREW SAMPLE # R70078802241402SJR

| | |
|------------------|-------|
| TARE WT VIAL | 9.7g |
| VIAL + SLURRY WT | 14.3g |
| SLURRY WT | 4.6g |

WT AFTER 3 WATER WASHES: 12.2 WET SOIL WT: 2.5g

| | |
|----------------------|-------|
| WT WASH WATER VIAL | 19.8g |
| VIAL + WASH WATER WT | 39.3g |
| WASH WATER WT | 19.5g |

R700702/24/88 New Bedford vermiculite1600
Continued

Tare wt wash water vial: 19.6g
 vial + water washes: 40.7g
 Water washes wt: 20.5g

1602 Drew sample # R70078802241602SJR

Tare wt. 8ml vial: 9.8g

Vial + slurry wt: 14.6g

Slurry wt: 4.8g

Weight \bar{p} water wash \times 3: 10.7g Wet soil wt: 0.9g

Tare wt. water wash vial: 19.6g

Vial + water washes: 40.4g

Water washes wt: 20.8g

1610 Sampling now more difficult, often unable to eject solids ^{dry} from the pipette.

1600 Temps: Oil: 161.7°C
 Reactor #1: 156°C
 Reactor #2: 151°C

Drew Sample # R70078802241700SJR Extracted

Tare wt. 8ml vial: 9.6g

Slurry + vial wt: 17.9g

Slurry wt: 8.2g

Weight \bar{p} water wash \times 3: 13.2g Wet soil wt: 2.6g

Tare wt. water wash vial: 19.4g

Vial + water washes wt: 41.3g

Water washes wt: 21.9g

¹⁷⁰
1602 Drew Sample # R70078802241702SJR Extracted

Tare wt. 8ml vial: 9.7g

Vial + slurry wt: 17.2g

Slurry wt: 7.5g

Weight \bar{p} water wash \times 3: 13.6g Wet soil wt: 2.6g

Tare wt. water wash vial: 19.7g

Vial + water washes wt: 39.6g

R7007

02/25/89 New Bedford - vermiculite

0730 Weighing reaction components from reactions on 02/24/89

Reactor # 1 (vermic. @ 20°C) : 871.6g
 Less foil cover wt : - 2.8g
 Wt. reactor+contents : 868.8g

Reactor # 2 (vermic. @ 150°C) : 921.8g
 Less foil cover wt : - 2.6g
 Wt. reactor + contents : 919.2g

Tare wt #1 condensate flask: 105.8g
 Foil, Flask + condensate wt : 317.8g
 Foil cover + condensate : 212.0g
 Less foil cover wt : - 0.4g
 Condensate wt : 211.8g

Tare wt. # 2 condensate flask: 120.3g
 Foil cover, flask + condensate wt: 313.1g
 Foil cover + condensate wt: 192.8g
 Less foil cover wt : - 0.4g
 Condensate wt : 192.4g

#1 Cold trap tare wt: 79.9g
 Trap + distillate : 79.9g
 Distillate wt: 0.0g

#2 Cold trap tare wt : 80.9g
 Trap + distillate : 80.9g
 Distillate wt : ~~80.9g~~ 0.0g

Tare #1 Silica gel tube, drying tube: 23.4g
 Final wt. drying tube: 23.4g
 Distillate wt : 0.0g

Tare wt #2 Silica gel drying tube: 22.7g
 Final wt. drying tube: 22.8g
 Distillate wt: 0.1g

R7007

~~02/25/88~~ New Bedford, vermiculite filtering

1040 Experimenting w/ "seawater" flocculation/settling + treated NB soil

Tare wt. 40ml beaker: 30.3g

Will mix approx. 0.2g NaCl to simulate estuary water

Begin wt. DI water: 10.0g

DI water + NaCl: 10.24g

1045 Saline water added to 8ml vial = 1.2g slurry from Reactor #1

Tare wt. vial + slurry: 10.7g

Vial + slurry + saline wt: 12.7g

Saline: ~~wt~~: 2.0g

1047 DI water added to 8ml vial = 1.1g slurry from Reactor #1

Tare wt. vial + slurry: 10.7g

Vial + slurry + DI H₂O: 12.8g

DI H₂O wt: 2.1g

1050 Both vials vortex mixed x 30sec. then allowed to settle x 10min.
Will try same settling experiment w/ adding 1N HCl in DI water

Tare wt. 8ml vial: 9.6g

Vial + slurry: 10.9g

Slurry wt: 1.5g

| | |
|------------------------|-------------|
| TARE WT VIAL + SLURRY | 10.9g |
| VIAL, SLURRY, 0.2N HCl | <u>12.9</u> |
| 0.2N HCl | 2.0g |

1100 HCl/Slurry vial checked for pH: 11, $\frac{5}{5}$ vortex mixed x 30 sec.
Will add 1.0g, mix & recheck pH: 10, will allow to settle x 10 min

Better liquid/solid interface noted for DI water sample (1047, above)
than simulated "seawater" sample (1045 above). Both samples centrifuge
to check for suspended solids. DI water sample still shows better inter-
face. Saline wash water app. not helpful.

R700Z

02/25/88 New Bedford settling tests

1330 Tare wt 8ml vial for "household ammonia": 9.7g
 Slurry + vial wt: 10.6g
 Slurry wt : 0.9g

| | |
|--------------------------|--------------|
| VIAL + SLURRY WT | 10.6g |
| VIAL, SLURRY, + OJ WATER | <u>12.7g</u> |
| OJ WATER | 2.1g |

| | |
|----------------------------------|--------------|
| VIAL, SLURRY, OJ WATER | 12.7g |
| VIAL, SLURRY, OJ WATER + AMMONIA | <u>12.9g</u> |
| AMMONIA | 0.2g |

START SETTLING 1410 SOME VISIBLE SETTLING

1 min CENTRIFUGE DISTINCT GRAY + VERY DARK LAYER.
~~STILL FINE IN H₂O~~ H₂O STILL TUR.

Tare wt 8ml vial for "Clorox" bleach: 9.7g
 vial + slurry wt: 11.3g
 Slurry wt: 1.6g

| | |
|--------------------------|--------------|
| VIAL + SLURRY WT | 11.3g |
| VIAL, SLURRY, + OJ WATER | <u>13.3g</u> |
| OJ WATER | 2.0g |

| | |
|-----------------------------------|--------------|
| VIAL, SLURRY, OJ WATER | 13.3g |
| VIAL, SLURRY, OJ WATER, + CHLOROX | <u>13.4g</u> |
| CHLOROX | 0.1g |

START SETTLING 1358 VERY LITTLE SETTLING (SAW)

1 min CENTRIFUGE DISTINCT GRAY LAYER + VERY DARK LAYER.
~~STILL FINE IN H₂O~~ H₂O STILL TUR.

R7007

2/25/81 New Bedford Setting tests

1335

Tare wt 8ml vial for ~~Fallers Earth~~^{BAKING SODA}: 9.6g
 Slurry + vial wt: 11.5g
 Slurry wt: 1.9g

| | |
|-------------------------|--------------|
| VIAL & SLURRY WT | 11.5g |
| VIAL, SLURRY & OJ WATER | <u>13.5g</u> |
| OJ WATER | 2.0g |

| | |
|---------------------------------|--------------|
| VIAL, SLURRY & OJ WATER | 13.3g |
| VIAL, SLURRY, OJ WATER + BAKING | <u>13.6g</u> |
| BAKING SODA | 0.1g |

START SETTLING 1523 NO VISIBLE SETTLE

1 min CENTRIFUGE

SPIN SOME SOLIDS OUT
NOT GOOD INTERFACE

Tare wt 8ml vial for vermiculite: 9.5g
 Vial + Slurry: 10.8g
 Slurry wt: 1.3g

| | |
|--------------------------|--------------|
| VIAL + SLURRY WT | 10.8g |
| VIAL, SLURRY, + OJ WATER | <u>12.8g</u> |
| OJ WATER | 2.0g |

| | |
|------------------------------|--------------|
| VIAL, SLURRY, + OJ WATER | 12.8g |
| VIAL, SLURRY, OJ WATER + VER | <u>12.9g</u> |
| VERMICULITE | 0.1g |

START SETTLING 1415 (SAND)
 Some settling noted, vermiculite floating on water layer, no flocculation

1 min CENTRIFUGE

SOIL SPIN OUT NO DISTINCT LAYERS
 H_2O still TURBID

R7007

2/22/88

1720 Extracted sample R700788022216005TG

R700702/25/88 New Bedford Settling tests

1342

Tare wt 8ml vial for ferrous sulfate: 9.6g
 Slurry + vial wt: 10.6g
 Slurry wt: 1.0g

| | |
|--------------------------|--------------|
| VIAL & SLURRY WT | 16.6g |
| VIAL, SLURRY, & OJ WATER | <u>12.6g</u> |
| OJ WATER | 2.0g |

| | |
|--|--------------|
| VIAL, SLURRY, OJ WATER | 12.6g |
| VIAL, SLURRY, OJ WATER & FERROUS SULFATE | <u>12.7g</u> |
| FERROUS SULFATE | 0.1g |

START SETTLING 1422 NO SETTLING COATS SOLES

ADD HCl BRING PH TO 3 FORMED A GEL
 START SETTLING 1437

1 min CENTRIFUGE SPIN SOIL OUT GET AMBER LIQUID ON TOP

TARE WT 8ml VIAL FOR FERROUS AMMONIUM SULFATE 9.7g
 VIAL & SLURRY WT 11.3g
 SLURRY WT

| | |
|--------------------------|--------------|
| VIAL & SLURRY | 11.3g |
| VIAL, SLURRY, & OJ WATER | <u>13.3g</u> |
| OJ WATER | 20g |

VIAL, SLURRY, OJ WATER 13.3g
 VIAL, SLURRY, OJ WATER FERROUS AMM SULFATE 13.4g
 FERROUS AMMONIUM SULFATE 0.1g

START SETTLING: 1428

NO SETTLING COATS SOLES

ADD HCl BRING PH TO

1/24/88

R7007

1545

TARE WT 8 ml VIAL FOR HCl
 VIAL + SLURRY 9.45
9.65
10.6g
 SLURRY WT 21.25
21.25

VIAL + SLURRY WT 10.6g
 VIAL, SLURRY, + OJ WATER 12.75
OJ WATER 2.1g

VIAL, SLURRY, OJ WATER, ~~HCl~~ 12.7g
 VIAL, SLURRY, OJ WATER + HCl 12.8
 8N HCl 0.1g

START SETTLING 1558 pH = 4
 1 min later SOIL SPIN OUT cloudy BUT TRANSPARENT
 LIQUOR

TARE WT 8 ml VIAL FOR FERRIC SULFATE 9.6g
 VIAL + SLURRY 11.1g
 SLURRY WT

VIAL + SLURRY WT 11.1g
 VIAL SLURRY + OJ WATER 13.2
OJ WATER 20.1

VIAL, SLURRY, OJ WATER 13.2g
 VIAL SLURRY, OJ WATER FERRIC SULFATE 13.3
 FERRIC SULFATE 0.1g

START SETTLING 1654

1 min later SOIL SPIN OUT cloudy BUT TRANSPARENT
 LIQUOR

15 MIN SETTLING TIME

2/24/58 R

R7007

0707

| | | |
|----------------------|-------------------------|-------|
| TARE WT VIAL FOR HCl | 9.5 _s | PH 10 |
| VIAL + SLURRY | <u>10.9_s</u> | |
| SLURRY | 1.4 _s | |

| | | |
|-------------------------|-------------------------|---|
| VIAL + SLURRY | 10.9 _s | — |
| VIAL, SLURRY + OJ WATER | <u>12.9_s</u> | |
| OJ WATER | 2.0 _s | |

| | | |
|-------------------------------|-------------------|-----|
| VIAL, SLURRY, OJ WATER | 12.9 _s | 11. |
| VIAL SLURRY OJ WATER + 8N HCl | — | |
| 8N HCl | S | |

START SETTLING 0728 - Still cloudy @ 0743

20 min CENTRIFUGE - layer of finest sand @ bottom, liquor still murky

START SETTLING 0802

ADD 2.8_s 1% FeSO₄ 12.9_s → 15.7_s = 2.8_s

| | | |
|---------------------------------------|-------------------------|------------------|
| TARE WT VIAL FOR 1% FeSO ₄ | 9.6 _s | NO PH ADJUSTMENT |
| VIAL + SLURRY | <u>10.8_s</u> | |
| SLURRY | 1.2 _s | ADD OJ WATER |

| | | |
|--------------------------|-------------------------|--|
| VIAL + SLURRY | 10.8 _s | |
| VIAL, SLURRY, + OJ WATER | <u>11.8_s</u> | |
| OJ WATER | 1.0 _s | |

| | | |
|---|-------------------------|--|
| VIAL, SLURRY, + OJ WATER | 11.8 _s | |
| VIAL, SLURRY, OJ WATER + 1% FeSO ₄ | <u>13.0_s</u> | |
| 1% FeSO ₄ | 1.2 _s | |

START SETTLING 0728 - Still cloudy @ 0743, sand in bottom

1 mi CENTRIFUGE - layer of finest sand @ bottom, liquor still dark

START SETTLING 0802

E-49

2/26/88R7007

FROM PAGE 133 THIS BOOK

HCl pH 10 ADD 2% FeSO₄

NO SETTLING FOAMING ON TOP

1 min CENTRIFUGE

LIQUID MURKY

SOLIDS SETTLE

5 min CENTRIFUGE

NO CHANGE

1% FeSO₄ ADD ANOTHER 1% FeSO₄

NO SETTLING FOAMING ON TOP

1 min CENTRIFUGE

LIQUID MURKY

SOLIDS SETTLE

5 min CENTRIFUGE

NO CHANGE

2/16/88

RD007

TARE WT BEAKER 114.15
 BEAKER + 1% FeSO₄ 162.15
 1% FeSO₄ 48.05

BEAKER + 1% FeSO₄ 162.15
 BEAKER, 1% FeSO₄ + FeSO₄ 164.15
 FeSO₄ 2.05

masses 5% FeSO₄~~LOOKS LIKE A GEL~~ F2% FeSO₄ → WITH OZ WATERADD 1.9_s OF 5% FeSO₄ TO MAKE 10%
NO PH ADJUSTMENT

START SETTLING 0857

LOOKS LIKE A GEL FOAMY

1 min CENTRIFUGE

SOLDS OUT
LIQUOR AMBER1% FeSO₄ NO OZ WATERADD 2.2_s OF 5% FeSO₄ TO MAKE 5% FeSO₄
NO PH ADJUSTMENT

START SETTLING 0857

LOOKS LIKE A GEL FOAMY

1 min CENTRIFUGE

SOLDS OUT
LIQUOR DARK & SOME SOL.

BRNG PH TO 10

30R0

1 min CENT

HCl

SOLDS OUT (A LOT)

LIQUOR DARK BUT FEW SOL.

2/26/88

RDOO7

TARE WT VIAL FOR 7½% FeSO₄ 9.7g
 VIAL + SLURRY WT 11.5g
 SLURRY WT 1.8g

VIAL + SLURRY WT 11.8g
 VIAL, SLURRY WT, + 5% FeSO₄ 14.5g
 5% FeSO₄ 2.7g

CHECK pH = 9
 1 min CENTRIFUGE
 ALL SOLDIS OUT
 LIQUOR IS DARK AMBER

CHECK pH = 9

1030 Dumping slurry from aborted filtering attempt to clear 500ml jar = teflon-lined cap. Will neutralize \approx 1tHCl to pH 6-7 + settle over w/e. Added 20g DI water to flush as much solids out as possible.

Tare wt 500ml jar: 177.3g
 Wt of dumping rinse: 178.4g

Tare wt 500ml clear jar: 233.8g
 Jar, slurry + water rinse wt: 343.0g
 Transf. slurry wt: 110.8g
 Less rinse wt: 20.0g
 Slurry wt: 90.8g

Initial pH transferred slurry: >13

1040 After adding 7.0g of 8N HCl slurry has ~~been~~ become thick + gelatinous. Will add another 50g DI water to create thinner slurry. pH > 12

Tare jar + slurry: 350.4g
 Jar, slurry + DI H₂O: 400.4g
 Added DI H₂O: 50.0g

JAR SLURRY + DI H₂O 400.4g
 JAR SLURRY, DI H₂O, + 8N HCl 415.3g
 pH = 5 8N HCl 14.9g

14.9g

R7007

02/29/88 WB

1358 Sample # R70078802171620 SJR Beaker + soil wt : 62.7g
Begin wt. beaker + wet soil : 90.5g
Moisture wt : 27.6g
Less fare wt. beaker : 49.9g
Final dried soil wt : 12.8g
% moisture content based on 40.4g begin wet soil wt: 68.3%

R7007

02/02/88 NB, Metallic sample cleanup experiments

- 0715 Continuing a Cu-wash clean-up trials, see extraction notes 0715 03/01/88
- 0800 Experimenting = [#]R70078802221600STG, a sample not yet Cu-washed.
- 0930 Running [#]R70078802221600STG through a 2nd Cu-wash, using procedure described 0715, 03/01/88. See chromatograms for results
- 1000 Experimenting a Mercury wash, using small beads of metallic mercury drawn off top of Slack festers manometer. Used same extraction procedure described above, but substituted Hg for Cu. After vortex mixing sample a cloudy grey, Hg is small clumps of slag in bottom of 4 ml vial.

3/7/88 NB, CLEAN UP EXPERIMENT

~~USE~~ SAMPLE R70078802221402SJR

0715 PUT IN EXCESS AMOUNT OF 6 METALLIC COPPER UNTRIATED.
ADD ~2 ml of SAMPLE AND VORTEX MJX FOR ~2 min.
ADD H₂SO₄ & VORTEX MJX FOR ~2 min. THEN CENTRIFUGE
FOR ~2 min. PUT IN 1.5 ml ALS VIAL. WORKED

0745 USE SAMPLE R70078802241702SJ1 FOLLOW PROCEDURE AT
0715 WORKED.

0725 ~~try~~ Preparing soils for centrifuge/decant experiment at offsite lab.
Will split DMSO/Vermiculite @ 150°C reaction, from 02/24/88, and
Sulfolane reaction, from 02/22/88 into two aliquots ea. + pour them
into 380ml centrifuge jars. Sulfolane reaction will be transferred to
centrifuge jars #1 & #2. Vermiculite @ 150° reaction will be transferred
to centrifuge jars #3 & #4.

Tare wt. centrifuge jar #1 : 242.3g
jar + contents wt : 403.0g
Contents wt : 260.7g

Experiments x
Sampling x
Sampling Table
B15 ft
Cen. Siberia

3/8/88

R7007

R70078802220000SJR

| | |
|-----------------|--------------|
| TARE WT VIAL | 9.9g |
| VIAL + DRY SOIL | <u>11.3g</u> |
| DRY SOIL | 1.4g |

~~OFF FROM~~ WET SOIL WT 2.8g

R70078802221100SJR

| | |
|-----------------|--------------|
| TARE WT VIAL | 9.8g |
| VIAL + DRY SOIL | <u>10.9g</u> |
| DRY SOIL | 1.1g |

~~OFF FROM~~ WET SOIL WT 2.3g

R70078802221200SJR

| | |
|-----------------|--------------|
| TARE WT VIAL | 9.7g |
| VIAL + DRY SOIL | <u>11.0g</u> |
| DRY SOIL | 1.3g |

~~OFF FROM~~ WET SOIL WT 2.6

R70078802221300SJR

| | |
|-----------------|--------------|
| TARE WT VIAL | 9.8g |
| VIAL + DRY SOIL | <u>10.9g</u> |
| DRY SOIL | 1.1g |

~~OFF FROM~~ WET SOIL WT 2.7g

R70078802221400SJR

| | |
|-----------------|--------------|
| TARE WT VIAL | 9.7g |
| VIAL + DRY SOIL | <u>10.2g</u> |
| DRY SOIL | 0.5g |

WET SOIL WT 1.4g

NB Un 2/22
and WMNB 3/07

WMNB 3/01

NB Un 2/22
and WMNB 3/07

WMNB 3/01

Un 2/22
and WMNB 3/07

3/8/88

R7007

R70078802221002 SJR

| | | |
|-----------------|------|--------------|
| TARE WT | VIAL | 9.6g |
| VIAL + DRY SOIL | | <u>10.1g</u> |
| DRY SOIL | | 0.5g |

~~DIFF FROM WET SOIL WT~~ 1.5g

R70078802221102 SJR

| | | |
|-----------------|------|--------------|
| TARE WT | VIAL | 9.6g |
| VIAL + DRY SOIL | | <u>10.5g</u> |
| DRY SOIL | | 0.9g |

~~DIFF FROM WET SOIL WT~~ 1.9g

R70078802221202 SJR

| | | |
|-----------------|------|--------------|
| TARE WT | VIAL | 9.5g |
| VIAL + DRY SOIL | | <u>10.3g</u> |
| DRY SOIL | | 0.8g |

~~DIFF FROM WET SOIL WT~~ 1.6g

R700788022201302 SJR

| | | |
|-----------------|------|--------------|
| TARE WT | VIAL | 9.6g |
| VIAL + DRY SOIL | | <u>11.2g</u> |
| DRY SOIL | | 2.1g |

~~DIFF FROM WET SOIL WT~~ 3.7g

R70078802221402 SJR

| | | |
|-----------------|------|--------------|
| TARE WT | VIAL | 9.7g |
| VIAL + DRY SOIL | | <u>11.2g</u> |
| DRY SOIL | | 1.5g |

~~DIFF FROM WET SOIL~~ 2.5g

3/8/88

R7007

R70078802241100 SJR

| | | |
|-----------------|--|--------------|
| TARE WT VIAL | | 9.6g |
| VIAL + DRY SOIL | | <u>11.2g</u> |
| DRY SOIL | | 2-1g |

nb u m 3/24
WMNB3/07

~~DIFF FROM WET SOIL WT~~ 4.1g

R70078802241200 SJR

| | | |
|-----------------|--|------|
| TARE WT VIAL | | 9.6g |
| VIAL + DRY SOIL | | |
| DRY SOIL | | |

Vial dropped + broken, unable to
retrieve sample - 03/4/88

~~DIFF FROM WET SOIL WT~~ 3.7g

relabel in WMVB
3/07

R70078802241300 SJR

| | | |
|-----------------|--|--------------|
| TARE WT VIAL | | 9.5g |
| VIAL + DRY SOIL | | <u>10.2g</u> |
| DRY SOIL | | 0.7g |

nb u m 3/24

~~DIFF FROM WET SOIL WT~~ 1.9g

R70078802241400 SJR

| | | |
|-----------------|--|--------------|
| TARE WT VIAL | | 9.8g |
| VIAL + DRY SOIL | | <u>11.2g</u> |
| DRY SOIL | | 1.4g |

nb u m 3/07
WMNB3/07

~~DIFF FROM DRY SOIL~~ 2.5g

R70078802241600 SJR

| | | |
|-----------------|--|-------|
| TARE WT VIAL | | 9.8g |
| VIAL + DRY SOIL | | 11.0g |
| DRY SOIL | | 1.5g |

nb u m 3/07
WMNB3/07

~~DIFF FROM WET SOIL WT~~ 3.4g

3/8/88

R7007

R7007 880224 1602 SJR

| | |
|-----------------|------------------|
| TARE WT VIAL | 9.8 _S |
| VIAL + DRY SOIL | 10.1g |
| DRY SOIL | 0.3g |
| WET SOIL WT | 0.9 _S |

WM NB > 10⁷

R7007 880224 1702 SJR

| | |
|-----------------|-------------------------|
| TARE WT VIAL | 9.7 _S |
| VIAL + DRY SOIL | <u>11.3_S</u> |
| DRY SOIL | 1.6 _S |

NB WM γ/3M
and WMNB3/10⁷

~~- OFF FROM WET SOIL WT 2.6_S~~

3/8/88

R200

1500 Tare wt condensate receiver flasks:

Flask, #1 reactor : 106.2g

Flask, #2 reactor : 110.3g

1515 ~~1515~~ Making up more 1:1:2 (PEG:TMH:DMSO) for reactions on
03/09/88 in ratios PEG=150g : TMH=150g : DMSO = 300g

1520 Tare wts silica gel moisture trap tubes:

Silica gel tube, Reactor #1: 21.3g

Silica gel tube, Reactor #2: 20.8g

1530 Tare wts; Cold-trap receivers for distillate/condensate system

Cold-trap receiver, Reactor #1: 79.9g

Cold-trap receiver, Reactor #2: 80.9g

3/5/88

R7007

0730 TEMPS OIL BATH 112.7°C
REACTOR #1 110°C
REACTOR #2 109°C

0800 TEMPS OIL BATH 130.9°C
REACTOR #1 112°C
REACTOR #2 112°C

TAKE SAMPLE R70078803090800STG Extracted

TARE WT VIAL 9.6
VIAL + SLURRY $\frac{17.5}{7.9}$
SLURRY WT
WET SOIL WT AFTER 3 WATER $12.8 - 9.6 = 3.2$
Soil Dry wt: 1.3g

TARE WT WATER WASH VIAL $\frac{20.1}{35.2}$
VIAL + WATER WASHES
WATER WASHES 15.1g

0802 TAKE SAMPLE R70078803090802STG Extracted

TARE WT VIAL 10.15
VIAL + SLURRY $\frac{19.3}{8.2}$
SLURRY

NET SOIL WT AFTER 3 WATER WASHES $13.6 - 10.15 = 3.4$
Soil Dry soil: 1.4g

TARE WT WATER WASH VIAL $\frac{20.15}{35.1}$
VIAL + WATER WASHES
WATER WASHES 15.0g

0930 Temps Oil Bath 132.9°C
Reactor #1 115°C
Reactor #2 115°C

3/9/89

R7007

1000

Drew Sample # R7007880309/0005 To Extracted

Tare wt vial
vial + Slurry
Slurry wt

9.55
+ 16.9
26.4g

wet soil wt after 3 washes Dry Soil: 0.4g

Tare wt wash vial
wash + vial
wash wt

20.3g
+ 7.

Drew Sample # R7007880309/0025 To Extracted

Tare wt vial
vial + Slurry
Slurry wt

9.6g
+ 17.2
26.8g

wet soil wt after 3 washes Dry soil wt: 0.6g

Tare wt wash vial
washes + vial
wash wt

20.1g

1000 Temps Oil Bath: 131.1°C
Reactor #1: 131°C
Reactor #2: 134°C

1030 Temps Oil Bath: 132.5
Reactor #1: 136
Reactor #2: 139

Oil bath in small pan too low, so oil temp reading inaccurate. Balance adjusted, oil temp ↑ 162.3°C by 1035

R7007

03/09/88 WB High PCB reactions

1200
cont.

R70078803091200SJR:

Tare wt vial: 10.1g
Vial + slurry wt: 13.9g (mostly solid)
Slurry wt: 3.8g

1202 Drew sample # R70078803091202SJR:
wt. - p 3 water washes: 14.0g (!) Wet soil: 3.9g
Dry soil: 2.8g

Tare wt vial: 9.6g
Vial + slurry wt: 15.7g
Slurry wt: 6.1g

wt. - p 3 water washes: 12.4g Wet soil: 2.8g

| | | |
|------|-------------------------|-------|
| 1200 | TARE WT WATER WASH VIAL | 20.2g |
| | VIAL + WATER WASH | 35.7g |
| | WATER WASH | 15.5g |

| | | |
|------|-------------------------|-------|
| 1202 | TARE WT WATER WASH VIAL | 20.1g |
| | VIAL + WATER WASH | 38.0g |
| | WATER WASH | 17.9g |

1210 TURN HEATER TO 165°C

1235 Turn oil heater ↓ to 162°C

1240 TURN OIL HEATER TO 160°C

R7007

03/09/88 NB, High PCB reactions

1400 Drew sample # R70078803091400SJR

Tare wt. vial: 7.6 g
 Vial + Slurry wt: 17.2 g

~~1402~~ Slurry wt: 7.6 g
~~1402~~ Wt. p 3 water washes: 10.8 g

Wet soil: 1.2 g
 Dry soil: 0.6 g

Tare wt wash water vial: 19.9 g
 Vial + water washes: 43.1 g
 Waterwashes wt: 23.3 g

1402 Drew sample # R70078803091402SJR

Tare wt. vial: 9.5 g
 Vial + Slurry wt: 15.5 g
 Slurry wt: 6.0 g

Wt. p 3 water washes: 12.0

Wet soil: 2.5
 Dry soil: 1.6 g

Tare wt. water wash vial: 20.1 g
 Vial + water washes: 38.5 g
 Waterwash wt: 18.4 g

KOH check on reaction 1

R70078803091400RJR (Reagent + wash from soil sample)

Full vial 43.2 g after aliquot removed 41.3 after aliquot 40.6

Empty vial 19.8 total aliquot = 0.7 g

Total 23.4 g aliquot mass = 2.9 g

Slurry mass was 7.6 g titrated w/ 3 ml of 0.2 N HCl (overshot)

Reagent ≈ 7.6 - 7.2 = 0.4 g dry aliquot titrated w/ 0.02 NH₃SO₄, 10.4 ml

$$\% \text{ KOH in reagent} = \frac{10.4 \text{ ml} \times 0.02 \text{ M} \times 56 \text{ mg}}{0.7 \text{ g} \times 23.4 \text{ g}} \times 100\% = 6.08 \rightarrow 6.08 \text{ mg/g}$$

Reactor 2 - R70078803091402RJR

$$\text{Full vial } 38.5 \text{ after aliquot removal } 32.3 \text{ g } \% \text{ KOH} = \frac{22.1 \times 0.02 \times 56 \times 18.4}{1.2 \times 3.5 \times 1.0} = 13.3\%$$

- and 20.1 aliquot mass = 1.2 g

titrated w/ 27.1 ml 0.02 N H₃SO₄. After reagent was 6.0 - 2.5 = 3.5 g

R7007

3/09/88 NB, High PCB

Temps:

Oil bath: 160°C
 Reactor # 1: 153°C
 Reactor # 2:

Drew sample # R70078803091600 SJR

Tare wt. vial: 9.7g
 Vial + slurry wt: 14.2g
 Slurry wt: 4.5g
 Wt. p 3 washes: 12.8g Wet soil: 3.1g
 Dry soil: 1.7g
 Tare wt. water wash vial: 19.9g
 Vial + water washes: 36.8g
 Water washes wt: 16.9

1602 Drew sample # R70078803091602 SJR

Tare wt. vial: 10.2g
 Vial + slurry wt: 14.9g
 Slurry wt: 4.7g
 Wt. p 3 water washes: 14.2g Wet soil: 4.0g
 Dry soil: 2.2g

Tare wt. water wash vial: 20.1g
 Vial + water washes: 36.0g
 Water washes wt: 15.9g

1700 Temps:

Oil: 161°C
 Reactor # 1: 152°C
 Reactor # 2: 152°C

Drew sample # R70078803091700 SJR

Tare wt. vial: 9.5g
 Vial + slurry: 12.7g
 Slurry wt: 3.2g
 Wt. p 3 washes: 12.3g Wet soil: 2.8g

Tare wt. water washes vial: 20.1g
 Vial + water washes: 37.2g
 Water washes wt: 17.1g

R700703/09/88 WB, High PCB

1845 Temps both reactors < 100°C added 525g DI water to both. Keep agitating X 15 min to mix (H2O) well

1910 Oil circulator turned off, stirring motors turned off
Oil bath : 99.6°
Reactor # 1 : 50°C
Reactor # 2 : 53°C

3/10/88

R7007

1325

TARE WT 250 ml BEAKER 119.72_s
 BEAKER + REAGENT 120.72_s
 REAGENT 1.00_s

ADD 15 ml OF WATER CHECK PH = 9 ADD
 DROPS PHENOPHTHALEIN

START BURST AT 15.0 ml END BURST AT 25.4 ml
 10.4 ml 0.02 N H₂SO₄

(R70078803101145LRG)

$$\text{mg/l KOH} \cdot \frac{10.4 \text{ ml} \times 0.02 \text{ N}}{1.0 \text{ s}} \times \frac{\text{mmole}}{\text{ml}} \times \frac{56 \text{ mg/mole}}{\text{mmole}} = 11.6 \text{ mg/l KOH}$$

1620 Wt. of condensate receivers from 03/09/88:

Tare wt. cond. flask, Reactor #1: 106.2g
 Condensate + flask wt : 310.5g
 *R70078803101620CJR → Condensate wt : 204.3g

Tare wt. cond. flask, Reactor #2: 110.3g
 Condensate + flask wt : ~~322.1g~~ 322.1g
 R70078803101622CJR → Condensate wt: 211.8g

Note: Both condensate receiver flasks have discreet globs of oily-
 appearing, pale greenish-yellow material on the bottom of
 the flask.

1625 Weighing condensate receiver flasks for continuation of reaction
 03/11/88:

Tare wt. cond. flask, reactor #1: 112.6g

Tare wt. cond. flask reactor #2: 106.1eg

3/11/88

R7007

0545

TARE WT BEAKER
BEAKER + SOLID KOH
SOLID KOH

| | |
|-------|-------------|
| 49.9g | <u>39.9</u> |
| | 40.0g |

REACTOR #1

TARE WT BEAKER
BEAKER + SOLID KOH
SOLID KOH

| | |
|-------|-------------|
| 49.7g | <u>38.7</u> |
| | 40.0g |

0600

Temps Oil Bath
REACTOR #1 22 °C
REACTOR #2 39 °C
REACTOR #2 36 °C

0610 Oil bath not circulating, had to pull sm. amt of oil from lg. pan to sm. pan. Some large piece of soil cake is circulating in reactor #1, jams against thermometer + stops agitator dead. Raised thermometer probe ~ 2cm in housing.

0630

Temps Oil: 65.4°C
Reactor #1: 49°C
Reactor #2: 51°C

Reactor #1 still making scraping/grinding noises, but solid chunk no longer striking thermometer probe.

0700

Temps: Oil: 69.3°C
Reactor #1: 83°C
Reactor #2: 87°C

Drew sample R7007-880309 0700 SJR

Tare wt. 8ml vial: 9.8g

Vial + slurry wt : 18.3g

Slurry wt : 8.5g

Wt. p 3 water washes: 11.5g wet soil: 1.7g

R7007

03/11/88 NB, High PCB, continuation

0930

Temps: oil: 166.7°C
 Reactor #1: 145°C
 Reactor #2: 145°C

0900

TEMPS OIL PATH 166.9°C
 REACTOR #1 151°C
 REACTOR #2 148°C

0900

TAKE SAMPLE # R70078803110900SJR

| | |
|---------------|--------------|
| TARE WT VIAL | 9.7g |
| VIAL + SLURRY | <u>17.0g</u> |
| SLURRY | 7.3g |

WT AFTER 3 WATER WASHES 12.1g WET SOL WT 2.4g

| | |
|-------------------------|----------------------|
| TARE WT WATER WASH VIAL | 20.2g |
| VIAL + WATER WASHES | <u>42.0g</u> |
| WATER WASHES | <u>+2.1g</u> - 21.8g |

0902

TAKE SAMPLE # R70078803110902SJR

| | |
|---------------|-------|
| TARE WT VIAL | 9.8g |
| VIAL + SLURRY | 21.9 |
| SLURRY | 11.3g |

WT AFTER 3 WATER WASHES 14.5 WET SOL WT 4.7g

| | |
|--------------------------|---------------|
| TARE WT WATER WASH VIALS | 19.9g |
| VIAL + WATER WASHES | <u>38.7</u> |
| WATER WASHES | <u>-18.8g</u> |

0910 Reactor #2 occasionally jumping/snatching as though a large chunk is rotating about inside & causing the agitator to jump.

3/11/88

R7007

1030 TEMPS OIL BATH 112°C
 REACTOR #1 153°C
 REACTOR #2 153°C

1100 TEMPS OIL BATH 161.5°C
 REACTOR #1 153°C
 REACTOR #2 153°C

TAKE SAMPLE R7007 88031111005JR

| | |
|---------------|-------|
| TARE WT VIAL | 9.8g |
| VIAL + SLURRY | 20.4g |
| SLURRY | 10.6g |

WT AFTER 3 WATER WASHES: 13.1g WET SOIL WT 3.3g

| | |
|-------------------------|--------------------------|
| TARE WT WATER WASH VIAL | 20.1g |
| VIAL + WATER WASHES | 39.9g |
| WATER WASHES | 8.4g 19.9g |

1102 TAKE SAMPLE R7007 88031111025JR

| | |
|---------------|-------|
| TARE WT VIAL | 9.8g |
| VIAL + SLURRY | 16.7g |
| SLURRY | 6.9g |

WT AFTER 3 WATER WASHES: 13.3g WET SOIL WT: 3.5g
Dry soil: 2.8g

| | |
|-------------------------|-------|
| TARE WT WATER WASH VIAL | 20.1g |
| VIAL + WATER WASHES | 36.8g |
| WATER WASHES | 16.7g |

3/11/88

R7007

1230 TEMPS OIL BATH 162°C
 REACTOR #1 152°C
 REACTOR #2 153°C

1300 TEMPS OIL BATH
 REACTOR #1
 REACTOR #2

TAKE SAMPLE R70078803111300 S&F

| | |
|---------------|--------------|
| TARE WT VIAL | 9.9g |
| VIAL + SLURRY | <u>17.3g</u> |
| SLURRY | 7.4g |

WT AFTER 3 WATER WASHES 13.0g WET SOIL WT 3.1

| | |
|-------------------------|--------------|
| TARE WT WATER WASH VIAL | 19.8g |
| VIAL + WATER WASH | <u>38.9g</u> |
| WATER WASHES | 19.0g |

1302 TAKE SAMPLE R70078803111302 S

| | |
|---------------|--------------|
| TARE WT VIAL | 9.7g |
| VIAL + SLURRY | <u>19.2g</u> |
| SLURRY | 9.5g |

WT AFTER 3 WATER WASHES 14.3 WET SOIL WT 4.6

| | |
|-------------------------|--------------|
| TARE WT WATER WASH VIAL | 20.1g |
| VIAL + WATER WASHES | <u>38.7g</u> |
| WATER WASHES | 18.6g |

3/11/88

R7007

1500 Temps: Oil bath 162.2°C
Reactor 1 150°C
Reactor 2 150°C

Take Sample # R70078803101500STG from reactor 1

Tare Vial 9.60g
+ Slurry 16.3g
Slurry wt 6.7g

After 3 waterwashes: 12.1 wet soil = 2.5g

Tare Reagent & Wash vial 19.85
+ " " " 36.85
Net Reagent & Wash v 17.0g

1502

Take Sample # R70078803101502STG from Reactor 2

Sample Vial tare 9.69g
plus Slurry 17.2g
Slurry wt 7.51

After 3 water-washes: 10.65 wet soil = 0.96g

Reagent & wash vial tare 20.28
+ Reagent & washes 41.40
Net weight 21.12g

2
3/11/88

R7007

700 Temps Oil Bath 162.2°C
 Reactor 1 147°C
 Reactor 2 149°C

Drew Sample R700788031117005T6

Tare wt vial 9.8g
vial + slurry 13.3
Slurry wt 3.5g

wt after 3 washes 11.1 wt of washes = 1.3g

Tare wt of wash vial 19.9g
vial + washes 21.1
wt of washes 1.2

702 Drew Sample R700788031117025T6

Tare wt vial 9.9g
vial + slurry 17.2
slurry wt 7.3g

wt after 3 washes 11.5 wt of washes = 1.6g

Tare wt of wash vial 20.1
vial + washes 38.8
washes wt 18.7g

730 Temps Oil Bath 162.2°C
 Reactor 1 149°C
 Reactor 2 151°C

750 Turned off oil bath heater

PO

3/14/68

R2007

0630 EXTRACT SAMPLES R2007880311 1800STG
R2007880311 1802STG

0810 TARE WT FLASK 84.6 g REACTION 1
WT FLASK & REAGENT 85.6g
REAGENT 1.0g

ADD 15.0 ml OJ WATER CHECK PH = 11
ADD 10 DROPS PHENOPHTHALEIN

START BURET AT 1.0 ml, END BURET AT 39.1 ml
USE ml 0.02 N H₂SO₄

$$\text{mg/s KOH} = \frac{38.1 \text{ ml} \times 0.02 \text{ N} \frac{\text{mole}}{\text{ml}} \times 56 \frac{\text{mg}}{\text{mole}}}{5} = 42.7 \text{ mg/s KOH}$$

0815 TARE WT FLASK 71.45 g
WT FLASK & REAGENT 92.47g
REAGENT 1.0g

ADD 15.0 ml OJ WATER, CHECK PH = 10
ADD 10 DROPS PHENOPHTHALEIN.

START BURET AT 1.0 ml, END BURET AT 33.1 ml
USE ml 0.02 N H₂SO₄

$$\text{mg/s KOH} = \frac{32.1 \text{ ml} \times 0.02 \text{ N} \frac{\text{mole}}{\text{ml}} \times 56 \frac{\text{mg}}{\text{mole}}}{1.025} = 35.2 \text{ mg/s KOH}$$

R7007

03/14/88 NB, High PCB

1325 cont.

Weighing silica gel moisture trap tubes:

Tare wt. silica gel tube, Reactor #2: 20.8g

Tube + condensate wt: 21.2g

Condensate wt: 0.4g

Note: Both abovementioned silica gel tubes displayed black discoloration, $\frac{1}{4}$ to $\frac{1}{2}$ way up tube.

1335

Weighing "cold trap" assemblies:

Tare wt. Cold trap assembly, Reactor #1: 79.9g

Cold trap + condensate: 80.6g

Condensate wt: 0.2g

Tare wt. cold trap assembly, Reactor #2: 80.9g

Cold trap + condensate wt: 81.0g

Condensate wt: 0.1g

1340

Weighing reactor bodies, C contents, High PCB reactions 03/09 to 03/11/88:

Reactor body + slurry, Reactor #1: 798.6g

Tare wt. reactor body #1: 568.5g

Contents wt. Reactor #1: ~~164.9g~~
230.1g

Reactor body + slurry, Reactor #2: 796.5g

Tare wt. reactor body #2: 587.9g

Contents wt., Reactor #2: 208.6g

1420

Transferring Reactor contents to 250ml jars:

Tare wt. 250ml jar, Reactor #1: 178.3g

Jar + reactor contents wt: 416.8g

(from 1340 above) > Contents wt. Reactor #1: 230.1g

#R70078803141350SJR \rightarrow Transferred contents wt: 238.5gTransfer losses, Reactor #1: gained 8.4g! Note
that reactor lost ~ 15g
during 24 hr reaction time

3/15/88

R0007

0620

TARE WT RING 130.9g
 RING + REACTANT
 REACTANT 184.6g
~~130.9g~~
~~53.7g~~

TARE RING + REACTANT 684.5g USING TRIPLE SENS.
 RING, REACTANT + SOIL 984.5g
 SOIL 200.0g
 USING HIGH PCO SOIL

TARE WT VIAL 9.6g
 VIAL + SOIL 12.9g
 SOIL 3.3g

TARE WT CONDENSATE FLASK 115.1g

TARE WT COLD TRAP 80.0g w/ NOSES

TARE WT SILICA GEL TUBE 20.6g
 R700788932, 1800.0g

3/21/88

TARE WT BEAKER 244.0g 244.2g after
 BEAKER + OMSO 344.0g 344.0g

OMSO 100.0g

BEAKER, OMSO, PEG 344.0g

BEAKER, OMSO, PEG 394.0g

PEG 50.0g

TARE BEAKER, OMSO, PEG 394.0g

BEAKER, OMSO, PEG, TMT 444.0g

TMT 50.0g

~~45%~~ 45% KOH BEAKER TARE 109.4g

BEAKER + KOH 209.4g

KOH 100.0g

R7007

03/21/88 NB, High PCB

0820 Oil bath heater alarms as soon as temp reaches 176°C
Temp + to 175.4°C

0830 Temps: Oil: 174.4°C
Reactor: 144°C

Will wait on extracting R70078803210800SJR due to
problems w/ stds. injection on HP GC.

0840 Condensate slowed to occasional drip, temp in Reactor @ 145.

0845 RLP reset oil bath alarm circuit potentiometer to 200°, temp
reset to 185°C

Spiking + extracting 0800 sample

0900 Temps: Oil: 184.6°C
Reactor: 154

Drew sample # R70078803210900SJR

0910 Approx 2-2.5 ml spilled out of 10ml volumetric for sample #
R70078803210800SJR. Area cleaned w/ H₂O-soaked towel.

0930 Temps Oil: 184.5°
Reactor: 161°C

1000 Temps Oil: 184.6°C
Reactor: 166°C

Drew sample # R70078803211000SJR

1030 Temps: Oil: 184.5°C
Reactor: 168°C

1100 Temps Oil: 184.6g°C
Reactor: 173°C

Drew Sample # R70078803211100SJR

3/21/58

R7007

~~"never mind" JPR~~

~~0100 CIL 50H 22.5 °C~~

~~1115 CIL 50H 17.5 °C~~

1115 Extracting R70078803181102SJR, Starting soil per standard method.

1130 ~~+10°~~ Temps: Oil: 184.5 °C
Reactor: 176. °C

1200 Temps CIL 184.5 °C
REACTOR 178 °C

Drew sample # R70078803211200SJ, washed + extracted per standard GRC.

1230 Temps: Oil: 184.4 °C
Reactor: 178 °C

1300 Temps: Oil: 184.4 °C
Reactor: 178. °C

Drew Sample # R70078803211300SJ, will extract this sample since 1200 sample shows reaction to be virtually "clean."

1330 Temps: Oil: 184.5 °C
Reactor: 179. °C

1400 Temps: Oil: 184.3 °C
Reactor: 179. °C

Drew sample # R70078803211400SJ, washed only, reactor heating shut down, began cooling & fan, oil bath circulating, reactors still agitating.

R7007

03/24/88 New Bedford

1045 Extracted condensate for High PCB reaction 03/21/88:

Tare wt. 250 ml jar: 178.1g

Jar + condensate: 396.8g

FR70078803211430CRG → Extracted condensate: 218.1g

1100 Wt. of reactor + slurry: 946.1g

Reactor contents dumped into 500 ml jar

Tare wt. 500 ml jar: 230.6g

Reactor contents + jar: 622.7g

Recovered → Reactor contents wt: 392.1g

Wt. reactor bottom p cleaning: 547.1g

Contents + Reactor bottom wt: 946.1g

Calculated Contents wt: 399.0g

3/28/86

0600 ADD 1:1:2 PEG; TMH: OMSO + 45% KOH

TEMPS OIL BATH 22 °C
 REACTOR 28 °C

0630 Temps: Oil Bath: 81 °C
 Reactor : 48 °C

0700 Temps: Oil Bath: 126 °C
 Reactor : 94 °C

0715 Reactor @ 108 °C, Boiling very actively, condensate coming across rapidly, obviously heavy oil globules in condensate. Vacuum turned off, reactor still "burped" reagent into condensate receiver. Will add 1% vermiculite & hopefully control foaming + "burping".

TARE WATER BOTTLE 57.65
WATER + BOTTLE 138.78

WASH CONDENSER & COND FLASK
REWEIGH WATER BOTTLE

3/29/89

R2007

RUN ISAL REACTION WITH DUAL CONDENSERS
ON ON EACH SIDE OF 3 NECK FLASK

0545 WATCH OUT 200₃ WATER + ADD TO REACTOR

0600 TEMPS OIL BATH 24 °C
REACTOR 24 °C

0630 Temps: Oil Bath: 85°C
Reactor: 52°C

0700 TEMPS OIL BATH 120 °C
REACTOR 94 °C

0725 Reactor "burped" again. Blowout tube moved water column ± .25". Approximately 500-600ml slurry boiled into 3000ml condensate receiver. System broken down & cooled. Reactor @ 109°C when it "burped". Added another "T" joint above existing apparatus, lengthened vertical column. Poured slurry back into reactor

0755 Started reactor back up. Temps Oil Bath: 114°C
Reactor: 99°C

0830 Temps: Oil Bath: 145°C
Reactor: 109°C

0900 TEMPS OIL BATH 155 °C
REACTOR 110 °C

0930 TEMPS OIL BATH 161 °C
REACTOR 111 °C

3/30/88R7017

1030 TARE WT R7017 131.0_s
R7018 * 3000 FLASK 722.2_s
3001 FLASK 591.9_s

1040 WT OF SILICA GEL TUBE 21.7_s
R7007880311800 R7016

3/31/88

R7007

0600 ADD REAGENT TO REACTOR

TEMPS OIL BATH: 28°C
REACTOR : 173°F or 78°C

0630 TEMPS OIL BATH 82.7°C
REACTOR 159°F OR 70.5°C

0700 Temps: Oil Bath: 119°C
Reactor: 96°C

Drew sample # R7007803310700SJR

0730 TEMPS OIL BATH RT 145°C
REACTOR : 124°C

Reactor showing only minimal frothing /boiling

0735 Reactor boiling more actively now. Still no obvious condensate coming across in either column.

0740 Reactor still boiling under control, some condensate coming across in front column.

0800 Temps: Oil Bath: 157°
Reactor : 127°

Drew sample # R7007803310800SJR (Extracted)

Reactor still boiling nicely, under control

0830 Temps: Oil Bath: 164°C
Reactor : 130.5°C

0900 Temps: Oil Bath: 168°C
Reactor : 135°C

R700T

03/31/88 New Bedford (gallon, High PCB

0900 Drew sample # R70078803310900 SJR

0930 Temps: Oil Bath: 173°C
Reactor: 142°C

1000 Temps: Oil Bath: 174.5°C
Reactor: 146°C

Drew sample # R70078803311000 SJR

1030 Temps: Oil Bath: 174.5°C
Reactor: 150.5°C

1100 Temps: Oil Bath: 174°C
Reactor: 154°C

Drew sample # R70078803311100 SJR

1130 TEMPS OIL BATH 174.3°C
REACTOR 313°F OR 156.1°C

1200 Temps: Oil Bath: 174.2°C
Reactor: 316°F OR 157.0°C

Drew sample # R70078803311200 SRC

1230 TEMPS OIL BATH 174.1°C
REACTOR 160°C

1300 Temps: Oil Bath: 174°C
Reactor: 162°C

1330 Temps: Oil Bath: 173.7°C
Reactor: 162.7°C

Some sort of distillation still occurring in proximate area
of condensation column.

R7007

3/31/88

- 1830 Temps Oil Bath 113.1°C
 Reactor 121.7°C
- 1900 Temps Oil - 98.3 Reactor: 224°F (107°C)
Water added - Beaker + water 1829.7g
 Beaker after addition 290.9g
 Water added 1588.8g
Reactor Temp after addition = 190°F (88°C)
- 1900 Copper & Acid washed sample # R700788033118005TG again
 due to the large ZO peak.
- 20:00 Reactor 165°F (76°C) Bath 70°C
 Everything turned off (including stirring)

4/4/88

1000

TARE WT BOX 1.0lb
BOX & REACTOR ENDING 16.2lb
ENDING REACTOR 15.2lb

HIGH NB. SOIL

empty reactor tank (15.2) = 2.7lb

0830 TARE WT REACTOR FOR LOW NB SOIL

1274.0
BOX & REACTOR 1738.7

TARE BOX 1.0lb
BOX & REACTOR 3.8lb
REACTOR 2.8lb

TARE BOX & REACTOR 3.8lb
BOX, REACTOR LOW NB SOIL 9.8lb
LOW NB SOIL 6.0lb

0905

TARE WT JAR 384.0s
JAR & ~~SOLID KOH~~ 1301.2
SOLID KOH 917.2 917.2s

TARE WT PLASTIC ~~74.4~~ 74.4s
JAR & SOLID KOH 518.4
SOLID KOH 444.0s 1361.2s = 3lb

TARE WT COLD TRAP 152.3s WITH STOPPER

TARE WT RING 131.0s
RING & 3000ml FLASK 712.7s
3000ml FLASK 581.7s

R7007

04/05/88 New Bedford - 1 gal reaction

0830

Temps:

Oil Bath: 169°C
Reactor : 143°C
133°C

0900

TEMPS

OIL BATH 173.3°C
REACTOR 280°F OR 139.7°C

Drew sample# R700788040509005JR (Extracted)

0930

Temps:

Oil Bath: 174°C
Reactor : 143°C

1000

TEMPS

OIL BATH 174°C
REACTOR 148.8°C

1030

TEMPS

OIL BATH: 174°C
REACTOR : 153°C

SAMPLE R700788040510005JR DROPPED OUT OF WATER
WASHING SAMPLE IS VOID

1100

Temps:

Oil Bath: 174°C
Reactor : 156°C

Drew sample# R700788040511005JR (Extracted)

1130

Temps:

Oil Bath: 174°C
Reactor : 159°C

1200

TEMPS

OIL BATH 173.5°C

REACTOR 321°F OR 160.5°C

OPEN SAMPLE R700788040512005JR EXTRACTED

1230

TEMPS

OIL BATH 173.8°C

REACTOR 322°F OR 161°C

P2

4/6/88

R7007

0650 TARE WT RING 131.0g
TARE WT → 3000 ml FLASK 581.7g
 RING FLASK + CONDENSATE 1581.4g
 CONDENSATE 867.1g

R70078804051720 ERG
 1341.6g

TARE WT RING 131.0g
 TARE WT 1000 ml FLASK 241.1g
 FLASK, RING, + CONDENSATE 382.9g
 CONDENSATE 372.9g

TARE WT BURP BUCKET 81.0g
 BURP BUCKET + CONDENSATE 139.9g
 CONDENSATE 58.9g

AIR COOLED

TARE WT COLD TRAP 152.3g
 COLD TRAP ENODING 152.3g
 COLD TRAP GAIN 0.0g

TARE WT SILICA GEL TUBE 20.3g
 ENODING WT SILICA GEL TUBE 20.3g
 SILICA GEL TUBE GAIN 0.0g

0840 Weighing reactor + contents: Total wt slurry, reactor + box: 16.8 lbs

4/21/88

R1007

OO CENTRIFUGE WITH SAND REACTION

TOTAL WT OF JAR, SAND, & 1:1:2 15.2 lb
WT AFTER PUTTING INTO CENTRI 2.6 lb
SAND, & 1:1:2 12.6 lb

S#4 R10078804210940RRG TARE WT JAR 2.3 lb
JAR & FILTRATE 2.8 lb
FILTRATE 6.5 lb

WT OF WASH #1

TARE OF JAR 2.3 lb
JAR & WATER 10.3 lb
WATER 8.0 lb

TARE WT OF JAR 2.3 lb
JAR & WASH #1 10.3 lb
WASH #1 FILTERED 8.0 lb

TARE WT JAR 2.3 lb
JAR & WASH #2 WATER 8.3 lb
WATER 6.0 lb

TARE WT JAR 2.3 lb
JAR & WASH #2 8.6 lb
WASH #2 FILTERED 6.3 lb

FINISHED SOIL 2.6 lb TARE
12.2 lb
9.6 lb NET SOIL

Regh. Soil

4/21/88

(000)

| | | |
|---------|--------------|---------------|
| TARE WT | WET SOIL JAR | 2.3 lb |
| JAR + | WET SOIL | 7.4 lb |
| | WET SOIL WT | <u>2.1 lb</u> |

SF # R700788042115305RG

4/22/88

PROCEDURE USED FOR CENTRIFUGING.

THE CENTRIFUGE WAS STARTED & THE REAGENT JUG PLACED AT THE ~~OUT~~ DISCHARGE POINT OF THE CENTRIFUGE AND THE CONTENTS OF THE REACTOR MIXED UP. THIS MATERIAL WAS SLOWLY FED INTO THE CENTRIFUGE AND ALLOWED TO SPIN FOR 5 MIN. A THICK EMULSION WAS LEFT IN THE CENTRIFUGE. THE REAGENT IN THE BOWL WAS DECANTED AND ADDED TO WHAT HAD BEEN CENTRIFUGED. THE REAGENT PORTION WAS THEN RUN THROUGH THE CENTRIFUGE A SECOND TIME. THE EMULSION STILL REMAINED. THE REAGENT WAS AGAIN DECANTED AND ADDED TO THE CENTRIFUGE PORTION. THE SOIL EMULSION WERE REMOVED FROM THE CENTRIFUGE AND ADDED TO A JUG. THE REACTOR WAS RINSED WITH WASH WATER #1 AND PUT IN THE JUG. THE CONTENTS OF THE JUG WERE WELL MIXED. THE CENTRIFUGE WAS AGAIN STARTED WITH WASH WATER #1 JUG AT THE DISCHARGE. THE CONTENTS OF THE JUG WITH SOIL AND WASH WATER WERE ADDED TO THE CENTRIFUGE. THE REMAINING WASH WATER RINSED REACTOR & JUG BEFORE ADDING TO THE CENTRIFUGE.

Reagent Jug

4/22/88

MON

SP #

R7007880422/050SRC

| | |
|--------------------------|---------------|
| TARE WT JAR FOR JORDAN | 126.1g |
| JAR & SOIL AFTER WASH #1 | |
| WET SOIL WASH #1 | |
| | |
| TARE WT JAR FOR CALSON | 134.7g |
| JAR & SOIL AFTER WASH #1 | <u>125.4g</u> |
| WET SOIL WASH #1 | 104.7g |

| | |
|---------------------|---------------|
| TARE WT JAR | 2.4 lb |
| JAR & WASH WATER #2 | <u>8.4 lb</u> |
| WASH WATER #2 ADDED | 6.0 lb |

| | |
|---------------|---------------|
| TAR WT JAR | 2.3 lb |
| JAR & WASH #2 | <u>8.4 lb</u> |
| WASH #2 | 6.1 lb |

SP # R7007880422/051WRG

| | |
|------------------------------|---------------|
| TARE WT JAR | 2.3 lb |
| JAR & WET SOIL AFTER WASH #2 | <u>4.0 lb</u> |
| WET SOIL AFTER WASH #2 | 1.7 lb |

SP # R7007880422/120SRC

WT OF REFLCTOR 1253.9g

Regh Ball

4/25/88

R7007

TARE WT JAR 132.5g
 JAR & WET WASHED SOIL AFTER WASH #1 242.7g
 WET WASHED SOIL FROM WASH #1 110.2g
 SP# R70078804250955SRC

WATER WASH #2

| | |
|-------------|---------------|
| JAR TARE WT | 2.4 fl |
| JAR & WATER | <u>8.4 fl</u> |
| WATER | <u>6.0 fl</u> |

TARE WT JAR 2.3 fl
 JAR AND WASH WATER #2 8.4 fl
 WASH WATER #2 6.1 fl
 SP# R70078804251000WRG

TARE WT JAR 2.3 fl
 JAR AND WET WASHED SOIL 3.8 fl
 WET WASHED SOIL 1.5 fl
 SP# R70078804251025SRC

REACTOR WT AFTER 1918.3g

2nd bath

4/26/85

R.D. 807.

NO LOW SWL: SHIPPED SAMPLES TO JORDAN

1145 50s TARE WT JAR 126.1g
JAR + WET WASH #1 SOIL 195.3g FR SP # R1607530-1221050SR (1
WET WASH #1 SOIL METALS

100s TARE WT JAR 131.1g
 JAR + WET WASH #2 SOIL 230.5g FR SP # RICM 880422 ~~1120~~ SRC
 1148 WET WASH #2 SOIL METAL SEMI VOLATILES

TARE WT JAR 125.8g
 JAR + WET WASH #2 SOIL 315.4g FR S# # R700788042L1120 SRC
 WET WASH #2 SOIL METALS EP TOX

TARE WT JAR 131.2g
JAR + NET WASH #2 SGL 158.2g FR SP # R7007980412 11205RC
WT WASH #2 SGL METALS EP TOX

TARE WT BOTTLE 512.6g
 BOTTLE & DRAINED REAGENT 1043.9g FR SP # R70078804220925RAG
 DRAINED REAGENT METALS SOLIDS SEMI QUANTITATIVE

TARE WT BOTTLE 59.8g
BOTTLE + WASH WATER #1 927.1g FR SP# R7007880422/035 WR(1)
WASH WATER #1 METALSO SOLID

TARE w/ BOTTLE 513.9_S ✓
BOTTLE & WASH WATER = 1325.5 FR 58 # R7007830422 1035UR
WASH WATER # 1 SEMI VOLATILES

Page 5 of 5

4/26/88

R2007

NC HGT SOL

TARE WT BEAKER 49.1g
BEAKER + DRAINED REAGENT SIL ~~51.9 + 3~~
NET DRAINED REAGENT SIL 10.8g

SP # R70078804250925SRG

* TARE WT BEAKER 49.1g 49.1
BEAKER + DRY SIL 57.1g
DRY SIL 8.0g 74% solids

TARE WT BEAKER 49.1g
BEAKER + WASH #1 SIL 60.1g
WASH #1 SIL 11.0g

SP # R70078804250955SRG

TARE WT BEAKER 49.1g
BEAKER + DRY SIL 56.2g
DRY SIL 7.1g 65% solids

TARE WT BEAKER 160.7g
BEAKER + WET WASH #2 SIL 223.4g
WET WASH #2 SIL 62.7g

SP # R70078804251025SRG

TARE WT BEAKER 160.7g
BEAKER + DRY SIL 195.4g
DRY SIL 37.7g 55% solids

2nd Soln

4/21/88

R7007

1133 HIGH SOIL SAMPLES SHIPPED TO JORDAN

1128 100g TARE WT BOTTLE & WASH #1 510.4g
BOTTLE & WASH #2 707.6g
WASH #2 40.2050 METALS

1130 FULL TARE WT BOTTLE & WASH #1 670.0g
BOTTLE & WASH #2 1192.9g
WASH #2 SEMI VOLATILES

Post Edit

4/27/88

R7007

QA/QC FOR NB HIGH SWL

FROM SP # R70078804251025SRC

SP # R70078804271400SRC

| | |
|----------------|--------------|
| TARE WT VIAL | 9.7g |
| VIAL + DRY SWL | <u>12.3g</u> |
| DRY SWL | 2.6g |

SP # R70078804271405SRC

| | |
|----------------|--------------|
| TARE WT VIAL | 9.7g |
| VIAL + DRY SWL | <u>12.3g</u> |
| DRY SWL | 2.6g |

SP # R70078804271410SRC

| | |
|----------------|--------------|
| TARE WT VIAL | 9.6g |
| VIAL + DRY SWL | <u>12.1g</u> |
| DRY SWL | 2.5g |

STAKE WITH ARCHER 1248 1 μ g/ μ l LOT # A. 12592
USE 12.5 μ l

pages 65, 66, 71 & 72
 Copied from lab reactions & Data
 Notebook #3

6/15/88

R7007

Reagent Analysis Prep

| Sample # | Cert Value | tube# Sample | Sample# | Volume |
|----------------------|---------------|-----------------|---------|--------|
| R7007 8804250840 RRG | 15.5 | 16.7 | 1.2 | 10 |
| R7007 8804250938WRG | 15.2 | 16.5 | 1.3 | 10 |
| R7007 8804251000WRG | 15.1 | 20.3 | 5.2 | 10 |
| R7007 8804220925RRG | 15.3 | 16.3 | 1.0 | 10 |
| R7007 8804220035WRG | 15.1 | 16.6 | 1.5 | 10 |
| R7007 8804221050WRG | 15.1 | 19.3 | 4.2 | 10 |

Kim Berents
 6/15/88

This page out of date sequence - Should have been crossed out

81

Oct 10, 1988

Re-analysis of final Gallow Sediments
for PCB (especially Monochlorobiphenyl)

R7007

"low PCB" Reaction - Final soil is Sample # R700788042211205RG
(New samples were taken from that sample for analysis)

"high PCB" Reaction - Final soil is sample # R700788042510255RG

| Sample # | Source | Dry weight bottom | + wet sample | + dry sample | Net weight sample | Wet/Dry sample | PPM PCB | DCB% |
|------------|--------------|----------------------|--------------|--------------|----------------------|-------------------|---------|------|
| 1007880908 | 1400SEM Low | 9.88 | 14.22 | 12.73 | 4.34 | 2.8 | 0.50 | 51 |
| | 1410SEM Low | 9.78 | 13.57 | 12.23 | 3.79 | 2.41 | 0.746 | 48 |
| | 1420SEM Low | 9.74 | 13.75 | 12.37 | 4.01 | 2.6 | 6.4 | 41 |
| | 1430SEM high | 9.73 | 13.56 | 12.30 | 3.83 | 2.6 | 2.8 | 70 |
| | 1440SEM high | 9.77 | 13.93 | 12.58 | 4.16 | 2.8 | 2.7 | 62 |
| 1007880909 | 1450SEM high | 9.80 | 15.55 | 13.46 | 5.75 | 3.1 | 7.1 | 55 |
| | | | 14.74 | | 4.94 | | | |

All samples were spiked with 5 ul of 296 ppm Decachlorobiphenyl

* Samples spiked with 5 ul of 500 ppm Aroclor 1242.

Samples rested overnight between spiking and extraction.

Calculation file is WBWM 09/09 - later moved to WMNB 09/09

(40-70%)

Note: DCB recoveries will be low - moral is don't spike the night before extracting - spike on the day of extraction. The residual reagent in the soil may have dechlorinated some of the PCBs. The Mono results look OK and all of the DCB %R's were over 40. Given such recoveries we good.

These analyses must be repeated - See pg 90

Sep 12, 1988
Edwin Mullin

July 19, 1988

Analysis of Vent Traps for PCB

R7007

The traps had been allowed to "dry" thoroughly & were stored in plastic jars (covered). They seem to have absorbed ^{in the open lab} ~~water~~ moisture from the air.

| Sample | Reaction Time | Dry weight | Loss |
|---------------------|------------------|------------|------|
| R70078803311800 DRG | 1 hr 20 min | 24.5 g | 21.7 |
| R70078804051800 DRG | 1 hr 50 min | 22.8 g | 20.3 |

The traps were emptied into 4 oz jars & desorbed with ³⁰ mL Potassium bromate. The samples were spiked with 5 mL of 5% RSG (246 mg/mL Decachlorobiphenyl) and were allowed to "soak" overnight in the refrigerator (with occasional agitations from 9:30 AM - 6:00 PM).

July 20, 1988. A portion of the hexane from each sample was shaken with 0.5 mL (spupper beaker measure) of copper powder, then 1 mL of concentrated HCl was added (to the 4 mL vial). The samples were shaken vigorously with copper & acid, then centrifuged to separate the hexane. The hexane layer was transferred to a 1.5 mL vial for GC injection.

July 19, 1988

Reagent components in soil

R7007

I used sample # R7007880422/120SLG today to test the new extraction method. (For KOH I will simply turbid soil slurry w water)

Plan: ^{2nd & 3rd} Weigh soil (wet) into Soil slurry with water & adjust pH to < 7 using 25% H₂SO₄. Add ~3 ml Methanol, Scribe & open (centrifuge) decant as much liquid as possible into centrifuge tube. Add more methanol & repeat for a total of 3 passes. Collect wash in same tube. Blow down (evaporate methanol). Adjust final volume as desired w DI water. F/T₂ & inject into HPLC for PEG, TMH & DMSO

| # | Description | Vial (tare) + Sol. | Net sol. | Final Vol. |
|--------------------|--|--------------------|----------|------------|
| R7007880719/1005EM | 0+22/120SLG for test | 9.7 g | 13.4 | 3.7 |
| R7007880719/105SEM | 0422/120SLG + Spike ² (25 μl PEG, 25 μl TMH, 50 μl DMSO) | 9.7 g | 13.7 | 4.0 |

A light grey precipitate formed in the centrifuge tubes when the 2nd & 3rd wash were added. - Probably some water soluble, methanol insoluble salt (K₂SO₄?)

The methanol was evaporated away under a stream of purified air & used a vacuum pump with a filtration column at the outlet and a C-18 SPE column at the inlet end of the tubing system. To speed up the evaporation, the centrifuge tube was placed in a beaker of warm water

After drying
+ 25 μl water
currently available

| Spike Recovery Calculations | | | | | | | | | |
|-----------------------------|-------|----------|---------|---------------------|---------------------|------------|----------|-------|--------------|
| Analyte | g/ml | ml added | mg/gram | mL ¹ /in | mL ¹ /in | additional | | | |
| PEG | 1.125 | 25 | 7.0 | 1.105 | 1.105 | found | Recovery | 100/9 | after extra |
| TMH | 1.054 | 25 | 6.6 | 1.121 | 1.121 | NA | % | 110% | distillation |
| DMSO | 1.101 | 50 | 13.8 | 1.643 | 1.643 | 8.94 4.7 | W/F | 7.0 | 7.0 |

mg/ml = "X"

3-d evaporation (sample # 105...) took from 3.15 to 3.45 to go from ~16 ml to ~3.7 ml. Both samples were slightly turbid (or off) after concentration & volume adjustment. There was just a little brown precipitate (possibly just soil particles) in the final water solution.

PEG results are strange in that the peaks for the packed sample (105) look higher, but the reported peak height are lower resulting in a low reported concentration. The spiked sample did not have a negative "base" peak. This indicates that methanol was not adequately removed and probably caused the strange height reports.

July 20, 1988

Reagents in Soil

R2004

| | for PEG/TM/TMSO | | | for KOH | | | | |
|---|-----------------|----------------|---------------|---------|------------|--------------------|-------------|---------------------------------------|
| | Sample Time | Sample Time | Break Time | Sample | Net Sample | ml OIN HCl used | KOH mg/g | Description |
| Sample I | | | | | | | | |
| 270075804220959SRG | 9.7 | 12.3 | 2.0 | 104.1 | 107.6 | 3.5 | 101.0 | H ₂ O ₂ 162 |
| 042210503SRG | 9.8 | 12.7 | 2.9 | 106.3 | 109.1 | 2.8 | 30.8 | H ₂ O ₂ 62 |
| 042211205SRG | 9.8 | 13.5 | 3.6 | 104.4 | 112.5 | 8.1 | 29.75 | Na ₂ CO ₃ 21 |
| 04250925SRG | 9.9 | 12.4 | 2.5 | 102.2 | 107.2 | 5.0 | 119.1 | H ₂ O ₂ Residue |
| 04250955SRG | 9.8 | 11.9 | 2.1 | 105.3 | 108.7 | 3.4 | 43.0 | H ₂ O ₂ 871 |
| 04251025SRG | 9.7 | 11.8 | 2.1 | 103.5 | 110.1 | 6.6 | 24.25* | H ₂ O ₂ 22 |
| 20075804201007SEM* | 9.8 | 13.9 | 7.1 | 106.7 | 112.1 | 5.4 | 18.4 | 19. Duplicate |
| Indicate if ... 042211205SRG | | | | | | | | |
| not done | | | | | | | | |
| Extr. w/ 2 ml H₂O | | | | | | | | |
| Extr. w/ 1 ml H₂O | | | | | | | | |
| Extr. w/ 1 ml TMSO | | | | | | | | |
| Required duplicate sample | | | | | | | | |
| 270075804220959SRG | | | | | | | | |
| See Calc file | | | | | | | | |
| NBLG 07/21/88 | | | | | | | | |
| For these results | | | | | | | | |
| Extracted as on | | | | | | | | |
| pH 8.5, except | | | | | | | | |
| only 2 ml of H ₂ O used | | | | | | | | |

→ HPLC samples were all blown down from 1 ml (with methanol) to 2 ml, it got rid of the methanol and were then brought up to 5 ml final volume with water. The water extracts were mixed well & centrifuged for 2 min and filtered with LiqEx filters for HPLC.

Mean, Std Dev, and % Recovery, Calculation, from data in NBLG 07/21

mg/g found in duplicates

| | mg/g added | mg/g found | mg/g recd | Percent Recd |
|----------|--------------|--------------|--------------|--------------|
| Ammonium | 0.7191000000 | 042211205SRG | 0.7191000000 | 100.0000 |
| TMSO | 4.3 | 4.4 | 4.2 | 74.3 |
| TMH | 2.3 | 2.3 | 2.3 | 100.0 |
| PEG | 1.3 | 1.4 | 1.2 | 92.3 |
| KOH | NA | 21 | 19 | 71.4 |
| | | 20 | 1.4 | 7.0 |

* = 0.5310071105 - Garbage

July 22, 1988
Sylvia Phillips

8/4/88

QA Review - corrective actions

The Monobromobiphenyl results in the WMNB 4/28/88 were anomalous and did not agree with result of soil monitoring samples (3/31 and 4/5). I examined the standards and compared the areas of the peak II and DCB peaks.

| Spreadsheet 3/31 | | WMNB 4/1 | WMNB 4/5/88 | WMNB 4/28/88 | WMCE 4/21 | from another project |
|------------------|---------|----------|-------------|--------------|-----------|----------------------|
| Standards | peak II | DCB | peak II | DCB | peak II | DCB |
| 1) low | 64.69 | 434.37 | 101.04 | 483.98 | 104.28 | 362.6 |
| 2) middle | 129.4 | 867.12 | 170.64 | 7679.98 | 188.08 | 7223.56 |
| 3) high | 808.5 | 4689.8 | 1078.32 | 5166.7 | 1183.49 | 5200.7 |
| 4) re-injects | | | | | 1111.32 | 4526.4 |
| | | | | | | WMCE 4/15 |
| | | | | | | 86.51 |
| | | | | | | 213.82 |
| | | | | | | 4030.21 |
| | | | | | | 1021.61 |
| | | | | | | 3526.5 |

The peak II areas of 4/28 for the low and middle standard are unusually large, although the area of the high standard for peak II is normal. The DCB peak area for the low standard is also unusually large.

~~The standards~~, although the DCB areas for the middle and high standards are normal. These facts, and an inspection of the chromatograms, lead me to believe that there was baseline interference in the standard - to correct the problem I will substitute the standard of 4/21 (from another project) for calculating samples of 4/28. ~~4/21~~ is closest in time to 4/28 and the chromatogram look OK. The DCB areas in the samples and the chromatogram indicate that the interference was taking out gradually, even while the standards were running and were pretty well gone before correctly diluted samples were injected.

I also changed the standard the same way in WMCE 4/28/88.

I did not do the change because they actually made matters worse. We need to re-analyze the final oils from NB's galvan reactions.

Meanwhile the results ~~can~~ must be deleted from the report as far as Monobromobiphenyl is concerned.

~~→~~ I did not notice earlier, but some of the peak II areas in samples of 4/28 are 60x the highest standard. That alone is enough to re-run them. (more dilute)

6/15/88

R7007

Reagent Analysis Prep

Notebook
"Lab 3"

| Sample # | Cert tubet | tube# | Sample | Sample# | Volume |
|---------------------|---------------|-------|--------|---------|--------|
| R70078804250840 RRG | 15.5 | 16.7 | | 1.2 | 10 |
| R70078804250938WRG | 15.2 | 16.5 | | 1.3 | 10 |
| R70078804251000WRG | 15.1 | 20.3 | | 5.2 | 10 |
| R70078804220925RRG | 15.3 | 16.3 | | 1.0 | 10 |
| R70078804224035WRG | 15.1 | 16.6 | | 1.5 | 10 |
| R70078804221050WRG | 15.1 | 19.3 | | 4.2 | 10 |

Kim Berante
6/15/88

6/18/88

~~R7007~~⁷⁰ R7007PCB analysis P_M for Reagents & Washes

| Sample # | Vial time | Initial Spike | Samples |
|------------------|-----------|------------------|---------|
| 078804250840RRG | 9.7 | 13.6 | 3.9 |
| 078804250938WRG | 9.9 | 13.1 | 3.2 |
| 078804251000WRG | 9.7 | 12.9 | 3.2 |
| 0078804221050WRG | 9.9 | 13.4 | 3.5 |
| 078804221035WRG | 9.8 | 13.4 | 3.6 |
| 0078804220925RRG | 9.8 | 13.9 | 4.1 |
| 078806181540RT6 | 9.9 | 14.1 | 4.2 |
| 078806181550RT6 | 9.7 | 13.8 | 4.1 |

Took subsample of R7007 8804220925RT6 for Duplicate & Spike

Duplicate R70078806181540RT6
 Spike R70078806181550 RT6

Spiked sample R70078806181550 with 5ml of 500 ppm PCB


 Tom Mante
 6/18/88