Update on Hg CEMS

They're here to stay ...

Jeffrey V. Ryan ryan.jeff@epa.gov (919) 541-1437

U.S. Environmental Protection Agency
Office of Research and Development
Air Pollution Prevention and Control Division
Research Triangle Park, NC 27711, U.S.A.

OAQPS Measurement Technology Workshop 2010 December 6, 2010

Overview

- Regulatory Update
- Hg CEMS
- Sorbent trap monitoring
- Hg Emissions monitoring performance and related issues
- NIST Traceability
- Take home messages ...
- Questions



Regulatory Update

- EPA Part 60 compliance monitoring procedures promulgated as part of Portland Cement MACT amendments (75 FR 54970 9/9/2010)
 - PS12A http://www.epa.gov/ttn/emc/perfspec/ps-12A.pdf
 - Appendix F Procedure 5 (Hg CEMS continued QA/QC) http://www.epa.gov/ttn/emc/perfspec/AppFProc5.pdf
 - PS12B (Sorbent traps initial certification and continued QA/QC) http://www.epa.gov/ttn/emc/perfspec/ps-12B.pdf
- Hg CEMS and sorbent trap monitoring procedures now formally exist




Monitoring Requirements

- PS12A: Hg CEMS Performance specifications for initial certification
 - Measurement Error Test (linearity) with Hg⁰ and HgCl₂
 - 7-Day Calibration Drift Test with zero and mid-level Hg⁰
 - Relative Accuracy Test
- Appendix F Procedure 5: Continued QC/QA requirements
 - Daily Calibration Drift Assessment
 - Weekly System Integrity Check
 - Data Accuracy Assessment
 - Relative Accuracy Test Audit
 - Quarterly Gas Audit
 - Relative Accuracy Audit (alternative)
- PS12B: Sorbent Traps Performance specifications for initial certification and continued QC/QA requirements



Hg Emissions Monitoring

- Hg CEMS
- Sorbent Traps









Tekran

- 50 lpm sample extraction
- Inertial filter
- Dilution-based
- Thermal-catalytic converter located in the rack
- Pre-concentration CVAFS
- 0.001 ug/wm³ resolution
- 150 second cycle time
- Fully automated





Thermo-Scientific

- 50 lpm sample extraction
- Inertial filter
- Dilution-based
- Thermal converter located in the probe
- Real-time CVAFS
- 0.01 ug/wm³ resolution
- Fully automated



CEMTREX



- 10 lpm sample extraction
- Standard filter
- Dilution-based
- Thermal converter located in the probe
- Pre-concentration CVAAS
- 0.01 ug/wm³ resolution
- 180–360 second cycle time
- Fully automated



Hg CEMS: Where we're at ...

- ~600 sold to utilities
 - At least half installed/certified (see NESCAUM Report for breakdown) http://www.nescaum.org/documents/hg-control-and-measurement-techs-at-us-pps_201007.pdf
 - How many implementing NIST traceability program?
- Trend towards low level measurements (< 1µg/m³)
- Hg CEMS now considered for other source categories



Sorbent Trap Hg Emission Monitoring Systems

- Multiple providers and systems
 - Manual and automated
- >200 sold to utilities
 - Many installed/certified
 - Many as "backups" to Hg CEMS
- Suitable for low and high level Hg measurements
- More vulnerable to data loss (due to length of monitoring)






Hg CEMS Emission Monitoring Issues ...

- Reliability
- Low Hg concentrations
- Other source categories
 - Measurement environment
 - Dynamic range of emissions
- Status of NIST traceability
- Range of available Hg calibration gas concentrations






Percent Monitor Availability for HgCEMS Full Year Results 2009






Power Plant - Hg CEMS RATA Results Low-Level Emissions Tests








Cement Plant - Hg CEMS RATA Results Low-Level Emissions Tests



Source: Tekran



Cement Plant - Hg CEMS RATA Results Low-Level Emissions Tests




Source: Tekran



Hg Emissions Data Hg CEMS vs. Sorbent Traps

- See what you're missing ...
 - Process characterization
 - Data variability



(b) Source: NESCAUM 2010




NIST Traceability

- Certified "NIST Traceable" gas standards are needed to support regulatory applications
- EPA defines NIST Traceability
- Where possible, the certified concentration is derived from an unbroken chain of direct comparisons linked to a primary reference originating from NIST
- With collaboration from the utility industry, Hg CEM vendors and NIST, EPA has developed Interim Protocols to establish certification and continuing QA procedures for Hg⁰ and HgCl₂ gas standards



How NIST Traceability Works





Hg Calibration Gases

- NIST-traceable Hg⁰ and Hg² calibration gases now available
- Hg⁰ and Hg⁺² Interim Protocols used to establish traceability http://www.epa.gov/ttn/emc/metals/OxHgProtocol.pdf
 http://www.epa.gov/ttn/emc/metals/OxHgProtocol.pdf
- Final NIST traceability protocols expected in the next 12-18 months
- Nominal NIST-traceable Hg⁰ concentrations of 0.5 μg/m³ to 300 μg/m³ now available (NIST recently extended upper end from 45 μg/m³)
- Fundamental bias (7-10%) exists between Hg⁰ and evaporative Hg⁺² standards
 - Reason unknown (but we're still working on it)
 - Does not limit NIST traceability or regulatory use of Hg CEMs



Take Home Messages ...

- Hg CEMS are indeed ready for "prime time"
- Now being used on multiple source categories
 - Cement plants, HWIs, steel plants, power plants
- Promulgated monitoring procedures for Hg CEMS and sorbent traps now available
- NIST traceability available and functional for Hg⁰ and Hg⁺² calibration gases
- NIST traceable Hg⁰ gases available from ~0.5 μg/m³ to 300 μg/m³
- Don't underestimate the benefit of using Hg CEMS for process characterization.



Questions?

