

Continuous Ammonia Monitoring

Jim Schwab, ASRC, University at Albany, SUNY

With contributions from Eric Edgerton, ARA, Cary, NC



Additional Contributors

- Minsuk Bae, Yongquan Li, Ken Demerjian, John Spicer – ASRC
- Sara Pryor – Indiana University
- Bjarne Jensen - Danish National Environmental Research Institute
- Jian Hou, Xianliang Zhou – University at Albany School of Public Health
- Donna Kenski - LADCO

Measurement Challenges


- Low concentrations – generally near or less than 1 ppbv, except near sources
- Highly reactive – sticks to surfaces, especially those that are “wetted” or covered with water molecules
- Oxidized nitrogen species (NO , NO_2 , HNO_3 , etc.) are generally much more abundant – it can be difficult to “see” the reduced nitrogen species against this background.

Integrated Methods

- Passive Samplers
 - Tube
 - Badge
- Active Samplers
 - Denuders
 - Annular
 - Honeycomb
 - Tubular
 - Filter Packs (ACID-MODES)
 - Fabric Mesh Filters (Dennis Fitz, UCR)

Source: Eric Edgerton

Mean NH₃ at SEARCH Sites (ppb) CY 2004 – Annular Denuder Method




Continuous Methods

- Research Methods
 - Tunable Diode Laser – TDLAS
 - Wet Effusive Diffusion Denuder (WEDD)
 - Wet Scrubbing Long Path Absorption Spectrometer – WS-LOPAP
 - Wet Scrubbing IC analysis (URG AIM 9000, Dionex GP-IC?)
 - MARGA – Steam Jet Collection – IC
- Potential Routine Methods
 - Ion Mobility Spectrometer
 - Laser Acousto-Optical Detection
 - Chemiluminescence
 - SEARCH TRN
 - API Model 201E or Thermo Model 17C (1 ppb LDL)
 - AiRRmonia – ECN, Netherlands, Mechatronics Instruments, b.v.

SEARCH Continuous NH_3 Method (TRN)

- 2-channel oxidized AND reduced nitrogen chemiluminescence analyzer
- Channel 1 samples ambient air through a sodium carbonate denuder (TN), then two heated converters
- Channel 2 samples ambient air through dual sodium carbonate and citric acid denuders (TN^*), then through a single moly converter
- NH_3 operationally defined as $\text{TN}-\text{TN}^*$

Total Reduced Nitrogen (TRN) Analyzer




Total Reactive Nitrogen after Na_2CO_3 denuder

Total Oxidized Nitrogen after Na_2CO_3 and citric acid denuders

- Legend
-  1/4" 2-way NC Teflon Solenoid valve
 -  1/4" OD Heavy Wall PFA Tubing
 -  25 mm Teflon Inline Filter Pack


NH₃ and NH₄⁺ during CFPP Plume Event



NH₄⁺ increases; NH₃ disappears; NH_x conserved


SEARCH

1-minute NH₃ and WD at Yorkville



Spikes between 90 and 180 degrees suggest nearby NH₃ sources.

Local Sources of NH_3 at YRK



Method 2 - IMS


- Candidate for routine monitoring
- IMS – Ion Mobility Spectrometer (AirSentry-IMS Ammonia Analyzer, Particle Measuring Systems, Boulder, CO)
- Ionization based time-of-flight technique performed at atmospheric pressure
- Instruments are targeted to a specific molecule in a specific concentration range
- Range for this instrument: 0–300 ppb (Lab Intercomparison); 0-100 ppb (Field Deployment)
- Cost (with OBC) ~ \$26 K

Operational Details


- Requires up to 5 li/min of clean, dry instrument air (dewpoint $\leq -40^{\circ}$ C)
- Internal sample pump option
- Factory default “Smoothing Factor” (8) should be increased for minute (or longer) averaged data
- Optional “On Board Calibration” - integral permeation oven set up (recommended)
- Nickel 63 sealed radioactive source (less than .005 microcuries) – ionization source

IMS Field Data

NH₃ - PSP - Addison, NY; March 5-11, 2006



NH₃ - PSP - Addison, NY; May 7-13, 2006



Preliminary data: do not cite or quote!

Laboratory Intercomparison

- September 12-30, 2005 at ASRC
- Six measurement Methods – seven instruments in all (Chemiluminescence method not included in analysis due to “conversion problem”)
- Heated glass manifold for uniformity of sampling environment
- Synthetic air and calibration system
- “Ambient” sample for two extended periods

Pranalytica Nitrolux NH3 Analyzer



Note: Instrument used was one of the first sold by Pranalytica and company claims to have made significant improvements to later (i.e. current) instruments

**Photoacoustic spectroscopy
CO2 laser**

Low-noise microphone

In-line particle filter (40 μm)

LDL and cost depend on model

Model 1000 – LDL ~ 1 ppb;

Cost ~\$24K

Model 200 – LDL ~ 0.2 ppb;

Cost ~\$38K


Model 100 – LDL ~ 0.1 ppb;

Cost ~\$72K

Method Characteristics Tested during Intercomparison


- Response to known $[\text{NH}_3]$ – accuracy and precision of calibration
- Time Response – to step changes and “spikes”
- Comparability during ambient sampling
- Potential interferences

9/28: Zero, 5, 10, 20 ppb




Preliminary data: do not cite or quote!

9/26: 40 ppb spike from zero



Preliminary data: do not cite or quote!

9/24: Ambient Spike



Preliminary data: do not cite or quote!

Sampling and response time

- This is an important issue for gaseous ammonia measurement – it clearly affects methods detecting gaseous ammonia directly and ammonium after scrubbing.
- The TDL is the system of choice for quick and accurate response – but it is not a “routine” method!

Best Candidate Methods for Monitoring – and their Major Shortcoming(s) (Editorial Opinions!)

- ARA TRN (chemiluminescence)
 - Not ammonia specific
 - Three heated converters – difference
 - Custom implementation of proven analyzer
 - Response time?
- AirSentry IMS (Particle Measuring)
 - Response Time
- Nitrolux 200 (or 100) (Pranalytica)
 - Response Time (worst of all tested instruments, but should be better in current versions)
 - Cost – Highest of “routine monitoring” candidates (for sufficiently low LDL)

Acknowledgements

- Funding from
 - EPA
 - NYSERDA
 - NYSDEC
- Although the research described in this article has been funded in part by the U.S. Environmental Protection Agency, it has not been subjected to the Agency's required peer and policy review and therefore does not necessarily reflect the views of the Agency and no official endorsement should be inferred.