

# Approaches to Measurement of Airborne Engineered Nano-Objects

Aleksandr B. Stefaniak, Ph.D., CIH  
National Institute for Occupational Safety and Health  
Division of Respiratory Disease Studies  
Morgantown, WV 26505

304-285-6302

[AStefaniak@cdc.gov](mailto:AStefaniak@cdc.gov)

March 2, 2009



# What is “nano”? - ISO 27687:2008

- Nanoscale
  - ~ 1 nm to 100 nm
- Nano-object
  - 1 to 3 external dimensions in nanoscale
- Major categories of nano-objects
  - Nanoparticle: 3 external dimensions
  - Nanofiber: 2 external dimensions
  - Nanoplate: 1 external dimension

# Why Care about Nano-Objects?

C. Performance Dress Twills with NANO-TEX. Our Nano-Tex<sup>®</sup> finish makes spills bead up – but all you'll feel is soft 100% cotton fabric. We include an alterable waistband with Ban-Rol<sup>®</sup>, French fly, lined crotch. Button-through back pockets. Hemming is free. Machine wash. Imported. Colors, below.

## Pleated Front


<b>R</b> Regular even 30-46, odd 31-37.	04483-82K8	\$49.50
<b>L</b> Long even 34-46.	04483-92K2	\$55.00
<b>S</b> Short even 30-36.	00902-42KX	\$49.50
<b>B</b> Big even 48-52.	16602-62K8	\$59.50
<b>B&amp;T</b> Big/Tall even 48-52.	16602-72K2	\$59.50

## Plain Front (not shown)

<b>R</b> Regular even 30-46, odd 31-37.	04483-62K9	\$49.50
<b>L</b> Long even 34-44.	04483-72K3	\$55.00



# Where is the Exposure?



# Current Concerns for Nano-Objects

- Oxidative stress
- Pulmonary inflammation
- Early interstitial lung fibrosis and granulomas
- Asbestos-like pathogenicity
- Translocation from respiratory tract
  - Oxidative damage in human blood serum
  - Inflammatory and pro-clotting effects in blood

# Parameters That Could Affect Nano-object Toxicity

- Size
- Shape
- Composition
- Solubility
- Crystalline structure
- Charge
- Surface characteristic
- Attached functional groups
- Agglomeration
- Impurities

# NIOSH Nanotoxicology Summary

- Nano-objects under investigation
  - SWCNT, MWCNT, TiO<sub>2</sub>, CB, metal oxides, nanowires, and nanospheres
- Target organs
  - Lung, skin, brain, cardiovascular system
- End points
  - Inflammation, oxidant stress, fibrosis, translocation

# Risk Assessment: Ultrafine TiO<sub>2</sub>

NIOSH draft recommended exposure limits (RELs):

- 1.5 mg/m<sup>3</sup> fine TiO<sub>2</sub>
- 0.1 mg/m<sup>3</sup> ultrafine TiO<sub>2</sub>
- Reflects greater inflammation & tumor risk of ultrafine on mass basis
- [www.cdc.gov/niosh/review/peer/tio2/](http://www.cdc.gov/niosh/review/peer/tio2/)

Same message: The OEL for a material in its 'large' form may not be appropriate for the nano form

# Hazard and Risk Picture - CNTs


## Aspiration of SWCNT resulted in:

- Rapid but transient inflammation and damage
- Granulomas and fibrosis at deposition sites of large agglomerates of SWCNT
- Rapid and progressive interstitial fibrosis at deposition sites of dispersed SWCNT
- Results were verified with inhalation study

## Message:

- SWCNTs more fibrogenic than an equal mass of ultrafine carbon black or fine quartz
- Doses approximated exposure at the PEL for graphite ( $5 \text{ mg/m}^3$ ) for 20 days

**Message: The PEL for the 'large' form of a material may not be a good guide for the nano form.**



Graphics courtesy of  
Andrew  
Maynard and Anna  
Shvedova

# Parameters That Could Affect Nano-object Toxicity

- Size
- Shape
- Composition
- Solubility
- Crystalline structure
- Charge
- Surface characteristic
- Attached functional groups
- Agglomeration
- Impurities

# Existing Measurement Tools

- Condensation particle counter
- Optical particle counter
- Diffusion charger
- Aerosol photometer
- Electrostatic low pressure impactor
- Scanning electron microscope
- Wet impactor
- Wet deposition particle sizer
- NanoMCS particle surface area analyzer
- Plate cassette (25- or 37-mm)
- Electrostatic precipitator

Lack of specificity for engineered nano-objects

Lack of validation for these tools

# NIOSH Nano-Object Exposure Assessment: A Progression

- Initial screening: Baseline assessment
- Detailed investigation: Baseline as a guide to more detailed investigation
- Long-term personal exposure surveillance



# Baseline Assessment

- What has been used?
  - Particle count in conjunction with broad size information
  - Aerosol sampling
  - Elemental mass: Metals, carbon
- Has it been successful?
  - Instruments and a ‘trained eye’
  - Good for a ‘yes/no’ approach on emissions and controls
- Limitations
  - Instrument overload
  - Area versus personal monitoring

# Correlate Simple and Complex Measurements



Starting Point



TEM analysis of aerosol

Mass, size distribution,  
surface area, etc.


# Detailed Investigations

- An additional level of complexity
- Particle size distribution: by size and number
  - SMPS and ELPI
- Mass (element) by size
  - MOUDI and personal impactors

Additional metrics = less portable

# What are our Critical Needs?

- Standard protocols
  - Exposure measurement
  - Sample analysis




# Standards for Measurement

- Biologically relevant metrics
  - Mass, number, surface area, etc.
- Suitable reference materials
- Validated exposure assessment tools
  - Measurements linked to biological mechanism
- Validated protocols
  - Demonstrated accuracy and precision

# Standards for Analysis


- Analysis of airborne nano-objects
  - Preserve object in native state
  - Measure linked to tox mechanism of interest
  - Validated
- Measurement can not alter parameter being measured
  - Example 1: nano-object size
  - Example 2: nano-object surface area

# Example 1: Particle Size




**Figure 3.** Low resolution TEM images of amorphous Fe oxide particles acquired at approximately (A) 0; (B) 20; (C) 40; (D) 50; (E) 60; and (F) 120 s exposure in the 80 keV beam. Scale bar is 15.

# Example 1: Particle Size




Thickening of oxide layer results in change in particle size by  $\sim 6\text{nm}$

# Example 2: Particle Surface Area



# Summary of Needs

- Reference materials
- Tools to measure airborne nano-objects
  - Specificity: nanoscale vs nano-object
  - Biologically relevant metric
  - Personal samplers
- Standard protocols
  - Sample collection
  - Sample analysis



Titanium dioxide

The findings and conclusions in this report are those of the authors and do not necessarily represent the views of the National Institute for Occupational Safety and Health.

Mention of a specific product or company does not constitute endorsement by the National Institute for Occupational Safety and Health.