

GENERAL DIRECTIONS

All surfaces should be thoroughly cleaned before sanitizing with FS-101 solution containing 100 ppm available chlorine. If possible, parts should be submerged for two minutes or more. **DO NOT SOAK OVERNIGHT.** See Proportions of Use.

RECIRCULATION METHOD

Prepare 100 ppm available chlorine solution. Test to maintain a solution above 50 ppm available chlorine.

SPRAY METHOD

Spray all surfaces with 100 ppm available chlorine solution.

FOR BEST RESULTS

Sanitize equipment just before using. Follow the complete IBA Sanitation Program. Rinse empty container thoroughly with water and discard it.

LOCAL, STATE REGULATIONS

Where local or state regulations are in effect, consult rules of your local authorities.

Manufactured for IBA Inc., Millbury, Mass. 01527
Sanitation Division

IBA

ACCEPTED
MAR 9 1978
2405-1

FOR SANITIZING ONLY - 2% FREE AVAILABLE CHLORINE

ACTIVE INGREDIENTS

NET WEIGHT 1.000 LBS

KEEP OUT OF REACH OF CHILDREN

See this Panel For First Aid and Additional Precautions

EPA REG. NO. 690-1
EPA EST. 00401-001-1

PROPORTIONS OF USE

To prepare a 100 ppm available chlorine solution, use 1 level teaspoon per 3 gal. water or 1 oz. of FS-101 in 27 gal. water. Note: If concentrations of more than 100 ppm available chlorine solutions are used on food contact surfaces **MUST** be thoroughly rinsed with terminal potable water supply before equipment is used for food storage or transport.

STORAGE & DISPOSAL

Keep container closed when not in use. Do not reuse container. Discard in trash.

DANGER

Corrosive. Causes eye and skin damage. Do Not get in eyes, on skin, or on clothing. Wear goggles or face shield and rubber gloves when handling. Harmful or fatal if swallowed.

Do Not mix FS-101 with acid type detergents or household cleaners.

FIRST AID

Internally food: head soaked in milk followed by drink or cooking oil. Call a physician. In case of contact, remove excess material and flush skin or eye with cold water for at least 15 minutes. For eye contact, merck attention. Clean contaminated clothing before reuse.