

INSTANT CLEAN

CLEAN WATER MAKER

ACTIVE INGREDIENT:

Metallic Silver 1.05%

INERT INGREDIENT:

Activated Carbon 98.95%

CAUTION:

Keep Out of Reach of Children

CAUTION:

Connect to cold water tap only

Net Contents:

1 Clean Water Maker Unit

Water Safe Products, Inc.


913-888-8373

8337 Nieman Road
Lenexa, Kansas 66214

Dispose of this container by wrapping
in newspaper and placing in trash.

Directions: Read the enclosed literature
for installation, operating instructions
and preventive maintenance.

EPA Reg. No. 37756-1
EPA Est. No. 37756-KS-1
U.S. Pat. Pend.



ACCEPTED
37756

37756



37756

ACCESSORY KIT AK-200

Under Counter Installation

This accessory kit was designed for added convenience and easy installation of your Instant Clean™, Clean Water Maker.

Please Follow All Instructions





Step One:

You may install your convenience tap by removing the spray attachment from your sink, or utilizing the hole provided for the spray attachment...or select another location and drilling a 7/16" hole in your sink top.

Caution: Drilling porcelain sinks, use a carbide drill to minimize chipping around the hole; also use a carbide drill for stainless steel sinks.

Caution: Before drilling be sure you select a spot with access to the bottom for ease of installation.



Step Two:

Install saddle valve as follows:

1. Back needle out by turning handle counter clockwise until it stops. Make certain the waprene washer is in place.
2. Position both halves of the valve on the tubing using proper inserts--replace Phillips screws and tighten evenly.
3. Place 1/4" compression nut on tube - threaded end out. Slip bushing on tube, insert end of tube into valve and tighten compression nut onto port.
4. Turn needle stem clockwise until it stops. This will puncture the tubing and seal the puncture.
5. To commence flow, open valve by turning stem counter clockwise. Position of stem regulates flow.

Caution: Do not open valve until Instant Clean TM , Clean Water Maker is installed.

Step Three:

Connect the tube from the saddle valve to the "Fail Safe" sediment cleaner --

Connect tube from "Fail Safe" to center fitting on Instant Clean TM , Clean Water Maker.

(Be sure to install safety locks on both fittings.)

Step Four:

Connect tube from 2nd fitting on Instant Clean TM , Clean Water Maker to convenience tap (see illustration for connection.)

Optional: You may want to purchase a "Tee Fitting" and install it in the line from your Instant Clean TM , Clean Water Maker to your convenience tap -- this will allow you to direct "Treated Water" to your ice maker or refrigerator (see illustration.)

Step Five:

Place the convenience in the "up" and "on" locked position - and then turn on the saddle valve.

Note: You will notice air coming from your convenience tap while the Instant Clean TM , Clean Water Maker is being filled with water; and then you will see dark water coming from your convenience tap. Let the water flow for 10 minutes before using. This running time clears up the sediment from shipping.

Step Six:

Check for leaks - tighten accordingly and go back over installation instructions.

Preventive Maintenance

The sediment trapped in your "Fail Safe" could slow down the water flow from your convenience faucet and also filter through and "clog" the primary sediment screen on your Instant Clean TM , Clean Water Maker. To prevent this, from time to time do as follows:

1. Open convenience tap to "on" locked position.
2. Turn off saddle valve.
3. Remove "Fail Safe" and clean away sediment by running under water in opposite direction of flow.
4. Switch tubes on bottom of Instant Clean TM , Clean Water Maker and turn on saddle valve for 10 minutes - this will "back flush" and remove any sediment on primary screen.

Caution: Do not use this water.

5. Be sure to reconnect tubes after "back flushing."

INSTANT CLEAN TM, "CLEAN WATER MAKER"

MODEL BAC-1

Installation and Operating Instructions

"General Classification"

"It is a violation of Federal law to use this product in a manner inconsistent with its labeling."

Instant Clean TM, Clean Water Maker, was engineered and designed for home use on cold, municipal tap water outlets as the "final filter" at a flow rate of 0.4 gallon per minute. This unit has been thoroughly tested for a 6,000 gallonage volume to provide better-tasting, crystal clear tap water for drinking and cooking. Depending on the clarity and quality of the water input, a 5 gallon supply of tap water may be processed daily for 3 years, but not limited to only 5 gallons per day. This product is a Bacteriostatic Treatment Unit and as such, is only to be recommended for use on municipally treated water.

In order for you and your loved ones to receive the maximum benefits of this new appliance, please follow all instructions.

Step One:

Remove the aerator from your faucet.

Note: If you have a portable dishwasher, simply install a quick disconnect to your new Instant Clean TM, Clean Water Maker diverter valve. Then you can use either unit at your convenience.

Step Two:

Select the proper sized adaptor (if needed) to fit your faucet.

Step Three:

Screw the Instant Clean TM, Clean Water Maker diverter valve, with proper washers and adaptors (if needed) finger-tight on your faucet - using caution in starting threads even and not forcing or cross-threading. Position the dial so it is facing the front of your faucet.

Step Four:

Connect the dual tubing by forcing over the high spots on the two fittings on the bottom of your Instant Clean TM, Clean Water Maker.

Note: If you place the ends of the tubing under hot water for a few seconds, they will be more pliable and easier to install.

Step Five:

Place the "Instant Clean TM, Clean Water Maker" in your selected location on either side of your sink and bring the tubing to the Instant Clean TM, Clean Water Maker diverter valve as indicated in the drawing.


Note: You can shorten tubing by cutting with a scissors.

Step Six:

Caution: Be sure to connect the hoses correctly.

Turn the diverter valve about a quarter turn to facilitate installing the tubing. Locate the tube that is connected to the center of your Instant Clean TM, Clean Water Maker and connect to the top fitting on your diverter valve by forcing over the high spot on the fitting (again you can place hose ends under hot water for easier installation.)

Connect second tube to bottom fitting on diverter valve.



Step Seven:

Turn the valve selector to the "on" position and then slowly turn on the "cold" water.

Caution: Use only cold tap water with this unit.

You will notice air coming from your valve outlet while the unit is being filled, and then you will notice dark water coming out of your valve. Let the water run for about 15 minutes and increase the water pressure during this time. The water will clear up after the sediment from shipping has been removed.

You are now ready to experience "Instant Clean TM, Clean Water Maker. Water... and everything made with water...will taste better!

Step Eight:

Check for leaks:

1. If hose leaks at fitting merely push tubing all the way onto the fitting.
2. If the valve leaks, you may have to tighten the valve on the faucet (by hand and cautiously only). If valve continues to leak, check to make sure washers have been installed and that they haven't slipped out of place.

Preventive Maintenance

From time to time you can clean the "screen washer" of sediment. This can be accomplished by disconnecting the hoses on the diverter valve and unscrewing the valve from your faucet, remove the screen for cleaning. By holding the screen under your faucet for a few seconds the sediment can be washed away.

When reinstalling your valve, follow all previous installation instructions except reversing the tubing on your diverter valve allowing your Instant Clean TM, Clean Water Maker to be back-washed of any sediment that may have passed by the screen washer. Place valve in the "on" position and let water run through for 5-10 minutes. (Caution: Do Not Use This Water.) Be sure to reconnect the tubing as instructed in the installation directions before using water for consumption.

Warranty

The Instant Clean TM, Clean Water Maker, valve and tubing are warranted for one year from purchase date for defective material and/or workmanship. The Instant Clean TM, Clean Water Maker, valve and tubing must be sent to Water Safe Products, Inc., 8337 Nieman Road, Lenexa, Kansas 66214, postpaid. After inspection, if unit is found to be defective and free of misuse or abuse, it will be repaired or replaced and returned postage prepaid. Proof of sales date and owner's name and address must accompany unit. If the unit, valve, and tubing don't qualify under this warranty, the unit, valve, and tubing will be shipped collect to the sender.

Optional Under Counter Installation Kit AK-200

An accessory kit lets any do-it-yourselfer install Instant Clean TM, Clean Water Maker permanently under the sink. It then has its own convenient clean water faucet.

\$19.95

WATER SAFE PRODUCTS, INC.
8337 Nieman Road
Lenexa, Kansas 66214 (913) 888-8373

EPA Reg. No. 37756-1

EPA Est. No. 37756-KS-1