

Basement Construction

(1) Treat the soil adjacent to the outside foundation wall by trenching or ridding to the top of the footing at a rate of 4 gallons of 1% emulsion (1 pint BONIDE CHLORDANE 74% E in 10 gals. water for a 1% emulsion) per 10 linear feet per 1 foot of depth. Treat the soil as it is returned to the trench and cover it with a thin layer of untreated soil.

(2) Treat under the basement floor and around sewer pipes, conduits and piers. Holes can be drilled through the floor along the inside perimeter and interior walls. Drill 6 inches from the wall and about 1 foot apart. Inject 1% emulsion (1 pint BONIDE CHLORDANE 74% E in 10 gals. water for a 1% emulsion) through the holes at the rate of at least 4 gallons per 10 linear feet of wall. Avoid drilling into plumbing or electrical conduits.

(3) Treat voids in hollow-block foundations as described in slab-on-ground construction.

"Avoid contamination of public and private water supplies by following these precautions. Use anti-back-flow siphonage equipment. Refer to federal (Federal Housing Administration), state, and local specifications for safe distances of treatment areas from wells. Soil in the vicinity of wells should not be treated if it is water saturated, or by injecting the solution under pressure. Soil should be removed to an area safe from well contamination, treated, and returned to the trench which has been lined with plastic sheeting."

Buyer's Guarantee Limited to Label Claims and Refund of Purchase Price.

MFG. by BONIDE CHEMICAL CO., INC., YORKVILLE, N.Y. 13495

