



ROXIDE

1 L. CHLORDANE E
(Termites - PCO)

FOR TERMITE CONTROL BY PCO's
IN EXISTING BUILDINGS

EPA EST. NO. 4-NY-1 EPA REG. NO. 4-275

ACTIVE INGREDIENTS:

Technical Chlordane*..... 45.4%
Kerosene..... 48.0%

INERT INGREDIENTS:..... 6.6%

*Equivalent to 27.2% Octachloro-4,7-methanotetrahydroindane
and 18.2% related compounds. Contains 4 lbs. Chlordane per gal.

KEEP OUT OF REACH OF CHILDREN

CAUTION

ANTIDOTE

STATEMENT OF PRACTICAL TREATMENT

If swallowed - Drink one or two glasses of water and induce vomiting
by touching back of throat with finger. Do not induce vomiting or
give anything by mouth to an unconscious person. Get medical atten-
tion immediately.

If inhaled - Remove victim to fresh air and apply respiration if
indicated.

If on skin - Wash promptly with soap and water. Rinse thoroughly.

If in eyes - Rinse eyes for at least 15 minutes with water and call
a physician immediately.

5 Gal.

90

4 LB. CHLORDANE E
(Termites - PCO)
EPA Reg. No. 4-275

FRONT PANEL
(Cont'd)
Page 2

PRECAUTIONARY STATEMENTS

HAZARDS TO HUMANS & DOMESTIC ANIMALS

Harmful if swallowed. Contact with skin can cause toxic symptoms. In case of contact with skin, wash with soap and water. Avoid breathing spray mist. Avoid contamination of feed and foodstuffs. Do not use on humans or household pets or near uncovered fish bowls or pools. Keep children and pets off treated areas until material has been thoroughly soaked into soil and area has dried.

ENVIRONMENTAL HAZARDS

This product is toxic to fish, birds, and other wildlife. Birds feeding on treated areas may be killed. Keep out of lakes, streams and ponds. Do not apply where runoff is likely to occur. Do not apply when weather favors drift from treated areas. Do not contaminate water by cleaning of equipment or disposal of wastes. Apply this product only as specified on this label.

PHYSICAL OR CHEMICAL HAZARDS

Do not use, pour, spill, or store near heat or open flame.

DIRECTIONS FOR USE

It is a violation of federal law to use this product in a manner inconsistent with its labeling.

STORAGE AND DISPOSAL

1. Prohibitions - Do not contaminate water, food, or feed by storage or disposal. Open dumping is prohibited. Do not reuse empty container. 2. Pesticide Disposal - Pesticide, spray mixture, or rinsate that cannot be used or chemically reprocessed should be disposed of in a landfill approved for pesticides or buried in a safe place away from water supplies. 3. Container Disposal - Triple rinse (or equivalent) and dispose of in an approved landfill or bury in a safe place. 4. General - Consult Federal, state or local disposal authorities for approved alternative procedures.

BONIDE 4 LB. CHLORDANE E
(Termites - PCO)
EPA Reg. No. 4-275

BACK PANEL
Page 1

BONIDE 4 LB. CHLORDANE E (TERMITES - PCO)

DIRECTIONS FOR USE (Continued)

SUBTERRANEAN TERMITES

TERMITE CONTROL IN EXISTING BUILDINGS

Slab-on-ground Construction

(1) Infestations in this type of construction are difficult to control. One method is to drill holes about 6 inches from the wall and about one foot apart through the concrete slab, adjacent to all cracks and expansion joints, and injecting the chemical into the soil beneath the slab. Avoid drilling into air ducts, plumbing and electrical conduits. Another method is to drill through the foundation walls from the outside and force the chemical just beneath the slab along the cracks and expansion joints. A 1% emulsion (2 2/3 oz. or 5 1/3 tbsp. per gal. of water for a 1% emulsion) should be applied at the rate of at least 4 gallons per 10 linear feet of foundation or expansion joint.

(2) Dig a trench 1 foot in depth, but not below the top of the footing, along the outside of the foundation walls. Apply a 1% emulsion (2 2/3 oz. or 5 1/3 tbsp. per gal. of water for a 1% emulsion) at the rate of 4 gallons per 10 linear feet of trench. The chemical should be mixed with the soil as it is being replaced in the trench. Treated soil should be covered with a thin layer of untreated soil.

(3) Treat voids in hollow-block foundations at the rate of 2 gallons of 1% emulsion (2 2/3 oz. or 5 1/3 tbsp. per gal. of water for a 1% emulsion) per 10 linear feet of wall so that the emulsion will reach the footing. Do this by drilling or probing. Avoid drilling into plumbing, heating or electrical conduits.

Crawl-space Construction

(1) Dig a trench or rod adjacent to and around all piers and pipes and along both sides of the foundation walls. Dig the trench or rod to, but not below the top of the footing. However, poured concrete foundations may be trenched only 3-4 inches deep. Treat the soil at the rate of 4 gallons of 1% emulsion (2 2/3 oz. or 5 1/3 tbsp. per gal. of water for a 1% emulsion) per 10 linear feet per 1 foot of depth. Cover the treated soil with a thin layer of untreated soil.

(2) Treat voids in hollow-block foundations as described in slab-on-ground construction.

Basement Construction

(1) Treat the soil adjacent to the outside foundation wall by trenching or rodding to the top of the footing at a rate of 4 gallons of 1% emulsion (2 2/3 oz. or 5 1/3 tbsp. per gal. of water for a 1% emulsion) per 10 linear feet per 1 foot of depth. Treat the soil as it is returned to the trench and cover it with a thin layer of untreated soil.

(2) Treat under the basement flooring and around sewer pipes, conduits and piers. Holes can be drilled through the floor along the inside perimeter and interior walls. Drill 6 inches from the wall and about 1 foot apart. Inject 1% emulsion (2 2/3 oz. or 5 1/3 tbsp. per gal. of water for a 1% emulsion) through the holes at the rate of at least 4 gallons per 10 linear feet of wall. Avoid drilling into plumbing or electrical conduits.

(3) Treat voids in hollow-block foundations as described in slab-on-ground construction.

"Avoid contamination of public and private water supplies by following these precautions. Use anti-back-flow siphonage equipment. Refer to federal (Federal Housing Administration), state, and local specifications for safe distances of treatment areas from wells. Soil in the vicinity of wells should not be treated if it is water saturated, or by injecting the solution under pressure. Soil should be removed to an area safe from well contamination, treated, and returned to the trench which has been lined with plastic sheeing."

Buyer's Guarantee Limited to Label Claims and Refund of Purchase Price.

MFG. by BONIDE CHEMICAL CO., INC., YORKVILLE, N.Y. 13495

