

Basement Construction

(1) Treat along the exterior and interior walls of foundations, around piers, plumbing and conduits as described above for crawl-space construction.

(2) Prior to the laying of slabs and the basement floor treat the soil as described for slab-on-ground construction.

(3) Treat all voids in hollow-block foundation as described in slab-on-ground construction.

Note: If concrete slabs cannot be poured over soil treated the same day, a waterproof cover, such as polyethylene sheeting should be placed over the soil. However, this is not necessary if foundation cinder blocks or bricks surrounding the treated area have already been installed.

"Avoid contamination of public and private water supplies by following these precautions. Use anti-back-flow siphonage equipment. Refer to federal (Federal Housing Administration), state and local specifications for safe distances of treatment areas from wells. Soil in the vicinity of wells should not be treated if it is water saturated, or by injecting the solution under pressure. Soil should be removed to an area safe from well contamination, treated, and returned to the trench which has been lined with plastic sheeting."

Buyer's Guarantee Limited to Label Claims and Refund of Purchase Price.

MFG. by BONIDE CHEMICAL CO., INC., YORKVILLE, OCTY. 7 1985

**ACCEPTED**

Under the Federal Insecticide, Fungicide, and Rodenticide Act, as amended, for the pesticide registered under EPA Reg. No. 4-286