748-296 9/16/2003 Page 1217

SEP 16 2003

Donna L. Butler PPG Industries, Inc. One PPG Place - 8 North Pittsburgh, PA. 15272

SUBJECT: June 13, 2003 Amendment Application

PPG 70 Cal Hypo Granules EPA Registration 748-296

Dear Ms. Butler:

The labeling referred to above, submitted in connection with registration under the Federal Insecticide, Fungicide, and Rodenticide Act, as amended, is acceptable with the following conditions:

Your First Aid statement must be rewritten in the following order: Eyes, Skin, Swallowed, Inhaled. The first two lines after the First Aid heading pertaining to emergency phone assistance must be removed from the beginning and placed at the end.

Delete the word Interim from National Primary Drinking Water Regulations on page 3

Make Heading for Public Wells bold under Directions For Use on page 3.

Fix typos on page 4 and page 5.

Also, fix typos in the appended instructions which were taken from the 1986 Standard which is not part of your label and will be filed with the PPG brochure which was not reviewed.

A copy of your conditionally approved stamped label is enclosed. You must submit a finished clean copy to this Office for our files. If you have any questions regarding this letter, please contact Tom Luminello of my staff at (703) 308-8075.

Sincerely yours.

Robert S. Brennis

Product Manager (32)

Regulatory Management Branch II Antimicrobial Division (7510-C)

## PPG 70 CAL HYPO GRANULES

Dry Chlorinating Granules
for Swimming Pools or Industrial Applications
Bactericide – Algaecide
Water Treating Agent – Bleach – Sanitizer
Lowest Residue – Fast Dissolving

EPA Reg. No. 748-296 EPA Est. No. 748-WV-1

Minimum 70% Available Chlorine

# KEEP OUT OF REACH OF CHILDREN DANGER

Do not mix with other chemicals.

Do not add water to product – Add product to water

See additional precautionary statements on back label.

FIRST AID: Contact 1-304-843-1300 or your poison control center for 24-hour emergency medical treatment information. Have the product container or label with you when calling a poison control center or doctor, or going for treatment/If on skin or clothing, take off contaminated clothing. Rinse skin immediately with plenty of water for 15-20 minutes. Call a poison control center or doctor for treatment advice. If in eyes, hold eye open and rinse slowly and gently with water for 15-20 minutes. Remove contact lenses, if present, after the first 5 minutes, then continue rinsing eye. Call a poison control center or doctor for treatment advice. If inhaled, move person to fresh air. If person is not breathing, call 911 or an ambulance, then give artificial respiration, preferably by mouth-to-mouth, if possible. Call a poison control center or doctor for further treatment advice. If swallowed, call poison control center or doctor immediately for treatment advice. Have person sip a glass of water if able to swallow. Do not induce vomiting unless told to do so by the poison control center or doctor. Do not give anything by mouth to an unconscious person. Note to physician, probable mucosal damage may contraindicate the use of gastric lavage.

Manufactured by
PG INDUSTRIES, INC.
One PPG Place
Pittsburgh, PA 15272
Emergency Telephone Number: 1-304-843-1300

NET WT. 100 lbs.

6/13/03 EPA update draft

ACCEPTED WITH COMMENTS In EPALetter Doted

# PRECAUTIONARY STATEMENTS HAZARDS TO HUMANS AND DOMESTIC ANIMALS -

**DANGER** - Highly Corrosive. Causes irreversible eye and skin damage. Do not get in eyes, on skin, or on clothing. Wear goggles or face shield and rubber gloves when handling. Wash thoroughly with soap and water after handling and before eating, drinking, chewing gum, or using tobacco. Remove and wash contaminated clothing and shoes before reuse. May be Fatal if swallowed. Irritating to Nose and Throat. Avoid breathing dust.

**ENVIRONMENTAL HAZARDS**: This pesticide is toxic to fish and aquatic organisms. Do not discharge effluent containing this product into lakes, streams, ponds, estuaries, oceans or other waters unless in accordance with the requirements of a National Pollutant Discharge Elimination System (NPDES) permit and the permitting authority has been notified in writing prior to discharge. Do not discharge effluent containing this product to sewer systems without previously notifying the sewage treatment plant authority. For guidance contact your State Water Board or Regional Office of the EPA.

PHYSICAL AND CHEMICAL HAZARDS: Strong oxidizing agent! Mix only with water. Never add water to product. Always add product to large quantities of water. Use only a clean, dry utensil made of metal or plastic each time product is taken from the container. Do not mix with any other chemicals. Do not add this product to any dispensing device containing remnants of any other product. Such use may cause violent reaction leading to fire or explosion. Contamination with moisture, acids, organic matter, other chemicals, or easily combustible materials such as petroleum or paint products may start a chemical reaction with generation of heat, liberation of hazardous gases and possible generation of a fire or explosion. In case of contamination or decomposition, do not reseal container. If possible isolate container in open air or well-ventilated area. Flood with large volumes of water, if necessary.

STORAGE AND DISPOSAL: Keep in original container in a cool, dry, well-ventilated place. Keep container closed when not in use. Keep away from heat sources, sparks, open flames and lighted tobacco products. Container Disposal - Do not reuse container. Residual material remaining in empty container can react to cause fire. Thoroughly flush empty container with water then destroy by placing in trash collection. Pesticide Disposal - Wastes resulting from the use of this product may be disposed of on site or at an approved waste disposal facility. Do not contaminate water, food, or feed by storage or disposal. In Case of Fire - Drench with water. Calcium hypochlorite supplies oxygen; therefore, attempts to smother fire with a wet blanket, carbon dioxide, or a dry chemical extinguisher are ineffective. In Case of Spill or Leak - Use extreme caution. Contamination may cause fire or violent reaction. If fire or reaction occurs in area of spill, douse with plenty of water. Otherwise sweep up spilled material, using a clean, dry shovel and broom and dissolve spilled material in water. Then immediately use solution as directed.

## HANDY REFERENCE GUIDE FOR SOLUTIONS:

- \* 1 lb. (16 ounces) of calcium hypochlorite in 80,000 gallons of water is 1 ppm available chlorine.
- \* 1.25 lbs. (20 ounces) of calcium hypochlorite in 100 gallons of water is 1,000 ppm available chlorine.
- \* 6.25 lbs. (100 ounces) of calcium hypochlorite in 50 gallons of water is a 1% solution (10,000 ppm available chlorine).

(1 ounce of calcium hypochlorite equals approximately 2 level tablespoons)

# [SWIMMING POOL USE DIRECTIONS:]

**DIRECTIONS FOR USE**: It is a violation of Federal law to use this product in a manner inconsistent with its labeling.

Calcium Hypochlorite is a dry granular material in free flowing form that contains a minimum of 70% available chlorine. It provides a rapid source of a chlorine containing disinfectant that protects the pool against the growth of bacteria and algae to help keep the pool in a sanitary condition.

HOW TO APPLY: This product is best added to the pool as a solution. Predissolve the required quantity of this product in a plastic pail using 1 gallon of water to dissolve every 2 ounces (4 level tbsp.). NOTE: Never add water to product. Always add product to large quantities of water. Allow the mixture to settle and decant off the clear solution into a plastic sprinkling can and use the clear solution for treatment. Calcium Hypochlorite may also be added to the pool by broadcasting the dry granules over the pool water surface. No one should be in the pool when chemicals are being added.

## **REGULAR TREATMENT FOR POOLS IN USE:**

Maintain pool water parameters in the ranges recommended below or at levels required by location regulations. Obtain and make use of a pool test kit to measure pH, free chlorine residual, total alkalinity, water hardness, and cyanuric acid concentration.

Parameter	Test Frequency	Recommended Level
pH	Daily	7.2 to 7.6
Free Chlorine Residual	Daily	1 to 3 ppm in unstabilized pools.
		2 to 4 ppm minimum in stabilized pools.
Total Alkalinity as CaCO <sub>3</sub>	Weekly	60-120 ppm
Stabilizer (Cyanuric Acid)	Monthly	20 to 50 ppm
Water Hardness as CaCO <sub>3</sub>	Monthly	200 ppm minimum

[or instead of the above paragraph and table, use the following paragraph form on smaller packages: Maintain pool water parameters as follows: adjust pH to 7.2-7 6, free chlorine residual 1-4 ppm, total alkalinity 60-120 ppm, stabilizer 20-50 ppm, and water hardness at 200 ppm minimum. Obtain and make use of a pool test kit to measure the levels. ]

Initial Chlorination: Begin operation of your recirculation equipment. Superchlorinate the pool following the directions given below for superchlorination. Wait at least 4 hours, preferably overnight, then vacuum the pool bottom. Determine the free chlorine residual using your test kit. If no residual is found, superchlorinate again. Wait 30 minutes then retest. Repeat the treatment until a minimum of 1.5 ppm (parts per million) free chlorine residual has been established. Do not enter the water until the free chlorine residual is 4.0 ppm or less. Make certain the pool water parameters listed above are in their proper ranges.

Routine Chlorination: The pH, total alkalinity, water hardness, and stabilizer concentration should be maintained at values recommended in the prior table. Subsequently, add 3-4 ounces of this product (1-2 ounces in stabilized pools) per 5,000 gallons of water daily or as often as needed to maintain the desired free chlorine residual whether the pool is in use or not. Actual dosages of this product required to maintain the desired free chlorine residual will vary with sunlight, water temperature, bathing load, stabilizer concentration, water balance, and other factors. Use a test kit frequently to determine and maintain the proper free chlorine residual. For small changes in free chlorine residual once a free chlorine residual is detected, the addition of 1 ounce (2 level tbsp.) of this product to 5,000 gallons of water will raise the free chlorine residual approximately 1.0 ppm.

# ADDITIONAL HELPFUL HINTS IN SWIMMING POOL CARE:

**Superchlorination:** Superchlorination is recommended to combat the growth of algae and other microorganisms and to destroy unfiltered organic contamination that could build up in the pool water. Adjust pH between 7.2 and 7.4 prior to superchlorinating. Add 5 oz. of Calcium Hypochlorite to every 5,000 gallons of water. **NOTE: Never add water to product. Always add product to large quantities of water.** Maintain operation of your pump and filter. Treatment should be done at night or during a period when the pool is not in use. Superchlorinate at least once per week during period of heavy use or when water temperatures are above 80°F and once every two weeks in residential pools receiving normal usage. Do not enter the pool until the free chlorine residual has dropped to 4.0 ppm or less.

Shock Treatment: Shocking is recommended when certain pool water quality problems such as visible signs of algae growth, noxious odors or other unusual water quality problems develop. Adjust pH between 7.2 and (7.4) prior to shocking. Add 10 oz. of Calcium Hypochlorite to every 5,000 gallons of water. Maintain operation of your pump of and filter. Treatment should be done at night or during a period when the pool is not in use. Do not enter the pool until the free chlorine residual has dropped to 4.0 ppm or less as measured using your test kit.

Proper Water Balance and Use of Stabilizer: Maintaining the proper pH, total alkalinity, and water hardness is necessary to obtain proper water balance, and help avoid problems such as cloudy water, scaling, corrosion and swimmer discomfort. Stabilizer (cyanuric acid) slows down the rate at which chlorine is destroyed by sunlight. Follow carefully the directions given with the product when using a stabilizer. Kits for testing free chlorine, pH, total alkalinity, water hardness, and cyanuric acid concentration are an integral part of a proper program for controlling the quality of your pool water. The kits are inexpensive and available from most pool chemical dealers.

## How to Determine the Capacity of Your Pool:

First:

Approximate the average depth in feet by adding the depth at the deep end to the

depth at the shallow end and divide the total by two.

Then:

For rectangular or square pools: Multiply length (ft) x width (ft) x average depth

(ft)  $\times$  7.5 = capacity of pool in gallons.

For circular pools: Multiply diameter (ft) x diameter (ft) x average depth (ft)  $\times 5.9 =$ 

capacity of pool in gallons.

For oval pools: Multiply long axis (ft) x short axis (ft) x average depth (ft) x 5.9 =

capacity of pool in gallons.

NOTE:

If pool has sloping sides, multiply total gallons calculated by 0.85 to arrive at the capacity of your

pool.

### **OTHER USES:**

Calcium Hypochlorite is also used in the sanitization of water systems, municipal water mains, sewage and industrial waste treatment, pulp bleaching, sanitization in the food industry, restaurants, dairies, and hospitals, odor and taste control in potable water systems, algae control in industrial cooling water systems, and general industrial sanitizations. For specific literature on these and other accepted uses, write to the address on the front label.

# [INDUSTRIAL USE DIRECTIONS:]

**DIRECTIONS FOR USE**: It is a violation of Federal law to use this product in a manner inconsistent with its labeling.

# **DISINFECTION OF DRINKING WATER (Potable Water):**

**PUBLIC SYSTEMS:** Mix a ratio of 1 ounce of this product to 6,000 gallons of water. Begin feeding this solution with a hypochlorinator until a free available chlorine residual of at least 0.2 ppm and no more than 0.6 ppm is attained throughout the distribution system. Check water frequently with a chlorine test kit. Bacteriological sampling must be conducted at a frequency no less than that prescribed by the National Interim Primary Drinking Water Regulations. Contact your local Health Department for further details.

## INDIVIDUAL WATER SYSTEMS:

**Dug Wells** - Upon completion of the casing (lining) wash the interior of the casing (lining) with a 100 ppm available chlorine solution using a stiff brush. This solution can be made by thoroughly mixing 1 ounce of this product into 40 gallons of water. After covering the well, pour the sanitizing solution into the well through both the pipe sleeve opening and the pipeline. Wash the exterior of the pump cylinder also with the sanitizing solution. Start pump and pump water until strong odor of chlorine in water is noted. Stop pump and wait at least 24 hours. After 24 hours flush well until all traces of chlorine have been removed from the water. Contact your local Health Department for further details.

**Drilled, Driven & Bored Wells** - Run pump until water is as free from turbidity as possible. Pour a 100 ppm available chlorine sanitizing solution into the well. This solution can be made by thoroughly mixing 1 ounce of this product into 40 gallons of water. Add 5 to 10 gallons of clean, chlorinated water to the well in order to force the sanitizer into the rock formation. Wash the exterior of pump cylinder with the sanitizer. Drop pipeline into well, start pump and pump water until strong odor of chlorine in water is noted. Stop pump and wait at least 24 hours. After 24 hours flush well until all traces of chlorine have been removed from the water. Deep wells with high water levels may necessitate the use of special methods for introduction of the sanitizer into the well. Consult your local Health Department for further details.

Flowing Artesian Wells - Artesian wells generally do not require disinfection. If analyses indicate persistent contamination, the well should be disinfected. Consult your local Health Department for further details.

**EMERGENCY DISINFECTION:** When boiling of water for 1 minute is not practical, water can be made potable by using this product. Prior to addition of the sanitizer, remove all suspended material by filtration or by allowing it to settle to the bottom. Decant the clarified, contaminated water to a clean container and add 1 grain of this product to 1 gallon of water. One grain is approximately the size of the letter "O" in this sentence. Allow the treated water to stand for 30 minutes. Properly treated water should have a slight chlorine odor, if not, repeat dosage and allow the water to stand an additional 15 minutes. The treated water can then be made palatable by pouring it between clean containers for several times.

## **PUBLIC WATER SYSTEMS:**

**Reservoirs – Algae Control –** Hypochlorinate streams feeding the reservoir. Suitable feeding points should be selected on each stream at least 50 yards upstream from the points of entry into the reservoir.

Mains – Thoroughly flush section to be sanitized by discharging from hydrants. Permit a water flow of at least 2.5 feet per minute to continue under pressure while injecting this product by means of a hypochiorinator. Stop water flow when a chlorine residual test of 50 ppm is obtained at the low pressure end of the new main section after a 24 hour retention time. When chlorination is completed, the system must be flushed free of all heavily chlorinated water.

5

SEP 162003

New Tanks, Basins, etc. – Remove all physical soil from surfaces. Place 4 ounces of this product for each 5 cubic feet of working capacity (500 ppm available chlorine). Fill to working capacity and allow to stand for at least 4 hours. Drain and flush with potable water and return to surface.

**New Filter Sand** – Apply 16 ounces of this product for each 150 to 200 cubic feet of sand. The action of the product dissolving as the water passes through the bed will aid in sanitizing the new sand.

New Wells – Flush the casing with a 50 ppm available chlorine solution of water containing 1 ounce of this product for each 100 gallons of water. The solution should be pumped or fed by gravity into the well after thorough mixing with agitation. The well should stand for several hours or overnight under chlorination. It may then be pumped until a representative raw water sample is obtained. Bacterial examination of the water will indicate whether further treatment is necessary.

**Existing Equipment** – Remove equipment from service, thoroughly clean surfaces of all physical soil. Sanitize by placing 4 ounces of this product for each 5 cubic feet capacity (approximately 500 ppm available chlorine). Fill to working capacity and let stand at least 4 hours. Drain and place in service. If the previous treatment is not practical, surfaces may be sprayed with a solution containing 1 ounce of this product for each 5 gallons of water (approximately 1,000 ppm available chlorine). After drying, flush with water and return to service.

### **OTHER USES:**

Calcium Hypochlorite is approved for use in a broad range of industrial, municipal, and institutional applications, including those listed below. For specific literature on these and other accepted uses, please write to the address on the front of the label.

## Water Systems:

- Emergency Disinfection of Water Systems after Floods, Fires, Droughts, and Water Main Breaks
- Sewage and Wastewater Effluent Treatment
- \* Sewage and Wastewater Treatment
- Cooling Tower/Evaporative Condenser Water Treatment
- Pulp and Paper Mill Process Water System
- Swimming Pool Water Disinfection
- Disinfection of Spas, Hot-Tubs, Immersion Tanks, etc.

### Surfaces:

- Sanitization of Nonporous Food Contact Surfaces
- Sanitization of Porous Food Contact Surfaces
- Sanitization of Nonporous Non-Food Contact Surfaces
- Disinfection of Nonporous Non-Food Contact Surfaces
- Sanitization of Porous Non-Food Contact Surfaces

## Food and Agricultural:

- \* Farm Premises
- \* Agricultural Uses (post-harvest protection of potatoes and roots, bee cells and boards, food egg cleaning, fruit and vegetable washing, seeds, and mushrooms)
- \* Aquacultural Uses (fish ponds and equipment, Maine lobster ponds, conditioning live oysters, control of scavengers in fish hatchery ponds)
- Food Processing Plants

## Miscellaneous

- Laundry Sanitizers (household and commercial)
- Sanitization of Dialysis Machines
- Asphalt of Wood Roofs and Sidings
- Boat Bottoms
- \* Artificial Sand Beaches

ACCEPTED

TO COMMENTS

Letter Dated:

SEP 16 2003

Carling Bar, Ma.

Carlotte and the second

**SWIMMING POOL WATER DISINFECTION:** 

Swimming Pools: For a new pool or spring start-up, superchlorinate with 10 to 20 ounces of product for each 10,000 gallons of water to yield 5 to 10 ppm available chlorine by weight. Check the level of available chlorine with a test kit. Adjust and maintain pool water pH between 7.2 and 7.6. Adjust and maintain the alkalinity of the pool to between 50 to 100 ppm. To maintain the pool, add manually or by a feeder device 2 ounces of this product for each 10,000 gallons of water to yield an available chlorine residual between 0.6 to 1.0 ppm by weight. Stabilized pools should maintain a residual of 1.0 to 1.5 ppm available chlorine. Test the pH, available chlorine residual and alkalinity of the water frequently with appropriate test kits. Frequency of water treatment will depend upon temperature and number of swimmers. Every 7 days, or as necessary, superchlorinate the pool with 10 to 20 ounces of product for each 10,000 gallons of water to yield 5 to 10 ppm available chlorine by weight. Check the level of available chlorine with a test (kit) Do not re-enter the pool until the chlorine residual is between 1.0 to 4.0 ppm. At the end of the swimming pool season or when water is to be drained from the pool, chlorine must be allowed to dissipate from treated pool water before discharge. Do not chlorinate the pool within 24 hours prior to discharge.

**Winterizing Pool:** While water is still clear and clean, apply 0.6 ounces of product per 1000 gallons, while filter is running, to obtain a 3 ppm available chlorine residual, as determined by a suitable test kit. Cover pool, prepare heater, filter and heater components for winter by following manufacturers' instructions.

## SPAS, HOT-TUBS, IMMERSION TANKS, etc.:

Spas / Hot-tubs: Apply 0.5 ounces of product per 500 gallons of water to obtain a free available chlorine concentration of 5 ppm, as determined by a suitable chlorine test kit. Adjust and maintain pool water pH to between 7.2 and 7.8. Some oils, lotions, fragrances, cleaners, etc. may cause foaming or cloudy water as well as reduce the efficiency of the product. To maintain the water, apply 0.5 ounces of product per 500 gallons of water over the surface to maintain a chlorine concentration of 5 ppm. After each use, shock treat with 1.5 ounces of this product per 500 gallons of water to control odor and algae. During extended period of disuse, add 1.5 ounces of product daily per 500 gallons of water to maintain a 3 ppm chlorine concentration. Hubbard and immersion Tanks: Add 0.5 ounces of this product per 100 gallons of water before patient use to obtain a chlorine residual of 25 ppm, as determined by a suitable test kit. Adjust and maintain the water pH to between 7.2 and 7.6. After each use drain the tank. Add 0.5 ounces to a bucket of water and circulate this solution through the agitator of the tank for 15 minutes and then rinse out the solution. Clean tank thoroughly and dry with clean cloths. Hydrotherapy Tanks: Add 1 ounce of this product per 1000 gallons of water to obtain a chlorine residual of 1 ppm, as determined by a suitable chlorine test kit. Pool should not be entered until the chlorine residual is below 3 ppm. Adjust and maintain the water pH to between 7.2 and 7.6. Operate pool filter continuously. Drain pool weekly, and clean before refilling.

#### SANITIZATION OF NONPOROUS FOOD CONTACT SURFACES:

Rinse method: A solution of 100 ppm available chlorine may be used in the sanitizing solution if a chlorine test kit is available. Solutions containing an initial concentration of 100 ppm available chlorine must be tested and adjusted periodically to insure that the available chlorine does not drop below 50 ppm. Prepare a 100 ppm sanitizing solution by thoroughly mixing 1 ounce of this product with 40 gallons of water. If no test kit is available, prepare a sanitizing solution by thoroughly mixing 1 ounce of this product with 20 gallons of water to provide approximately 200 ppm available chlorine by weight. Clean equipment surfaces in the normal manner. Prior to use, rinse all surfaces thoroughly with the sanitizing solution, maintaining contact with the sanitizer for at least 2 minutes. If solution contains less than 50 ppm available chlorine, as determined by a suitable test kit, either discard the solution or add sufficient product to reestablish a 200 ppm residual. Do not rinse equipment with water after treatment and do not soak equipment overnight. Sanitizers used in automated systems may be used for general cleaning but may not be reused for sanitizing purposes.

SEP 16 2003

Appendix -1-

24.8-296

Immersion method: A solution of 100 ppm available chlorine may be used in the sanitizing solution if a chlorine test kit is available. Solutions containing an initial concentration of 100 ppm available chlorine must be tested and adjusted periodically to insure that the available chlorine does not drop below 50 ppm. Prepare a 100 ppm sanitizing solution by thoroughly mixing 1 ounce of this product with 40 gallons of water. If no test kit is available, prepare a sanitizing solution by thoroughly mixing 1 ounce of this product with 20 gallons of water to provide approximately 200 ppm available chlorine by weight. Clean equipment in the normal manner. Prior to use, immerse equipment in the sanitizing solution for at least 2 minutes and allow the sanitizer to drain. If solution contains less than 50 ppm available chlorine, as determined by a suitable test kit, either discard the solution or add sufficient product to reestablish a 200 ppm residual, do not rinse equipment with water after treatment. Sanitizers used in automated systems may be used for general cleaning but may not be reused for sanitizing purposes. Flow/pressure method: Disassemble equipment and thoroughly clean after use. Assemble equipment in operating position prior to use. Prepare a volume of a 200 ppm available chlorine sanitizing solution equal to 110% of volume capacity of the equipment by mixing the product in a ratio of 1 ounce product with 20 gallons of water. Pump solution through the system until full flow is obtained at all extremities, the system is completely filled with the sanitizer and all air is removed from the system. Close drain valves and hold under pressure for at least 2 minutes to insure contact with all internal surfaces. Remove some cleaning solution from drain valve and test with a chlorine test kit. Repeat entire cleaning/sanitizing process if effluent contains less than 50 ppm available chlorine.

Clean-in-place method: Thoroughly clean equipment after use. Prepare a volume of 200 ppm available chlorine sanitizing solution equal to 110% of volume capacity of the equipment by mixing the product in a ratio of 1 ounce product with 20 gallons of water. Pump solution through the system until full flow is obtained at all extremities, the system is completely filled with the sanitizer and all air is removed from the system. Close drain valves and hold under pressure for at least 10 minutes to insure contact with all internal surfaces. Remove some cleaning solution from drain valve and test with a chlorine test kit. Repeat entire cleaning/sanitizing process if effluent contains less than 50 ppm available chlorine.

Spray/fog method: Preclean all surfaces after use. Use a 200 ppm available chlorine solution to control bacteria, mold or fungi and a 600 ppm solution to control bacteriophage. Prepare a 200 ppm sanitizing solution of sufficient size by thoroughly mixing the product in a ratio of 1 ounce product with 20 gallons of water. Prepare a 600 ppm solution by thoroughly mixing the product in a ratio of 3 ounces product with 20 gallons of water. Use spray or fogging equipment which can resist hypochlorite solutions. Always empty and rinse spray/fog equipment with potable water after use. Thoroughly spray or fog all surfaces until wet, allowing excess sanitizer to drain. Vacate area for at least 2 hours. Prior to using equipment, rinse all surfaces treated with a 600 ppm solution with a 200 ppm solution.

#### **SANITIZATION OF POROUS FOOD CONTACT SURFACES:**

Rinse method: Prepare a 600 ppm solution by thoroughly mixing 3 ounces of this product with 20 gallons of water. Clean surfaces in the normal manner. Rinse all surfaces thoroughly with the 600 ppm solution, maintaining contact for at least 2 minutes. Prepare a 200 ppm sanitizing solution by thoroughly mixing 1 ounce of this product with 20 gallons of water. Prior to using equipment, rinse all surfaces with a 200 ppm available chlorine solution. Do not rinse and do not 200 gallons of water.

Immersion method: Prepare a 600 ppm solution by thoroughly mixing, in an immersion tank, 3 ounces of this product with 20 gallons of water. Clean equipment in the normal manner. Prepare a 200 ppm sanitizing solution by thoroughly mixing 2 ounces of this product with 10 gallons of water. Prior to using, immerse equipment in the 200 ppm sanitizing solution for at least 2 minutes and allow the sanitizer to drain. Do not rinse and do not soak equipment overnight.

Spray/fog method: Preclean all surfaces after use. Prepare a 600 ppm available chlorine sanitizing solution of sufficient size by thoroughly mixing the product in a ratio of 3 ounces product with 20 gallons of water. Use spray or fogging equipment that can resist hypochlorite solutions.

Always empty and rinse spray/fog equipment with potable water after use. Thoroughly spray or fog all surfaces until wet, allowing excess sanitizer to drain. Vacate area for at least 2 hours.

748-296

SEP 16 2003

Prior to using equipment, rinse all surfaces with a 200 ppm available chlorine solution. Prepare a 200 ppm sanitizing solution by thoroughly mixing 1 ounce of this product with 20 gallons of water.

# SANITIZATION OF NONPOROUS NON-FOOD CONTACT SURFACES:

748-296

Rinse method: Prepare a sanitizing solution by thoroughly mixing 1 ounce of this product with 20 gallons of water to provide approximately 200 ppm available chlorine by weight. Clean equipment surfaces in the normal manner. Prior to use, rinse all surfaces thoroughly with the sanitizing solution, maintaining contact with the sanitizer for at least 2 minutes. Do not rinse equipment with water after treatment and do not soak equipment overnight.

Immersion method: Prepare a sanitizing solution by thoroughly mixing, in an immersion tank, 1 ounce of this product with 20 gallons of water to provide approximately 200 ppm available chlorine by weight. Clean equipment in the normal manner. Prior to use, immerse equipment in the sanitizing solution for at least 2 minutes and allow the sanitizer to drain. Do not rinse equipment with water after treatment.

**Spray/fog method:** Preclean all surfaces after use. Prepare a 200 ppm available chlorine sanitizing solution of sufficient size by thoroughly mixing the product in a ratio of 1 ounce product with 20 gallons of water. Use spray or fogging equipment which can resist hypochlorite solutions. Prior to using equipment, thoroughly spray or fog all surfaces until wet, allowing excess sanitizer to drain. Vacate area for at least 2 hours.

## **DISINFECTION OF NONPOROUS NON-FOOD CONTACT SURFACES:**

Rinse method: Prepare a disinfecting solution by thoroughly mixing 3 ounces of this product with 20 gallons of water to provide approximately 600 ppm available chlorine by weight. Clean equipment surfaces in the normal manner. Prior to use, rinse all surfaces thoroughly with the disinfecting solution, maintaining contact with the solution for at least 10 minutes. Do not rinse equipment with water after treatment and do not soak equipment overnight.

Immersion method: Prepare a disinfecting solution by thoroughly mixing, in an immersion tank, 3 ounces of this product with 20 gallons of water to provide approximately 600 ppm available chlorine by weight. Clean equipment in the normal manner. Prior to use, immerse equipment in the disinfecting solution for at least 10 minutes and allow the solution to drain. Do not rinse equipment with water after treatment.

## SANITIZATION OF POROUS NON-FOOD CONTACT SURFACES:

Rinse method: Prepare a sanitizing solution by thoroughly mixing 3 ounces of this product with 20 gallons of water to provide approximately 600 ppm available chlorine by weight. Clean equipment surfaces in the normal manner. Prior to use, rinse all surfaces thoroughly with the sanitizing solution, maintaining contact with the sanitizer for at least 2 minutes. Do not rinse equipment with water after treatment and do not soak equipment overnight.

Immersion method: Prepare a sanitizing solution by thoroughly mixing, in an immersion tank. 3

ounces of this product with 20 gallons of water to provide approximately 600 ppm available chlorine by weight. Clean equipment in the normal manner. Prior to use, immerse equipment in the sanitizing solution for at least 2 minutes and allow the sanitizer to drain. Do not rinse equipment with water after treatment.

Spray/fog method: After cleaning, sanitize non-food contact surfaces with 600 ppm available chlorine by thoroughly mixing the product in a ratio of 3 ounces of this product with 20 gallons of water. Use spray or fogging equipment which can resist hypochlorite solutions. Aways empty and rinse spray/fog equipment with potable water after use. Prior to using equipment, thoroughly spray or fog all surfaces until wet, allowing excess sanitizer to drain. Vacate area for at least 2 hours.

# **SEWAGE AND WASTEWATER TREATMENT:**

Effluent Treatment: The disinfection of sewage effluent must be evaluated by determining the total number of coliform bacteria and/or fecal coliform bacteria, as determined by the Most Probable Number (MPN) procedure, of the chlorinated effluent has been reduced to or below the maximum permitted by the controlling regulatory jurisdiction. On the average, satisfactory

Appendix -3-

SEP 16 disinfection of secondary wastewater effluent can be obtained when the chlorine residual is 0.5 ppm after 15 minutes contact. Although the chlorine residual is the critical factor in disinfection. the importance of correlating chlorine residual with bacterial kill must be emphasized. The MPN of the effluent, which is directly related to the water quality standards requirements, should be the final and primary standard and the chlorine residual should be considered an operating standard valid only to the extent verified by the coliform quality of the effluent. The following are critical factors affecting wastewater disinfection: 1. Mixing: It is imperative that the product and the 748-296 waste water be instantaneously and completely flash mixed to assure reaction with every chemically active soluble and particulate component of the waste water. 2. Contacting: Upon flash mixing, the flow through the system must be maintained. 3. Dosage/Residual Control: Successful disinfection is extremely dependent on response to fluctuating chlorine demand to maintain a predetermined, desirable chlorine level. Secondary effluent should contain 0.2 to 1.0 ppm chlorine residual after a 15 to 30 minute contact time. A reasonable average of residual chlorine is 0.5 ppm after 15 minutes contact time.

Effluent Slime Control: Apply a 100 to 1000 ppm available chlorine solution at a location which will allow complete mixing. Prepare this solution by mixing 2 to 20 ounces of this product with 100 gallons of water. Once control is evident, apply a 15 ppm available chlorine solution. Prepare this solution by mixing 0.3 ounces of this product with 100 gallons of water.

Filter Beds – Slime Control: Remove the filter from service, drain it to a depth of 1 foot above the filter sand, and add 16 ounces of this product per 20 square feet evenly over the surface. Wait 30 minutes before draining water to a level that is even with the top of the filter. Wait for 4 to 6 hours before completely draining and backwashing the filter.

# DISINFECTION OF DRINKING WATER (Potable Water) - PUBLIC WATER SYSTEMS:

Public Systems: Mix a ratio of 1 ounce of this product to 6000 gallons of water. Begin feeding this solution with a hypochlorinator until a free available chlorine residual of at least 0.2 ppm and no more than 0.6 ppm is attained throughout the distribution system. Check water frequently with a chlorine test kit. Bacteriological sampling must be conducted at a frequency no less than that prescribed by the National Interim Primary Drinking Water Regulations. Contact your local Health Department for further details.

**Reservoirs - Algae control:** Hypochlorinate streams feeding the reservoir. Suitable feeding points should be selected on each stream at least 50 yards upstream from the points of entry into the reservoir.

**Mains:** Thoroughly flush section to be sanitized by discharging from hydrants. Permit a water flow of at least 2.5 feet per minute to continue under pressure while injecting this product by means of a hypochlorinator. Stop water flow when a chlorine residual test of 50 ppm is obtained at the low pressure end of the new main section after a 24 hour retention time. When chlorination is completed, the system must be flushed free of all heavily chlorinated water.

New Tanks, Basins, etc.: Remove all physical soil from surfaces. Place 4 ounces of this product for each 5 cubic feet of working capacity (500 ppm available chlorine). Fill to working capacity and allow to stand for at least 4 hours. Drain and flush with potable water and return to surface.

New Filter Sand: Apply 16 ounces of this product for each 150 to 200 cubic feet of sand. The action of the product dissolving as the water passes through the bed will aid in sanitizing the new sand.

New Wells: Flush the casing with a 50 ppm available chlorine solution of water containing 1 ounce of this product for each 100 gallons of water. The solution should be pumped of fed by gravity into the well after thorough mixing with agitation. The well should stand for several hours or overnight under chlorination. It may then be pumped until a representative raw water sample is obtained. Bacterial examination of the water will indicate whether further treatment is necessary.

**Existing Equipment:** Remove equipment from service, thoroughly clean surfaces of all physical soil. Sanitize by placing 4 ounces of this product for each 5 cubic feet capacity (approximately 500 ppm available chlorine). Fill to working capacity and let stand at least 4 hours. Drain and place in service. If the previous treatment is not practical, surfaces may be sprayed with a

Wite

Appendix -4-

SEP 16 2003

2002013

solution containing 1 ounce of this product for each 5 gallons of water (approximately 1000 ppm available chlorine). After drying, flush with water and return to service.

# **DISINFECTION OF DRINKING WATER (Potable Water) - INDIVIDUAL SYSTEMS:**

**Dug Wells:** Upon completion of the casing (lining) wash the interior of the casing (lining) with a 100 ppm available chlorine solution using a stiff brush. This solution can be made by thoroughly mixing 1 ounce of this product into 40 gallons of water. After covering the well, pour the sanitizing solution into the well through both the pipe sleeve opening and the pipeline. Wash the exterior of the pump cylinder also with the sanitizing solution. Start pump and pump water until strong odor of chlorine in water is noted. Stop pump and wait at least 24 hours. After 24 hours flush well until all traces of chlorine have been removed from the water. Contact your local Health Department for further details.

**Drilled, Driven & Bored Wells:** Run pump until water is as free from turbidity as possible. Pour a 100 ppm available chlorine sanitizing solution into the well. This solution can be made by thoroughly mixing 1 ounce of this product into 40 gallons of water. Add 5 to 10 gallons of clean, chlorinated water to the well in order to force the sanitizer into the rock formation. Wash the exterior of pump cylinder with the sanitizer. Drop pipeline into well, start pump and pump water until strong odor of chlorine in water is noted. Stop pump and wait at least 24 hours. After 24 hours flush well until all traces of chlorine have been removed from the water. Deep wells with high water levels may necessitate the use of special methods for introduction of the sanitizer into the well. Consult your local Health Department for further details.

**Flowing Artesian Wells:** Artesian wells generally do not require disinfection. If analyses indicate persistent contamination, the well should be disinfected. Consult your local Health Department for further details.

DISINFECTION OF DRINKING WATER (Potable Water) - EMERGENCY DISINFECTION:

When boiling of water for 1 minute is not practical, water can be made potable by using this product. Prior to addition of the sanitizer, remove all suspended material by filtration or by allowing it to settle to the bottom. Decant the clarified, contaminated water to a clean container and add 1 grain of this product to 1 gallon of water. One grain is approximately the size of the letter "O" in this sentence. Allow the treated water to stand for 30 minutes. Properly treated water should have a slight chlorine odor, if not, repeat dosage and allow the water to stand an additional 15 minutes. The treated water can then be made palatable by pouring it between clean containers for several times.

**Emergency Disinfection After Floods** 

Wells: Thoroughly flush contaminated casing with a 500 ppm available chlorine solution. Prepare this solution by mixing 1 ounce of this product with 10 gallons of water. Backwash the well to increase yield and reduce turbidity, adding sufficient chlorinating solution to the backwash to produce a 10 ppm available chlorine residual, as determined by a chlorine test kit. After the turbidity has been reduced and the casing has been treated, add sufficient chlorinating solution to produce a 50 ppm available chlorine residual. Aggitate the well water for several hours and take a representative water sample. Re-treat well if water samples are biologically unacceptable. Reservoirs: In case of contamination by overflowing streams, establish hypochlorinating stations upstream of the reservoir. Chlorinate the inlet water until the entire reservoir obtains a 0.2 ppm available chlorine residual, as determined by a suitable chlorine test kit. In case of contamination from surface drainage, apply sufficient product directly to the reservoir to obtain a 0.2 ppm available chlorine residual in all parts of the reservoir.

Basins, tanks, flumes, etc.: Thoroughly clean all equipment, then apply 4 ounces of product per 5 cubic feet of water to obtain 500 ppm available chlorine, as determine dby a suitable test kit. • After 24 hours, drain, flush, and return to service. If the previous method is not suitable, spray or • • flush the equipment with a solution containing 1 ounce of this product for each 5 gallons of water (1000 ppm available chlorine). Allow water to stand for 2 to 4 hours, then flush and return to service.

Appendix -5.

Mps

Filters: When the sand filter needs replacement, apply 16 ounces of this product for each 150 to 200 cubic feet of sand. When the filter is severely contaminated, additional product should be distributed over the surface at the rate of 16 ounces per 20 square feet. Water should stand at a depth of 1 foot above the surface of the filter bed for 4 to 24 hours. When filter beds can be backwashed of mud and silt, apply 16 ounces of this product per each 50 square feet, allowing the water to stand at a depth of 1 foot above the filter sand. After 30 minutes, drain water to the 749-294 level of the filter. After 4 to 6 hours, drain and proceed with normal backworking level of the filter. After 4 to 6 hours, drain and proceed with normal backwashing. Distribution system: Flush repaired or replaced section with water. Establish a hypochlorinating station and apply sufficient product until a consistent available chlorine residual

**Emergency Disinfection After Fires** 

Cross connections or emergency connections: Hypochlorination or gravity feed equipment should be set up near the intake of the untreated water supply. Apply sufficient product to give a chlorine residual of at least 0.1 to 0.2 ppm at the point where the untreated supply enters the regular distribution system. Use a chlorine test kit.

of at least 10 ppm remains after a 24-hour retention time. Use a chlorine test kit.

**Emergency Disinfection After Droughts** 

Supplementary water supplies: Gravity or mechanical hypochlorite feeders should set up on a supplementary line to dose the water to a minimum chlorine residual of 0.2 ppm after a 20-minute contact time. Use a chlorine test kit.

Water shipped in by tanks, tank cars, trucks, etc.: Thoroughly clean all containers and equipment. Spray a 500 ppm available chlorine solution and rinse with potable water after 5 minutes. This solution is made by mixing 1 ounce of this product for each 5 gallons of water. During the filling of the containers, dose with sufficient amounts of this product to provide at least a 0.2 ppm chlorine residual. Use a chlorine test kit.

**Emergency Disinfection After Main Breaks** 

Mains: Before assembly of the repaired section, flush out mud and soil. Permit a water flow of at least 2.5 feet per minute to continue under pressure while injecting this product by means of a hypochlorinator. Stop water flow when a chlorine residual test of 50 ppm is obtained at the lowpressure end of the new main section after a 24-hour retention time. When chlorination is completed, the system must be flushed free of all heavily chlorinated water.

## **COOLING TOWER / EVAPORATIVE CONDENSER WATER:**

Slug Feed Method - Initial dose: When system is noticeably fouled, apply 10 to 20 ounces of this product per 10,000 gallons of water in the system to obtain 5 to 10 ppm available chloring. Repeat until control is achieved. Subsequent dose: When microbial control is evident, add 2 ounces of this product per 10,000 gallons of water in the system daily, or as needed to maintain control and keep the chlorine residual at 1 ppm. Badly fouled system must be cleaned before treatment is begun.

Intermittent Feed Method - Initial dose: When system is noticeably fouled, apply 10 to 20 ounces of this product per 10,000 gallons of water in the system to obtain 5 to 10 ppm available \*\*\*. chlorine. Apply half (or 1/3, 1/4, or 1/5) of this initial dose when half (or 1/3, 1/4, or 1/5) of the water in the system has been lost by blowdown. Subsequent dose: When microbial control is \*\*\*\*. evident, add 2 ounces of this product per 10,000 gallons of water in the system to obtain a 1 ppm. residual. Apply half (or 1/3, 1/4, or 1/5) of this initial dose when half (or 1/3, 1/4, of 1/5) of the water in the system has been lost by blowdown. Badly fouled system must be cleaned before treatment is begun.

Continuous Feed Method - Initial dose: When system is noticeably fouled, apply 10 to 20 ounces of this product per 10,000 gallons of water in the system to obtain 5 to 10 ppth available . chlorine. Subsequent dose: Maintain this treatment level by starting a continuous feed of 1 ounce of this product per 3,000 gallons of water lost by blowdown to maintain a 1 ppm residual. •••• Badly fouled system must be cleaned before treatment is begun.

Briquettes or Tablets - Initial dose: Initially slug dose the system with 10 ounces of this product per 10,000 gallons of water in the system. Badly fouled system must be cleaned before

Appendix .6.

SEP 16 2003

treatment is begun. **Subsequent dose:** When microbial control is evident, add 2 ounces of this product per 10,000 gallons of water in the system daily, or as needed to maintain control and keep the chlorine residual at 1 ppm. Badly fouled system must be cleaned before treatment is begun.

748-296

### **HOUSEHOLD LAUNDRY SANITIZERS:**

**In Soaking Suds** – thoroughly mix 1 tablespoons of this product to 10 gallons of wash water to provide 200 ppm available chlorine. Wait 5 minutes; then add soap or detergent. Immerse laundry for at least 11 minutes prior to starting the wash/rinse cycle.

In Washing Suds – thoroughly mix 1 tablespoons of this product to 10 gallons of wash water containing clothes to provide 200 ppm available chlorine. Wait 5 minutes; then add soap or detergent and start the wash/rinse cycle.

### **COMMERCIAL LAUNDRY SANITIZERS:**

Wet fabrics or clothes should be spun dry prior to sanitization. Thoroughly mix 1 ounce of this product with 20 gallons of water to yield 200 ppm available chlorine. Promptly after mixing the sanitizer, add the solution into the prewash prior to washing fabrics/clothes in the regular wash cycle with a good detergent. Test the level of available chlorine, if solution has been allowed to stand. Add more of this product if the available chlorine level has dropped below 200 ppm.

#### **FARM PREMISES:**

Remove all animals, poultry, and feed from premises, vehicles, and enclosures, vehicles. Remove all litter and manure from floors, walls and surfaces of barns, pens, stalls, chutes, and other facilities occupied or traversed by animals or poultry. Empty all troughs, racks and other feeding and watering appliances. Thoroughly clean all surfaces with soap or detergent and rinse with water. To disinfect, saturate all surfaces with a solution of at least 1000 ppm available chlorine for a period of 10 minutes. A 1000 ppm solution can be made by thoroughly mixing 2 ounces of this product with 10 gallons of water. Immerse all halters, ropes, and other equipment used in handling and restraining animals or poultry, as well as the cleaned forks, shovels and scrapers used for removing litter and manure. Ventilate the buildings, cars, boats and other closed spaces. Do not house livestock or poultry or employ equipment until chlorine has been dissipated. All treated feed racks, mangers, troughs, automatic feeders, fountains and waterers must be rinsed with potable water before reuse.

# PULP AND PAPER MILL PROCESS WATER SYSTEMS:

Slug Feed Method – Initial dose: When system is noticeably fouled, apply 10 to 20 ounces of this product per 10,000 gallons of water in the system to obtain 5 to 10 ppm available chlorine. Repeat until control is achieved. Subsequent dose: When microbial control is evident, add 2 ounces of this product per 10,000 gallons of water in the system daily, or as needed to maintain control and keep the chlorine residual at 1 ppm. Badly fouled system must be cleaned before treatment is begun.

Intermittent Feed Method – Initial dose: When system is noticeably fouled, apply 10 to 20 ounces of this product per 10,000 gallons of water in the system to obtain 5 to 10 ppm available chlorine. Apply half (or 1/3, 1/4, or 1/5) of this initial dose when half (or 1/3, 1/4, or 1/5) of the water in the system has been lost by blowdown. Subsequent dose: When microbial control is evident, add 2 ounces of this product per 10,000 gallons of water in the system to obtain a 1 ppm residual. Apply half (or 1/3, 1/4, or 1/5) of this initial dose when half (or 1/3, 1/4, or 1/5) of the water in the system has been lost by blowdown. Badly fouled system must be cleaned before treatment is begun.

Continuous Feed Method – Initial dose: When system is noticeably fouled, apply 10 to 20 ounces of this product per 10,000 gallons of water in the system to obtain 5 to 10 ppm available on chlorine. Subsequent dose: Maintain this treatment level by starting a continuous feed of 2 ounces of this product per 1,000 gallons of water lost by blowdown to maintain a 1 ppm residual. Badly fouled system must be cleaned before treatment is begun.

Appendix -7-

ACCUPTED 15 & 1'

Briquettes or Tablets – Initial dose: Initially slug dose the system with 10 ounces of this insection become product per 10,000 gallons of water in the system. Badly fouled system must be cleaned before treatment is begun. Subsequent dose: When microbial control is evident, add 2 ounces of this product per 10,000 gallons of water in the system daily, or as needed to maintain control and keep the chlorine residual at 1 ppm. Badly fouled system must be cleaned before treatment is 748 – 296 begun.

## **AGRICULTURAL USES:**

**Post-Harvest Protection – Harvested Potatoes:** Potatoes can be sanitized after cleaning and prior to storage by spraying with a sanitizing solution at a level of 1 gallon of sanitizing solution per tons of potatoes. Thoroughly mix 1 ounce of this product to 10 gallons of water to obtain 500 ppm available chlorine.

Bee Cells And Boards: Disinfect leafcutting bee cells and bee boards by immersion in a solution containing 1 ppm available chlorine for 3 minutes. Allow cells to drain for 2 minutes and dry for 4 to 5 hours, or until no chlorine odor can be detected. This solution is made by thoroughly mixing ¼ teaspoon of this product to 200 gallons of water. Bee domiciles are disinfected by spraying with a 0.1 ppm solution until all surfaces are thoroughly wet. Allow the domicile to dry until all chlorine odor has dissipated.

**Food Egg Sanitization:** Thoroughly clean all eggs. Thoroughly mix 1 ounce of this product with 20 gallons of warm water to product a 200 ppm available chlorine solution. The sanitizer temperature should not exceed 130°F. Spray the warm sanitizer so that the eggs are thoroughly wetted. Allow the eggs to thoroughly dry before casing or breaking. Do not apply a potable water rinse. The solutions should not be reused to sanitize eggs.

Fruit & Vegetable Washing: Thoroughly clean all fruits and vegetables in a wash tank. Thoroughly mix 1 ounce of this product in 200 gallons of water to make a sanitizing solution of 25 ppm available chlorine. After draining the tank, submerge fruit or vegetables for two minutes in a second wash tank containing the recirculating sanitizing solution. Spray rinse vegetables with the sanitizing solution prior to packaging. Rinse fruit with potable water only prior to packaging.

Seeds: To control bacterial spot (Xanthomonas vesticatoris) on pimentos seeds, initially remove moist seeds from ripe fruits. To control surface fungi and bacteria on tomato seeds, initially wash seeds. Immediately soak seeds in 39,000 ppm solution for 15 minutes with continuous agitation. After treatment, rinse seeds in potable water for 15 minutes. Dry seeds to normal moisture. Make this solution by mixing 8 ounces of this product with 1 gallon of water.

Mushrooms: To control bacterial blotch (Pseudomonas toloasii), apply a 100 to 200 ppm solution prior to watering mushroom production surfaces. This solution may be made by mixing 0.2 to 0.4 ounces of this product with 10 gallons of water. First application should begin when pins form, and thereafter between breaks on a need basis depending on the occurrence of bacterial blotch. This product may be applied directly to pins to control small infection foci. Apply 1.5 to 2.0 ounces per square foot of growing space.

Post-Harvest Roots – Harvested Sweet Potatoes: To control and reduce the spread of soft rot-causing organisms in water and on sweet potatoes (Ipomoea batatas), spray or dip the potatoes with a 150 to 500 ppm solution for 2 to 5 minutes. Thoroughly mix 0.3 to 1.0 ounces of this product per 10 gallons of water to obtain this solution. Monitor the chlorine concentration and change the solution after one hour or as needed.

## **AQUACULTURAL USES:**

Fish Ponds: Remove all fish from ponds prior to treatment. Thereafter, thoroughly mix 20 ounces of this product for each 10,000 gallons of pond water to obtain 10 ppm available chlorine. Repeat the treatment if the available chlorine level is below 1 ppm after 5 minutes. Return fish to the pond after the available chlorine level reaches zero.

**Fish Pond Equipment:** Thoroughly clean all equipment prior to treatment. Thoroughly mix 1 ounce of this product to 20 gallons of water to obtain 200 ppm available chlorine. Porous equipment should soak for one hour.

Maine Lobster Equipment: Remove lobster, seaweed, etc. from ponds prior to treatment. Drain the pond and thoroughly mix 1200 ounces (75 pounds) of this product to each 10,000

Appendix -8-

gallons of water to obtain at least 600 ppm available chlorine. Apply so that all barrows, gates, rocks and dam are treated with the product. Permit high tide to fill the pond and then close gates. Allow water to stand 2 to 3 days until the available chlorine level reaches zero. Open the gates and allow two tidal cycles to flush the pond before returning lobsters to the pond.

748-296

**Conditioning Live Oysters:** Thoroughly mix 1 ounce of this product to 10,000 gallons of water at 50 to 70°F to obtain 0.5 ppm available chlorine. Expose the oysters to this solution for at least 15 minutes, monitoring the available chlorine level so that it does not fall below 0.05 ppm. Repeat the entire process if the available chlorine level drops below 0.05 ppm or the temperature falls below 50°F.

Control Of Scavengers in Fish Hatchery Ponds: Prepare a solution containing 200 ppm of available chlorine by mixing 0.5 ounces of product with 10 gallons of water. Pour into drained pond potholes and repeat if necessary. Do not put desirable fish back into refilled ponds until chlorine residual has dropped to zero ppm, as determined by a test kit.

### **SANITIZING DIALYSIS MACHINES:**

Flush dialysis equipment thoroughly with water prior to sanitizing. Thoroughly dissolve 7 ounces of this product in 60 gallons of water to obtain at least a 600 ppm available chlorine solution. Use this solution in the hemodialysate system immediately allowing a minimum contact time of 15 minutes at 20 degrees C. Thereafter, drain the system of the sanitizing solution and thoroughly rinse with potable water. Discard and do not reuse the spent sanitizer. Rinsate must be monitored with a suitable test kit to insure that no available chlorine remains in the system. This product is recommended for decontaminating single and multipatient hemodialysate systems. This product has been shown to be an effective disinfectant (virucide, fungicide, bactericide, pseudomonicide) when tested by AOAC and EPA test methods. This product may not totally eiiinate)all vegetative microorganisms in hemodialysate delivery systems due to their construction and/or assembly, but can be relied upon to reduce the number of microorganisms to acceptable levels when used as directed. This product should be used in a disinfectant program that includes bacteriological monitoring of the hemodialysate delivery system. This product is not recommended for use in hemodialysate or reverse osmosis (RO) membranes. Consult the quidelines for hemodialysate systems that are available from the Hepatitis Laboratories, CDC, Phoenix, AZ 85021.

# ASPHALT OR WOOD ROOFS AND SIDINGS:

To control fungus and mildew, first remove all physical soil by brushing and hosing with clean water, and apply a 5000 ppm available chlorine solution. Mix 1 ounce of this product per gallon of water and brush or spray roof or siding. After 30 minutes, rinse by hosing with clean water.

# **BOAT BOTTOMS:**

Boat Hulls: To control slime on boat hulls, sling a plastic tarp under the boat, retaining enough water to cover the fouled bottom area. Do not allow additional water to entire enclosed area. This envelope should contain approximately 500 gallons of water for a 14 foot boat. Add 3.5 ounces of this product to the enclosed water to obtain a 35 ppm available chlorine concentration. Leave immersed for 8 to 12 hours. Repeat if necessary. Do not discharge the solution until the free chlorine level has dropped to 0 ppm, as determined by a test kit.

## **ARTIFICIAL SAND BEACHES:**

To sanitize the sand, spray a 500 ppm available chlorine solution containing 0.1 ounces of this product per gallon of water at frequent intervals. Small areas can be sprinkled with a watering can.

can.

Appendix -9-

# **FOOD PROCESSING PLANTS:**


**Poultry Drinking Water:** Spray or flush with a solution containing 1 ounce of this product for every gallon of water. Treat poultry drinking water to a dosage of 1 to 5 ppm available chlorine by adding 1 to 5 ounces of this product per 1000 gallons of water.

Pecan Cracking And Bleaching: Prepare a 1000 ppm available chlorine soaking solution by adding 1 ounce of this product for each 5 gallons of water to obtain a 1000 ppm available chlorine content. Soak for a minimum of 10 minutes. After removal, age pecans for 24 hours. Before bleaching, pecans are placed in a rotary cleaner where they are washed, drained, and soaked in a 2% sulfuric acid bath at 80 to 90 degrees F for one minute. Transfer to a solution containing 100 ounces of this product for each 100 gallons of water (5000 ppm). After 4 to 8 minutes, they are drained and washed in a 1% sulfuric acid bath at 80 to 90°F. They are then dried.

EPA ReReg Standard 2\_1986.doc 6/13/03

WHACOMMENTS IN EPALETTE 2003

rederal Insecticide, and Rodenticide, as as a Rodenticide, nor the pesticide, No. 148-296



Appendix - 10 -