


(center)

S E C O

SECO SAN



CONCENTRATED

IODINE SANITIZER

APPROVED U.S. PATENT No. 2977315
No. 2931777

SECO CHEMICALS, INC.

5657 Lauderdale Ave. Detroit, Michigan 48209

Phone: (313) 841-7170
Subsidiary of Stan SAX Corp.

CAUTION: Keep Out of Reach of Children see back-
side Panel for Additional Precautions

(right)

RECEIVED
3/19/68
1442

CLEANING OPERATIONS:

1. Immediately after each milking, thoroughly flush all utensils and milking machines with cold or lukewarm water until ALL the milk is washed out. DO NOT use hot water.
2. Fill wash-tank with lukewarm water (90°F) to which is added one (1) ounce of SECO SAN For each five (5) gallons of water. (Provides 25 ppm available iodine.)
3. Take milking machines apart--immerse parts, air-hoses, inflations, and metal parts except pulsator, in SECO SAN solution before brushing. Wash pails and strainers in same solution.

GERMICIDAL OPERATIONS:

4. In the rinse-tank, add $\frac{1}{2}$ ounce of SECO SAN for each five (5) gallons of lukewarm water to assist in preventing recontamination of sanitized equipment by contaminated rinse water and by possible carry-over of organic matter from the wash-tank. (Provide 12.5 ppm available iodine.)
5. Immerse washed utensils and milking machine parts in the rinse-tank solution for at least 2 minutes.
6. Before each milking, assemble and flush machines with SECO SAN solution -- $\frac{1}{2}$ ounce of SECO SAN to a 10-quart pail of cold water. (Provides 12.5 ppm available iodine.)

NOTE: Use freshly made solutions for each morning and night milking. Where Health Departments require dismantling twice a day, the same method would be used at night as in the morning.

Follow State and Local Health Department requirements covering cleaning and sanitizing.

FOR FARM BULK TANKS:

CLEANING OPERATIONS:

1. Flush with lukewarm water until ALL milk is washed out.
2. Wash with SECO SAN solution -- one (1) ounce of SECO SAN TO five (5) gallons cold water. (Provides 25 ppm available iodine.)
3. Brush thoroughly, drain and rinse for 2 minutes.

GERMICIDAL RINSE OPERATION: (Where code permits, brush or spray the tank with

iodine.)

3. Take milking machines apart--immerse parts, air-hoses, inflations, and metal parts except pulsator, in SECO SAN solution before brushing. Wash pails and strainers in same solution.

GERMICIDAL OPERATIONS:

4. In the rinse-tank, add $\frac{1}{2}$ ounce of SECO SAN for each five (5) gallons of lukewarm water to assist in preventing recontamination of sanitized equipment by contaminated rinse water and by possible carry-over of organic matter from the wash-tank. (Provide 12.5 ppm available iodine.)

5. Immerse washed utensils and milking machine parts in the rinse-tank solution for at least 2 minutes.

6. Before each milking, assemble and flush machines with SECO SAN solution -- $\frac{1}{2}$ ounce of SECO SAN to a 10-quart pail of cold water. (Provides 12.5 ppm available iodine.)

NOTE: Use freshly made solutions for each morning and night milking. Where Health Departments require dismantling twice a day, the same method would be used at night as in the morning.

Follow State and Local Health Department requirements covering cleaning and sanitizing.

FOR FARM BULK TANKS:

CLEANING OPERATIONS:

1. Flush with lukewarm water until ALL milk is washed out.

2. Wash with SECO SAN solution -- one (1) ounce of SECO SAN TO five (5) gallons cold water. (Provides 25 ppm available iodine.)

3. Brush thoroughly, drain and rinse for 2 minutes.

GERMICIDAL RINSE OPERATION: (Where code permits, brush or spray the tank with SECO SAN Solution) $\frac{1}{2}$ ounce of SECO SAN to 10- quart pail of cold water. (Provides 12.5 ppm available iodine.)

FOR UDDERS: Use a clean paper towel for each cow--wet in SECO SAN solution-- $\frac{1}{2}$ ounce SECO SAN to 10-quart pail of lukewarm water (90°F). Provides 25 ppm available iodine.)

FOR MILK STONE REMOVAL: Should yellow color show on equipment after the first use of SECO SAN, milkstone is indicated. Remove it using a SECO SAN solution -- equal parts of SECO SAN and lukewarm water -- spread over surfaces to be cleaned -- wait 2 to 3 minutes -- then brush and rise. The daily use of SECO SAN will prevent the formation of milkstone.