


RLP MOBILE PAINTS

ACTIVE INGREDIENT:	
Copper Oxide	38.3%
INERT INGREDIENTS	61.7%
TOTAL	100.0%




**ANTI-FOULING COLD PLASTIC
FORMULA NO. 105 MIL-P-19451B**

WARNING

KEEP OUT OF REACH OF
VAPOR HAZARDOUS

See Other Containers

105-1-11-1000



Jack Tar

Marine Finishes

ACCEPTED
Feb. 26, 1974
FEDERAL INSECTICIDE
AND RODENTICIDE ACT
REGISTERED
1719-17

**ANTI-FOULING COLD PLASTIC
FORMULA NO. 105 MIL-P-19451B**

MOBILE PAINT MFG. CO., INC. MOBILE, ALABAMA

WARNING!

KEEP OUT OF REACH OF CHILDREN
VAPOR HARMFUL

See Other Cautions on Back Panel



DANGER!
TOXIC AND
FIRE HAZARD
CONTAINS

XYLENE OF 81 F. MIN. F.P.

AVOID INHALING, SWALLOWING OR
CONTACT WITH THE SKIN
AVOID SPARKS, OPEN FLAME AND
SPILLS.
KEEP CONTAINER CLOSED.

ONE GALLON



ONE GALLON

XBOBIT

This paint is intended to protect steel, wood, and fiberglass boats from fouling by barnacles and similar marine life. Disperse thoroughly before each use by pouring most of the liquid off and working any settled pigment into a smooth paste using a stiff paddle. Continue by adding small portions of the liquid to the paste until paint is completely mixed.

Steel: Hull should be cleaned by scraping, chipping and mechanical wire brushing to remove all rust and scale. Prime by applying 3-coats of Anti-Corrosive Primer 409-68 following the directions on the can. When dry apply 2-coats of Jack Tar Formula No. 105 Anti-Fouling MIL-P-19451B allowing a minimum of 4 hours between coats. Allow to dry at least overnight before returning to water.

Wood: If old surface, scrape clean and hose off with high pressure water and stiff brush. Allow to dry completely. If new work or cleaned old surface, apply 2-coats Anti-Corrosive Primer 409-68 following directions on the can. When dry apply 2-coats of Jack Tar Formula No. 105 Anti-Fouling MIL-P-19451B allowing a minimum of 4 hours between coats and at least overnight before returning to water.

Fiberglass: SAND THOROUGHLY with medium-fine grit sandpaper. Wash sanded surface with a CLEAN cloth saturated with Methyl Isobutyl Ketone to remove all traces of "mold release compound". Apply one very thin coat of BLP Jack Tar Wash Primer 409-42 followed by 2-coats of Jack Tar Formula No. 105 Anti-Fouling MIL-P-19451B.

NOTE: DO NOT use Linseed Oil to thin. Use BLP Xylol 75-15 (TT-X-916) if necessary.

CAUTION! COMBUSTIBLE
Contains Xylol

Keep away from heat and open flame. Avoid prolonged contact with skin or eyes and breathing of vapor or spray mist. In case of contact with eyes, flood repeatedly with water. CALL PHYSICIAN IMMEDIATELY. Do not transfer contents to unlabeled containers. Close container after each use. Do not reuse empty container. Destroy it by perforating or crushing. Bury or discard in a safe place away from water supply.

Do not contaminate water by cleaning of equipment, or disposal of wastes.

Use with adequate ventilation.

KEEP OUT OF REACH OF CHILDREN

EPA REG. NO. 1719-17