

WARNING: KEEP OUT OF REACH OF CHILDREN. May be fatal if swallowed. Do not breathe vapor, dust or spray mist. Do not get on skin. In case of contact, wash immediately with soap and water. Do not contaminate feed and foodstuffs.

ANTIDOTE: External — In case of spillage on skin, wash promptly with soap and water. Internal — Emetic of 1 tablespoonful mustard in tumbler of water. Call a physician.

DIRECTIONS: FOR TERMITE CONTROL. Add 2½ gallons of Heptachlor 5 lbs. actual Heptachlor) to 120 gallons of water. This gives a .5% emulsion. Apply the emulsion as recommended below:

1—Slab-Type Construction

- a—Apply 1 gallon per 10 square feet as an overall pre-construction treatment under the slab and along attached porches or entrance platforms.
- b—Apply 2 gallons per 5 lineal feet to critical areas under the slab as pre-construction treatment, such as along the inside of the foundation walls and around utility entrances and interior partition foundation walls.

2—Building With Crawl Spaces

- a—Apply 2 gallons per 5 lineal feet in a trench along the outside of foundation walls, including entrance platforms and porches where the foundation is not more than 15-18 inches deep. If over 15-18 inches deep but not over 30 inches, apply 4 gallons per 5 lineal feet. Do not go deeper than the top of the footing.
- b—Apply 2 gallons per 5 lineal feet as a trenching application to critical areas under the house, such as along the inside of foundation walls and around piers and utility entrances. If trench is deeper than 15-18 inches but not over 30 inches, apply 4 gallons per 5 lineal feet. Do not go deeper than the top of the footing.

PEE GEE

Heptachlor Pre-Treat Concentrate

(Contains 2 Lbs. Heptachlor Per Gallon)

ACTIVE INGREDIENTS:


Heptachlor (Heptachlor-4, 7-Methanotetrahydroindene)	23.41%
Related Compounds	9.10%
Xylene	61.36%

INERT INGREDIENTS: 6.13%

TOTAL 100.0%

Parramore & Griffin

Valdosta, Georgia



- c—Apply 1 gallon per 10 square feet as an overall pre-construction treatment under the slab and along attached porches or entrance platforms.
- d—Apply 1 gallon per 5 lineal feet to critical areas under the slab as pre-construction treatment, such as along the inside of the foundation walls and around utility entrances and interior partition foundation walls.

3—Buildings With Crawl Spaces

- a—Apply 1 gallon per 10 square feet as an overall pre-construction treatment under the slab and along attached porches or entrance platforms.
- b—Apply 2 gallons per 5 lineal feet to critical areas under the slab as pre-construction treatment, such as along the inside of the foundation walls and around utility entrances and interior partition foundation walls.
- c—Apply 2 gallons per 5 lineal feet to critical areas under the house, such as along the inside of foundation walls and around piers and utility entrances. If trench is deeper than 15-18 inches but not over 30 inches, apply 4 gallons per 5 lineal feet. Do not go deeper than the top of the footing.
- d—Treat all voids under the house at the rate of 1 gallon per 10 square feet.

Premises treated with a minimum of five gallons per 100 square feet.

WARRANTY: Parramore & Griffin warrants that the above described product will perform as represented on the label. No other warranty is made.

May be fatal
ist. Do not get
oap and water.

wash promptly
oonful mustard

gallons of Hep-
ter. This gives
d below:

re-construction
porches or en-

under the slab
e inside of the
nd interior par-

ong the outside
ns and porches
nches deep. If
apply 4 gallons
of the footing.
g application to
the inside of
entrances. If
30 inches, ap-
er than the top

PEE GEE

Heptachlor Pre-Treat Concentrate

(Contains 2 Lbs. Heptachlor Per Gallon)

ACTIVE INGREDIENTS:

Heptachlor (Heptachlor-4, 7-Methanotetrahydroindene)	23.41%
Related Compounds	9.10%
Xylene	61.36%

INERT INGREDIENTS: 6.13%

TOTAL 100.0%



Parramore & Griffin

Valdosta, Georgia

c—Apply 1 gallon per square feet of soil surface as a pre-construction treatment where the attached porches, entrance platforms, utility entrances, etc., have covering slab on fill of ground.

d—Apply 1 gallon per 5 lineal feet of wall to voids in hollow masonry units of the foundation.

3—Buildings With Basements

a—Apply 1 gallon per 10 square feet as an overall pre-construction treatment under the basement flooring, attached porches, entrance platforms, utility entrances, and similar situations where slab fill is at ground level.

b—Apply 2 gallons per 5 lineal feet in a trench along the outside of foundation walls, including entrance platforms and porches where the foundation is not more than 15-18 inches deep. If over 15-18 inches deep but not over 30 inches, apply 4 gallons per 5 lineal feet. Do not go deeper than the top of the footing.

c—Apply 2 gallons per 5 lineal feet as a trenching application to critical areas under the house, such as along the inside of foundation walls, porches, entrances and piers. If trench is deeper than 15-18 inches but not over 30 inches, apply 4 gallons per 5 lineal feet. Do not go deeper than the top of the footing.

d—Treat all voids in hollow masonry units of the foundation at the rate of 1 gallon per 5 lineal feet of wall.

Premises treated with 0.5% heptachlor will give residual control for a minimum of five years.

WARRANTY: Parramore & Griffin warrants to the extent of purchase price only that this product conforms to stated chemical analysis. No other warranty is expressed or implied.

U. S. P. A. Reg. No. 1812-X

1812-11

[Handwritten signature]