## TERMINIX WP CONCENTRATE

ACTIVE INGREDIENTS:

Pentachlorophenol\*
Other Chlorophenols & Related Compounds\*

Butoxyethanol
Nimeral Spärits
Beta-Naphthol
Technical Chlordane\*\*

7.8%

IMERT INGREDIENTS:

From Technical Pentachlorophenol\*

TOTAL 100.0

\* Equivalent to 37.6% Technical Pentachlorophenol as defined in Federal Specification TT-W-570.

\*\* Equivalent to 4.7% of octachloro-4,7-methanotetrahydroindane and 3.1% of related compounds.

NOTE: Terminix WP is for the combined treatment of ground and the spray and pressure treatment of timber to kill rot fungi, subterranean termites and powder-post beetles and to prevent reinfestation. For use only in servicing work and is not for resale.

MIX 5 GALLONS OF THE CONCENTRATE WITH 50 GALLONS OF MINERAL SPIRITS OR #2 FUEL OIL.



E. L. BRUCE CO

MEMPHIS 1, TENN.

## WARNING: KEEP OUT OF REACH OF CHILDREN

WARNING: HARMFUL IF SWALLOWED OR IF ABSORBED THROUGH SKIN:
CAUSES SKIN IRRITATION.
AVOID CONTAMINATION OF FEED AND FOODSTUFFS.
DO NOT BREATHE VAPOR OR SPRAY MIST.
DO NOT GET IN EYES, ON SKIN OR ON CLOTHING.
WASH THOROUGHLY AFTER HANDLING.
DO NOT SPRAY NEAR OR TOWARD AN OPEN FLAME.

NET CONTENTS-5 U. S. GALLONS USDA Rog. No. 1927-11

CHLOR etions gubbl fol] **8** the Ç an with at ch and eq ELG0 purpose savings .....18% ai .... 190%

Good for Builders

\* KILLS TERMITES, POWDER
POST REETLES, PUNGI when
applied and for many years

\* DECEMBASES His of humbor

· CORNEL to handle

\* 0000 to mild

· PROGRATES doubly

Good for Pointer

· CLEAR on version

. MATT MOA BYOOM

· PADRAM

• CMS westeld point

· Militable paint failures

<del>딩</del>

nd

9

oont

not

DIRECTIONS

LUMBER LAST can be applied in several ways. In order of offectiveness they are: COLD SOAK or DIP, BRUSH, SPRAY. Degree of offectiveness is entirely dependent on amount absorbed.

COLD SOAK or DIP: Ordinary Millwork should be dipped 3 to 5 minutes for each inch of thickness. From 10 to 15 gallons of LUMBER LAST can be observed into 1000 board feet of lumber in this manner. Flooring could be dipped in an improvised eave-wough 'vat'. Joistonds could be soaked in an open 5 gellon reil. Heavier Construction Timbers and Posts should soak from one to 48 hours and punding on thickness and whether use is to be in an above ground. Open-end 55 gellon drums are useful for this purpose. Posts to be treated should be peeled and seasoned.

BRUSHING: Apply two heavy coats, if possible, weiting 6 to 24 hours between coats, 1900 bound test of lumber will take about 5 gettens this way. Cut-ends should be brushed liberally, since these open grain ends are mest receptive to moisture end ret. SPRAYING: Use garden type sprayer. Hold nozzle 3 inches from surface. (Under 3" spray bounces, over 3" spray is lost in mist). Repeat efter several hours.

IMPORTANT: Lumber to be treated must be reasonably dry for best results. BEFORE PAINTING, treated lumber must be dry; otherwise finish will take longer to dry. Drying time depends an amount of absorption in wood and also an climatic conditions. Minimum drying time is 24 hours. LUMBER LAST IS COMPATIBLE with primers, house paints, enamels, varnishes lacquers, oil stains. (Water stains will not take).

SHINGLE TREATMENT: LUMBER LAST makes on excellent shingle stain bese; just add color ground in ail.

TERMITE CONTROL: Treatment of wood is just one step in the procedure for controlling termites. Treatment of the soil next to foundations is an extremely important step.

MARMINIC