

# BALTIMORE COPPER PAINT CO.

BALTIMORE, MD. 21230

NEW YORK, N.Y. 10038

Baltoguard is a fibreglass, prop is in good cond

Stir thoroughly 4 to 6 hours dr more than 3 da is not necessary

### FIBREGLASS: S

down carefully Solvent Wash at gel-coat.

An alternate me Wash and 3351 necessity of san

WOOD: Apply th

METAL: Apply d REGATTA 3630/

PREVIOUSLY CO

### CAUTION! COMI FLAME. CONTA

on any interior s sills, toys, cribs vapor or spray n OUT OF REACH skin or on clott wash with soap

Keep container empty container Do not contamin



| PIGMENT 60.07%                 |         |
|--------------------------------|---------|
| Cuprous Oxide                  | 46.27%  |
| Tributyitin Flueride           | 0.91%   |
| 2-(Ethylamine)-4-(iseprepylami | NO) -   |
| 6- (Mothylthio) -s-Triazine    | 0.334   |
| Red Iron Oxide                 | 6.96%   |
| Zine Oxide                     | 2.55%   |
| Inert Pigment                  | 3.05%   |
| VEHICLE 39.93%                 |         |
| Chlerinated Rubber             | 7.65%   |
| Resin                          | 3.88%   |
| Trieresyl Phesphate            | 2.614   |
| Aromatia Hydrocarbons          | 25 184/ |
| Additives                      | 0.626   |
|                                | 0.03%   |
|                                | 100.00% |

EPA Reg. No. 2568-50



# 1870 **FTR** PAINT RED

| U      | / |  |
|--------|---|--|
|        |   |  |
| \<br>\ |   |  |

| ANALYSIS  |          |
|---|----------|
| PIGI CNT 60.07%   |          |
| C .erous Oxide<br>Tibutyitin Fluoride<br>2-(Ethylamino) -4-(Isopropylam | Ú.91%    |
| 6-(Methylthie)-s-Triazine   | 0.33%    |
| Red from Oxide  | 6.96%    |
| Zine Oxide  | 2.55%    |
| Inert Pigment   | 3.05%    |
| VEHICLE 39.93%  |          |
| Chierinated Rubber  | 7.65%    |
| Resi e  | 3.88%    |
| Tricresyl Phosphate   | 2.61-/-  |
| Arematic Hydrocarbons   | 25.164/- |
| Additives   | 0.63%    |
|   | 100.00%  |

EPA Reg. No. 2568-50

Baltoguard is an anti-fouling paint based on Chlorinated Rubber. It may be used on wood, fibreglass, properly primed metal or most types of previous seasons anti-fouling paint that is in good condition.

Stir thoroughly both before and during application. Apply at least two coats-allowing 4 to 6 hours drying time between final coat and launch. It is not advisable to delay launch more than 3 days after final coat. Apply by brush, roller, or spray gun. Ordinarily thinning is not necessary, but where it is desired, add not more than 10% Regatta 3802 Xylol Solvent.

FIBREGLASS: Sand the bottom thoroughly, using medium grit (about #100) caper. Wipe down carefully with REGATTA 3830 Fibreglass Solvent Wash. Use generous quantities of Solvent Wash and clean rags in order to remove the wax-like substance from the fibreglass gel-coat.

An alternate method of surface preparation is to use REGATTA 3840 Fibreglass Pre-Prime Wash and 3351 Fibreglass No-Sand Primer according to directions, thereby avoiding the necessity of sanding.

METAL: Apply one coat of REGATTA Vinyltex 50/51 Wash Primer followed by two coats of REGATTA 3630/3631 Epoxydur Black Mastic.

Solvent.

CAUTION! COMBUSTIBLE! DO NOT USE, POUR, SPILL OR STORE NEAR HEAT OR OPEN FLAME. CONTAINS COMPOUNDS HARMFUL OR FATAL IF SWALLOWED. Do not apply on any interior surfaces of a dwelling, or a place used for the care of children, or on window sills, toys, cribs and other furniture which might be chewed by children. Avoid breathing vapor or spray mist. Wash thoroughly after handling and before eating or smoking. KEEP OUT OF REACH OF CHILDREN. May be absorbed through skin. Do not get in eyes, on skin or on clothing. In case of contact, immediately remove contaminated clothing and wash with soap and water. Wash contaminated clothing before reuse. Causes skin irritation.

Keep container closed when not in use. Use with adequate ventilation. Do not reuse empty container. Destroy it by perforating or crushing. Burn or discard in a safe place. Do not contaminate water by cleaning equipment or disposal of waste.

D BY

OUT OF

SEE BACK

**NUTIONS** 

.ON

# PER PAINT CO.

NEW YORK, N.Y. 10038

# DIRECTIONS

# SURFACE PREPARATION

WOOD: Apply three coats Baltoguard directly to bare wood. Allow 4-6 hours between coats.

PREVIOUSLY COATED SURFACES: Sand thoroughly, then wipe down with 3802 Xylol

