




ONE U.S. STANDARD GALLON

IMPERIAL MEAS. 132 FL. OZ.



DOLPHIN Copperpac



(For Salt Water)

WARNING!

KEEP OUT OF REACH
OF CHILDREN
HARMFUL OR FATAL
IF SWALLOWED

See Back Panel for
additional required
precautions

ACCEPTED

8-19-71

3658-16

9120

Anti-Fouling Bottom Paint

TYPE 2

NET CONT. 128 FL. OZS. (1 GAL.)

9120 Anti-Fouling Bottom Paint Type 2

Pigment:		60.7%
Cuprous Oxide	58.88%	
Inert	1.82%	
Vehicle:		5.3%
98.9% Phenolic Ester Gum		
Hardened Rosin		
Fung & Linseed Oil		
1.1% Driers		
Volatile:		34.0%
35.8% Aromatic Thinners		
42.8% Petroleum Thinners		
21.4% Turpentine		
Active Ingredients		100.0%
Cuprous Oxide	58.88%	
Inert Ingredients	41.12%	
Copper Expressed As Metallic	50.5	100.0%

MANUFACTURED BY THE DOLPHIN PAINT & CHEMICAL COMPANY TOLEDO 3, OHIO, U.S.A.

" DO IT RIGHT - WITH *Dolfinite* "

DOLFINITE COPPERPAC 9120 (Type 2) Anti-Fouling Bottom Paint for use in salt water was developed jointly by the manufacturer and The Marine Laboratory of the University of Miami, Florida.

Copperpac is unique in that it is consistent in performance in all places and seasons, and has a controlled toxic release and leeching rate which are constant and above the critical rate at all times. Copperpac can be applied during storage in anticipation of early launching. Boats painted with Copperpac may be launched with the film either wet OR dry. Boats protected with Copperpac should be scrubbed with a stiff brush and fresh water immediately upon removal from the water to remove the bacterial slime before it oxidizes and thereby protect the anti-fouling qualities.

DIRECTIONS FOR APPLICATION

Copperpac is easily applied by brush, roller or spray and dries to a smooth, flat reddish-brown film. Shake thoroughly before and stir frequently while using to insure even and complete distribution of the anti-fouling ingredients. **THINNING IS NOT RECOMMENDED OR REQUIRED.** Should a partially used can require thinning, add only a small amount of pure gum turpentine — any other material may completely destroy the effectiveness of Copperpac.

WOOD — The surface should be clean, dry and well sanded. No undercoat is required. Apply two coats to insure complete protection; both coats may be applied during the same day allowing 4 hours drying time between coats.

SUGGESTION — For added protection we suggest a coat of Dolfinite Wormicide, which contains Biomet, be applied directly to the bare wood before the application of Copperpac. This will insure protection from marine worms, borers, teredos or other marine growth in the event of mars, scrapes or scuffs.

FIBER GLASS — Fiber Glass must be thoroughly and carefully cleaned of all waxes, mold release agents, etc. by cleaning thoroughly with a strong solvent; sanded vigorously to provide a roughened surface for good adhesion. No undercoat is required — apply two coats of Copperpac allowing 4 hours between coats.

STEEL AND ALUMINUM — Aluminum and steel boats require a complete system of anti-corrosive and galvanic protection barrier coats prior to the application of Copperpac. Ask your marine dealer for our booklet giving complete and detailed instructions for applying Copperpac to steel and aluminum boats.

BRUSHES — May be cleaned with turpentine or mineral spirits.

WARNING: CONTAINS XYLOL AND COPPER. Keep away from heat, sparks and open flame. Avoid contact with skin and breathing of vapor or spray mist. Close container after each use. Do not reuse empty container. Destroy it by perforating or crushing. Bury or discard in a safe place. **USE WITH ADEQUATE VENTILATION.**

ANTIDOTE: If swallowed, do not induce vomiting. **CALL PHYSICIAN IMMEDIATELY.**

U.S.D.A. REGISTRATION NO. 3658.16

QUALITY PRODUCTS SINCE 1885

ACCEPTED

8-19-71

3658-16