



CHLORDANE E.C. FOR TERMITE CONTROL

ACTIVE INGREDIENTS:

*Technical Chlordane	42.00%
Aromatic Petroleum Hydrocarbons	54.00%
INERT INGREDIENTS	4.00%
Total	100.00%

*Equivalent to 35.37% Octachloro-4, 7-methanotetrahydroindane and 16.92% related compounds.

**KEEP OUT OF THE REACH OF CHILDREN
CAUTION**

STATEMENT OF PRACTICAL TREATMENT

- If swallowed** — Call a physician or Poison Control Center immediately. Gastric lavage is indicated if material was taken internally. **DO NOT INDUCE VOMITING;** vomiting may cause aspiration pneumonia.
- If inhaled** — Remove victim to fresh air. Apply artificial respiration if indicated.
- If on skin** — Remove contaminated clothing and wash affected areas with soap and water.
- If in eyes** — Flush eyes with plenty of water. Get medical attention immediately.

SEE SIDE PANEL FOR ADDITIONAL PRECAUTIONARY STATEMENTS

EPA Est. 407-1A-1
EPA Reg. No. 3772-8

G-82-V-892C-H

NET CONTENTS 1/2 GALLON

MANUFACTURED FOR
MAY SEED & NURSERY CO.
EMENANDOAM, IOWA 51603

PRECAUTIONARY STATEMENTS HAZARDS TO HUMANS AND DOMESTIC ANIMALS

CAUTION

Harmful if swallowed. Contact with skin can cause toxic symptoms. Avoid breathing spray mist. In case of contact with skin wash with soap and water. Avoid contamination of feed and foodstuffs.

ENVIRONMENTAL HAZARDS

This product is toxic to fish and wildlife. Keep out of any body of water. Apply this product only as specified on this label. Do not contaminate water by cleaning of equipment or disposal of wastes.

PHYSICAL OR CHEMICAL HAZARDS

Do not use, pour, spill or store near heat or open flame.

DISPOSAL

DO NOT REUSE EMPTY CONTAINER. WRAP CONTAINER AND PUT IN TRASH COLLECTION.

DIRECTIONS FOR USE

It is a violation of Federal law to use this product in a manner inconsistent with its labeling.

Use a 1% emulsion for subterranean termites. Mix 1 gallon of Earl May Chlordane E.C. in 49 gallons of water (2 1/2 ounces to 1 gallon) to produce a 1% water emulsion.

SUBTERRANEAN TERMITES — DIRECTIONS FOR HOMEOWNER USE

TERMITE CONTROL IN EXISTING STRUCTURES Buildings with Basements or Crawl-Spaces

First remove all wood debris and wood forms. Around pipes, chimneys, bases and along foundations of poured concrete dig a trench 6 inches wide and 4 inches deep. For brick and block foundations dig the trench about 12 inches deep. If footing is more than 12 inches deep, make holes with a crowbar, pipe or a rod about one foot apart that extend from the trench bottom to the top of the footing. Make holes closer in hard-packed clay soils. **NEVER DIG BELOW THE TOP OF THE FOOTING.** Apply the emulsion (or solution) in the trench at a rate of 4 gallons per 10 linear feet per foot of depth. Apply half of this to the back fill. Likewise treat along the base of foundations of crawl spaces. To treat soil, take treated soil with a thin layer of untreated soil.

For termites in attics, basements and other voids, drill holes at one foot intervals, 12 inches from the foundation and pour one-half gallon of emulsion for each.

KI

EPA
EPA 1