
(0)

! GALLON

USDA Reg. No. 8145-1



## CU-PRE-SERV 4192 CLEAR PRESERVATIVE

### DANGER!

**FLAMMABLE** 

HARMFUL OR FATAL IF SWALLOWED
CONTAINS PETROLEUM DISTILLATES. If Swallowed,
CALL PHYSICIAN IMMEDIATELY. FLAMMABLE. Keep
from heat, sparks and open flame. USE ADEQUATE VENTILATION.
Harmful if inhaled. Avoid contact with eyes, skin or clothing.
Wash thoroughly after handling. Do not transfer contents to bottles or other unlabeled containers. Close container after each use. KEEP OUT OF THE REACH OF CHILDREN.

S145-1

(3)-67

BURGESS FOBES PAINT

#### A clean, long-lasting treatment for

FENCE POSTS HEAVY TIMBER NURSERY LUMBER FLATS PLANT BANDS BURLAP

PRESERVES wood against termites, rot, and decay. Also preserves fabric, rope, nets, and seines.

PROTECTS wood, fabric, and rope against decay, mold and mildew. Also for protection against termites and other wood boring beetles.

#### DIRECTIONS FOR USE

Surface preparation: Wood to be treated should be dry and well seasoned. Fence posts must have bark removed.

Thinning: For general use as a surface treatment by dip, brush or spray, Cu-Pre-Serv should be applied without dilution. If thinning is desired mineral spirits, kerosene, or diesel oil may be used. NOTE: If lumber treated with Cu-Pre-Serv is to be painted or if the treated wood, burlap twine or fabric, when dry, is to come in contact with growing plants, USE ONLY clean mineral spirits of the Stoddard Solvent type (i.e., painters' naphtha) for dilution. Allow to dry thoroughly before using. To be an effective preservative, Cu-Pre-Serv should be thinned with no more than one part of thinner to one part Cu-Pre-Serv.

Application: Fence posts, timbers or finished lumber to be buried in the soil should be immersed in full strength Cu-Pre-Serv 12 to 48 hours for long term protection. (Pine species may allow adequate penetration in 6 to 8 hours.) Finished lumber and cut timbers should be immersed 15 to 30 minutes per inch of thickness except in the case of pine species which absorb the preservative at a faster rate. Rope, netting, burlap, canvas and other fabric should be immersed in Cu-Pre-Serv for three hours or until wet through.

When **Cu-Pre-Serv** is applied by brush or spray (above ground use only) generous flooding coats on all surfaces are recommended. Two brish or spray upnications 4 to 6 hours apart or a minimum 3 minute dip are recommended for wood intended for contact with the solution termite protection at wood should be treated after all outs are made and before use in a structure.

ALLOW CU-PRE-SERV TO DRY THOROUGHLY better bainting.

Coverage: 300 to 400 square feet per gail none that depending in the phrasity and much hass of the surface.

Type of Cu-Pre-Serv to use: 4191 areas is intended for use where the lor of the treated wood is marker a criwhere the treated wood is to be paint id. Use 4192 clear under stains or where surfaces are to be 1 ft with a natural clear form.

Cu-Pre-Serv month U. S. Witt. of Common on Common at Standards

# BURGESS FOBES PAINT PORTLAND, MAINE