

ACCEPTED  
 July 17, 1975  
 9743-7  
 UNDER THE FEDERAL INSECTICIDE  
 FUNGICIDE AND RODENTICIDE ACT  
 FOR ECONOMIC POISON REGISTERED  
 UNDER NO.

# MICROBIOCIDES NO. H

For use in recirculating cooling water systems for the control of algae, bacterial slime, and fungi.

Active Ingredient:

Sodium Hypochlorite . . . . .	12.5%
Inert Ingredient . . . . .	87.5%

**WARNING: KEEP OUT OF THE REACH OF CHILDREN**

Harmful if swallowed. Avoid contact with skin and eyes. In case of contact, flush with copious amounts of water for at least 15 minutes. If skin irritation persists, get medical attention. For eyes, get prompt medical attention. Strong Oxidant. May produce chemical burns.

Add Microbiocide No. H only to water. Degrades with age. Use a test kit and increase dosage as necessary to obtain required level of available chlorine. Keep in a cool place.

This product is toxic to fish. Treated effluent should not be discharged where it will drain into lakes, streams, ponds or public water. Do not contaminate water by cleaning of equipment or disposal of wastes.

**USE ONLY AS DIRECTED ON SIDE PANEL**

10.4# /GAL.                      NET CONTENTS                      GALS.                      E P A REG. NO. 09743 00007 AA

Repacked by

**SKASOL INCORPORATED**

40 CLEVELAND STREET                      •                      SAN FRANCISCO, CALIFORNIA 94103                      •                      PHONE: 431-5000

## INDUSTRIAL WATER TREATMENT CHEMICAL CLEANING

### DIRECTIONS FOR USE

Begin treatment when the system is in jeopardy of becoming affected or when the efficiency is already impaired. Badly fouled systems must be cleaned before treatment is begun.

*Initial Dose* — Apply 0.5 to 1.0 gallon of product per 10,000 gallons of water in the system. Repeat until control is evident. Add 0.5 to 1.0 gallon of product per 10,000 gallons of water in the system every 4-7 days or as needed to maintain control. Test water to insure proper chlorine residual of at least 1 ppm for a minimum of 4 hours.

The frequency of addition depends on the relative amount of bleed-off, and the severity of the microbiological problem. Slug additions should be made in the sump of the system or where it will be uniformly mixed before recirculation.

*Do not reuse empty drum.* Return to drum reconditioner or destroy by perforating or crushing and burying in a safe place away from water supplies.

E P A EST. NO. 9743-CA-1