

DIRECTIONS FOR USE:

Mixing Instructions:

Mix the amount of material shown below into 5 gallons of water. Then add this amount of material at the pump discharge for uniform mixing.

Initial Dose:

Badly fouled systems must be cleaned before treatment is begun. The recommended initial dose is 4 ounces of P-21 Algae Control per 1,000 gallons of water in the system. Repeat until control is achieved.

Subsequent Dose:

When microbial control is evident, add 2 ounces of P-21 Algae Control per 1,000 gallons of water in the system every 2 days and repeat the above dosages as needed to maintain the recommended chlorine residual in water at all times with a chlorine test kit.

This product is toxic to fish. Treated effluent should not be discharged where it will drain into lakes, streams, or ponds of public water. Do not contaminate water by cleaning of equipment or disposal of wastes. Apply this product only as specified on this label.

**P-21, ALGAE CONTROL
(Granular)
CHLORINE COMPOUND**

For Control Of Bacterial And Algal Slime Growth In Industrial Cooling Water Systems.

ACTIVE INGREDIENTS

"Pantowon (Dichloro-s-triazinone)"

100%

EPA Reg. No. 14886-9

WARNING

KEEP OUT OF REACH OF CHILDREN.

See side panel for additional precautionary handling instructions.
Container Disposal: "Do not reuse container. Destroy when empty."

MANUFACTURED BY

PARKER ENGINEERED CHEMICALS, INC.
320 Hodgkin Street, P. O. Box 509
High Point, North Carolina 27261

NET CONTENTS

KEEP OUT OF REACH OF CHILDREN

WARNING!

**HARMFUL TO SKIN AND EYES.
OXIDIZING MATERIAL.
CONTACT WITH ORGANIC MATTER
MAY CAUSE FIRE
WILL BURN WITH EVOLUTION OF
CHLORINE AND EQUALLY
TOXIC GASES**

Avoid contact with skin.
Avoid contact with eyes.
Avoid contact with organic material.
Avoid breathing dust.
Do not take internally.
Store away from flammable material.
In case of contact, immediately flush skin or eyes with cold water for at least 15 minutes. For eyes get medical attention.

Retie polyethylene lining after each use and keep container tightly closed.

Store in a dry place. Keep containers off wet floors.

Sweep up spillage and flush down sewer with LARGE VOLUME of water and provide adequate ventilation.

14886-9

ACCEPTED

TO REGISTER COMMENT