



OFFICE OF CHEMICAL SAFETY AND POLLUTION PREVENTION

WASHINGTON, D.C. 20460

February 10, 2025

Teri Muchow
teri.muchow@arxada.com
ARCH WOOD PROTECTION, INC.

Subject: Non-PRIA (Pesticide Registration Improvement Act) Labeling Amendment - Add Language to the Directions for Use Section
Product Name: FRAMEGUARD
Admin Number: 62190-43
EPA Receipt Date: 04/05/2023
Action Case Number: 00446193

Dear Teri Muchow:

The amended labeling referred to above, submitted in connection with registration under the Federal Insecticide, Fungicide, and Rodenticide Act, as amended, is acceptable.

This approval does not affect any terms or conditions that were previously imposed on this registration. You continue to be subject to existing terms or conditions on your registration and any deadlines connected with them.

A stamped copy of your labeling is enclosed for your records. This labeling supersedes all previously accepted labeling. You must submit one (1) copy of the final printed labeling before you release this product for shipment with the new labeling. In accordance with 40 CFR § 152.130(c), you may distribute or sell this product under the previously approved labeling for 18 months from the date of this letter. After 18 months, you may only distribute or sell this product if it bears this new revised labeling or subsequently approved labeling. "To distribute or sell" is defined under FIFRA section 2(gg) and its implementing regulation at 40 CFR § 152.3.

Should you wish to add/retain a reference to your company's website on your label, then please be aware that the website becomes labeling under FIFRA and is subject to review by EPA. If the website is false or misleading, the product will be considered to be misbranded and sale or distribution of the product is unlawful under FIFRA section 12(a)(1)(E). 40 CFR § 156.10(a)(5) lists examples of statements the EPA may consider false or misleading. In addition, regardless of whether a website is referenced on your product's label, claims made on the website may not substantially differ from those claims approved through the registration process. Therefore, should the EPA find or if it is brought to our attention that a website contains statements or claims substantially differing from statements or claims made in connection with obtaining a FIFRA section 3 registration, the website will be referred to the EPA's Office of Enforcement and Compliance Assurance.

Your release for shipment of this product constitutes acceptance of these terms. If these terms are not complied with, this registration will be subject to cancellation in accordance with FIFRA section 6.

If you have questions, please contact Terria Northern via email at northern.terria@epa.gov.

Sincerely,


A handwritten signature in black ink that reads "Heather A. Garvie". The script is elegant and cursive, with the first letters of each word being capitalized and prominent.

Heather Garvie, Senior Regulatory Advisor
RMB2, AD
Office of Pesticide Programs

FrameGuard Pack B40 Revised Draft Label – 2/10/2025

[] Denotes alternate/optional language

{ } Denotes language that will not appear on market labeling.



Boric Acid/ Sodium Salts	Group:	8D	Insecticide Fungicide
-----------------------------	--------	----	--------------------------

{the MOA Box will be used if required}

FRAMEGUARD[®] Pack B40

Termiticide, Insecticide and Fungicide Concentrate

{Alternate Brand Name: AntiBlu[®] Diffuze 40}

Active Ingredient:

Disodium Octaborate Tetrahydrate (CAS No. 12280-03-4) 40%

Other Ingredients 60%

Total 100%

KEEP OUT OF REACH OF CHILDREN

CAUTION

See side panel for additional Precautionary Statements

For the Prevention and Control of: Subterranean Termites, (which includes) Formosan Termites, Drywood Termites, Carpenter Ants, Listed Wood Destroying Beetles, Fungi (Rot), Algae

For use in and around Residential, Institutional and Commercial Structures and Vehicles.

Manufactured by:

ARCH WOOD PROTECTION, INC.

3941 Bonsal Road

Conley, GA 30288

EPA Reg. No. 62190-43

EPA Est. xxxxx-yy-zz

Net Contents: #####

PRECAUTIONARY STATEMENTS:

HAZARDS TO HUMANS AND DOMESTIC ANIMALS

CAUTION. Harmful if absorbed through skin. Avoid contact with skin, eyes or clothing. Wash thoroughly with soap and water after handling and before eating, drinking, chewing gum, using tobacco, or using the toilet. Remove and wash contaminated clothing before reuse.

PERSONAL PROTECTIVE EQUIPMENT (PPE)

Applicators, mixers and other handlers must wear long-sleeved shirt, long pants, socks, shoes, chemical-resistant gloves (made of barrier laminate; butyl, nitrile, neoprene and natural rubbers ≥ 14 mils; polyethylene; polyvinyl chloride; and viton ≥ 14 mils) and protective eyewear.

USER SAFETY REQUIREMENTS

Follow manufacturer's instructions for cleaning/maintaining PPE. If no such instructions for washables exist, use detergent and hot water. Keep and wash PPE separately from other laundry.

USER SAFETY RECOMMENDATIONS

Users should:

- Wash hands before eating, drinking, chewing gum, using tobacco or using the toilet;
- Remove clothing immediately if pesticide gets inside, then wash thoroughly and put on clean clothing;
- Remove PPE immediately after handling this product. Wash the outside of gloves before removing. As soon as possible, wash thoroughly and change into clean clothing.

ENVIRONMENTAL HAZARDS

Wood treatment facilities must take steps to prevent runoff of the product into the waterway. Treated material stored outdoors within 100 feet of a pond, lake, stream, or river must be covered, surrounded by a containment berm, or otherwise protected to prevent surface water runoff. The containment berm must be of sufficient height to prevent runoff during heavy rainfall events. This pesticide is toxic to fish and wildlife. Do not apply directly to water, to intertidal areas where surface water is present or to intertidal areas below the mean high water mark. Do not contaminate water when cleaning equipment or disposing of equipment washwaters. Do not discharge effluent containing this product into lakes, streams, ponds, estuaries, oceans or other waters unless in accordance with the requirements of a National Pollutant Discharge Elimination System (NPDES) permit and the permitting authority has been

FIRST AID

IF ON SKIN OR CLOTHING: Take off contaminated clothing. Immediately rinse skin with plenty of water for 15-20 minutes. Call a poison control center or doctor for treatment advice.

IF IN EYES: Hold eye open and rinse lowly and gently with water for 15-20 minutes. Remove contact lenses, if present, after the first 5 minutes, then continue rinsing eye. Call a poison control center or doctor for treatment advice.

Call a poison control center or doctor for further treatment advice. Have the product container or label with you when calling a poison control center or doctor or going for treatment. You may also contact: CHEMTREC 1-800-424-9300 [CCN 864796] for emergency medical treatment information.

notified in writing prior to discharge. Do not discharge effluent containing this product to sewer systems without previously notifying the local sewage treatment plant authority. For guidance contact your state water board or regional office of the EPA.

DIRECTIONS FOR USE

It is a violation of Federal law to use this product in a manner inconsistent with its labeling. Use of this product for the control of bed bugs is prohibited. Applications to carpets are prohibited. Do not exceed label dosage rates. Do not mix this product with any other product if prohibited by that label.

USE RESTRICTIONS

Do not use or on food contact surfaces when food is prepared. Do not use in serving areas where food is exposed. Do not contaminate feed, water or food. Do not enter or allow others to enter or occupy treated areas until spray has been absorbed into the wood. Treated areas must not be occupied during application.

PHYTOTOXICITY

This product may be phytotoxic to plants. When treating around the exterior of structures, cover and protect shrubs and other plants that may be potentially exposed to this product.

I. MIXING INSTRUCTIONS

FrameGuard® Pack B40 is a concentrate that **must** be diluted with clean water or a combination of water and permitted insecticide and/or repellent/coating, and/or antimicrobial before use. A power impeller-type mixer can be used with an electric drill to shorten mixing time.

FrameGuard® Pack B40 solutions can be mixed with FrameGuard Pack A (EPA Reg. No. 62190-25) for mold control, in accordance with the most restrictive of label limitations and precautions.

To make it easier to see where FrameGuard® Pack B40 has been applied, an appropriate marker dye or pigment may be added to the mix solution. Refer to the dye or pigment product label for the recommended amount to add to the FrameGuard® Pack B40 solution.

Do not leave unused solution under pressure or in tank overnight. Rinse equipment and lines with water after use.

Target Pests	Mixing Ratios Diluent PLUS Frameguard Pack B40	Application Notes
Subterranean Termites which includes Formosan Termites	1:1 or 2:1	For remedial and preventative treatments apply a 1:1 dilution for all treatments by spray, injection, brush or roller. The 2:1 dilution may be used for

		foaming or misting, for application into inaccessible wall voids.
Drywood Termites	1:1, 2:1 or 5:1	For remedial treatment apply the 1:1 or 2:1 dilution by foam or by misting. Use the 5:1 dilution for prevention.
Anobiid and Lyctinae Powderpost Beetles	1:1 or 5:1	For all remedial treatments use a 1:1 dilution. Use a 5:1 dilution for treating hardwood floors. Use the 5:1 dilution for prevention.
Old House Borers, Longhorned Beetles and Ambrosia Beetles	1:1 or 5:1	Use a 1:1 dilution for remedial and preventative treatment in wood > 4" thick. Use the 5:1 dilution for prevention in wood less than 4" thick or hardwood floors.
Carpenter Ants	1:1, 2:1 or 5:1	Use the 1:1 dilution for all remedial treatments. Use the 2:1 dilution for remedial treatments applied by foam or with a misting machine (or applicator). Use the 5:1 dilution for prevention.
Fungi (Rot) and Algae	1:1, 3:1 or 5:1	For remedial control use a 1:1 dilution on wood members 4" thick or greater. Use a 3:1 dilution for wood less than 4" in thick or for active remedial treatment of dry rot. For prevention use a 5:1 dilution. May be used at a 5:1 dilution to control and prevent fungi on wood less than 4" thick when mixed with other fungicides.

II. PRODUCT INFORMATION

FrameGuard® Pack B40 is not intended for application to soil; it is not a soil termiticide. **Do not use to directly treat soil. Prior to using this product, consult with your state regulatory agency to see if there are additional requirements beyond the label.**

FrameGuard® Pack B40 contains an inorganic borate salt, soluble in water, with insecticidal and fungicidal properties effective against wood destroying organisms, including the target pests listed below. This product may be used as a remedial treatment of infested wood and as a preventative treatment of wood in existing or new construction. FrameGuard® Pack B40 solution is recommended for protection of all interior and exterior wood (including wood-foam composite structural components). Treatment is intact provided the treated material is not exposed to rain, continuous water or in direct contact with the ground.

Subterranean Termites: *Reticulitermes*, *Heterotermes*, *Coptotermes*

Drywood Termites: *Kaloterms*, *Incisitermes* Dampwood Termites: *Zootermopsis*, *Neotermes*

True Powderpost Beetles: *Lyctinae*,
False Powderpost Beetles: *Bostrichidae*
Anobiid Beetles: *Anobiidae*
Old House Borers, Longhorned Beetles: *Cerambycidae*, *Hylotrupes*
Ambrosia/Bark Beetles: *Platypodidae*, *Scolytidae*, *Curculionidae*
Metallic Wood Boring Beetle: *Buprestidae*
Carpenter Ants: *Camponotus*
Brown Rot (including dry rot), White Rot, Wood Decay

Frameguard Pack B40 solutions may be used on all cellulose materials, concrete, block, brick, metals, PVC plumbing pipes and other non-cellulosic materials not intended for food contact. Apply Frameguard Pack B40 solutions only to bare surfaces where an intact water-repellent barrier, such as paint, stain, or sealer is not present.

When spraying overhead interior areas of homes, apartment buildings, etc., cover or protect all surfaces below the areas being sprayed with plastic sheeting or other material and dispose if contamination from dripping occurs. Do not apply in food serving areas while food is exposed. Cover all food contact and preparation surfaces prior to treatment. After treatment, thoroughly clean all food contact surfaces with a water/detergent solution followed with a potable water rinse. Remove all pets; turn off fish aquarium pumps and cover.

In new construction applications for the prevention of subterranean termites, structural wood is defined as: only wood needed for the basic building structure as found in the “dried-in” stage of construction, including wood in direct contact with foundations, interior and exterior wall sill plates, wood studs, wood or cellulosic sheathing, floor joists and sub- flooring.

In structures where a soil treatment termiticide has been applied and/or termite bait system installed, Frameguard Pack B40 solution may be applied as an additional treatment to protect wood from subterranean termites that may have penetrated the gaps occurring within the termiticide-treated soil or have bypassed the bait/monitor systems.

As a remedial treatment, Frameguard Pack B40 solution will help control and prevent future infestations of Formosan, native subterranean termites, wood boring beetles, carpenter ants and decay fungi.

[The active ingredient in Frameguard Pack B40, disodium octaborate tetrahydrate, is toxic to listed insects, decay fungi and algae. Once Frameguard Pack B40 solution has been applied, those insects that eat or infest the wood come in contact with the active borate ingredient and are killed.]

Wood boring beetle larvae and pupae, already present in the wood at the time of treatment may occasionally emerge as adults sometime after treatment, but reinfestations will be prevented.

III. Remedial Infested Wood Treatment

A. Accessible wood: Spray and/or inject Frameguard Pack B40 solution into beetle holes, termite and carpenter ant galleries and decay pockets. Apply 1 [one] coat of Frameguard Pack B40 solution to the point of surface saturation to all infested and susceptible wood, paying particular attention to infested areas. Apply 2 [two] coats of Frameguard Pack B40 solution to those wood members with only 1 [one] or 2 [two] exposed sides. For quicker control, apply an additional coat to heavily infested areas. Allow first application to dry by waiting at least 20 minutes between applications. For specific pests to be controlled refer to **Table A** for applicable mixing instructions.

In cases where the infestation is not accessible from the surface, drill small holes into the wood to gain access to the infested area. Inject enough solution to completely flood galleries or voids. Adjacent intact wood may be treated by pressure injecting Frameguard Pack B40 solution into holes drilled into the wood at 8- [eight-] to 10- [ten-] inch intervals.

B. Basements and crawl spaces: Apply 1 [one] coat of Frameguard Pack B40 solution to all accessible surfaces including concrete walls, sill plates, piers, girders, subfloors, floor joists and any wood exposed to vertical access above ground. On wood where access is limited to 1 [one] or 2 [two] sides of wood members, such as sills and plates on foundation walls, apply 2 [two] coats of Frameguard Pack B40 solution. Allow first application to dry by waiting at least 20 minutes between applications. One gallon of solution will treat up to 400 square feet of floor area (subfloor, floor joists, header and sill plates).

C. Buildings on concrete slabs: Apply Frameguard Pack B40 solution into wall voids by foaming or misting. Locate each stud and drill a small hole through the wall covering to gain access to the infested area. Drill holes every 18-24 inches adjacent to the side of each stud and apply Frameguard Pack B40 solution to capacity per hole. Drill at least one hole per stud bay near the floor to treat the base plate in each void. Treat entire wall area as opposed to single stud bays to completely include the infested area within the treatment zone. Treat at least 6 [six] inches of concrete slab out from the penetration site, if accessible.

D. Wood flooring, paneling or other visible wood: Treat by spray, brush or roller application. Prior to application, remove any existing finish by coarse sanding or stripping. Apply a 2:1 Frameguard Pack B40 solution [(2 [two] parts diluent to 1 [one] part Frameguard Pack B40)] at a rate of approximately 1 [one] gallon of solution per 500 square feet of floor surface. Allow floor to completely dry (typically 48 to 72 hours). Moisture content must be 16% or less before applying final finish. Frameguard Pack B40 solution applications may raise the grain of the wood and an additional **light** sanding may be necessary before applying a new finish. The Frameguard Pack B40 solution is compatible with most floor coatings; always test a small section of treated floor with the new finish and check for appropriate adhesion prior to coating the entire floor.

Note: Heartwood is not penetrated quickly: If surface is tacky or residue is evident after 72 hours of drying time, wash affected area with clean water and a mop, cloth or sponge, rinsing frequently. Allow surface to dry prior to final **light** sanding and application of finish coat. Wood

that is wetted can swell so an expansion gap may be needed. Wood that is thoroughly wetted and redried may warp or twist.

E. Inaccessible wall voids, wall studs and wood members: Apply by foaming or misting into voids and channels of damaged or suspected infested wood and/or through small holes drilled into walls and baseboard areas. Space holes no more than 24" apart along each member to be treated and at least 1 [one] hole must be drilled between each wall stud when inaccessible treating base plates. Use sufficient amount of solution to cover all areas to the point of surface saturation. **Note:** Existing insulation may block distribution of the Frameguard Pack B40 solution. Remove insulation prior to treatment.

F. Foam application: Add appropriate amount of foaming agent to produce a desired foam expansion.

G. Foam insulation: Apply by injecting a 1:1 Frameguard Pack B40 solution [(1 [one] part water to 1 [one] part Bora- Care)] into the infested area and/or by low pressure surface spraying. **Note:** Some types of foam insulation, such as polyisocyanurate and extruded polystyrene, have closed cell structures that do not allow significant penetration from surface application. Inject and surface spray these types of insulation.

H. Non-cellulose (or non-wood) treatments: Apply a supplemental treatment of Frameguard Pack B40 solution to concrete, block or brick on the interior of crawl space and basement foundations to prevent shelter tubing by subterranean termites. Apply a 1:1 Frameguard Pack B40 solution [(1 [one] part diluent to 1 [one] part Frameguard Pack B40)] at the rate of 1 [one] gallon to up to 400 square feet of surface area. In crawl space, apply solution 2 [two] feet [24 inches] up from the ground on interior wall surfaces. In unfinished basements with bare concrete slabs, apply the 1:1 Frameguard Pack B40 solution 2 [two] feet [24 inches] up from the concrete slab on interior foundation walls. In addition to the wall treatment, extend application up to 6 [six] inches away from foundation walls onto the horizontal surface of the bare concrete slab. Treat bath trap areas in concrete slab construction, after obtaining access to the area, by evenly applying 8 [eight] ounces of the 1:1 Frameguard Pack B40 solution into the traps out at least 1 [one] foot [12 inches] in all directions from the edge of the trap area. Treat other termite access areas (such as plumbing penetrations, expansion joints and abutting slabs) by applying the 1:1 Frameguard Pack B40 solution into the penetration, out at least 1 [one] foot [12 inches] in all directions from the edge of the penetration area. Also treat protruding utilities and adjacent wood to a height of 2 [two] feet [24 inches].

IV. Preventative Treatment of Wooden Structures for Drywood and Dampwood Termites, Carpenter Ants, Old House Borers, Powderpost and Other Wood Boring Beetles, and Fungi (Rot)

Note: Frameguard Pack B40 solution is not intended for application to soil.

Apply when access to wooden structural components is optimized such as at the “dried-in” stage.

For treatment of new log structures see Section XIII. Treat all structural wood with a 5:1 Frameguard Pack B40 solution [(5 [five] parts diluent to 1 [one] part Frameguard Pack B40)]. Concentrate application in areas susceptible to attack, to include all sills, plates, floor joists, piers, girders and subfloors. Treat structural wood in all plumbing, electrical and ductwork areas where they penetrate walls and/or floors. Treat all structural wood base plates and studs on interior and exterior walls, especially those surrounding any high moisture areas such as bathrooms, kitchens and laundry rooms. For buildings built on concrete slabs, treat all structural wood in contact with the concrete slab, all interior and exterior wall studs and wall sheathing material. In attics, treat all structural wood including ceiling joists, trusses, top plates, rafters and roof decking. Treat all structural wood sill plates and structural wood contacting garages and porches.

In areas where access is limited to 1 [one] or 2 [two] sides of a wood member, including exterior wall base plates and any married studs, apply 2 [two] coats of Frameguard Pack B40 solution to the exposed surfaces. Allow first application to dry by waiting at least 20 minutes between applications.

Treat all exterior wood including siding, facias, soffits, eaves, roofing, porches, decks and railings.

V. Preventative Treatments and Pretreatments for Subterranean Termites including Formosan Termites (Crawl Space, Basement and Concrete Slab)

Note: This treatment serves as a primary treatment for the control of subterranean termites including Formosan termites and must be applied with a 1:1 Frameguard Pack B40 solution [(1 [one] part diluent to 1 [one] part Frameguard Pack B40)].

In new construction applications for the prevention of subterranean termites, structural wood is defined as: only wood needed for the basic building structure as found in the “dried-in” stage of construction, including wood in direct contact with foundations, interior and exterior wall sill plates, wood studs, wood or cellulosic sheathing, floor joists and sub-flooring.

Apply when access to wooden structural components is optimized and when no further framing modifications will be made, such as after final framing inspection. If treatment is carried out prior to framing inspection, a second visit is required to ensure full treatment is still intact.

In areas where access is limited to 1 [one] or 2 [two] sides of a wood member, including exterior wall base plates and any married studs, apply 2 [two] coats of Frameguard Pack B40 solution to the exposed surfaces. Allow first application to dry by waiting at least 20 minutes between applications.

If additional protection is desired for the remaining structure treat all remaining structural wood with a 5:1 Frameguard Pack B40 solution [(5 [five] parts diluent to 1 [one] part Frameguard Pack B40)].

A. Crawl Spaces and/or Basements: Apply 1 [one] coat of a 1:1 Frameguard Pack B40 solution [(1 [one] gallon diluent to 1 [one] gallon Frameguard Pack B40)] in a 2- [two-] foot [24-inches]

high uninterrupted band to the point of surface saturation to all structural surfaces in crawl spaces and basements, to include all sills, plates, floor joists, piers, girders and subfloors as well as structural wood exposed to direct vertical access from the soil. To prevent termite shelter tubes on crawl space or basement walls, apply a 1:1 Frameguard Pack B40 solution to crawl space concrete or block walls in a 2 [two] foot [(24 inches)] band up from the ground on interior wall surfaces. Apply at the rate of 1 [one] gallon to up to 400 square feet of surface area. Treat a 2- [two-] foot [24-inches] band around construction materials and structural wood adjacent to plumbing, electrical conduit and ducts where they penetrate subfloors, if they provide a direct vertical access from the soil. Treat all structural wood, in finished basements where structural wood framing is immediately adjacent to the exterior foundation walls. Spray the concrete slab surface a minimum of 2 [two] to a maximum of 8 [eight] inches.

On structural wood where access is limited to 1 [one] or 2 [two] sides of wood members, such as sill plates and headers on foundation walls, married studs or wrapped sheathing, apply 2 [two] coats of Frameguard Pack B40 solution. Allow first application to dry by waiting at least 20 minutes between applications. If accessible, treat the exterior of structural wood sill areas around the entire perimeter of the structure with a 2- [two-] foot [24-inches] high band of a 1:1 Frameguard Pack B40 solution beginning with the sill area and extending upwards onto the sheathing material. On multiple story structures, treat only the first story above the masonry foundation level.

Structures on concrete slabs [(including structures with little or no structural wood in contact with the concrete slab foundation)]: Apply 1 [one] coat of a 1:1 Frameguard Pack B40 solution [(1 [one] gallon diluent to 1 [one] gallon Frameguard Pack B40)] to all wood[, metal and/or non-cellulosic] sill/base plates and the bottom 2 [two] feet [24 inches] of all wood[, metal and/or non-cellulosic] studs on all exterior and interior walls in contact with the concrete slab. Treat at the rate of 1 [one] gallon of solution to up to 400 linear feet of stud walls. Treat all wood in plumbing walls, bath traps and any wood adjacent to plumbing, electrical conduit and duct penetrations to provide a minimum 2- [two-] foot [24-inches] high barrier of treatment between the bottom of the penetration site and the balance of the structure. **In areas where access is limited to 1 [one] or 2 [two] sides of a structural wood member, such as sills and plates on foundation walls, married studs or wrapped sheathing, apply 2 [two] coats of Frameguard Pack B40 solution to the exposed surfaces.** Allow first application to dry by waiting at least 20 minutes between applications. When spraying base plates, also treat the concrete slab a minimum of 2 [two] inches to a maximum of 8 [eight] inches out from plates. Treat the concrete slab where any visible cracks may be occurring, extending treatment 8 [eight] to 12 inches out on each side of the concrete slab crack.

Treat all penetrations (such as plumbing, expansion joints and abutting concrete slabs) by spraying the 1:1 Frameguard Pack B40 solution 2 [two] feet [24 inches] high and extending application to cover at least 6 [six] inches of concrete slab out from penetration site.

Evenly treat bath traps with a minimum of 8 [eight] ounces of the 1:1 Frameguard Pack B40 solution to a maximum of 16 ounces per square foot of trap. Treat all concrete slabs at least 1 [one] foot out from all bath trap penetrations.

Concrete, cinder block or non-cellulosic exterior walls must be treated with a 1:1 Frameguard Pack B40 solution 2 [two] feet [24-inches] on the interior side of wall surface up from the concrete slab. This treatment must be applied as a continuous 2- [two-] foot [24-inches] barrier

to all interior surfaces of all exterior walls. Treat at the rate of 1 [one] gallon of a 1:1 Frameguard Pack B40 solution to up to 400 square feet of surface area.

[In Florida Only: Do not use as a standalone for new construction treatments if the total linear footage of the cellulosic base plates is less than 60% of the total linear footage of all base plates in the structure to include exterior and interior walls. In new construction with 60% or more linear footage of base plates, but without continuous wood on every exterior wall, the Frameguard Pack B40 must be applied to all other exterior structural construction materials, including brick or block, to a height of 2 [two] feet [24 inches] and extended out onto the slab a minimum of 2 [two] to a maximum of 8 [eight] inches.]

B. Foam insulation: Treat with low-pressure surface spraying or by injecting a 1:1 Frameguard Pack B40 solution ([1 [one] part water to 1 [one] part Frameguard Pack B40]) to the infested area at the rate of 1 [one] gallon to up to 400 square feet.

Note: Some types of foam insulation, such as polyisocyanurate and extruded polystyrene, have closed cell structures that do not allow significant penetration from surface application. Inject and surface spray these types of insulation.

VI. Preventative Treatment for Drywood Termites and Powderpost Beetles

Apply 1 [one] coat of a 5:1 Frameguard Pack B40 solution ([5 [five] gallons water to 1 [one] gallon Frameguard Pack B40]) to the point of surface saturation to all structural wood surfaces using a brush, spray or mist. Apply 2 [two] coats of Bora- Care solution to those surfaces where access is limited to 1 [one] or 2 [two] sides of structural wood members. Allow first application to dry by waiting at least 20 minutes between applications.

VII. Treatment of Exterior Wood Surfaces Less Than Two Inches Thick such as Decks, Sheds and Fences

Apply only to bare wood or to wood surfaces where an intact water repellent or finish is not present. Remove paint or finish prior to application. Apply 1 [one] coat of Frameguard Pack B40 solution to the point of surface saturation to all wood surfaces. Apply 2 [two] coats of Frameguard Pack B40 solution to heavily infested areas and to those surfaces where access is limited to 1 [one] or 2 [two] sides of wood members. Allow first application to dry by waiting at least 20 minutes between applications. Do not apply in rain or snow. Do not expose treated exterior wood surfaces to rain or snow for at least 48 hours after treatment. If inclement weather is expected, protect exterior treated surfaces with a plastic tarp. For wood in contact with the ground or soil, see Section X.

A. Finishing and Maintaining Treated Surfaces: For best results, exterior wood surfaces that have been treated with Frameguard Pack B40 solution will require a topcoating with a water-resistant finish such as paint or exterior stain. Apply the finish or topcoat within 6 [six] weeks of treatment. It is important to allow Frameguard Pack B40-treated wood to completely dry (at least 48 hours) before applying any protective topcoat. Coat a small section of treated wood with the finish to be used and check for compatibility prior to complete application.

VIII. Treatment of Log Structures, Timbers, Beams, Pilings and Exterior Wood Members Two or More Inches Thick

Apply only to bare wood or to wood surfaces where an intact water repellent or other finish is not present. Remove paint or finish prior to application. Prior to treatment, clean interior, unfinished surfaces that have accumulated dirt or cooking oils with a strong detergent. Apply a 1:1 Frameguard Pack B40 solution [(1 [one] part diluent to 1 [one] part Frameguard Pack B40)] to the point of surface saturation to all interior and exterior wood surfaces. Apply 2 [two] coats of Frameguard Pack B40 solution to log ends, notches, corners and sill logs. Wait at least 1 [one] hour before re-application.

Actual number of coats necessary will depend upon wood size, surface porosity and number of sides accessible for treatment. Refer to application chart for the minimum amount of Frameguard Pack B40 solution needed to treat various sized logs or beams. Typically, 2 [two] coats of solution are required to treat round logs 10" or greater in diameter and rectangular logs larger than 6" x 12". Wait at least 20 [twenty] minutes before re-application. Do not apply in rain or snow. Do not expose treated exterior wood surfaces to rain or snow for at least 48 hours after treatment. If inclement weather is expected, cover exterior treated surfaces.

A. Finishing and Maintaining Treated Surfaces: Exterior wood surfaces that have been treated with Frameguard Pack B40 solution will require a topcoating with a water-resistant finish, paint or exterior stain. Apply the finish or topcoat within 6 [six] weeks of treatment. It is important to allow Bora- Care-treated wood to completely dry (at least 48 hours) before applying any protective topcoat. Coat a small section of treated wood with the finish to be used and check for compatibility prior to complete application.

IX. Dip Treating Logs and Lumber

Prepare a 5:1 Frameguard Pack B40 dip treating solution [(5 [five] parts diluent to 1 [one] part Frameguard Pack B40)]. This will result in a stable solution containing 9% active ingredient. Sticker bundled wood to ensure the solution covers all wood surfaces. Submerge logs and/or lumber in the solution for at least 1 [one] minute or until all entrapped air has escaped. Protect treated wood from rain or snow for at least 24 hours after treatment.

X. Treatment of Wood in Contact with the Ground

A Frameguard Pack B40 solution treatment to wood in contact with the ground or soil has a limited lifespan and will require periodic reapplication.

XI. Prevention and Remedial Control of Algae

On Cellulosic Building Components: Apply Frameguard Pack B40 solution for the prevention and remedial control of algae to cellulosic building components (drywall, insulation) in new construction and existing structures and where an intact water repellent barrier such as paint, stain or sealer is not present. Apply the Frameguard Pack B40 solution at the rate of 1 [one] gallon of solution to up to 400 square feet of surface area. Apply only to the back paper side of drywall and to cellulose insulation. In areas where drywall has been installed and insulation is enclosed, apply the Frameguard Pack B40 solution using a misting machine (or applicator) applying sufficient solution to cover surfaces at the rate of 1 [one] gallon to up to 400 square feet. Refer to Tables A and B for mixing ratios for preventative and remedial algae treatments.

On Exterior Stone, Concrete Walkways and Concrete Walls: Apply Frameguard Pack B40 solution to exterior stone and concrete walkways and walls for the prevention and control of

algae growth. Apply a 5:1 Frameguard Pack B40 solution [(5 [five] gallons of water to 1 [one] gallon Frameguard Pack B40)] at the rate of 1 [one] gallon of solution to up to 400 square feet of walkway or wall surface area. Do not spray abutting grass or plantings.

XII. General Pest Control Applications

The application of Frameguard Pack B40 solution to the surface of wood in new construction or to wood surfaces inside wall void areas in existing structures helps to prevent the establishment of cockroach, ant (except Fire, Harvester and Pharaoh ants), silverfish, earwig, boxelder bug, millipede and cricket infestations that come in direct contact with these treated areas. Apply 1 [one] gallon of Frameguard Pack B40 solution per 400 square feet of surface area or refer to Tables A and B when applying as a surface application.

XIII. FRAMEGUARD® PACK B40 WOOD PRESERVATIVE FOR USE PRIOR TO INSTALLATION OF LUMBER

FrameGuard® Pack B40 is a wood preservative for protection and treatment of wood against brown rot, white rot, fungi (rot) and wood destroying insects including beetles, termites and carpenter ants. Treatment is permanent provided the treated material is not exposed to rain, moisture or ground contact.

- A. SURFACE PREPARATION:** Apply only to bare wood or to wood surfaces where an intact water repellent or other finish is not present. Remove any previous finishes or water repellents before application of the FrameGuard® Pack B40 solution. Surfaces must be free of dirt and other contaminants. Prior to treatment, clean with a strong detergent all interior, unfinished surfaces that are to be treated and that have accumulated dirt or cooking oils. If finished appearance is a concern, prior to application of FrameGuard® Pack B40 solution, remove any mold or mildew with an appropriate wood cleaner followed by thorough surface rinsing.
- B. APPLICATION INSTRUCTIONS:** Do not apply in rain or snow. Do not expose treated exterior wood surfaces to rain or snow for at least 48 hours after treatment. If inclement weather is expected, protect exterior treated surfaces with a plastic tarp. Apply by spray, brush, roller, or dip. Use dilutions in Table B.
- C. RETENTION RATES:** One gallon of FrameGuard® Pack B40 concentrate (2 gallons of FrameGuard® Pack B40 solution as applied) will treat 800 board feet of wood to a minimum retention level of 0.084 pounds per cubic foot boric acid equivalent (BAE). Since the active ingredient penetrates throughout the wood being treated, calculate the amount of FrameGuard® Pack B40 solution needed on the volume of wood being treated, not just the surface area. Use the following formulas to calculate the required amount of FrameGuard® Pack B40 solution:

LUMBER:

(2 x 4, 2 x 6, 2 x 12, etc.)

Material thickness (inches) x material width (inches) x material length (feet)
divided by 12 = Board Feet

FOR LOG HOMES:

Log height (inches) x log thickness (inches) x perimeter (feet) x number of
courses divided by 12 = Board Feet

(For round logs use the average diameter for both height and thickness
measurements)

FOR SIDING AND PANELING:

One gallon of FrameGuard® Pack B40 concentrate (2 gallons of solution) will
treat 800 sq. ft. of 1" thick wood by spraying only one side. If siding or paneling is
1/2" thick, 1 gallon of FrameGuard® Pack B40 concentrate (2 gallons solution)
treats 1,600 sq. ft.

D. ESTIMATED VOLUME OF FRAMEGUARD® PACK B40 NEEDED:

TABLE A – DIMENSIONAL LUMBER:

LUMBER SIZE (INCHES)	1 GALLON OF DILUTED FRAMEGUARD® PACK B40 WILL TREAT UP TO
1 X 4	1,200 Linear Feet
1 X 12	400
2 X 4	600
2 X 6	400
2 X 8	308
2 X 10	240
2 X 12	200
4 X 4	300
4 X 6	200
4 X 8	150
4 X 12	100
6 X 6	133
6 X 8	100
6 X 10	80
6 X 12	68

TABLE B — PANELS, SIDING AND PLYWOOD (1:1 OR 2:1 MIXING RATIO):

THICKNESS (INCHES)	1 GALLON OF DILUTED FRAMEGUARD® PACK B40 WILL TREAT UP TO
1/4	1,600 sq. ft.
3/8	1,067

1/2	800
3/4	533
1	400

TABLE C —ROUND LOG (ONLY THE 1:1 MIXING RATIO):

DIAMETER (INCHES)	1 GALLON OF DILUTED FRAMEGUARD® PACK B40 WILL TREAT UP TO
6	167 Linear Feet
8	96
10	61
12	43

NOTE: The numbers listed above are based on an application rate of 1 gallon of FrameGuard® Pack B40 solution to 400 board feet of wood.

XIV. FOR PREVENTION AND CONTROL OF LISTED WOOD DESTROYING BEETLES, DECAY FUNGI (ROT) AND DRYWOOD TERMITES; AND MOLD CONTROL WHEN MIXED WITH FRAMEGUARD® PACK A:

For mold control mix 1 pint of FrameGuard® Pack A and 1 gallon of FrameGuard® Pack B40 in 5 gallons of diluent. The solution will remain stable for up to 30 days. Do not leave unused solution under pressure or in tank overnight. Clean and/or flush equipment and lines with water after use.

FrameGuard® Pack B40 may be mixed with FrameGuard® Pack A for performance against mold, provided the products' labels contain no prohibition against such mixing, following the more restrictive label's precautions and limitations. Do not exceed label dosage rates.

FRAMEGUARD® PACK B40 & FRAMEGUARD® PACK A MIXING CHART (5:1)

INITIAL DESIRED MIXBACK	GALS OF PACK A	GALS OF PACK B40	GALS OF COLORANT	GALS OF WATER
25	1.6	4.2	0.3	18.9
50	3.1	8.3	0.7	37.9
75	4.7	12.5	1	56.8
100	6.3	16.7	1.4	75.7
125	7.8	20.8	1.7	94.7
*150	9.4	25.0	2.0	113.6
175	10.9	29.2	2.4	132.5
200	12.5	33.3	2.7	151.5
225	14.1	37.5	3.1	170.4
250	15.6	41.7	3.4	189.3
275	17.2	45.8	3.7	208.2
300	18.8	50.0	4.1	227.2
325	20.3	54.2	4.4	246.1
350	21.9	58.3	4.7	265.0

375	23.4	62.5	5.1	284.0
400	25.0	66.7	5.4	302.9
425	26.6	70.8	5.8	321.8
450	28.1	75.0	6.1	340.8
475	29.7	79.2	6.4	359.7
500	31.3	83.3	6.8	378.6

* Denotes typical mixback.

STORAGE AND DISPOSAL:

Do not contaminate water, food or feed by storage or disposal.

PESTICIDE STORAGE: Store in a cool, dry (preferably locked) storage area inaccessible to children and pets. Do not freeze.

PESTICIDE DISPOSAL: Wastes resulting from the use of this product may be disposed of on site or at an approved waste disposal facility.

CONTAINER HANDLING:

CONTAINERS LESS THAN OR EQUAL TO 5 GALLONS: Nonrefillable container; do not reuse or refill this container. Triple rinse (or equivalent) container promptly after emptying. Triple rinse as follows: Empty the remaining contents into application equipment or a mix tank and drain for 10 seconds after the flow begins to drip. Fill the container $\frac{1}{4}$ full with water and recap. Shake for 10 seconds. Pour rinsate into application equipment or a mix tank or store rinsate for later use or disposal. Drain for 10 seconds after the flow begins to drip. Repeat this procedure two more times, then offer for recycling, if available; or reconditioning, if appropriate; or puncture and dispose of in a sanitary landfill; or by incineration.

CONTAINERS GREATER THAN 5 GALLONS: Nonrefillable container; do not reuse or refill this container. Triple rinse (or equivalent) container promptly after emptying. Triple rinse as follows. Empty the remaining contents into application equipment or a mix tank. Fill the container $\frac{1}{4}$ full with water. Replace and tighten closures. Tip container on its side and roll it back and forth, ensuring at least one complete revolution, for 30 seconds. Stand the container on its end and tip it back and forth several times. Turn the container over onto its other end and tip it back and forth several times. Empty the rinsate into application equipment or a mix tank or store rinsate for later use or disposal. Repeat this procedure two more times. Then offer for recycling, if available; or reconditioning, if appropriate; or puncture and dispose of in a sanitary landfill; or by incineration.