

62719-380

9-7-2001

1/2

Please read instructions on reverse before completing form.

Form Approved OMB No. 2070-0060. Approval expires 05-31-98

	United States Environmental Protection Agency Washington, DC 20460	<input type="checkbox"/> Registration	OPP Identifier Number 276717
		<input checked="" type="checkbox"/> Other	

Application for Pesticide - Section I

1. Company/Product Number Dow AgroSciences/62719-380	2. EPA Product Manager Thomas C. Harris	3. Proposed Classification <input checked="" type="checkbox"/> None <input type="checkbox"/> Restricted
4. Company/Product (Name) Dow AgroSciences/Lorsban* 12.6%	PM# 19	
5. Name and Address of Applicant (Include ZIP Code) Dow AgroSciences LLC 9330 Zionsville Road Indianapolis, IN 46268 <input type="checkbox"/> Check if this is a new address	6. Expedited Review. In accordance with FIFRA Section 3(c)(3) (b)(i), my product is similar or identical in composition and labeling to: NOTIFICATION EPA Reg. No. SEP 7 2001 Product Name	

Section - II

<input type="checkbox"/> Amendment - Explain below.	<input type="checkbox"/> Final printed labels in response to Agency letter dated _____
<input type="checkbox"/> Resubmission in response to Agency letter dated _____	<input type="checkbox"/> "Me Too" Application.
<input checked="" type="checkbox"/> Notification - Explain below.	<input type="checkbox"/> Other- Explain below.

Explanation: Use additional page(s) if necessary. (For Section I and Section II.)

Supplemental label notification for control of subterranean termites as a pre-construction soil treatment.

Section - III

1. Material This Product Will Be Packaged In:				2. Type of Container	
Child-Resistant Packaging <input type="checkbox"/> Yes* <input type="checkbox"/> No	Unit Packaging <input type="checkbox"/> Yes <input type="checkbox"/> No	Water Soluble Packaging <input type="checkbox"/> Yes <input type="checkbox"/> No		<input type="checkbox"/> Metal	<input type="checkbox"/> Plastic
*Certification must be submitted		If "Yes" Unit Packaging wgt. No. per container	If "Yes" Package wgt No. per container	<input type="checkbox"/> Glass	<input type="checkbox"/> Paper
				<input type="checkbox"/> Other (Specify) _____	
3. Location of Net Contents Information <input type="checkbox"/> Label <input type="checkbox"/> Container		4. Size(s) Retail Container		5. Location of Label Directions <input checked="" type="checkbox"/> On Label <input type="checkbox"/> On Labeling accompanying product	
6. Manner in Which Label is Affixed to Product		<input checked="" type="checkbox"/> Lithograph <input type="checkbox"/> Paper glued <input type="checkbox"/> Stenciled		<input type="checkbox"/> Other _____	

Section - IV

1. Contact Point /Complete items directly below for identification of individual to be contacted, if necessary, to process this application)		
Name John J. Jachetta, Ph.D.	Title Regulatory Manager	Telephone No. (include Area Code) (317) 337-4686
Certification I certify that the statements I have made on this form and all attachments thereto are true, accurate and complete. I acknowledge that any knowing false or misleading statement may be punishable by fine or imprisonment or both under applicable law.		8. Date Application Received (Stamped)
2. Signature 	3. Title Regulatory Manager	
4. Typed Name John J. Jachetta, Ph.D.	5. Date August 10, 2001	

2/12

A1A / Lorsban 12.6% / Notif - Termiticide Uses / 08-09-01

Lorsban* 12.6%

EPA Reg. No. 62719-380

Registration Notes:

Final printed package labeling based on EPA-accepted copy (Notice of Registration) dated August 6, 2001, with conditions of acceptance

Revisions: Termiticide uses removed to this supplemental label from main product label.

*Trademark of Dow AgroSciences LLC

Supplemental Labeling



NOTIFICATION 3/12
SEP 7 2001

Dow AgroSciences LLC

9330 Zionsville Road

Indianapolis, IN 46268-1054 USA

RESTRICTED USE PESTICIDE

For retail sale to and use only by Certified Applicators or persons under their direct supervision and only for those uses covered by the Certified Applicator's certification.

Lorsban* 12.6%

EPA Reg. No. 62719-380

**For control of subterranean termites as a pre-construction soil treatment
(Post-construction use limited to outside local and spot barrier applications)**

ATTENTION

- It is a violation of Federal law to use this product in a manner inconsistent with its labeling.
- This labeling must be in the possession of the user at the time of application.
- Read the label affixed to the container for Lorsban* 12.6% insecticide before applying. Carefully follow all precautionary statements and applicable use directions.
- Use of Lorsban 12.6% according to this supplemental labeling is subject to all use precautions and limitations imposed by the label affixed to the product container.

Directions for Use

Subterranean Termites

Lorsban* 12.6% termiticide as a soil treatment may be used to establish a barrier that is lethal to termites. In order to provide an effective barrier between the wood in the structure and termite colonies in the soil, the chemical emulsion must be dispersed so as to avoid untreated gaps in the barrier.

It is important that the service technician be familiar with current control practices including trenching, rodding, subslab injection and low-pressure spray applications. These techniques must be correctly employed to prevent or control infestations by subterranean termite species of *Reticulitermes*, *Zootermopsis*, *Heterotermes* and *Coptotermes*. Choice of appropriate procedures includes consideration of such variable factors as the design of the structure, water table, soil type, soil compaction, grade conditions and the location and type of domestic water supplies. The biology and behavior of the involved termite species are important factors to be known as well as suspected location of the colony and severity of the infestation within the structure to be protected. For advice concerning current control practices for specific local conditions, consult resources in structural pest control.

Important Limitation

Postconstruction Use: For use outside structures only. For postconstruction use, this product may be applied only as spot or local barrier treatments with a maximum end-use dilution of 0.5%. Spot treatments not to exceed 25% of the amount required to treat the entire structure at the label rate. Areas treated must be inspected annually for signs of reinfestation. Postconstruction applications may be made until December 31, 2002. Thereafter, postconstruction use of this product is prohibited.

Structural Soil Precaution:

All nonessential wood and cellulose containing materials, including scrap wood and form boards, should be removed from around foundation walls, crawl spaces, and porches. This does not include existing structural soil contact wood that has been treated.

When treating adjacent to an existing structure, the applicator must check the areas to be treated, and immediately adjacent areas of the structure for visible and accessible cracks and holes to prevent any leaks or significant exposures to persons occupying the structure. People present or residing in the structure during application must be advised to remove their pets and themselves from the structure if they see any signs of leakage. After application, the applicator is required to check for leaks.

All leaks resulting in the deposition of termiticide in locations other than those prescribed on this label must be cleaned up prior to leaving the application site. Do not allow people or pets to contact contaminated areas or to reoccupy the contaminated areas of the structure until the cleanup is completed.

Retreatment for subterranean termites can only be performed if there is clear evidence of reinfestation or disruption of the barrier due to construction, excavation, or landscaping and/or evidence of the breakdown of the termiticide barrier in the soil. These vulnerable or reinfested areas may be retreated in accordance with application techniques described in this product's labeling. The timing and type of these retreatments will vary, depending on factors such as termite pressure, soil types, soil conditions and other factors that may reduce the effectiveness of the barrier.

Annual retreatment of the structure is prohibited unless there is clear evidence that reinfestation or barrier disruption has occurred.

Contamination of public and private water supplies must be avoided by following these minimum precautions:

1. Use anti-back flow equipment or procedures to prevent siphonage of pesticide back into water supplies.
2. Do not treat soil that is water saturated or frozen
3. Do not treat while precipitation is occurring.
4. Consult Federal, state and local specifications for information regarding approved treatment practices in your area.
5. Do not contaminate wells or cisterns. See specific "Treatment of Structures with Wells, Cisterns or Other Bodies of Water Adjacent to Treated Sites".

Rate Determination Guidelines:

- A dilution rate of 0.5% is required for all termiticide applications.
- A 1.0% to 2.0% dilution may be used to protect underground utility cable and conduit and utility poles and fence posts in non-residential areas.

Table 1 - Dilution Directions

Gallons of Finished Dilution Desired	Lorsban 12.6% Needed		
	0.5%	1.0%	2.0%
1	5.7 fl oz	10.4 fl oz	22.8 fl oz
5	28.7 fl oz	57.3 fl oz	3.6 qt
10	1.8 qt	3.6 qt	7.2 qt
24	4.3 qt	8.6 qt	17.2 qt
48	8.6 qt	17.2 qt	8.6 gal
97	4.3 gal	8.6 gal	17.2 gal

5/12

Mixing Directions

It is important that the termiticide dilution be uniformly mixed in the spray tank before beginning the treatment. Once mixed, Lorsban 12.6% will not settle out in the tank although the initial mixing will be enhanced by agitation, circulation through the treating hose, and the filling process.

1. Fill tank 1/4 to 1/3 full.
2. Start pump to begin by-pass agitation and place end of treating tool in tank to allow circulation through hose.
3. Add appropriate amount of Lorsban 12.6%.
4. Add remaining amount of water.
5. Let pump run and allow recirculation through the hose for 2 to 3 minutes.

Application Volume

To provide maximum control and protection against termite infestation, apply the specified volume of the finished water emulsion and active ingredient as set forth in the Directions for Use section of this label. If soil will not accept the labeled application volume, such as heavy, clay-type soils, the volume may be reduced provided there is a corresponding increase in concentration so that the amount of active ingredient applied to the soil remains the same. This would also apply to sensitive areas and/or horizontal applications where less volume may be desirable. Minimum volumes will be specified in the appropriate use directions. In light textured soils such as sand or gravel that accept larger amounts of water, increased volumes that deliver the appropriate concentration of termiticide in the soil may be used. Maximum volumes will be specified in the appropriate use directions. Note: Large reductions of application volume reduce the ability to obtain a continuous barrier. Variance is allowed when volume and concentration are consistent with label directed rates and a continuous barrier can still be achieved.

Directions for Structures With Wells/Cisterns and Other Bodies of Water Within or Adjacent to Foundations

Do not contaminate wells or cisterns.

1. **Structures With Wells/Cisterns Inside Foundations:** Structures that contain wells or cisterns within the foundation of a structure can only be treated using the following techniques:
 - a. Do not treat soil while it is beneath or within the foundation or along the exterior perimeter of a structure that contains a well or cistern. The treated backfill method may be used if soil is removed and treated outside/away from the foundation. The treated backfill technique is described as follows:
 - (1) Trench and remove soil to be treated onto heavy plastic sheeting or similar material or into a wheelbarrow.
 - (2) Treat the soil at the rate of 4 gallons of dilute emulsion per 10 linear feet per foot of depth of the trench, or 1 gallon per 1.0 cubic feet of soil. See "mixing Directions" section of this label. Mix thoroughly into the soil taking care to contain the liquid and prevent runoff or spillage.
 - (3) After the treated soil has absorbed the diluted emulsion, replace the soil into the trench.
 - b. Infested and/or damaged wood in place may be treated using an injection technique such as described in the "Control of Wood Infesting Insects" section of this label.
2. **Structures With Adjacent Wells/Cisterns and/or Other Water Bodies:** Applicators must inspect all structures with nearby water sources such as wells, cisterns, surface ponds, streams, and other bodies of water and evaluate, at a minimum, the treatment recommendations listed below prior to making an application.

6/12

- a. Prior to treatment, if feasible, expose the water pipe(s) coming from the well to the structure, if they enter the structure within 3 feet of grade.
- b. Prior to treatment, applicators are advised to take precautions to limit the risk of applying the termiticide into subsurface drains that could empty into any bodies of water. These precautions include evaluating whether application of the termiticide to the top of the footer may result in contamination of the subsurface drain. Factors such as depth to the drain system and soil type and degree of compaction should be taken into account in determining the depth of treatment.
- c. When appropriate (i.e., on the water side of the structure), the treated backfill technique (described above) can also be used to minimize off-site movement of termiticide.

Preconstruction Subterranean Termite Treatment

Areas treated with 0.5% or less must be reinspected annually for signs of reinfestation.

Preconstruction applications are defined as those applications made prior to the finished grade being installed. Effective Preconstruction treatment for subterranean termite prevention requires the establishment of vertical and/or horizontal chemical barriers between wood in the structure and the termite colonies in the soil. Follow state and local regulations to meet minimum treatment standards for preventive Preconstruction treatments. *IN FLORIDA and OHIO: The vertical barrier application is required to complete the preconstruction application. After completion, a consumer notice must be posted in an accessible location on or in the structure that informs the consumer that the soil under and around the structure has been treated for the prevention of termites and contains the following information: date of application, identity of treatment provider, and the need for annual inspection and renewal of treatment contract. IN KENTUCKY: Vertical and horizontal barrier applications are required to complete the preconstruction application. After completion, a consumer notice must be posted in an accessible location on or in the structure that informs the consumer that the soil under and around the structure has been treated for the prevention of termites and contains the following information: date of application, identity of treatment provider, and the need for annual inspection and renewal of treatment contract.*

Do not apply at a lower dosage and/or concentration than specified on this label for applications prior to installation of the finished grade.

Prior to each application, applicators must notify the general contractor, construction superintendent, or similar responsible party, of the intended termiticide application and intended sites of application and instruct the responsible person to notify construction workers and other individuals to leave the area to be treated during application and until the termiticide is absorbed into the soil.

See "Rate Determination Guidelines" and "Table 1" for dilution directions.

- 1. For **horizontal barriers**, applications shall be made using a low pressure spray (not to exceed 50 psi when measured at the treating tool to minimize exposure and potential for drift) after grading is completed and prior to the pouring of the slab or footing.
 - a. Apply 1 gallon of dilution per 10 square feet or use 5.7 fluid ounces of Lorsban 12.6% per 10 square feet in sufficient water (no less than 1/2 gallon or more than 2 gallons) to provide thorough and continuous coverage of the area being treated (See Application Volume section).

If the fill is washed gravel or other coarse material, it is important that a sufficient amount of dilution be used to reach the soil substrate beneath the coarse fill.

- b. If concrete slabs cannot be poured over the soil the same day it has been treated, a vapor barrier should be placed over the treated soil to prevent disturbance of the termiticide barrier.
2. For **vertical barriers**, apply the 0.5% end-use dilution at a rate of 4 gallons per 10 linear feet per foot of depth. Establish vertical barriers in areas such as around foundations, plumbing lines, backfilled soil against foundation walls and other areas that may warrant more than just a horizontal barrier.
- a. When treating foundations deeper than 4 feet, apply the termiticide as the backfill is being replaced, or if the construction contractor fails to notify the applicator to permit this, treat the foundation to a minimum depth of 4 feet after the backfill has been installed. The applicator must trench and rod into the trench or trench along the foundation walls and around pillars and other foundation elements, at the rate prescribed from grade to a minimum depth of 4 feet. When the top of the footing is exposed, the applicator must treat the soil adjacent to the footing to a depth not to exceed the bottom of the footing. However, in no case should a structure be treated below the footing.
 - b. Trenches need not be wider than 6 inches. Treat soil with the dilution as it is being replaced in the trench.

Apply 4 gallons of dilution per 10 linear feet per foot of depth or 22.9 fluid ounces of Lorsban 12.6% per 10 linear feet per foot of depth from grade to top of footing in sufficient water (not less than 2 gallons or more than 8 gallons) to ensure complete coverage.
 - c. Hollow block foundations or voids of masonry can be treated to make a complete chemical barrier especially if the soil was not treated prior to pouring the footing. Apply the dilution at a rate of 2 gallons per 10 linear feet so that it reaches the top of the footing.
 - d. For crawl spaces, establish a vertical barrier on both sides of the foundation and around all piers and areas where underground utilities exit the soil. Do not apply the dilution to the entire surface area intended as the crawl.
3. For **plenum type structures** that use a sealed underfloor space to circulate heated and/or cooled air throughout the structure. Apply the 0.5% dilution at the rate of 4 gallons per 10 linear feet per foot of depth. Soil adjacent to both sides of foundation walls, supporting piers, plumbing and conduits should be treated by trenching or rodding, where soil conditions permit, to a depth of 6 inches or, if less shallow, to the top of the footing. When conditions will not permit trenching or rodding, surface application adjacent to interior foundation walls may be made but the treated strip shall not exceed a width of 18 inches, horizontally, from the foundation walls, piers or pipes. The surface application should be made at a rate of 1 gallon per 10 square feet as a very coarse spray under low pressure (not to exceed 20 psi. when measured at the treating tool). After soil treatment, a continuous vapor barrier of at least 6 mil polyethylene film or other suitable vapor barrier must be installed on the ground surface over the entire subfloor area and on the inside of the plenum walls, in accordance with the recommended practices for plenum type structures.

Postconstruction Treatment

Postconstruction applications are defined as those applications made after the final grade is installed.

Use Limitations on Postconstruction Application: Post construction use of this product is limited to local and spot applications (see "Important Use Limitations" section at the beginning of the "Directions for Use" section). Spot or local treatments may be used to control active termite infestations or used preventatively. Complete barrier treatments for postconstruction application are prohibited.

Treatment of Active Termite Infestations: Spot and local application of this product must be limited to portions of the structure containing active termite infestations and underlying soil containing nesting sites. The extent of treatment must be limited to portions of the structure necessary to bring an existing termite infestation under control. When used as a spot or local application, it is recommended that Lorsban 12.6% be used in conjunction with the Sentricon* Colony Elimination System as part of an integrated pest management program to ensure continued protection of the entire structure.

Preventative Use: Preventative use is recommended in conjunction with the use of the Sentricon* Colony Elimination System as a part of the integrated pest management (IPM) program for control of subterranean termites. As a preventative treatment, Lorsban 12.6% may be use as a spot or local application in critical areas of the structure including plumbing and utility entry sites, bath traps, expansion joints, foundation cracks or other areas where termites may find entry or infestation is suspected.

See "Rate Determination Guidelines" and "Table 1" for dilution directions.

Precaution: Do not apply dilution until location of heat or air conditioning ducts, vents, water and sewer lines and electrical conduits are known and identified. Extreme caution must be taken to avoid contamination of these structural elements and airways.

All holes in commonly occupied areas into which material has been applied must be plugged. Plugs should be of a non-cellulose material or covered by an impervious, non-cellulose material.

1. For **slab-on-ground construction** applications may be made using techniques such as sub-slab injection, rodding and/or trenching. Injectors should not extend beyond the tops of the footings.
 - a. Treat along the outside of the foundation to form a continuous termiticide barrier in the soil.

For shallow foundations, 1 foot or less, dig a narrow trench approximately 6 inches wide along the outside of the foundation walls. Do not dig below the bottom of the footings. For foundations with exposed footings, dig a trench alongside the footing taking care not to undermine the footing. The dilution should be applied to the trench and mixed with the soil as it is replaced in the trench.

Apply 4 gallons of the 0.5% end-use dilution per 10 linear feet or use 22.9 fluid ounces of Lorsban 12.6% per 10 linear feet in sufficient water (no less than 2 gallons or more than 8 gallons) to provide thorough and complete coverage of the area being treated (See "Application Volume").

For foundations with footings deeper than 1 foot, apply the dilution at a rate of 4 gallons per 10 linear feet per foot of depth. For applications made after the final grade is installed, the applicator must trench and rod into the trench or trench along the foundation walls and around pillars and other foundation elements at the rate prescribed from grade to the top of the footing. When the footing is more than 4 feet below grade, the applicator must trench and rod into the trench or trench along the foundation wall at the rate prescribed to a minimum depth of 4 feet. The actual depth of treatment will vary depending on soil type, degree of compaction, and location of termite activity. When the top of the footing is exposed, the applicator must treat the soil adjacent to the footing to a depth not to exceed the bottom of the footing. However, in no case should a structure be treated below the footing.

- b. When treating cracks and expansion joints in the slab, along sidewalks or patios adjacent to the exterior foundation wall or other areas where holes are to be drilled to form a continuous termiticide barrier, the holes should be spaced at intervals up to 24 inches depending on soil type.

9/12

Hard, dry soils typically allow good lateral (horizontal) dispersion. However, they may be slow in absorption or downward movement. Care must be taken when injecting through slabs into areas with this type of soil. Low pressures should be considered in this situation. This will help to avoid backsplashing from the injection hole, backflow from cracks and expansion joints, and unwanted emergence of the termiticide dilution from adjacent drill holes. A slow, low-pressure application using the proper volume of termiticide dilution will allow the soil to absorb the liquid and provide an adequate vertical barrier. The wider drill hole spacings (18 to 24 inches) can usually be used in this situation. Sand, loam, or gravel backfill materials are commonly found under slab foundations. The type of fill, amount of settling that has occurred, moisture content, etc., will determine drill hole spacing and amount of termiticide dilution to be injected through each hole. Highly absorptive soils or those with large pore spaces (gravel, coarse sand) will afford rapid downward (vertical) movement and limited lateral (horizontal) distribution of the termiticide dilution. In this situation, consider using a lateral dispersion tip on the sub-slab injector and place the drill holes closer together (12 to 18 inches). Apply 4 gallons of 0.5% end-use dilution per 10 linear feet.

- c. It may be necessary to treat along one side of interior partition walls if there are cracks in the slab, plumbing entry points, existing termite infestations, or other conditions which would make treatment appropriate.
- d. To form a termiticide barrier under slab foundations, it may be necessary to drill and treat near plumbing and electrical entry areas, cracks, or other areas where termites might enter the structure. In this instance, one or more holes should be drilled in the slab as close to the entry point as is practical and termiticide placed in the fill. As a general rule, 3 to 5 gallons of dilution per entry point will usually give adequate coverage, however, the use of directional or lateral dispersion tips or foam delivery systems can give adequate coverage with lower volumes. Location of the drill hole in relation to the entry point, type of soil fill, presence or absence of a vapor barrier, application pressure and other considerations will affect the coverage and volume of termiticide needed to form a complete barrier. Precautions must be taken to avoid drilling into plumbing or electrical conduit.
- e. When necessary, drill through the foundation walls from the outside and force the dilution just beneath the slab either along the inside of the foundation or along all the cracks and expansion joints and other critical areas.
- f. **Bath traps:** Exposed soil or soil covered with tar or a similar type sealant beneath and around plumbing and/or drain pipe entry areas may be treated with the 0.5% end-use dilution of Lorsban 12.6%.

An access door or inspection vent should be cut and installed, if not already present. After inspection and removal of any wood or cellulose debris, the soil can be treated by rodding or drenching the soil. A one square foot bath trap will usually require about 3 to 5 gallons of dilution for thorough and complete coverage.

- 2. **Hollow block foundations or voids in masonry** resting on the footing can be treated to make a continuous chemical barrier in the voids. If the void has direct contact with the soil, it should be treated. Drill and treat all voids in multiple masonry elements of the structure extending from the structure to the soil in order to create a continuous treatment barrier in the area to be treated. Apply at the rate of 2 gallons of emulsion per 10 linear feet of footing using a nozzle pressure of less than 25 psi. When using this treatment, access holes must be drilled below the sill plate and should be as close as possible to the footing as is practical. Treatment of voids in block or rubble foundation walls must be closely examined. Applicators must inspect areas of possible runoff as a precaution against application leakage in the treated areas. Some areas may not be treatable or may require mechanical alteration prior to treatment.

10/12

Not for use in voids insulated with rigid foam.

3. For **basements**, apply at a rate of 4 gallons of dilution per 10 linear feet per foot of depth. Where footings are greater than 1 foot of depth from the grade to the top of the footing, application may be made by trenching and/or rodding at a rate of 4 gallons of dilution per 10 linear feet per foot of depth. When the footing is more than 4 feet below grade, the applicator must trench and rod into the trench or trench along the foundation wall at the rate prescribed to a minimum depth of 4 feet. The actual depth of treatment will vary depending on soil type, degree of compaction, and location of termite activity. When the top of the footing is exposed, the applicator must treat the soil adjacent to the footing to a depth not to exceed the bottom of the footing. However, in no case should a structure be treated below the footing. Treat outside of foundation walls, and if necessary beneath the basement floor along inside of foundation walls, along cracks in basement floors, along interior load bearing walls, around sewer pipes, conduits and piers.
4. **Accessible Crawl Spaces:** For crawl spaces, apply vertical termiticide barriers at the rate of 4 gallons of emulsion per 10 linear feet per foot of depth from grade to top of footing, or if the footing is more than 4 feet below grade, to a minimum depth of 4 feet.

Apply 4 gallons of the 0.5% end-use dilution per 10 linear feet per foot of depth or 22.9 fluid ounces of Lorsban 12.6% per 10 linear feet per foot of depth from grade to top of footing in sufficient water (not less than 2 gallons or more than 8 gallons) to ensure complete coverage.

Apply by trenching and rodding into the trench, or trenching. Treat both sides of foundation and around all piers and pipes. Where physical obstructions, such as concrete walkways adjacent to foundation elements, prevent trenching, treatment may be made by rodding alone. When soil type and/or conditions make trenching prohibitive, rodding may be used. When the top of the footing is exposed, the applicator must treat the soil adjacent to the footing to a depth not to exceed the bottom of the footing. Read and follow the mixing and use direction section of the label if situations are encountered where the soil will not accept the full application volume.

- a. Rod holes and trenches shall not extend below the bottom of the footing.
 - b. Rod holes shall be spaced so as to achieve a continuous chemical barrier but in no case more than 12 inches apart.
 - c. Trenches shall be a minimum of 6 inches deep or to the bottom of the footing, whichever is less, and need not be wider than 6 inches. When trenching in sloping (tiered) soil, the trench shall be stepped to ensure adequate distribution and to prevent termiticide from running off. The emulsion must be mixed with the soil as it is replaced in the trench.
 - d. When treating crawl spaces, turn off the air circulation system of the structure until application has been completed and all termiticide has been absorbed by the soil.
5. **Inaccessible Crawl Spaces:** For inaccessible interior areas, such as areas where there is insufficient clearance between floor joists and ground surfaces to allow operator access, excavate if possible, and treat according to the instructions for accessible crawl spaces. Otherwise, apply one or a combination of the following two methods.

Apply 4 gallons of the 0.5% end-use dilution per 10 linear feet or 22.9 fluid ounces of Lorsban 12.6% per 10 linear feet in sufficient water (not less than 2 gallons or more than 8 gallons) to ensure complete coverage (See "Application Volume").

- a. To establish a horizontal barrier, apply 1 gallon of emulsion per 10 sq ft to the soil surface. Use a nozzle pressure of less than 25 psi and a coarse application nozzle (e.g., Delavan Type RD Raindrop, RD-7 or larger, or Spraying Systems Co. 8010LP TeeJet or comparable

nozzle). For an area that cannot be reached with the application wand, use one or more extension rods to make the application to the soil. Do not broadcast or powerspray with higher pressures.

- b. To establish a horizontal barrier, drill through the foundation wall or through the floor above and treat the soil perimeter at a rate of 1 gallon of emulsion per 10 square feet. Drill spacing must be at intervals not to exceed 16 inches. Many states have smaller intervals so check state regulations that may apply.

When treating crawl spaces, turn off the air circulation system of the structure until application has been completed and all termiticide has been absorbed by the soil.

- c. In the presence of unsupported termite tubes, mechanically destroy each tube and apply approximately 1 pint of the end-use dilution to an area of no more than 18 inches in diameter where the tubes emerged from the soil.
6. In **plenum type structures**, which use a sealed underfloor space to circulate heated and/or cooled air within the structure, turn off the air circulation system of the structure until application has been completed and all termiticide has been absorbed by the soil. Apply the 0.5% end-use dilution at the rate of 4 gallons per 10 linear feet per foot of depth. Soil adjacent to both sides of foundation walls, supporting piers, plumbing and conduits should be treated by trenching or rodding, where soil conditions permit, to a depth of 6 inches or to the top of the footing. When conditions will not permit trenching or rodding, a surface application adjacent to interior foundation walls may be made, but the treated strip shall not exceed a width of 18 inches, horizontally, from the foundation piers or pipes. Surface application is made at a rate of 1 gallon per 10 square feet as a very coarse spray under low pressure (not to exceed 20 psi. when measured at the treating tool). In order to properly calculate the amount of termiticide dilution needed, use the following guideline: A strip 18 inches wide and 6 feet 8 inches long is equal to 10 square feet. Before treatment, a barrier of at least 6-mil polyethylene film or other suitable vapor barrier must be present on this ground surface over the entire subfloor area in accordance with recommended practices for plenum type structures. Install a new vapor barrier if barrier is absent or deteriorated. The vapor barrier film on the ground and foundation walls must be folded back from the areas to be treated prior to treatment and replaced immediately following treatment. Structures should be ventilated during application and until treatment is dry.
7. **Application using foam-generating equipment:** The emulsion may be converted to a foam and the foam used to control or prevent termite infestations.

Depending on circumstances, foam applications may be used alone or in combination with liquid emulsion applications. Applications may be made behind veneers, piers, chimney bases, into rubble foundations, into block voids or structural voids, under slabs, stoops, porches, or to the soil in crawl spaces, and other similar voids.

Foam and liquid application must be consistent with volume and active ingredient instructions in order to ensure proper application has been made. The volume and amount of active ingredient are essential to an effective treatment. At least 50 to 75% of the labeled liquid emulsion volume of product must be applied, with the remaining percent delivered to appropriate areas using foam application. Refer to the label and use recommendations of the foam manufacturer and the foaming equipment manufacturer for adjuvant rates to produce the needed expansion ratio with this product.

Foam applications are generally a good supplement to liquid treatments in difficult areas, but may be used alone in difficult spots.

12/12

The following provides the amount of Lorsban 12.6% required for a given area and volume range of the preformed termiticide dilution necessary for application of the product.

For a 0.5% rate, apply 22.9 fluid ounces of Lorsban 12.6% per 10 linear feet using no less than 2 gallons, or more than 8 gallons, of prefoamed dilution.

Underground Utility Cable and Conduit (Non-residential)

Preventative Treatment for Use Only in Guam, Hawaii, and Other Pacific Islands: Use a 1.0% to 2.0% dilution (See "Rate Determination Guidelines" and "Table 1" for dilution directions). After digging the trench, place approximately 6 inches of backfill or sand at the bottom and apply 2 gallons of the dilution per 10 linear feet. Allow treatment to dry then replace the cable backfill. Cover with an additional 6 inches of backfill or sand and apply another 2 gallons of emulsion per 10 linear feet. Finish filling trench with untreated soil.

Wherever cables emerge from the soil to enter poles, light frames, etc., treat the soil around the cable and pole or frame to establish a continuous 6-inch chemical barrier.

A continuous 6-inch chemical barrier must be established around the cable to insure protection from termite attack.

Utility Poles and Fence Posts (Non-residential)

Preventative Treatment: Use a 1.0 to 2.0% dilution (See "Rate Determination Guidelines" and "Table 1" for dilution directions). After pole or post hole has been dug, mix the dilution with the soil as it is being replaced to a depth of approximately 10 inches. Place pole or post on top of this layer. The remaining soil fill and termiticide dilution should be mixed while backfilling the hole. The treated soil zone around the post or pole should be approximately 6 inches wide. Soil for the base layer and backfill of each pole or post should be treated at a rate of 4 gallons of dilution per 10 cubic feet of soil.

Remedial Treatment: To control existing infestations or to prevent infestation of posts and poles already in place, use a 1.0% to 2.0% dilution. The termiticide dilution should be injected into termite galleries or channels in the wood. For maximum protection, injection sites should be at or below grade.

Posts or poles may also be treated by rodding down to the base of the structure. Rod holes should be placed approximately 3 inches away from the pole and about 6 inches apart. Inject approximately 12 fluid ounces of dilution per foot of depth into each rod hole.

It may be appropriate to use one or both treatment techniques depending upon the specific circumstances at the work site e.g. soil type.

*Trademark of Dow AgroSciences LLC

D06-XXX-XXX
Issue date: 08/09/01
Initial printing.

Revisions: Termiticide uses removed to this supplemental label from main product label.